

Hardware Module Commands

This module lists the hardware module commands for the Multicast configuration on the Cisco 8000 Series Routers.

For detailed information about the hardware module configuration tasks and examples, refer to the *Multicast Configuration Guide for Cisco 8000 Series Routers*.

- Hardware Module Commands, on page 2

Hardware Module Commands

Multicast Routing Forwarding Commands

- hw-module multicast route-scale
- hw-module route-stats