

Overview of Cisco Optical Network Controller

- Cisco Optical Network Controller Overview, on page 1
- Log in to Cisco Optical Network Controller, on page 3
- User access in Cisco Optical Network Controller, on page 4
- Add local users to Cisco Optical Network Controller, on page 6
- Set up authentication using LDAP, on page 9
- Set up authentication using SAMLv2 SSO, on page 11
- Set up Permission Mapping, on page 13
- Manage Certificates in Cisco Optical Network Controller, on page 15

Cisco Optical Network Controller Overview

Cisco Optical Network Controller (Cisco ONC) is an optical SDN Controller for Cisco optical networks. Cisco Optical Network Controller behaves as a Provisioning Network Controller (PNC) and performs these functions.

- Collects information about the inventory (device types, circuits and more) and topology (node arrangment) of the managed network.
- Monitors the physical or virtual topology of the network.
- Notifies of changes in topology and service changes.
- Supports the creation and deletion of optical paths.

Optical SDN controller

Optical SDN controller is a specialized SDN controller that

- manages and controls devices within a optical technology domain, and
- communicates with the higher-level SDN controller via east-west interfaces

Core functions of Cisco Optical Network Controller

Cisco Optical Network Controller collects data necessary for optical applications. This data is used to provide abstract network information to higher layer controllers. This abstraction enables centralized control of optical network.

Cisco Optical Network Controller supports several functions.

- Optical Domain Controller

  Cisco Optical Network Controller behaves as a domain controller for Cisco optical products. The domain controller feeds data into hierarchical controllers for high-level network orchestration. Cisco Optical Network Controller has a North Bound Interface (NBI) based on the OIF transport API (T-API) standard which enables it to connect to any hierarchical controller which has a TAPI compliant South Bound Interface (SBI) and provides its functions to the controller.

- Path Compute Engine (PCE)

  PCE service provides optical path computation to ensure optically valid paths are provisioned within the supplied constraints. PCE uses the latest network status to compute the optical path.

- Model Based Network Abstraction

  Cisco Optical Network Controller supports a standardized TAPI model which enables it to abstract the device level details from the hierarchical controller.

Note

- For more details on Cisco Optical Site Manager (COSM), see COSM Configuration Guide.
- For more details on Cisco Optical Network Planner (CONP), see CONP Configuration Guide.
- For further details about Cisco Optical Network Controller, see the Cisco Optical Network Controller (CONC) Data Sheet .

Important

- TAPI is disabled by default to ensure proper device integration and data collection, enabling seamless operation. You must enable it before onboarding devices.
- You must not enable TAPI after onboarding devices in Cisco Optical Network Controller. It must be enabled only before onboarding any of the devices.
- You must enable TAPI after de-boarding all the devices.

  To enable or disable TAPI, see Enabling and Disabling the TAPI Northbound Interface

Software Requirements

Cisco Optical Network Controller, Release 24.3.x supports these software versions.

Table 1: Software Support

Hardware and Software	Version
NCS 1001	Cisco IOS XR Release 7.10.1
NCS 1004	Cisco IOS XR Release 24.3.1

Hardware and Software	Version
NCS 1014	Cisco IOS XR Release 24.3.1
NCS 1010	Cisco IOS XR Release 24.3.1
Cisco Optical Site Manager	Cisco IOS XR Release 24.3.1

Log in to Cisco Optical Network Controller

Follow these steps to log into Cisco Optical Network Controller:

Procedure

Step 1 In the browser URL field, enter `https://<virtual-ip>:8443/`

Note
<virtual-ip> refers to the IP address or hostname of your Cisco Optical Network Controller deployment.


The browser displays the login page.

Step 2 Enter the username and password.

Username and password are provided by your system administrator.

Step 3 Click **Login**.

Figure 1: Log into Cisco Optical Network Controller



Note

Cisco Optical Network Controller supports a maximum of 25 users to log in concurrently.

User access in Cisco Optical Network Controller

Users, Roles, and Permissions

Cisco Optical Network Controller allows you to manage user access and permissions. It adds an additional layer of security. It works as a Single Authentication Agent, thus sharing local, Lightweight Directory Access Protocol (LDAP) and Security Assertion Markup Language (SAML) users. The Single Authentication Agent simplifies user management and provides a unified login experience across different authentication sources.

Cisco Optical Network Controller provides different permission levels for user access. See *Set up Permission Mapping*. To allow access to Cisco Optical Network Controller to a larger group of regular users, set the user authentication through LDAP or SAML Single Sign-On (SSO) protocols. You can use both protocols simultaneously, depending on your environment.


Table 2: User roles and permissions

User role	Permission	Access level
Admin	permission/admin	has no restrictions
Supervisor	permission/supervisor	has similar permission as admin but with restrictions on user management and log checks
Read-only	permission/readonly	can check data, but cannot provision.
Internal	permission/internal	collects debug logs in case of any triage or troubleshooting. **Note** We recommend using it only under the supervision of the Cisco Technical Assistance Center (TAC).

Accessing Settings


The settings button is available on the left navigation bar of Cisco Optical Network Controller.

Figure 2: Settings



After clicking **Settings** you see the settings panel.

Figure 3: Settings Options



System Info

The **System Info** section has the information about the latest versions of Cisco Optical Network Controller and the related microservices.

Security

The **Security** section is for access management and offers several options.

- **Local Users**: Display, create, and edit local users through the UI.
- **LDAP**: Set LDAP settings for user authentication.
- **SAML SSO**: Set SAML Single-Sign-On settings for user authentication.
- **Permission Mapping**: Handle permission management through the Cisco Policy Management Tool.

Note Cisco Optical Network Controller does not allow the configuration of timeout and retry client parameters for LDAP and SAML SSO authentication. Instead, it automatically applies the default values to the timeout and retry settings.

Add local users to Cisco Optical Network Controller

Add local user accounts to Cisco Optical Network Controller by completing these steps.

Before you begin

You need administrative user privileges to access Cisco Optical Network Controller.

Procedure

Step 1 From the Cisco Optical Network Controller home page click **Settings**.

Step 2 From the panel list, select **Local Users** and click **Add**.
The **Add User** screen appears.


Step 3 In the **Add User** screen, fill these mandatory fields.

a) Enter a username in **Username***.
b) In **Password***, enter a password.
c) In **Confirm Password***, re-enter the password to confirm the password.

Note
Cisco Optical Network Controller uses cryptographic mechanism to secure credentials stored in the system. Cisco Optical Network Controller CLI and Web UI passwords use salted one-way hashing with yescrypt and bcrypt, respectively. Cisco Optical Site Manager device credentials saved for enrolled nodes are also stored with cryptographic protection.

Step 4 Enter the access permissions in the form of a comma-separated list using **Access Permissions** and enter permission/admin as given in the example.


Figure 4: Local Users



For example *permission/<admin>*

Note
Description and **Display Name** are optional fields.

Figure 5: Add User



Step 5 Use the toggle switches to set the user status.

Note
The toggle switches are independent of each other, they can both be disabled or enabled at the same time.

- **Active enabled**: Allows the user to log into Cisco Optical Network Controller.
- **Active disabled**: Forbids the user from logging into Cisco Optical Network Controller.

- **Locked enabled**: Prevents deleting the user for auditing purposes or to retain historical data associated with that user.
- **Locked disabled**: Allows removal of the user

Table 3: Toggle combinations

Active status	Locked status	User status
Active enabled	Locked enabled	Prevents accidental deletion of user
Active enabled	Locked disabled	Allows user deletion
Active disabled	Locked disabled	Temporarily disables a user and allows user deletion
Active disabled	Locked enabled	Temporarily disables a user but prevent accidental deletion

Step 6 Click **Save**.

Cisco Optical Network Controller successfully saves the new user.

Set up authentication using LDAP

Set up user authentication using the Lightweight Directory Access Protocol (LDAP) on Cisco Optical Network Controller can be performed by following these instructions.

Before you begin


You need administrative user privileges to access Cisco Optical Network Controller.

Procedure

Step 1 From the Cisco Optical Network Controller home page click **Settings**.

Step 2 Click **LDAP**.

Figure 6: LDAP



Step 3 Enable **Enabled** toggle switch.

Step 4 Fill in the mandatory fields marked with an asterisk.

Table 4: Madatory LDAP fields

Field	Description	Value
LDAP Server Address	The IP address to your LDAP server.	This server address is set by your organization's LDAP administrator.

Field	Description	Value
Bind DN	The Distinguished Name of the user account used to connect to the LDAP directory.	This value is provided by your organization's LDAP administrator.
Bind Credentials	The password to authenticate your user account.	This value is provided by your organization's LDAP administrator.

LDAP Server Address, **Bind DN** and **Bind Credentials** are mandatory fields. The **Search Filter**, **Search Base** and **Root CAs** are optional fields.

Step 5 Click **Save**.

You have successfully completed the LDAP authentication setup.

Set up authentication using SAMLv2 SSO

The Security Assertion Markup Language (SAML) SSO allows you to gain single sign-on access based on the SAMLv2 protocol. Both local and external users can authenticate using SSO user credentials if their accounts are mapped.

Follow these instructions to set up SAML SSO authentication.

Before you begin


Ensure you have administrative user privileges to access Cisco Optical Network Controller.

To set up authentication using SAMLv2 SSO, ensure your SSO server is installed and configured for the application.

Procedure

Step 1 From the Cisco Optical Network Controller UI click **Settings** and select **SAML SSO**.

Figure 7: SAML SSO



Step 2 Enable **Enabled** toggle switch.

Step 3 Fill in the fields.

Table 5: SAML SSO fields

Field	Description	Value
Login URL	Sign on URL for the Cisco ONC	Cisco ONC URL
Entity ID	A unique identifier for Cisco ONC within the SAML federation, provided by your Identity Provider.	This value is provided by your organization's SSO administrator or identity provider (IdP)

Field	Description	Value
Base URL	Click **Use Current** to use the current URL.	Current URL
Signing Certificate	A downloaded certificate for Cisco ONC within the SAML federation, provided by your Identity Provider.	This value is provided by your organization's SSO administrator or identity provider (IdP)
Groups Attribute Name	Name of the group attribute that is assigned to you by your IdP.	memberOf

Step 4 Click **Save**.

You successfully completed the SAMLv2 SSO authentication setup.

Set up Permission Mapping

Cisco Optical Network Controller offers different permission levels for user access. Specific permissions can be granted to a user or group of users using this option. Follow these steps to set up permission mapping.

Before you begin

You need administrative user privileges to access Cisco Optical Network Controller.

Procedure

Step 1 From the Cisco Optical Network Controller home page click **Settings**.

Step 2 Select **Permission Mapping**.

Step 3 Click **Add**.

Step 4 In the **Add Permission Mapping** panel, choose one **Mapping Type** from the dropdown menu: **SAML User**, **SAML Group**, **LDAP User**, or **LDAP Group**.

Step 5 Fill the **Match** field.

For example, enter a specific username like 'jsmith' or a group name like 'network_admins' from your SAML/LDAP directory.

Step 6 Select the appropriate **Access Permission**.

Step 7 Click **Save**.

Figure 8: Permission Mapping





Figure 9: Add Permission Mapping



Manage Certificates in Cisco Optical Network Controller

When a Cisco Optical Network Controller cluster is created, unique self-signed EC/RSA certificates are generated for incoming HTTPS connections to the ingress-proxy. Ingress-proxy is the component that handles incoming network traffic and routes traffic to various services within the cluster. These certificates are intended for initial configuration only. From Cisco Optical Network Controller Release 24.3.1, you can create a Certificate Signing Request (CSR) and upload a signed certificate bundle using the sedo command-line interface (CLI) administration tool, a powerful tool for system administration.

Before you begin

This section requires advanced knowledge of certificate management, command-line interfaces, and security concepts.

Procedure

Step 1 Create a Certificate Signing Request (CSR) using the sedo CLI tool. You can choose between RSA and EC certificates.

Example:

For RSA:

```
sedo security certs request rsa --country <Country Name> --organization <Organization Name> <Domain
 Name or IP>
```

Example:

For EC:

```
sedo security certs request ec --country <Country Name> --organization <Organization Name> <Domain
Name or IP>
```

Step 2 Get the CSR Signed by a Certificate Authority (CA).

This is an external process. Submit the generated CSR to your organization's Certificate Authority (CA) or a trusted public CA to obtain a signed certificate.

Step 3 If your CA provides individual certificates instead of certificate chain, create a certificate chain. You must follow the exact order to create the chain. Copy the signed certificate to the CONC virtual machine location /data and create a chain of certificates in output.crt:

Example:

```
cat /data/signed_certificate.crt /path/to/issuing_ca_certificate.crt /path/to/root_ca_certificate.crt
 > /data/output.crt
```

Example:

Replace the paths with the actual paths to your Issuing CA and Root CA certificates. Ensure that the paths are accessible from the VM, and adjust the command as needed based on your specific environment and file paths.

Step 4 Upload the prepared certificate chain to the system:

Example:

```
sedo security certs upload output.crt
```

Step 5 Verify the uploaded certificates:

Example:

```
sedo security certs list

┌──────────────────────────────────────────────────────────────────────────┐
│ Installed Certificates
                                  │
├──┬───────────────────┬───────────────────┬─────────────┬─────────────┬─────┬────┬───────────────────────┤
│ TYPE │ SUBJECT                                    │ ISSUER                                    │ ISSUED
                          │ EXPIRES                         │ DNS SANS  │ IP SANS │ SERIAL NUMBER
                                │
├──┼───────────────────┼───────────────────┼─────────────┼─────────────┼─────┼────┼───────────────────────┤
│ EC    │ CN=NextFusion,O=Cisco,ST=California,C=US │ CN=NextFusion,O=Cisco,ST=California,C=US │ Mon
Nov 18 22:46:18 GMT 2024 │ Thu Nov 18 22:46:18 GMT 2027 │ nxf.local │          │
1445557328950165706858003484413381754985522282604 │

│ RSA   │ CN=NextFusion,O=Cisco,ST=California,C=US │ CN=NextFusion,O=Cisco,ST=California,C=US │ Mon
Nov 18 22:46:18 GMT 2024 │ Thu Nov 18 22:46:18 GMT 2027 │ nxf.local │          │
1232594841637394522581611101986931324866857045143 │
└──┴───────────────────┴───────────────────┴─────────────┴─────────────┴─────┴────┴───────────────────────┘
```

If you are replacing the self-signed certificate with the active `output.crt` (CA-signed chain certificate), ensure to delete any other certificates if only one certificate is being replaced. This helps avoid conflicts and ensure the system uses the newly uploaded, trusted certificate.

```
sedo security certs delete ec
```