

IS-IS Commands

This module describes the commands used to configure and monitor the Intermediate System-to-Intermediate System (IS-IS) protocol on Cisco ASR 9000 Series Aggregation Services Routers .

For detailed information about IS-IS concepts, configuration tasks, and examples, see the *Implementing IS-IS on* Cisco ASR 9000 Series Router module in the *Routing Configuration Guide for Cisco ASR 9000 Series Routers*.

- address-family (IS-IS), on page 5
- address-family multicast topology (IS-IS), on page 7
- adjacency-check disable, on page 9
- advertise passive-only, on page 11
- adjacency stagger (IS-IS), on page 12
- algorithm 0, on page 14
- attached-bit receive ignore, on page 15
- attached-bit send, on page 16
- authentication-check disable, on page 18
- circuit-type, on page 19
- clear isis process, on page 21
- clear isis route, on page 22
- clear isis statistics, on page 24
- cost-fallback anomaly delay, on page 26
- csnp-interval, on page 28
- default-information originate (IS-IS), on page 30
- disable (IS-IS), on page 32
- distance (IS-IS), on page 33
- distribute-list in (IS-IS), on page 35
- fast-reroute per-link (IS-IS), on page 37
- fast-reroute per-prefix (IS-IS), on page 39
- fast-reroute per-link priority-limit (IS-IS), on page 41
- fast-reroute per-link use-candidate-only (IS-IS), on page 43
- fast-reroute per-prefix load-sharing disable (IS-IS), on page 44
- fast-reroute per-prefix tiebreaker (IS-IS), on page 45
- fast-reroute per-prefix use-candidate-only (IS-IS), on page 47
- hello-interval (IS-IS), on page 48
- hello-multiplier, on page 50

- hello-padding, on page 52
- hello-password, on page 54
- hello-password keychain, on page 56
- hello-password accept, on page 58
- hostname dynamic disable, on page 60
- ignore-lsp-errors, on page 61
- instance-id, on page 62
- interface (IS-IS), on page 63
- ipfrr lfa, on page 65
- ipfrr lfa exclude interface, on page 67
- ispf, on page 69
- is-type, on page 70
- link-down fast-detect, on page 72
- link-group, on page 73
- log adjacency changes (IS-IS), on page 74
- log pdu drops, on page 75
- lsp fast-flood threshold, on page 76
- lsp-fast-flooding, on page 77
- lsp-gen-interval, on page 79
- lsp-interval, on page 81
- lsp-mtu, on page 82
- lsp-password, on page 84
- lsp-password accept, on page 86
- lsp-refresh-interval, on page 88
- maximum-paths (IS-IS), on page 90
- maximum-redistributed-prefixes (IS-IS), on page 91
- maximum-propagated-prefixes (IS-IS), on page 92
- max-lsp-lifetime, on page 93
- max-lsp-tx, on page 94
- max-metric, on page 95
- metric fallback anomaly, on page 97
- mesh-group (IS-IS), on page 99
- metric (IS-IS), on page 101
- metric-style narrow, on page 104
- metric-style transition, on page 106
- metric-style wide, on page 108
- microloop avoidance (IS-IS), on page 110
- min-lsp-arrivaltime, on page 112
- mpls ldp auto-config , on page 114
- mpls ldp sync (IS-IS), on page 115
- mpls traffic-eng (IS-IS), on page 117
- mpls traffic-eng multicast-intact (IS-IS), on page 119
- mpls traffic-eng path-selection ignore overload, on page 120
- mpls traffic-eng router-id (IS-IS), on page 122
- net, on page 124
- nsf (IS-IS), on page 126

- nsf interface-expires, on page 128
- nsf interface-timer, on page 130
- nsf lifetime (IS-IS), on page 132
- oor-set-overload-bit disable, on page 133
- passive (IS-IS), on page 134
- point-to-point, on page 135
- priority (IS-IS), on page 136
- propagate level, on page 138
- protocol shutdown (IS-IS), on page 140
- psnp-interval, on page 141
- redistribute (IS-IS), on page 142
- remote-psnp-delay, on page 146
- retransmit-interval (IS-IS), on page 148
- retransmit-throttle-interval, on page 150
- router isis, on page 152
- router isis static neighbor, on page 153
- route source first-hop, on page 154
- set default-isis-instance, on page 155
- set-overload-bit, on page 157
- set-attached-bit, on page 159
- show isis, on page 161
- show isis adjacency, on page 163
- show isis adjacency-log, on page 165
- show isis checkpoint adjacency, on page 167
- show isis checkpoint interface, on page 169
- show isis checkpoint lsp, on page 171
- show isis database, on page 173
- show isis database-log, on page 174
- show isis fast-reroute, on page 176
- show isis hostname, on page 179
- show isis interface, on page 181
- show isis lsp-log, on page 185
- show isis mesh-group, on page 187
- show isis mpls traffic-eng adjacency-log, on page 189
- show isis mpls traffic-eng advertisements, on page 191
- show isis neighbors, on page 194
- show isis protocol, on page 197
- show isis route, on page 200
- show isis spf-log, on page 203
- show isis statistics, on page 210
- show isis topology, on page 214
- show protocols (IS-IS), on page 217
- shutdown (IS-IS), on page 221
- single-topology, on page 222
- snmp-server traps isis, on page 223
- spf-interval, on page 224

- spf-interval ietf, on page 226
- spf prefix-priority (IS-IS), on page 228
- summary-prefix (IS-IS), on page 230
- suppressed, on page 232
- tag (IS-IS), on page 233
- topology-id, on page 234
- trace (IS-IS), on page 235
- ucmp (IS-IS), on page 236
- ucmp delay-interval, on page 238
- ucmp exclude interface, on page 240

address-family (IS-IS)

To enter address family configuration mode for configuring Intermediate System-to-Intermediate System (IS-IS) routing that use standard IP Version 4 (IPv4) and IP Version 6 (IPv6) address prefixes, use the **address-family** command in router configuration or interface configuration mode. To disable support for an address family, use the **no** form of this command.

address-family {**ipv4** | **ipv6**} {**unicast** | **multicast**}
no address-family {**ipv4** | **ipv6**} {**unicast** | **multicast**}

Syntax Description

ipv4	Specifies IPv4 address prefixes.
ipv6	Specifies IPv6 address prefixes.
unicast	Specifies unicast address prefixes.
multicast	Specifies multicast address prefixes.

Command Default

An address family is not specified. The default subaddress family (SAFI) is unicast.

Command Modes

Router configuration

Interface configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	Support for IPv6 was added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **address family** command to place the router or interface in address family configuration mode. In router address family configuration mode, you can configure routing that uses standard IPv4 or IPv6 address prefixes. An address family must be specified in interface configuration mode. In interface address family configuration mode, you can alter interface parameters for IPv4or IPv6.

You must specify an address family in order to configure parameters that pertain to a single address family.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure the IS-IS router process with IPv4 unicast address prefixes:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# interface gigabitEthernet 0/1/0/0
RP/0/RSP0/CPU0:router(config-isis-if)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-if-af)#
```

address-family multicast topology (IS-IS)

To enable a multicast topology when configuring Intermediate System-to-Intermediate System (IS-IS) routing (or to place a given topology within the IS-IS interface), use the **address-family multicast topology** command with either IPv4 or IPv6 address prefix in the appropriate configuration mode. To disable a multicast topology in IS-IS, use the **no** form of this command.

address-family {**ipv4** | **ipv6**} **multicast topology** *topo-name* [**maximum prefix** *prefix-limit*]
no address-family

Syntax Description

ipv4	Specifies IPv4 address prefixes.
ipv6	Specifies IPv6 address prefixes.
multicast	Specifies multicast address prefixes.
topology *topo-name*	Specifies the name of the topology.
maximum prefix	Specifies maximum number of prefixes that a routing table can have.
prefix-limit	Maximum number of prefixes. Range is from 32 to 2,000,000.

Command Default

An address family for multicast topology is not specified. The default subaddress family (SAFI) is unicast.

Command Modes

Router configuration

Interface configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	Support for IPv6 was added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **address family multicast topology** command to place the router or interface in address family configuration mode. In router address family configuration mode, you can associate an IS-IS topology ID with the topology you have created to add connected and local routes to a specific routing table.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure the IS-IS router topology with an IPv4 multicast address prefix:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv6 multicast topology green
RP/0/RSP0/CPU0:router(config-isis-af)#
```

or

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)#  interface gigabitethernet 0/3/0/0
RP/0/RSP0/CPU0:router(config-isis-if)# address-family ipv4 multicast topology green
RP/0/RSP0/CPU0:router(config-isis-if-af)#
```

Related Commands

Command	Description
topology-id, on page 234	Associates a topology ID with a named IS-IS topology to differentiate topologies in the domain.

adjacency-check disable

To suppress Intermediate System-to-Intermediate System (IS-IS) IP Version 4 (IPv4) or IP Version 6 (IPv6) protocol-support consistency checks that are performed prior to forming adjacencies on hello packets, use the **adjacency-check disable** command in address family configuration mode. To remove this function, use the **no** form of this command.

adjacency-check disable
no adjacency-check disable

Command Default

Adjacency check is enabled

Command Modes

Address family configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	Support was added for ipv6.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

IS-IS performs consistency checks on hello packets and forms an adjacency only with a neighboring router that supports the same set of protocols. A router running IS-IS for both IPv4 and IPv6 does not form an adjacency with a router running IS-IS for IPv4 only.

Use the **adjacency-check disable** command to suppress the consistency checks for IPv6 IS-IS and allow an IPv4 IS-IS router to form an adjacency with a router running IPv4 IS-IS and IPv6. IS-IS never forms an adjacency between a router running IPv4 IS-IS only and a router running IPv6 only.

In addition, the **adjacency-check disable** command suppresses the IPv4 or IPv6 subnet consistency check and allows IS-IS to form an adjacency with other routers regardless of whether they have an IPv4 or IPv6 subnet in common.

Task ID

Task ID	Operations
isis	read, write

Examples

The command in the following example disables the adjacency checks:

The following example shows how the network administrator introduces IPv6 into an existing IPv4 IS-IS network and ensures that the checking of hello packet checks from adjacent neighbors is disabled until all neighbor routers are configured to use IPv6:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv6 |ipv4
```

```
RP/0/RSP0/CPU0:router(config-isis-af)# adjacency-check disable
```

advertise passive-only

To configure IS-IS to advertise only prefixes that belong to passive interfaces, use the **advertise-passive-only** command in ISIS address family configuration mode. To disable advertisement only prefixes that belong to passive interfaces, use the **no** form of this command.

advertise passive-only
no advertise passive-only

Syntax Description

This command has no keywords or arguments.

Command Default

None

Command Modes

IPv4 unicast address family configuration

IPv4 multicast address family configuration

IPv6 unicast address family configuration

IPv6 multicast address family configuration

Command History

Release	Modification
Release 4.2.0	This command was introduced.
Release 5.0.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operation
isis	read, write

This example shows how to configure IS-IS to advertise only prefixes that belong to passive interfaces.

```
RP/0/RSP0/CPU0:router#configure
RP/0/RSP0/CPU0:router(config)#router isis isp
RP/0/RSP0/CPU0:router(config-isis)#address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-af)#advertise passive-only
```

adjacency stagger (IS-IS)

To configure staggering of IS-IS adjacency during reload, process restart, and process clear, use the **adjacency stagger** command in router configuration mode. To turn off adjacency staggering, either use the **disable** keyword or use the **no** form of this command.

adjacency stagger {**disable** | *initial-num-nbr* *max-num-nbr*}
no adjacency stagger

disable	Disables adjacency staggering.
initial-num-nbr	The initial number of simultaneous neighbors allowed to form adjacency to FULL in any area to bring up to FULL after a router reload, IS-IS process restart, or IS-IS process clear. Range is 1-65535. Default is 2.
max-num-nbr	The subsequent number of simultaneous neighbors allowed to form adjacency, per IS-IS instance, after the initial set of IS-IS neighbors have become FULL. Range is 1-65535. Default is 64.

Command Default

IS-IS adjacency staggering is enabled.

Command Modes

Router configuration

Table 1: Command History

Release	Modification
Release 6.3.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Staggering of the IS-IS adjacency during reload, process restart (without NSR or graceful-restart), and process clear reduces the overall adjacency convergence time.

Initially, allow 2 (configurable) neighbors to form adjacency to FULL per area. After the first adjacency reaches FULL, up to 64 (configurable) neighbors can form adjacency simultaneously for the IS-IS instance (all areas). However, areas without any FULL adjacency is restricted by the initial area limit.



Note Adjacency stagger and IS-IS nonstop forwarding (NSF) are mutually exclusive. Adjacency stagger is not activated if nonstop forwarding (NSF) is configured in the router along with IS-IS configuration.

Table 2: Task ID

Task ID	Operations
IS-IS	read, write

The following example shows how to configure adjacency stagger for a 2 neighbors initially and for a maximum of 32 neighbors:

```
Router# configure
Router(config)# router isis 1
Router(config-isis)# adjacency stagger 2 32
```

algorithm 0

The **algorithm 0** command allows you to override the maximum-paths configuration for an address-family and IS-IS instance pair. The **maximum-paths** subcommand under **algorithm 0** configuration block will be applied to the standard SPF algorithm of that IS-IS instance.

algorithm 0
address-family { **ipv4** | **ipv6** } **unicast**
maximum-paths *maximum-paths*

Syntax Description

address-family {ipv4 | ipv6}	Configures the address family for IS-IS.
unicast	Specifies unicast address prefixes.
maximum-paths	Specifies the maximum number of parallel routes that an IP routing protocol installs in the routing table. The range is 1 to 64.

Command Modes

IS-IS interface

Command History

Release	Modification
Release 7.8.1	This command was introduced.

Usage Guidelines

No specific guidelines impact the use of this command.

Task ID

Task ID	Operations
isis	read, write

attached-bit receive ignore

To ignore the attached bit in a received Level 1 link-state packet (LSP), use the **attached-bit receive ignore** command in address family configuration mode. To remove the **attached-bit receive ignore** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

attached-bit receive ignore
no attached-bit receive ignore

Command Default

The attached bit is set in the LSP.

Command Modes

Address family configuration

Command History

Release	Modification
Release 3.8.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure to ignore the attached bit in a received LSP:

```
RP/0/RSP0/CPU0:router(config)# router isis isp1
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-af)# attached-bit receive ignore
```

Related Commands

Command	Description
attached-bit send, on page 16	Configures an Intermediate System-to-Intermediate System (IS-IS) instance with an attached bit in the Level 1 link-state packet (LSP).

attached-bit send

To configure an Intermediate System-to-Intermediate System (IS-IS) instance with an attached bit in the Level 1 link-state packet (LSP), use the **attached-bit send** command in address family configuration mode. To remove the **attached-bit send** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

attached-bit send {**always-set** | **never-set**}
no attached-bit send {**always-set** | **never-set**}

Syntax Description

always-set	Specifies to always set the attached bit in the LSP.
never-set	Specifies to never set the attached bit in the LSP.

Command Default

The attached bit is not forced to be set or unset in the LSP.

Command Modes

Address family configuration

Command History

Release	Modification
Release 3.8.0	This command was introduced and replaces the set-attached-bit, on page 159 command.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **attached-bit send** command to set an IS-IS instance with an attached bit in the Level 1 LSP that allows another IS-IS instance to redistribute Level 2 topology. The attached bit is used when the Level 2 connectivity from another IS-IS instance is advertised by the Level 1 attached bit.

Cisco IOS XR software does not support multiple Level 1 areas in a single IS-IS routing instance; however the equivalent functionality is achieved by redistribution of routes between two IS-IS instances by using the redistribute (IS-IS), on page 142 command.

The attached bit is configured for a specific address family only if the **single-topology** command is not configured.

Note If connectivity for the Level 2 instance is lost, the attached bit in the Level 1 instance LSP continues sending traffic to the Level 2 instance and causes the traffic to be dropped.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure an Intermediate System-to-Intermediate System (IS-IS) instance with an attached bit:

```
RP/0/RSP0/CPU0:router(config)# router isis isp1
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-af)# attached-bit send always-set
```

Related Commands

Command	Description
redistribute (IS-IS), on page 142	Redistribute routes from one routing protocol into Intermediate System-to-Intermediate System (IS-IS).
single-topology, on page 222	Configures the link topology for IPv4 when IPv6 is configured.

authentication-check disable

To suppress Intermediate System-to-Intermediate System (IS-IS) authentication check, use the **authentication-check disable** command in configuration mode. To remove this function, use the **no** form of this command.

authentication-check disable
no authentication-check disable

Command Default

Authentication check is enabled

Command Modes

Global Configuration mode

Command History

Release	Modification
Release 7.7.1	This command was introduced.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to disable authentication check for IS-IS.

```
Router# configure
Router(config)# router isis 1
Router(config)# authentication-check disable
Router(config)# commit
```

circuit-type

To configure the type of adjacency used for the Intermediate System-to-Intermediate System (IS-IS) protocol, use the **circuit-type** command in interface configuration mode. To reset the circuit type to Level l and Level 2, use the **no** form of this command.

circuit-type {**level-1** | **level-1-2** | **level-2-only**}
no circuit-type

Syntax Description

level-1	Establishes only Level 1 adjacencies over an interface.
level-1-2	Establishes both Level 1 and Level 2 adjacencies, if possible.
level-2-only	Establishes only Level 2 adjacencies over an interface.

Command Default

Default adjacency types are Level 1 and Level 2 adjacencies.

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Adjacencies may not be established even if allowed by the **circuit-type** command. The proper way to establish adjacencies is to configure a router as a Level 1, Level 1 and Level 2, or Level 2-only system using the is-type, on page 70 command. Only on networking devices that are between areas (Level 1 and Level 2 networking devices) should you configure some interfaces to be Level 2-only to prevent wasting bandwidth by sending out unused Level 1 hello packets. Remember that on point-to-point interfaces, the Level 1 and Level 2 hello packets are in the same packet.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure a Level 1 adjacency with its neighbor on GigabitEthernetinterface 0/2/0/0 and Level 2 adjacencies with all Level 2-capable routers on GigabitEthernet interface 0/5/0/2:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# is-type level-1-2
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet 0/2/0/0
RP/0/RSP0/CPU0:router(config-isis-if)# circuit-type level-1
```

```
RP/0/RSP0/CPU0:router(config-isis-if)# exit
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet 0/5/0/2
RP/0/RSP0/CPU0:router(config-isis-if)# circuit-type level-2-only
```

In this example, only Level 2 adjacencies are established because the **is-type** command is configured:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# is-type level-2-only
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet 0/2/0/0
RP/0/RSP0/CPU0:router(config-isis-if)# circuit-type level-1-2
```

Related Commands

Command	Description
is-type, on page 70	Configures the routing level for an instance of the IS-IS routing process.
net, on page 124	Configures an IS-IS NET for the routing process.

clear isis process

To clear the link-state packet (LSP) database and adjacency database sessions for an Intermediate System-to-Intermediate System (IS-IS) instance or all IS-IS instances, use the **clear isis process** command in EXEC configuration mode.

clear isis [**instance** *instance-id*] **process**

Syntax Description

instance *instance-id*	(Optional) Specifies IS-IS sessions for the specified IS-IS instance only. • The *instance-id* argument is the instance identifier (alphanumeric) defined by the **router isis** command.

Command Default

No default behavior or values

Command Modes

EXEC configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **clear isis process** command without any keyword to clear all the IS-IS instances. Add the **instance** *instance-id* keyword and argument to clear the specified IS-IS instance.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows the IS-IS LSP database and adjacency sessions being cleared for instance 1:

```
RP/0/RSP0/CPU0:router# clear isis instance 1 process
```

Related Commands

Command	Description
show isis database, on page 173	Displays the IS-IS link-state database.
show isis neighbors, on page 194	Displays information about IS-IS neighbors.

clear isis route

To clear the Intermediate System-to-Intermediate System (IS-IS) routes in a topology, use the **clear isis route** command in EXEC configuration mode.

clear isis [**instance** *instance-id*] {**afi-all** | **ipv4** | **ipv6**} {**unicast** | **multicast** | **safi-all**} [**topology** *topo-name*] **route**

Syntax Description

instance *instance-id*	(Optional) Specifies IS-IS sessions for the specified IS-IS instance only. • The *instance-id* argument is the instance identifier (alphanumeric) defined by the **router isis** command.
afi-all	Specifies IP Version 4 (IPv4) and IP Version 6 (IPv6) address prefixes.
ipv4	Specifies IPv4 address prefixes.
ipv6	Specifies IPv6 address prefixes.
unicast	Specifies unicast address prefixes.
multicast	Specifies multicast address prefixes.
safi-all	Specifies all secondary address prefixes.
topology *topo-name*	(Optional) Specifies topology table information and name of the topology table.

Command Default

No default behavior or value

Command Modes

EXEC configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	Support for IPv6 was added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **clear isis route** command to clear the routes from the specified topology or all routes in all topologies if no topology is specified.

Task ID

Task ID	Operations
isis	execute
rib	read, write

Task ID	Operations
basic-services	read, write

Examples

The following example shows how to clear the routes with IPv4 unicast address prefixes:

```
RP/0/RSP0/CPU0:router# clear isis ipv4 unicast route
```

Related Commands

Command	Description
show isis database, on page 173	Displays the IS-IS link-state database.
show isis neighbors, on page 194	Displays information about IS-IS neighbors.

clear isis statistics

To clear the Intermediate System-to-Intermediate System (IS-IS) statistics, use the **clear isis statistics** command in EXEC configuration mode.

clear isis [**instance** *instance-id*] **statistics** [*type interface-path-id*]

Syntax Description

instance *instance-id*	(Optional) Clears IS-IS sessions for the specified IS-IS instance only. • The *instance-id* argument is the instance identifier (alphanumeric) defined by the **router isis** command.
type	Interface type. For more information, use the question mark (?) online help function.
interface-path-id	Physical interface or virtual interface. **Note** Use the **show interfaces** command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.

Command Default

No default behavior or values

Command Modes

EXEC configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **clear isis statistics** command to clear the information displayed by the **show isis statistics** command.

Task ID

Task ID	Operations
isis	execute
rib	read, write
basic-services	read, write

Examples

The following example shows the IS-IS statistics for a specified interface being cleared:

```
RP/0/RSP0/CPU0:router# clear isis instance 23 statistics
```

Related Commands

Command	Description
show isis statistics, on page 210	Displays the IS-IS statistics.

cost-fallback anomaly delay

cost-fallback anomaly delay { **igp-metric** | **te-metric** } { **increment** *penalty_value* | **multiplier** *penalty_multiplier* | **value** *penalized_metric* | **disable** }

Syntax Description

increment *penalty_value*	Increment the IGP cost by the specified value. The range is from 1 to 65534.
multiplier*penalty_multiplier*	Multiply the IGP cost by the specified value. The range is from 1 to 255.
value *penalized_metric*	Set the IGP cost to the specified value. The range is from 1 to 65535.

Command Modes

Interface Configuration

Area Configuration

Router Configuration

Command History

Release	Modification
Release 7.4.1	This command was introduced.

Usage Guidelines

Use the **cost-fallback anomaly delay** command to increase the metric when you configure link delay anomaly detection in Segment Routing Performance Measurement (SR-PM).

When you configure link delay anomaly detection, SR-PM sends an anomaly bit (A-bit) when the upper bound of the anomaly threshold is exceeded. When an anomaly is received for an interface, OSPF can increase the IGP metric or TE metric to make the link less attractive for traffic.

You can specify how to increase the metric in the following ways:

- As a factor by which the base metric is multiplied
- As an increment that is added to the base metric
- As a fixed high value (up to 0xFFFFFFFF).

Note Due to protocol limitations, there is a maximum value applied for the metric for all three options:

- IGP metric maximum value: 0xFFFF
- TE metric maximum value: 0xFFFFFFFF

The configuration can be applied at the OSPF interface, area, and instance levels, and is applicable only to non-loopback interfaces. When the configuration is applied at the OSPF interface level, it is applicable to that interface only.

Task ID

Task ID	Operation
ospf	read, write

Example

In the following examples, the base IGP metric values are 10.

This example shows how to increase the IGP and TE metrics for an interface. The IGP metric will be increased by 10 and the TE metric will be multiplied by 10. When an anomalous bit notification comes for interface GigabitEthernet0/2/0/0, the values advertised in the TLVs will be IGP metric 20 and TE metric 100.

```
Router(config)# router ospf 1
Router(config-ospf)# area 0
Router(config-ospf-ar)# interface GigabitEthernet 0/2/0/0
Router(config-ospf-ar-if)# cost-fallback anomaly delay igp-metric increment 10
Router(config-ospf-ar-if)# cost-fallback anomaly delay te-metric multiplier 10
```

This example shows how to set a specific IGP and TE metric value for an interface. When an anomalous bit notification comes for interface GigabitEthernet0/2/0/0, the values advertised in the TLVs will be IGP metric 100 and TE metric 50.

```
Router(config)# router ospf 1
Router(config-ospf)# area 0
Router(config-ospf-ar)# interface GigabitEthernet 0/2/0/0
Router(config-ospf-ar-if)# cost-fallback anomaly delay igp-metric value 100
Router(config-ospf-ar-if)# cost-fallback anomaly delay te-metric value 50
```

csnp-interval

To configure the interval at which periodic complete sequence number PDU (CSNP) packets are sent on broadcast interfaces, use the **csnp-interval** command in interface configuration mode. To restore the default value, use the **no** form of this command.

csnp-interval *seconds* [**level** {**1** | **2**}]
no csnp-interval *seconds* [**level** {**1** | **2**}]

Syntax Description

seconds	Interval (in seconds) of time between transmission of CSNPs on multiaccess networks. This interval applies only for the designated router. Range is 0 to 65535 seconds.
level { **1** | **2** }	(Optional) Specifies the interval of time between transmission of CSNPs for Level 1 or Level 2 independently.

Command Default

seconds : 10 seconds

Both Level 1 and Level 2 are configured if no level is specified.

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **csnp-interval** command applies only to the designated router (DR) for a specified interface. Only DRs send CSNP packets to maintain database synchronization. The CSNP interval can be configured independently for Level 1 and Level 2.

Use of the **csnp-interval** command on point-to-point subinterfaces makes sense only in combination with the IS-IS mesh-group feature.

Task ID

Task ID	Operations
isis	execute
rib	read, write
basic-services	read, write

Examples

The following example shows how to set the CSNP interval for Level 1 to 30 seconds:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
```

```
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet 0/0/2/0
RP/0/RSP0/CPU0:router(config-isis-if)# csnp-interval 30 level 1
```

default-information originate (IS-IS)

To generate a default route into an Intermediate System-to-Intermediate System (IS-IS) routing domain, use the **default-information originate** command in address family configuration mode. To remove the **default-information originate** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

default-information originate [**route-policy** *route-policy-name*]
no default-information originate [**external** | **route-policy** *route-policy-name*]

Syntax Description

route-policy	(Optional) Defines the conditions for the default route.
route-policy-name	(Optional) Name for the route policy.

Command Default

A default route is not generated into an IS-IS routing domain.

Command Modes

Address family configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If a router configured with the **default-information originate** command has a route to 0.0.0.0 in the routing table, IS-IS originates an advertisement for 0.0.0.0 in its link-state packets (LSPs).

Without a route policy, the default is advertised only in Level 2 LSPs. For Level 1 routing, there is another process to find the default route, which is to look for the closest Level 1 and Level 2 router. The closest Level 1 and Level 2 router can be found by looking at the attached-bit (ATT) in Level 1 LSPs.

A route policy can be used for two purposes:

- To make the router generate the default route in its Level 1 LSPs.
- To advertise 0.0.0.0/0 conditionally.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to generate a default external route into an IS-IS domain:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
```

```
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-af)# default-information originate
```

Related Commands

Command	Description
redistribute (IS-IS), on page 142	Redistributes routes from one routing protocol into Intermediate System-to-Intermediate System (IS-IS).
show isis database, on page 173	Displays the IS-IS link-state database.

disable (IS-IS)

To disable the Intermediate System-to-Intermediate System (IS-IS) topology on a specified interface, use the **disable** command in interface address family configuration mode. To remove this function, use the **no** form of this command.

disable
no disable

Command Default

IS-IS protocol is enabled.

Command Modes

Interface address family configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to disable the IS-IS protocol for IPv4 unicast on GigabitEthernet interface 0/1/0/1:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet 0/1/0/1
RP/0/RSP0/CPU0:router(config-isis-if)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-if-af)# disable
```

distance (IS-IS)

To define the administrative distance assigned to routes discovered by the Intermediate System-to-Intermediate System (IS-IS) protocol, use the **distance** command in address family configuration mode. To remove the **distance** command from the configuration file and restore the system to its default condition in which the software removes a distance definition, use the **no** form of this command.

distance *weight* [*prefix maskprefix/length* | [*prefix-list-name*]]
no distance [*weight*] [*prefix maskprefix/length* | [*prefix-list-name*]]

Syntax Description

weight	Administrative distance to be assigned to IS-IS routes. Range is 1 to 255.
prefix	(Optional) The *prefix* argument specifies the IP address in four-part, dotted-decimal notation.
mask	(Optional) IP address mask.
/length	(Optional) The length of the IP prefix. A decimal value that indicates how many of the high-order contiguous bits of the address compose the prefix (the network portion of the address). A slash must precede the decimal value. Range is 0 to 32 for IPv4 addresses and 0 to 128 for IPv6 addresses.
prefix-list-name	(Optional) List of routes to which administrative distance applies.

Command Default

weight : 115

Command Modes

Address family configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

An administrative distance is an integer from 1 to 255. In general, the higher the value, the lower the trust rating. An administrative distance of 255 means that the routing information source cannot be trusted at all and should be ignored. Weight values are subjective; no quantitative method exists for choosing weight values.

Use the **distance** command to configure the administrative distances applied to IS-IS routes when they are inserted into the Routing Information Base (RIB), and influence the likelihood of these routes being preferred over routes to the same destination addresses discovered by other protocols.

The *address/prefix-length* argument defines to which source router the distance applies. In other words, each IS-IS route is advertised by another router, and that router advertises an address that identifies it. This source address is displayed in the output of the **show isis route detail** command.

The **distance** command applies to the routes advertised by routers whose address matches the specified prefix. The *prefix-list-name* argument can then be used to refine this further so that the **distance** command affects only specific routes.

Task ID

Task ID	Operations
isis	read, write

Examples

In the following example, a distance of 10 is assigned to all routes to 2.0.0.0/8 and 3.0.0.0/8 (or more specific prefixes) that are advertised by routers whose ID is contained in 1.0.0.0/8. A distance of 80 is assigned to all other routes.

```
RP/0/RSP0/CPU0:router(config)# ipv4 prefix-list target_routes
RP/0/RSP0/CPU0:router(config-ipv4_pfx)# permit 2.0.0.0/8
RP/0/RSP0/CPU0:router(config-ipv4_pfx)# permit 3.0.0.0/8
RP/0/RSP0/CPU0:router(config-ipv4_pfx)# deny 0.0.0.0/0
RP/0/RSP0/CPU0:router(config-ipv4_pfx)# exit
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-af)# distance 10 1.0.0.0/8 target_routes
RP/0/RSP0/CPU0:router(config-isis-af)# distance 80
```

Related Commands

Command	Description
router isis, on page 152	Configures the IS-IS routing protocol and specifies an IS-IS instance.
show isis protocol, on page 197	Displays summary information about the IS-IS instance.
show isis route, on page 200 **detail**	Displays link-state packet (LSP) details.

distribute-list in (IS-IS)

To filter the routes that Intermediate System-to-Intermediate System (IS-IS) installs in the Routing Information Base (RIB), use the **distribute-list in** command in the appropriate configuration mode. To change or remove the filter, use the **no** form of this command.

distribute-list { {**prefix-list** *prefix-list-name* | **route-policy** *route-policy-name*} } **in**
no distribute-list { {**prefix-list** *prefix-list-name* | **route-policy** *route-policy-name*} } **in**

Syntax Description

prefix-list	IP Version 4 (IPv4) or IP Version 6 (IPv6) prefix list. The list defines which prefixes are to be installed and which are to be omitted when installing routes in the RIB.
route-policy	Specifies the route-policy to filter IS-IS routes.
in	Applies the prefix list or route-policy to incoming routing updates.

Command Default

All routes computed by IS-IS are installed in the RIB.

Command Modes

IS-IS router address-family

Command History

Release	Modification
Release 6.5.1	This command was introduced.

Usage Guidelines

When **distribute-list in** command is configured, some routes that IS-IS computes are not installed in the forwarding plane of the local router, but other IS-IS routers will not be aware of this. This introduces a difference between the forwarding state computed by other IS-IS routers and the actual forwarding state on this router. In some cases, this could lead to traffic being dropped or looped. Hence, be careful about when to use this command.

Task ID

Task ID	Operation
isis	read, write

Example

The following example shows how to filter the incoming IS-IS updates using prefix lists:

```
ipv6 prefix-list v6-1
 10 deny 2020:1000::101/128
 20 permit ::/0 le 128
!
ipv4 prefix-list v4-1
 10 deny 20.1.0.101/32
 20 permit 0.0.0.0/0 le 32
!
router isis 1
 net 49.0001.0000.0000.0100.00
```

```
 address-family ipv4 unicast
  metric-style wide
  distribute-list prefix-list v4-1 in
 !
 address-family ipv6 unicast
  metric-style wide
  distribute-list prefix-list v6-1 in
 !
```

The following example shows how to filter the incoming IS-IS updates using a route-policy for both IPv4 and IPv6:

```
prefix-set isis-ps-1
  2020:1000::101/128 le 128,
  20.1.0.101/32 le 32
end-set
!
route-policy isis-rp-1
  if destination in isis-ps-1 then
    drop
  elseif tag eq 0 then
    pass
  elseif tag le 100 then
    drop
  else
    pass
  endif
end-policy
!
router isis 1
 net 49.0001.0000.0000.0100.00
 address-family ipv4 unicast
  metric-style wide
  distribute-list route-policy isis-rp-1 in
 !
 address-family ipv6 unicast
  metric-style wide
  distribute-list route-policy isis-rp-1 in
 !
```

fast-reroute per-link (IS-IS)

To enable IP fast reroute (IPFRR) loop-free alternate (LFA) prefix independent per-link computation, use the **fast-reroute per-link** command in interface address family configuration mode. To disable this feature, use the **no** form of this command.

fast-reroute per-link [**exclude interface** *type interface-path-id* | **level** {**1** | **2**} | **lfa-candidate interface** *type interface-path-id*]
no fast-reroute per-link

Syntax Description

exclude	Specifies fast-reroute (FRR) loop-free alternate (LFA) computation exclusion information
level {1 | 2}	Configures FRR LFA computation for one level only.
lfa-candidate	Specifies FRR LFA computation candidate information
interface	Specifies an interface that needs to be either excluded from FRR LFA computation (when used with **exclude** keyword) or to be included to LFA candidate list in FRR LFA computation (when used with the **lfa-candidate** keyword).
type	Interface type. For more information, use the question mark (?) online help function.
interface-path-id	Physical interface or virtual interface. **Note** Use the show interfaces command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.

Command Default

IP fast-reroute LFA per-link computation is disabled.

Command Modes

Interface address family configuration

Command History

Release	Modification
Release 4.0.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operation
isis	read, write

This example shows how to configure per-link fast-reroute LFA computation for the IPv4 unicast topology at Level 1:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet 0/3/0/0
RP/0/RSP0/CPU0:router(config-isis-if)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-if-af)# fast-reroute per-link level 1
```

fast-reroute per-prefix (IS-IS)

To enable IP fast reroute (IPFRR) loop-free alternate (LFA) prefix dependent computation, use the **fast-reroute per-prefix** command in interface address family configuration mode. LFA is supported only on Enhanced Ethernet line card.

fast-reroute per-prefix [**exclude interface** *type interface-path-id* | **level** {**1** | **2**} | **lfa-candidate interface** *type interface-path-id* | **remote-lfa** {**maximum-metric** *metric-value* | **tunnel mpls-ldp**} **prefix-list***prefix-list-name*[**level** {**1** | **2**}]]

Syntax Description

exclude	Specifies fast-reroute (FRR) loop-free alternate (LFA) computation exclusion information
level {1 | 2}	Configures FRR LFA computation for one level only.
lfa-candidate	Specifies FRR LFA computation candidate information
interface	Specifies an interface that needs to be either excluded from FRR LFA computation (when used with **exclude** keyword) or to be included to LFA candidate list in FRR LFA computation (when used with the **lfa-candidate** keyword).
type	Interface type. For more information, use the question mark (?) online help function.
interface-path-id	Physical interface or virtual interface. **Note** Use the show interfaces command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.
remote-lfa	Enable remote LFA related configuration.
prefix-list *prefix-list-name*	Filter PQ node router ID based on prefix list.

Command Default

IP fast-reroute LFA per-prefix computation is disabled.

Command Modes

Interface address family configuration

Command History

Release	Modification
Release 6.0	This command was introduced.

Usage Guidelines

No specific guidelines impact the use of this command.

Task ID

Task ID	Operation
isis	read, write

This example shows how to configure per-prefix fast-reroute LFA computation for the IPv4 unicast topology at Level 1:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet 0/3/0/0
RP/0/RSP0/CPU0:router(config-isis-if)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-if-af)# fast-reroute per-prefix level 1
```

This example shows how to configure per-prefix remote-lfa prefix list. The prefix-list option filters PQ node router ID based on prefix list.

```
RP/0/RP0/CPU0:router(config-isis-af)# fast-reroute per-prefix remote-lfa prefix-list
```

fast-reroute per-link priority-limit (IS-IS)

To enable the IP fast reroute (IPFRR) loop-free alternate (LFA) prefix independent per-link computation, use the **fast-reroute per-link priority-limit** command in address family configuration mode. To disable this feature, use the **no** form of this command.

fast-reroute per-link priority-limit {**critical** | **high** | **medium**} **level** {**1** | **2**}
no fast-reroute per-link priority-limit

Syntax Description

critical	Enables LFA omputation for critical priority prefixes only.
high	Enables LFA computation for for criticaland high priority prefixes.
medium	Enables LFA computation for for critical, high, and medium priority prefixes.
level {1|2}	Sets priority-limit for routing Level 1 or Level 2 independently.

Command Default

Fast-reroute per link priority limit LFA computation is disabled.

Command Modes

IPv4 unicast address family configuration

IPv6 unicast address family configuration

IPv4 multicast address family configuration

IPv6 multicast address family configuration

Command History

Release	Modification
Release 4.0.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
isis	read, write

This example shows how to configure fast-reroute prefix independent per-link computation for critical priority prefixes for level 1 only:

```
RP/0/RSP0/CPU0:router#configure
RP/0/RSP0/CPU0:router(config)#router isis isp_lfa
RP/0/RSP0/CPU0:router(config-isis)#address-family ipv4
```

```
RP/0/RSP0/CPU0:router(config-isis-af)#fast-reroute per-link priority-limit critical level
1
```

fast-reroute per-link use-candidate-only (IS-IS)

To exclude all interfaces by default from prefix independent per-link fast-reroute computation, use the **fast-reroute per-link use-candidate-only** command ISIS address family configuration mode. To include all interfaces by default, use the no form of this command.

fast-reroute per-link use-candidate-only [**level** {**1** | **2**}]
no fast-reroute per-link use-candidate-only

Syntax Description

level {1 | 2}	[Optional] Sets priority-limit for routing Level 1 or Level 2 independently.

Command Default

None

Command Modes

IPv4 unicast address family configuration

IPv6 unicast address family configuration

IPv4 multicast address family configuration

IPv6 multicast address family configuration

Command History

Release	Modification
Release 4.2.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

This command can be configured for a specific level. If no level is given it is applicable for both level 1 and level 2.

Task ID

Task ID	Operation
isis	read, write

This example shows how to configure the **fast-reroute per-link use-candidate-only** command for Level 1.

```
RP/0/RSP0/CPU0:router#configure
RP/0/RSP0/CPU0:router(config)#router isis isp
RP/0/RSP0/CPU0:router(config-isis)#address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-af)#fast-reroute use-candidate-only per-link level 1
```

fast-reroute per-prefix load-sharing disable (IS-IS)

To disable load sharing prefixes across multiple backups, use the **fast-reroute per-prefix load-sharing disable** command in IPv4 address family configuration mode. To disable this feature, use the **no** form of this command.

fast-reroute per-prefix load-sharingdisable
no fast-reroute per-prefix load-sharingdisable

Syntax Description

level {1|2}	Disables load-sharing for Level 1 or Level 2 independently.

Command Default

Load sharing is enabled.

Command Modes

IPv4 unicast address family configuration

IPv4 multicast address family configuration

Command History

Release	Modification
Release 4.0.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
isis	read, write

This example shows how to disable load-sharing prefixes across multiple backups for level 1 routes:

```
RP/0/RSP0/CPU0:router#configure
RP/0/RSP0/CPU0:router(config)#router isis isp_lfa
RP/0/RSP0/CPU0:router(config-isis)#address-family ipv4
RP/0/RSP0/CPU0:router(config-isis-af)#fast-reroute per-prefix load-sharing disable level 1
```

fast-reroute per-prefix tiebreaker (IS-IS)

To configure tie-breaker for multiple backups, use the **fast-reroute per-prefix tiebreaker** command in IPv4 address family configuration mode. To disable tie-breaker configuration, use the **no** form of this command.

fast-reroute per-prefix tiebreaker [**downstream** | **lc-disjoint** | **lowest-backup-metric** | **node-protecting** | **primary-path** | **secondary-path** | **srlg-disjoint** *index*] **index** *index_number* **level {1 | 2}**
no fast-reroute per-prefix tiebreaker

Syntax Description

downstream	Configures to prefer backup path via downstream node, in case of tie-breaker.
lc-disjoint	Configures to prefer Prefer line card disjoint backup path.
lowest-backup-metric	Configures to prefer backup path with lowest total metric.
node-protecting	Configures to prefer node protecting backup path.
primary-path	Configures to prefer backup path from ECMP set.
secondary-path	Configures to prefer non-ECMP backup path.
srlg-disjoint	Configures to prefer srlg disjoint backup path.
index	Sets preference order among tie-breakers.
index_number	Value for the index. Range is 1-255.
level {1 | 2}	Configures tiebreaker for Level 1 or Level 2 independently.

Command Default

Tie-breaker for multiple backups is not configured.

Command Modes

IPv4 unicast address family configuration

IPv4 multicast address family configuration

Command History

Release	Modification
Release 4.0.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
isis	read, write

This example shows how to configure preference of backup path via downstream node in case of a tie-breaker for selection of backup path from multiple backup paths:

```
RP/0/RSP0/CPU0:router#configure
RP/0/RSP0/CPU0:router(config)#router isis isp_lfa
RP/0/RSP0/CPU0:router(config-isis)#address-family ipv4
RP/0/RSP0/CPU0:router(config-isis-af)#fast-reroute per-prefix tiebreaker downstream index
255
```

This example shows how to configure all the criterions for backup path selection:

```
RP/0/RSP0/CPU0:router#configure
RP/0/RSP0/CPU0:router(config)#router isis isp_lfa
RP/0/RSP0/CPU0:router(config-isis)#address-family ipv4
RP/0/RSP0/CPU0:router(config-isis-af)#fast-reroute per-prefix tiebreaker srlg-disjoint index
 10
RP/0/RSP0/CPU0:router(config-isis-af)#fast-reroute per-prefix tiebreaker primary-path index
 20
RP/0/RSP0/CPU0:router(config-isis-af)#fast-reroute per-prefix tiebreaker lowest-backup-metric
 index 30
RP/0/RSP0/CPU0:router(config-isis-af)#fast-reroute per-prefix tiebreaker lc-disjoint index
 40
RP/0/RSP0/CPU0:router(config-isis-af)#fast-reroute per-prefix tiebreaker node-protecting
index 50
```

fast-reroute per-prefix use-candidate-only (IS-IS)

To exclude all interfaces by default from prefix dependent fast-reroute computation, use the **fast-reroute per-prefix use-candidate-only** command ISIS address family configuration mode. To include all interfaces by default, use the **no** form of this command.

fast-reroute per-prefix use-candidate-only [**level** {**1** | **2**}]
no fast-reroute per-prefix use-candidate-only

Syntax Description

level {1 | 2}	[Optional] Sets priority-limit for routing Level 1 or Level 2 independently.

Command Default

None

Command Modes

IPv4 unicast address family configuration

IPv6 unicast address family configuration

IPv4 multicast address family configuration

IPv6 multicast address family configuration

Command History

Release	Modification
Release 4.2.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

This command can be configured for a specific level. If no level is given it is applicable for both level 1 and level 2.

Task ID

Task ID	Operation
isis	read, write

This example shows how to configure the **fast-reroute per-prefix use-candidate-only** command for Level 1.

```
RP/0/RSP0/CPU0:router#configure
RP/0/RSP0/CPU0:router(config)#router isis isp
RP/0/RSP0/CPU0:router(config-isis)#address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-af)#fast-reroute use-candidate-only per-link level 1
```

hello-interval (IS-IS)

To specify the length of time between consecutive hello packets sent by the Intermediate System-to-Intermediate System (IS-IS) protocol software, use the **hello-interval** command in interface configuration mode. To restore the default value, use the **no** form of this command.

hello-interval *seconds* [**level** {**1** | **2**}]
no hello-interval [*seconds*] [**level** {**1** | **2**}]

Syntax Description

seconds	Integer value (in seconds) for the length of time between consecutive hello packets. By default, a value three times the hello interval *seconds* is advertised as the *hold time* in the hello packets sent. (That multiplier of three can be changed by using the **hello-multiplier** command.) With smaller hello intervals, topological changes are detected more quickly, but there is more routing traffic. Range is 1 to 65535 seconds.
level { **1** | **2** }	(Optional) Specifies the hello interval for Level 1 and Level 2 independently. For broadcast interfaces only.

Command Default

seconds : 10 seconds

Both Level 1 and Level 2 are configured if no level is specified.

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The hello interval can be configured independently for Level 1 and Level 2, except on serial point-to-point interfaces. (Because only a single type of hello packet is sent on serial links, it is independent of Level 1 or Level 2.) Configuring Level 1 and Level 2 independently is used on LAN interfaces.

Note A shorter hello interval gives quicker convergence, but increases bandwidth and CPU usage. It might also add to instability in the network.

A slower hello interval saves bandwidth and CPU. Especially when used in combination with a higher hello multiplier, this strategy may increase overall network stability.

For point-to-point links, IS-IS sends only a single hello for Level 1 and Level 2, making the **level** keyword meaningless on point-to-point links. To modify hello parameters for a point-to-point interface, omit the **level** keyword.

Note Currently, a user can configure an aggressive hello-interval (lower than the default of 10 seconds for peer-to-peer session). But, if NSR or NSF is configured, the default hello interval has to be used so that the sessions do not run into the risk of flapping during switchover.

Using LAN adjacencies in high availability (HA) scenarios is not recommended, since there is no designated intermediate system (DIS) redundancy in the protocol and traffic will either drop or be rerouted temporarily during DIS re-election.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure TenGigE interface 0/6/0/0 to advertise hello packets every 5 seconds for Level 1 topology routes. This situation causes more traffic than configuring a longer interval, but topological changes are detected more quickly.

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# interface TenGigE 0/6/0/0
RP/0/RSP0/CPU0:router(config-isis-if)# hello-interval 5 level 1
```

Related Commands

Command	Description
hello-multiplier, on page 50	Specifies the number of IS-IS hello packets a neighbor must miss before the router should declare the adjacency as down.

hello-multiplier

To specify the number of Intermediate System-to-Intermediate System (IS-IS) hello packets a neighbor must miss before the router should declare the adjacency as down, use the **hello-multiplier** command in interface configuration mode. To restore the default value, use the **no** form of this command.

hello-multiplier *multiplier* [**level** {**1** | **2**}]
no hello-multiplier [*multiplier*] [**level** {**1** | **2**}]

Syntax Description

multiplier	Advertised hold time in IS-IS hello packets is set to the hello multiplier times the hello interval. Range is 3 to 1000. Neighbors declare an adjacency to this down router after not having received any IS-IS hello packets during the advertised hold time. The hold time (and thus the hello multiplier and the hello interval) can be set on an individual interface basis, and can be different between different networking devices in one area. Using a smaller hello multiplier gives faster convergence, but can result in more routing instability. Increase the hello multiplier to a larger value to help network stability when needed. Never configure a hello multiplier to a value lower than the default value of 3.
level { **1** | **2** }	(Optional) Specifies the hello multiplier independently for Level 1 or Level 2 adjacencies.

Command Default

multiplier : 3

Both Level 1 and Level 2 are configured if no level is specified.

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The “holding time” carried in an IS-IS hello packet determines how long a neighbor waits for another hello packet before declaring the neighbor to be down. This time determines how quickly a failed link or neighbor is detected so that routes can be recalculated.

Use the **hello-multiplier** command in circumstances where hello packets are lost frequently and IS-IS adjacencies are failing unnecessarily. You can raise the hello multiplier and lower the hello interval (hello-interval (IS-IS), on page 48 command) correspondingly to make the hello protocol more reliable without increasing the time required to detect a link failure.

On point-to-point links, there is only one hello for both Level 1 and Level 2. Separate Level 1 and Level 2 hello packets are also sent over nonbroadcast multiaccess (NBMA) networks in multipoint mode, such as X.25, Frame Relay, and ATM.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how the network administrator wants to increase network stability by making sure an adjacency goes down only when many (ten) hello packets are missed. The total time to detect link failure is 60 seconds. This strategy ensures that the network remains stable, even when the link is fully congested.

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet /2/0/1
RP/0/RSP0/CPU0:router(config-isis-if)# hello-interval 6
RP/0/RSP0/CPU0:router(config-isis-if)# hello-multiplier 10
```

Related Commands

Command	Description
hello-interval (IS-IS), on page 48	Specifies the length of time between hello packets that the software sends.

hello-padding

To configure padding on Intermediate System-to-Intermediate System (IS-IS) hello protocol data units (IIH PDUs) for all IS-IS interfaces on the router, use the **hello-padding** command in interface configuration mode. To suppress padding, use the **no** form of this command.

hello-padding {**disable** | **sometimes**} [**level** {**1** | **2**}]
no hello-padding {**disable** | **sometimes**} [**level** {**1** | **2**}]

Syntax Description

disable	Suppresses hello padding.
sometimes	Enables hello padding during adjacency formation only.
level { **1** | **2** }	(Optional) Specifies hello padding for Level 1 or Level 2 independently.

Command Default

Hello padding is enabled.

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

You might want to suppress hello padding to conserve network resources. The lower the circuit speed, the higher the percentage of padding overhead. Before suppressing the hello padding, you should know your physical and data link layer configurations and have control over them, and also know your router configuration at the network layer.

For point-to-point links, IS-IS sends only a single hello for Level 1 and Level 2, making the **level** keyword meaningless on point-to-point links. To modify hello parameters for a point-to-point interface, omit the **level** keyword.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to suppress IS-IS hello padding over local area network (LAN) circuits for interface GigabitEthernet 0/2/0/1:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet 0/2/0/1
RP/0/RSP0/CPU0:router(config-isis-if)# hello-padding disable
```

Related Commands

Command	Description
show isis interface, on page 181	Displays information about the IS-IS interface.

hello-password

To configure the authentication password for an Intermediate System-to-Intermediate System (IS-IS) interface, use the **hello-password** command in interface configuration mode. To disable authentication, use the **no** form of this command.

hello-password [**hmac-md5** | **text**] [**clear** | **encrypted**] *password* [**level** {**1** | **2**}] [**send-only**]
no hello-password [**hmac-md5** | **text**] [**clear** | **encrypted**] *password* [**level** {**1** | **2**}] [**send-only**]

Syntax Description

hmac-md5	(Optional) Specifies that the password use HMAC-MD5 authentication.
text	(Optional) Specifies that the password use clear text password authentication.
clear	(Optional) Specifies that the password be unencrypted.
encrypted	(Optional) Specifies that the password be encrypted using a two-way algorithm.
password	Authentication password you assign for an interface.
level { **1** | **2** }	(Optional) Specifies whether the password is for a Level 1 or a Level 2 protocol data unit (PDU).
send-only	(Optional) Specifies that the password applies only to protocol data units (PDUs) that are being sent and does not apply to PDUs that are being received.

Command Default

Both Level 1 and Level 2 are configured if no level is specified.

password: encrypted text

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

When a **text** password is configured, it is exchanged as clear text. Therefore, the **hello-password** command provides limited security.

When an **hmac-md5** password is configured, the password is never sent over the network and is instead used to calculate a cryptographic checksum to ensure the integrity of the exchanged data.

For point-to-point links, IS-IS sends only a single hello for Level 1 and Level 2, making the **level** keyword meaningless on point-to-point links. To modify hello parameters for a point-to-point interface, omit the **level** keyword.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure a password with HMAC-MD5 authentication for hello packets running on GigabitEthernet 0/2/0/3 interface:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet 0/2/0/3
RP/0/RSP0/CPU0:router(config-isis-if)# hello-password hmac-md5 clear mypassword
```

Related Commands

Command	Description
hello-password keychain, on page 56	Configures the authentication password keychain for an Intermediate System-to-Intermediate System (IS-IS) interface.
hello-password accept, on page 58	Configures an additional authentication password for an IS-IS interface.

hello-password keychain

To configure the authentication password keychain for an Intermediate System-to-Intermediate System (IS-IS) interface, use the **hello-password keychain** command in interface configuration mode. To disable the authentication password keychain, use the **no** form of this command.

hello-password keychain *keychain-name* [**level** {**1** | **2**}] [**send-only**]
no hello-password keychain *keychain-name* [**level** {**1** | **2**}] [**send-only**]

Syntax Description

keychain	Keyword that specifies the keychain to be configured. An authentication password keychain is a sequence of keys that are collectively managed and used for authenticating a peer-to-peer group.
keychain-name	Specifies the name of the keychain.
level { **1** | **2** }	(Optional) Specifies whether the keychain is for a Level 1 or a Level 2 protocol data unit (PDU).
send-only	(Optional) Specifies that the keychain applies only to protocol data units (PDUs) that are being sent and does not apply to PDUs that are being received.

Command Default

Both Level 1 and Level 2 are configured if no level is specified.

password: encrypted text

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Specify a keychain to enable keychain authentication between two IS-IS peers. Use the **keychain** *keychain-name* keyword and argument to implement hitless key rollover for authentication.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure a password keychain for level 1, send only authentication on a GigabitEthernet interface:

```
RP/0/RSP0/CPU0:routerRP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:routerRP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet 0/1/0/0
```

```
RP/0/RSP0/CPU0:routerRP/0/RSP0/CPU0:router(config-isis-if)# hello-password keychain
mykeychain level 1 send-only
```

Related Commands

Command	Description
hello-password, on page 54	Configures the authentication password for an Intermediate System-to-Intermediate System (IS-IS) interface.
hello-password accept, on page 58	Configures an additional authentication password for an IS-IS interface.

hello-password accept

To configure an additional authentication password for an Intermediate System-to-Intermediate System (IS-IS) interface, use the **hello-password accept** command in interface configuration mode. To disable authentication, use the **no** form of this command.

hello-password accept {**clear** | **encrypted**} *password* [**level** {**1** | **2**}]
no hello-password accept {**clear** | **encrypted**} *password* [**level** {**1** | **2**}]

Syntax Description

clear	Specifies that the password be unencrypted.
encrypted	Specifies that the password be encrypted using a two-way algorithm.
password	Authentication password you assign.
level { **1** | **2** }	(Optional) Specifies the password for Level 1 or Level 2 independently.

Command Default

Both Level 1 and Level 2 are configured if no level is specified.

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **hello-password accept** command to add an additional password for an IS-IS interface. An authentication password must be configured using the **hello-password** command before an accept password can be configured for the corresponding level.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure a password:

```
RP/0/RSP0/CPU0:routerRP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:routerRP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet 0/2/0/3

RP/0/RSP0/CPU0:routerRP/0/RSP0/CPU0:router(config-isis)# hello-password accept encrypted
111D1C1603
```

Related Commands

Command	Description
hello-password, on page 54	Configures an authentication password for an IS-IS interface.

hostname dynamic disable

To disable Intermediate System-to-Intermediate System (IS-IS) routing protocol dynamic hostname mapping, use the **hostname dynamic** command in router configuration mode. To remove the specified command from the configuration file and restore the system to its default condition, use the **no** form of this command.

hostname dynamic disable
no hostname dynamic disable

Syntax Description

disable	Disables dynamic host naming.

Command Default

Router names are dynamically mapped to system IDs.

Command Modes

Router configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

In an IS-IS routing domain, each router is represented by a 6-byte hexadecimal system ID. When network administrators maintain and troubleshoot networking devices, they must know the router name and corresponding system ID.

Link-state packets (LSPs) include the dynamic hostname in the type, length, and value (TLV) which carries the mapping information across the entire domain. Every router in the network, upon receiving the TLV from an LSP, tries to install it in a mapping table. The router then uses the mapping table when it wants to convert a system ID to a router name.

To display the entries in the mapping tables, use the **show isis hostname** command.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to disable dynamic mapping of hostnames to system IDs:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
 RP/0/RSP0/CPU0:router(config-isis)# hostname dynamic disable
```

Related Commands

Command	Description
hostname	Specifies the name of the local router.
show isis hostname, on page 179	Displays the router name-to-system ID mapping table.

ignore-lsp-errors

To override the default setting of a router to ignore Intermediate System-to-Intermediate System (IS-IS) link-state packets (LSPs) that are received with internal checksum errors, use the **ignore-lsp-errors disable** command in router configuration mode. To enable ignoring IS-IS LSP errors, use the **no** form of this command.

ignore-lsp-errors disable
no ignore-lsp-errors disable

Syntax Description

disable	Disables the functionality of the command.

Command Default

The system ignores corrupt LSPs.

Command Modes

Router configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The IS-IS protocol definition requires that a received LSP with an incorrect data-link checksum be purged by the receiver, which causes the initiator of the packet to regenerate it. However, if a network has a link that causes data corruption and at the same time is delivering LSPs with correct data-link checksums, a continuous cycle of purging and regenerating large numbers of packets can occur. Because this situation could render the network nonfunctional, use this command to ignore these LSPs rather than purge the packets.

The receiving network devices use link-state packets to maintain their routing tables.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to instruct the router to purge LSPs that cause the initiator to regenerate LSPs:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# ignore-lsp-errors disable
```

instance-id

To allow a router to share one or more circuits among multiple Intermediate System to Intermediate System (IS-IS) routing protocol instances, use the **instance-id** command in router configuration mode.

instance-id *identifier*

Syntax Description

identifier	Specifies the Intermediate System to Intermediate System (IS-IS) routing protocol instance. Range is 1-65535.

Command Default

Disabled

Command Modes

Router configuration

Command History

Release	Modification
Release 6.1.x	This command was introduced.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure multiple instances on a single router:

```
RP/0/RSP0/CPU0:router(config)# router isis ring
RP/0/RSP0/CPU0:router(config-isis)# instance-id 1
RP/0/RSP0/CPU0:router(config-isis)# exit
RP/0/RSP0/CPU0:router(config)# router isis 1
RP/0/RSP0/CPU0:router(config-isis)# instance-id 6
RP/0/RSP0/CPU0:router(config-isis)#
```

interface (IS-IS)

To configure the Intermediate System-to-Intermediate System (IS-IS) protocol on an interface, use the **interface** command in router configuration mode. To disable IS-IS routing for interfaces, use the **no** form of this command.

interface *type interface-path-id*
no interface *type interface-path-id*

Syntax Description

type	Interface type. For more information, use the question mark (**?**) online help function.
interface-path-id	Physical interface or virtual interface. **Note** Use the **show interfaces** command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (**?**) online help function.

Command Default

No interfaces are specified.

Command Modes

Router configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

An address family must be established on the IS-IS interface before the interface is enabled for IS-IS protocol operation.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to enable an IS-IS multitopology configuration for IPv4 on GigabitEthernet interface 0/3/0/0:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# net 49.0000.0000.0001.00
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet 0/3/0/0
RP/0/RSP0/CPU0:router(config-isis-if)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-if-af)# metric-style wide level 1
```

```
!
RP/0/RSP0/CPU0:router(config)# interface GigabitEthernet 0/3/0/0
RP/0/RSP0/CPU0:router(config-if)# ipv4 address 2001::1/64
```

Related Commands

Command	Description
log adjacency changes (IS-IS), on page 74	Configures the routing level for an instance of the IS-IS routing process.
net, on page 124	Configures an IS-IS network entity title (NET) for the routing process.
router isis, on page 152	Enables the IS-IS routing protocol.

ipfrr lfa

The ipfrr lfa commands are deprecated in Release 4.0.1, and replaced with the fast-reroute commands. For more information, see the following:

- fast-reroute per-link priority-limit [level <1-2>]
- fast-reroute per-prefix priority-limit [level <1-2>]
- fast-reroute per-prefix tiebreaker index <1-255> [level <1-2>]
- fast-reroute per-prefix load-sharing disable [level <1-2>]
- fast-reroute [level <1-2>]
- fast-reroute per-link exclude interface [level <1-2>]
- fast-reroute per-link lfa-candidate interface [level <1-2>]
- fast-reroute per-prefix exclude interface [level <1-2>]
- fast-reroute per-prefix lfa-candidate interface [level <1-2>]
- show isis fast-reroute summary
- show isis fast-reroute [prefix] [longer-prefixes]
- show isis fast-reroute detail [prefix] [longer-prefixes]

To enable the IP fast reroute (IPFRR) loop-free alternate (LFA) computation, use the **ipfrr lfa** command in interface address family configuration mode. To disable this feature, use the **no** form of this command.

ipfrr lfa level {**1** | **2**}
no ipfrr lfa level {**1** | **2**}

Syntax Description

level { **1** | **2** }	Configures IPFRR LFA for Level 1 or Level 2 independently.

Command Default

IPFRR LFA is disabled.

Command Modes

Interface address family configuration

Command History

Release	Modification
Release 3.9.0	This command was introduced.
Release 4.0.1	This command was deprecated and replaced with the fast-reroute commands.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **ipfrr lfa** command to compute loop-free alternates for all links or neighbors in the event of a link failure.

To enable node protection on broadcast links, IPRR and bidirectional forwarding detection (BFD) must be enabled on the interface under IS-IS. See *Cisco IOS XR Interface and Hardware Configuration Guide* for information on configuring BFD.



Note Multiprotocol Label Switching (MPLS) FRR and IPFRR cannot be configured on the same interface simultaneously.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure IPFRR for the IPv4 unicast topology at Level 1:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet 0/3/0/0
RP/0/RSP0/CPU0:router(config-isis-if)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-if-af)# ipfrr lfa level 1
```

ipfrr lfa exclude interface

To exclude an interface from the IP fast reroute (IPFRR) loop-free alternate (LFA) computation, use the **ipfrr lfa exclude interface** command in interface address family configuration mode. To disable this feature, use the **no** form of this command.

ipfrr lfa exclude interface *type interface-path-id*
no ipfrr lfa exclude interface *type interface-path-id*

Syntax Description

type	Interface type. For more information, use the question mark (?) online help function.
interface-path-id	Physical interface or virtual interface. **Note** Use the **show interfaces** command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.

Command Default

IPFRR LFA is disabled.

Command Modes

Interface address family configuration

Command History

Release	Modification
Release 3.9.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **ipfrr lfa** command to compute loop-free alternates for all links or neighbors in the event of a link failure.

To enable node protection on broadcast links, IPRR and bidirectional forwarding detection (BFD) must be enabled on the interface under IS-IS. See *Cisco IOS XR Interface and Hardware Configuration Guide* for information on configuring BFD.

Note Multiprotocol Label Switching (MPLS) FRR and IPFRR cannot be configured on the same interface simultaneously.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure to exclude 0/1/0/0 interface from IPFRR LFA:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet 0/1/0/0
RP/0/RSP0/CPU0:router(config-isis-if)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-if-af)# ipfrr lfa exclude interface GigabitEthernet 0/1/0/0
```

Related Commands

Command	Description
ipfrr lfa, on page 65	Enable the IP fast reroute (IPFRR) loop-free alternate (LFA) computation

ispf

To configure the incremental shortest path first (iSPF) algorithm to calculate network topology, use the **ispf** command in address family configuration mode. To disable this algorithm function, use the **no** form of this command.

ispf [**level** {**1** | **2**}]
no ispf [**level** {**1** | **2**}]

Syntax Description

level { **1** | **2** }	(Optional) Configures the iSPF algorithm for Level 1 or Level 2 independently.

Command Default

The iSPF algorithm is not configured.

Command Modes

Address family configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The iSPF algorithm may be used to reduce the processor load when IS-IS needs to recalculate its topology after minor changes.



Note The incremental shortest path first (ISPF) algorithm was developed to improve SPF performance in the days of slow CPUs and before more advanced technological solutions like Fast Re-Route (FRR) and micro-loop avoidance were available. FRR and micro-loop avoidance both depend on information that is computed during a full SPF calculation and saved in the resulting shortest path tree.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure iSPF for the IPv4 unicast topology at Level 1:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-af)# ispf level 1
```

is-type

To configure the routing level for an Intermediate System-to-Intermediate System (IS-IS) area, use the **is-type** command in router configuration mode. To set the routing level to the default level, use the **no** form of this command.

is-type {**level-1** | **level-1-2** | **level-2-only**}
no is-type [**level-1** | **level-1-2** | **level-2-only**]

Syntax Description

level-1	Specifies that the router perform only Level 1 (intra-area) routing. This router learns only about destinations inside its area. Level 2 (interarea) routing is performed by the closest Level 1-2 router.
level-1-2	Specifies that the router perform both Level 1 and Level 2 routing.
level-2-only	Specifies that the routing process acts as a Level 2 (interarea) router only. This router is part of the backbone, and does not communicate with Level 1-only routers in its own area.

Command Default

Both Level 1 and Level 2 are configured if no level is specified.

Command Modes

Router configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

When the router is configured with Level 1 routing only, this router learns about destinations only inside its area. Level 2 (interarea) routing is performed by the closest Level 1-2 router.

When the router is configured with Level 2 routing only, this router is part of the backbone, and does not communicate with Level 1 routers in its own area.

The router has one link-state packet database (LSDB) for destinations inside the area (Level 1 routing) and runs a shortest path first (SPF) calculation to discover the area topology. It also has another LSDB with link-state packets (LSPs) of all other backbone (Level 2) routers, and runs another SPF calculation to discover the topology of the backbone and the existence of all other areas.

We highly recommend that you configure the type of an IS-IS routing process to establish the proper level of adjacencies. If there is only one area in the network, there is no need to run both Level 1 and Level 2 routing algorithms.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to specify that the router is part of the backbone and that it does not communicate with Level 1-only routers:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# is-type level-2-only
```

Related Commands

Command	Description
circuit-type, on page 19	Configures the type of adjacency.
show isis neighbors, on page 194	Displays information about IS-IS neighbors.

link-down fast-detect

To enable fast detection of link down events under ISIS, use the **link-down fast-detect** command in ISIS interface configuration mode.

link-down fast-detect

Syntax Description

This command has no arguments or keywords.

Command Default Fast detect is not enabled.

Command Modes ISIS interface configuration.

Command History

Release	Modification
Release 3.9.1	This command was introduced.

Example

The following example shows how to enable fast detection of link down events under ISIS:

```
RP/0/RP0/CPU0:router(config)# router isis isp
RP/0/RP0/CPU0:router(config-isis)# interface HundredGigE0/3/0/2
RP/0/RP0/CPU0:router(config-isis-if)# link-down fast-detect
```

link-group

To configure an interface as a member of a link group, use the **link-group** command in the IS-IS interface or address-family configuration mode. To remove an interface from a link-group, use the **no** form of this command.

link-group *link-group-name*
no link-group *link-group-name*

Syntax Description

link-group-name	Name of a link group.

Command Default

No link groups are configured.

Command Modes

IS-IS interface configuration

Address-family configuration

Command History

Release	Modification
Release 4.3.1	This command was introduced.

Usage Guidelines

One IS-IS interface and address-family can specify only one link-group association. The default is for both levels regardless of current circuit-type. The link-group association can be specified for one level only if configured.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure GigabitEthernet interface 0/3/0/0 as a member of a link group:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet 0/3/0/0
RP/0/RSP0/CPU0:router(config-isis-if)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-if-af)# link-group purple
```

log adjacency changes (IS-IS)

To cause an IS-IS instance to generate a log message when an Intermediate System-to-Intermediate System (IS-IS) adjacency changes state (up or down), use the **log adjacency changes** command in router configuration mode. To restore the default value, use the **no** form of this command.

log adjacency changes
no log adjacency changes

Command Default

No IS-IS instance log messages are generated.

Command Modes

Router configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

Use the **log adjacency changes** command to monitor IS-IS adjacency state changes; it may be very useful when you are monitoring large networks. Messages are logged using the system error message facility. Messages can be in either of two forms:

```
%ISIS-4-ADJCHANGE: Adjacency to 0001.0000.0008 (Gi 0/2/1/0) (L2) Up, new adjacency
%ISIS-4-ADJCHANGE: Adjacency to router-gsr8 (Gi /2/1/0) (L1) Down, Holdtime expired
```

Using the **no** form of the command removes the specified command from the configuration file and restores the system to its default condition with respect to the command.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure the router to log adjacency changes:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# log adjacency changes
```

Related Commands

Command	Description
logging	Logs messages to a syslog server host.

log pdu drops

To log Intermediate System-to-Intermediate System (IS-IS) protocol data units (PDUs) that are dropped, use the **log pdu drops** command in router configuration mode. To disable this function, use the **no** form of this command.

log pdu drops
no log pdu drops

Command Default

PDU logging is disabled.

Command Modes

Router configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **log pdu drops** command to monitor a network when IS-IS PDUs are suspected of being dropped. The reason for the PDU being dropped and current PDU drop statistics are recorded.

The following are examples of PDU logging output:

```
%ISIS-4-ERR_LSP_INPUT_Q_OVERFLOW - An incoming LSP or SNP pdu was dropped because the input
 queue was full
%ISIS-3-ERR_SEND_PAK - The process encountered a software-error while sending the IS-IS
packet
```

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to enable PDU logging:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# log pdu drops
```

lsp fast-flood threshold

To configure the link-state packet (LSP) fast-flood threshold, use the **lsp fast-flood threshold** command in interface configuration mode. To restore the default value, use the **no** form of this command.

lsp fast-flood threshold *lsp-number* [**level** {**1** | **2**}]
no lsp fast-flood threshold [*lsp-number*] [**level** {**1** | **2**}]

Syntax Description

lsp-number	Number of LSPs to send back to back. Range is 1 to 4294967295.
level { **1** | **2** }	(Optional) Specifies the LSP threshold for Level 1 or Level 2 independently.

Command Default

10 LSPs are allowed in a back-to-back window

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **lsp fast-flood threshold** command to accelerate convergence of LSP database. LSPs are sent back-to-back over an interface up to the specified limit. Past the limit, LSPs are sent out in the next batch window as determined by LSP pacing interval.

Duration of back-to-back window = LSP interval * LSP fast-flood threshold limit.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure the LSP threshold:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet 0/3/0/0
RP/0/RSP0/CPU0:router(config-isis-if)# lsp fast-flood threshold 234 level 1
```

Related Commands

Command	Description
lsp-interval, on page 81	Configures the amount of time between consecutive LSPs sent on an IS-IS interface.

lsp-fast-flooding

To enable the fast flooding of Link State Packets (LSPs) to improve network response to topology changes, use the **lsp-fast-flooding** command in IS-IS router configuration mode.

lsp-fast-flooding [**max-lsp-tx** *lsps-per-sec* | **remote-psnp-delay** *milliseconds*\

Syntax Description

max-lsp-tx *lsps-per-sec*	(Optional) Sets the maximum number of LSPs that can be transmitted per second. The default is 1000. The range is from 33 through 5000
remote-psnp-delay *milliseconds*	(Optional) Specifies the maximum delay, in milliseconds, that the router should wait for a PSNP acknowledgment from neighbors after sending an LSP. The default is 500 ms. The range is from 1 through 5000 ms.

Command Default

This command is disabled by default. IS-IS fast flooding of LSPs is not enabled.

Command Modes

Router configuration

Command History

Release	Modification
Release 24.3.1	This command was introduced.

Usage Guidelines

None.

Task ID

Task ID	Operation
isis	read, write

Example

This example shows how to enable IS-IS fast flooding of LSPs.

```
Router# configure terminal
Router(config)# router isis 1
Router(config-router)# lsp-fast-flooding
```

This example shows how to set the maximum LSP transmission rate to 600 LSPs per second.

```
Router# configure terminal
Router(config)# router isis 1
Router(config-router)# lsp-fast-flooding
Router(config-isis-lsp-fast-flooding)# max-lsp-tx 600
```

This example shows how to set the PSNP acknowledgment delay to 600 milliseconds.

```
Router# configure terminal
Router(config)# router isis 1
Router(config-router)# lsp-fast-flooding
Router(config-isis-lsp-fast-flooding)# remote-psnp-delay 600
```

lsp-gen-interval

To customize IS-IS throttling of link-state packet (LSP) generation, use the **lsp-gen-interval** command in router configuration mode. To restore the default value, use the **no** form of this command.

lsp-gen-interval [**initial-wait** *initial*] [**secondary-wait** *secondary*] [**maximum-wait** *maximum*] [**level** {**1** | **2**}]
no lsp-gen-interval [[**initial-wait** *initial*] [**secondary-wait** *secondary*] [**maximum-wait** *maximum*]] [**level** {**1** | **2**}]

Syntax Description

initial-wait *initial*	Specifies the initial LSP generation delay (in milliseconds). Range is 0 to 120000 milliseconds.
secondary-wait *secondary*	Specifies the hold time between the first and second LSP generation (in milliseconds). Range is 1 to 120000 milliseconds.
maximum-wait *maximum*	Specifies the maximum interval (in milliseconds) between two consecutive occurrences of an LSP being generated. Range is 1 to 120000 milliseconds.
level { **1** | **2** }	(Optional) Specifies the LSP time interval for Level 1 or Level 2 independently.

Command Default

initial-wait *initial* : 50 milliseconds

secondary-wait *secondary* : 200 milliseconds

maximum-wait *maximum* : 5000 milliseconds

Command Modes

Router configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

During prolonged periods of network instability, repeated recalculation of LSPs can cause increased CPU load on the local router. Further, the flooding of these recalculated LSPs to the other Intermediate Systems in the network causes increased traffic and can result in other routers having to spend more time running route calculations.

Use the **lsp-gen-interval** command to reduce the rate of LSP generation during periods of instability in the network. This command can help to reduce CPU load on the router and to reduce the number of LSP transmissions to its IS-IS neighbors.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to set the maximum interval between two consecutive occurrences of an LSP to 15 milliseconds and the initial LSP generation delta to 5 milliseconds:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# lsp-gen-interval maximum-wait 15 initial-wait 5
```

Related Commands

Command	Description
retransmit-interval (IS-IS), on page 148	Configures the amount of time between retransmission of each IS-IS LSP on a point-to-point link.

lsp-interval

To configure the amount of time between consecutive link-state packets (LSPs) sent on an Intermediate System-to-Intermediate System (IS-IS) interface, use the **lsp-interval** command in interface configuration mode. To restore the default value, use the **no** form of this command.

lsp-interval *milliseconds* [**level** {**1** | **2**}]
no lsp-interval [*milliseconds*] [**level** {**1** | **2**}]

Syntax Description

milliseconds	Time delay (in milliseconds) between successive LSPs. Range is 1 to 4294967295.
level { **1** | **2** }	(Optional) Configures the LSP time delay for Level 1 or Level 2 independently.

Command Default

milliseconds : 33 milliseconds

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to cause the system to send LSPs every 100 milliseconds (10 packets per second) on Level 1 and Level 2:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet /2/0/1
RP/0/RSP0/CPU0:router(config-isis-if)# lsp-interval 100
```

Related Commands

Command	Description
retransmit-interval (IS-IS), on page 148	Configures the amount of time between retransmission of each IS-IS LSP on a point-to-point link.

lsp-mtu

To set the maximum transmission unit (MTU) size of Intermediate System-to-Intermediate System (IS-IS) link-state packets (LSPs), use the **lsp-mtu** command in router configuration mode. To restore the default, use the **no** form of this command.

lsp-mtu *bytes* [**level** {**1** | **2**}]
no lsp-mtu [*bytes*] [**level** {**1** | **2**}]

Syntax Description

bytes	Maximum packet size in bytes. The number of bytes must be less than or equal to the smallest MTU of any link in the network. Range is 128 to 4352 bytes. **Note** Range is 128 to 8979 bytes from Release 6.6.3 onwards.
level { **1** | **2** }	(Optional) Specifies routing Level 1 or Level 2 independently.

Command Default

Both Level 1 and Level 2 are configured if no level is specified.

Command Modes

Router configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.1	The maximum packet size is increased to 8979.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Under normal conditions, the default MTU size should be sufficient. However, if the MTU size of a link is less than 1500 bytes, the LSP MTU size must be lowered accordingly on each router in the network. If this action is not taken, routing becomes unpredictable.

This guideline applies to all Cisco networking devices in a network. If any link in the network has a reduced MTU size, all devices must be changed, not just the devices directly connected to the link.

Note Do not set the **lsp-mtu** command (network layer) to a value greater than the link MTU size that is set with the **mtu** command (physical layer).

To be certain about a link MTU size, use the show isis interface, on page 181 command to display the value.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to set the MTU size to 1300 bytes:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# lsp-mtu 1300
```

Related Commands

Command	Description
mtu	Adjusts the maximum packet size or MTU size.
show isis interface, on page 181	Displays information about the IS-IS interface.

lsp-password

To configure the link-state packet (LSP) authentication password, use the **lsp-password** command in router configuration mode. To remove the **lsp-password** command from the configuration file and disable link-state packet authentication, use the **no** form of this command.

lsp-password [[**hmac-md5** | **text**] [**clear** | **encrypted**] *password* | **keychain** *keychain-name*] [**level** {**1** | **2**}] [**send-only**] [**snp send-only**]]
no lsp-password [[**hmac-md5** | **text**] [**clear** | **encrypted**] *password* | **keychain** *keychain-name*] [**level** {**1** | **2**}] [**send-only**] [**snp send-only**]]

Syntax Description

hmac-md5	Specifies that the password uses HMAC-MD5 authentication.
text	Specifies that the password uses clear text password authentication.
clear	Specifies that the password be unencrypted.
encrypted	Specifies that the password be encrypted using a two-way algorithm.
password	Authentication password you assign.
keychain	(Optional) Specifies a keychain.
keychain-name	Name of the keychain.
level { **1** | **2** }	(Optional) Specifies the password for Level 1 or Level 2 independently.
send-only	(Optional) Adds passwords to LSP and sequence number protocol (SNP) data units when they are sent. Does not check for authentication in received LSPs or sequence number PDUs (SNPs).
snp send-only	(Optional) Adds passwords to SNP data units when they are sent. Does not check for authentication in received SNPs. This option is available when the **text** keyword is specified.

Command Default

Both Level 1 and Level 2 are configured if no level is specified.

Command Modes

Router configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

When a **text** password is configured, it is exchanged as clear text. Therefore, the **lsp-password** command provides limited security.

When an **HMAC-MD5** password is configured, the password is never sent over the network and is instead used to calculate a cryptographic checksum to ensure the integrity of the exchanged data.

The recommended password configuration is that both incoming and outgoing SNPs be authenticated.

Note To disable SNP password checking, the **snp send-only** keywords must be specified in the **lsp-password** command.

To configure an additional password, use the **lsp-password accept** command.

Specify a key chain to enable key chain authentication between two IS-IS peers. Use the **keychain** *keychain-name* keyword and argument to implement hitless key rollover for authentication.

If you are performing LSP authentication and want to use the Purge Originator Identification feature, then use the **enable-poi** keyword in the **lsp-password** command.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure separate Level 1 and Level 2 LSP and SNP passwords, one with HMAC-MD5 authentication and encryption and one with clear text password authentication and no encryption:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# lsp-password hmac-md5 clear password1 level 1
RP/0/RSP0/CPU0:router(config-isis)# lsp-password text clear password2 level 2
```

Related Commands

Command	Description
lsp-password accept, on page 86	Configures an additional LSP password when one LSP password is already configured for a level.

lsp-password accept

To configure an additional link-state packet (LSP) authentication password, use the **lsp-password accept** command in router configuration mode. To remove the **lsp-password accept** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

lsp-password accept {**clear** | **encrypted**} *password* [**level** {**1** | **2**}]
no lsp-password accept [{**clear** | **encrypted**} *password* [**level** {**1** | **2**}]]

Syntax Description

clear	Specifies that the password be unencrypted.
encrypted	Specifies that the password be encrypted using a two-way algorithm.
password	Authentication password you assign.
level { **1** | **2** }	(Optional) Specifies the password for Level 1 or Level 2 independently.

Command Default

Both Level 1 and Level 2 are configured if no level is specified.

Command Modes

Router configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **lsp-password accept** command adds an additional password for use when the system validates incoming LSPs and sequence number PDUs (SNPs). An LSP password must be configured using the **lsp-password** command before an accept password can be configured for the corresponding level.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure an Level 1 LSP and SNP password:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# lsp-password accept encrypted password1 level 1
```

Related Commands

Command	Description
lsp-password, on page 84	Configures an authentication LSP password.

lsp-refresh-interval

To set the time between regeneration of link-state packets (LSPs) that contain different sequence numbers, use the **lsp-refresh-interval** command in router configuration mode. To restore the default refresh interval, use the **no** form of this command.

lsp-refresh-interval *seconds* [**level** {**1** | **2**}]
no lsp-refresh-interval [*seconds* [**level** {**1** | **2**}]]

Syntax Description

seconds	Refresh interval (in seconds). Range is 1 to 65535 seconds.
level { **1** | **2** }	(Optional) Specifies routing Level 1 or Level 2 independently.

Command Default

seconds : 900 seconds (15 minutes)

Both Level 1 and Level 2 are configured if no level is specified.

Command Modes

Router configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The refresh interval determines the rate at which the software periodically sends the route topology information that it originates. This behavior is done to keep the information from becoming too old. By default, the refresh interval is 900 seconds (15 minutes).

LSPs must be refreshed periodically before their lifetimes expire. The refresh interval must be less than the LSP lifetime specified with this router command. Reducing the refresh interval reduces the amount of time that undetected link-state database corruption can persist at the cost of increased link utilization. (This event is extremely unlikely, however, because there are other safeguards against corruption.) Increasing the interval reduces the link utilization caused by the flooding of refreshed packets (although this utilization is very small).

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to change the LSP refresh interval to 10,800 seconds (3 hours):

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# lsp-refresh-interval 10800
```

Related Commands

Command	Description
max-lsp-lifetime, on page 93	Sets the maximum time that LSPs persist without being refreshed.

maximum-paths (IS-IS)

To configure the maximum number of parallel routes that an IP routing protocol will install in the routing table, use the **maximum-paths** command in address family configuration mode. To remove the **maximum-paths** command from the configuration file and restore the system default behavior, use the **no** form of this command. By default up to 8 parallel ECMP paths are used by IS-IS routing protocol.

maximum-paths *maximum*
no maximum-paths

Syntax Description

maximum	Maximum number of parallel routes that IS-IS can install in a routing table. Range is 1 to 64

Command Default



Note The default value used for maximum-paths is 8.

Command Modes

Address family configuration

Command History

Release	Modification
Release 5.3.0	ECMP support extended from 32 to 64 paths.
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to allow a maximum of 16 paths to a destination:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-af)# maximum-paths 16
```

maximum-redistributed-prefixes (IS-IS)

To specify an upper limit on the number of redistributed prefixes (subject to summarization) that the Intermediate System-to-Intermediate System (IS-IS) protocol advertises, use the **maximum-redistributed-prefixes** command in address family mode. To disable this feature, use the **no** form of this command.

maximum-redistributed-prefixes *maximum* [**level** {**1** | **2**}]
no maximum-redistributed-prefixes [*maximum* [**level** {**1** | **2**}]]

Syntax Description

maximum	Maximum number of redistributed prefixes advertised. Range is 1 to 28000.
level { **1** | **2** }	(Optional) Specifies maximum prefixes for Level 1 or Level 2.

Command Default

maximum: 10000

level : 1-2

Command Modes

Address family configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **maximum-redistributed-prefixes** command to prevent a misconfiguration from resulting in redistribution of excess prefixes. If IS-IS encounters more than the maximum number of prefixes, it sets a bi-state alarm. If the number of to-be-redistributed prefixes drops back to the maximum or lower—either through reconfiguration or a change in the redistribution source—IS-IS clears the alarm.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to specify the number of redistributed prefixes at 5000 for Level 2:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-af)# maximum-redistributed-prefixes 5000 level 2
```

maximum-propagated-prefixes (IS-IS)

To configure the maximum number of propagated prefixes, use the **maximum-propagated-prefixes** command in IS-IS configuration mode mode.

maximum-propagated-prefixes *limit* [**warning-only** | **warning-percentage** *percentage*] [**level** *value*]

Syntax Description

maximum-propagated-prefixes *limit*	Configures the maximum number of propagated prefixes.
warning-only	Configures the warning only behavior. The default warning-only threshold is 20,000 prefixes.
warning-percentage *percent*	Configures the warning threshold percentage. The default percentage is 70%
level *value*	Applies the limit to level 1 or level 2 propagation.

Command Default

None

Command Modes

IS-IS configuration

Command History

Release	Modification
Release 26.3.1	This command was introduced.

Usage Guidelines

None

Task ID

Task ID	Operations
isis	read, write

Examples

This example shows how to configure the maximum propagated prefix limit for the level 2 propagation:

```
Router(config)# router isis isp
Router(config-isis)# maximum-propagated-prefixes 8000 level 2
```

This example shows how to set an early warning threshold as a percentage.

```
Router(config)# router isis isp
Router(config-isis)# maximum-propagated-prefixes 8000 warning-percentage 70 level 2
```

This example shows how to configuring a warning-only threshold.

```
Router(config)# router isis isp
Router(config-isis)# maximum-propagated-prefixes 20000 warning-only level 2
```

max-lsp-lifetime

To set the maximum time that link-state packets (LSPs) persist without being refreshed, use the **max-lsp-lifetime** command in router configuration mode. To restore the default time, use the **no** form of this command.

max-lsp-lifetime *seconds* [**level** {**1** | **2**}]
no max-lsp-lifetime [*seconds* [**level** {**1** | **2**}]]

Syntax Description

seconds	Lifetime (in seconds) of the LSP. Range from 1 to 65535 seconds.
level { **1** | **2** }	(Optional) Specifies routing Level 1 or Level 2 independently.

Command Default

seconds : 1200 seconds (20 minutes)

Both Level 1 and Level 2 are configured if no level is specified.

Command Modes

Router configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

You might need to adjust the maximum LSP lifetime if you change the LSP refresh interval with the **lsp-refresh-interval** command. The maximum LSP lifetime must be greater than the LSP refresh interval.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to set the maximum time that the LSP persists to 11,000 seconds (more than 3 hours):

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# max-lsp-lifetime 11000
```

Related Commands

Command	Description
lsp-refresh-interval, on page 88	Sets the LSP refresh interval.

max-lsp-tx

To set the maximum number of Link State Packets (LSPs) that can be transmitted per second in an IS-IS routing process, use the **max-lsp-tx** command in IS-IS router lsp-fast-flooding configuration mode. To remove the configured maximum LSP transmission rate, use the **no** form of this command.

max-lsp-tx *lsps-per-sec*

Syntax Description

lsps-per-sec	The maximum number of LSPs that can be transmitted per second. The default is 1000 ms. The range is from 33 through 5000 ms.

Command Default

The command is disabled by default.

Command Modes

IS-IS router lsp-fast-flooding configuration

Command History

Release	Modification
Release 24.3.1	This command was introduced.

Usage Guidelines

None

Task ID

Task ID	Operation
isis	read, write

Example

This example shows how to set maximum LSP transmission rate to 600 LSPs per second.

```
Router# configure terminal
Router(config)# router isis 1
Router(config-isis)# lsp-fast-flooding
Router(config-isis-lsp-fast-flooding)# max-lsp-tx 600
```

max-metric

To configure the Intermediate System-to-Intermediate System (IS-IS) protocol to set maximum metrics for Network Layer Reachability Information (NLRI) during router overload, use the **max-metric** command in IS-IS configuration mode.

max-metric [**on-startup** *timeout* | *wait-for-bgp*] [**default-route** | **external** | **interlevel** | **srv6-locator** [**level**]

Syntax Description

on-startup	Override the default route metric value with the maximum metric value.
timeout	(Optional) Time in seconds to advertise the maximum metric after a reboot.
wait-for-bgp	(Optional) Sets the maximum metric on startup until BGP signal convergence or timeout.
default-route	Overrides the default route metric values with maximum metric value.
external	Overrides the metric of prefixes learned from another protocol with the maximum metric value.
interlevel	Overrides the metric of prefixes learned from another ISIS level with the maximum metric value.
srv6-locator	Overrides the Segment Routing IPv6 metric value with maximum metric value.
level	Sets the maximum metric value for one level only.

Command Default

Maximum metric is disabled.

Command Modes

IS-IS configuration

Command History

Release	Modification
7.0.2	This command was introduced.

Usage Guidelines

The router ignores the **max-metric on-startup** command and keyword combination when the IS-IS process restarts after configuring the **nsf** command, either with **cisco** or **ietf** keyword. This makes the IS-IS Max Metric feature compatible with the hitless switchover and process restart.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to enable maximum metric on a router:

```
Router(config)# router isis 1
Router(config-isis)# max-metric on-startup wait-for-bgp default-route external interlevel
```

```
srv6-locator level 2
Router(config-isis)# exit
```

metric fallback anomaly

To configure the metric when a delay or loss anomaly occurs for an Intermediate System-to-Intermediate System (IS-IS) interface, use the **metric fallback anomaly** command in address family or interface address family configuration mode.

metric fallback anomaly { [**delay** | **loss**] [**te-metric**] { **increment** *penalty_value* | **multiplier** *penalty_multiplier* | **maximum** } } [**level** { **1** | **2** }]

Syntax Description

maximum	Specifies maximum wide metric. All routers exclude this link from their shortest path first (SPF).
delay	Increases the link metric only when a delay anomaly occurs.
loss	Increases the link metric only when a loss anomaly occurs.
te-metric	Modifies the TE metric.
increment *penalty_value*	Increments the link metric by the specified amount. The range is from 1 to 16777213.
multiplier *penalty_multiplier*	Multiplies the link metric by the specified amount. The range is from 2 to 100000.
level { **1** | **2** }	(Optional) Specifies the SPF calculation for Level 1 or Level 2 independently.

Command Default

Level 1 and Level 2 are configured if no level is specified.

Command Modes

Address family configuration

Interface address family configuration

Command History

Release	Modification
Release 25.1.1	The **loss** keyword was introduced.
Release 7.4.1	This command was introduced.

Usage Guidelines

Specifying the **level** keyword resets the metric only for the specified level. We highly recommend that you configure metrics on all interfaces.

Use the **fallback anomaly** options to increase the metric when you configure link delay anomaly detection in Segment Routing Performance Measurement (SR-PM).

When you configure link delay anomaly detection, SR-PM sends an anomaly bit (A-bit) when the upper bound of the anomaly threshold is exceeded. When an anomaly is received for an interface, IS-IS can increase the IGP metric or TE metric to make the link less attractive for traffic.

From Release 25.1.1, you can configure link loss anomaly detection so that SR-PM sends an anomaly bit (A-bit) when the upper bound of the anomaly threshold is exceeded. When an anomaly is received for an interface, IS-IS can increase the IGP metric or TE metric to make the link less attractive for traffic.

You can specify how to increase the metric in the following ways:

- As a factor by which the base metric is multiplied
- As an increment that is added to the base metric
- As the maximum value. All routers will exclude this link from their SPF.

Task ID

Task ID	Operations
isis	read, write

Examples

In the following example, the base IGP metric value is 10. This example shows how to increase the IGP metrics for an interface. The IGP metric will be increased by 50. When an anomalous bit notification comes for interface HundredGigE 0/1/0/0, the value advertised in the TLVs will be IGP metric 60.

```
Router(config)# router isis 1
Router(config-isis)# interface HundredGigE 0/1/0/0
Router(config-isis-if)# address-family ipv4 unicast
Router(config-isis-if-af)# metric fallback anomaly delay increment 50
```

From Release 25.1.1, you can configure link loss anomaly detection. This example displays how to increase the IGP metrics for an interface.

Consider that the base IGP metric value is 10. You can configure the IGP metric to increase by 500, so that if an anomalous bit notification occurs for interface HundredGigE 0/1/0/0 due to packet loss, the value advertised in the TLVs will be IGP metric 510.

```
Router(config)# router isis 1
Router(config-isis)# interface HundredGigE 0/1/0/0
Router(config-isis-if)# address-family ipv4 unicast
Router(config-isis-if-af)# metric fallback anomaly loss increment 500
```

mesh-group (IS-IS)

To optimize link-state packet (LSP) flooding in highly meshed networks, use the **mesh-group** command in interface configuration mode. To remove a subinterface from a mesh group, use the **no** form of this command.

mesh-group {*number* | **blocked**}
no mesh-group

Syntax Description

number	Number identifying the mesh group of which this interface is a member. Range is 1 to 4294967295.
blocked	Specifies that no LSP flooding takes place on this interface.

Command Default

There is no mesh group configuration (normal LSP flooding).

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

LSPs first received on subinterfaces that are not part of a mesh group are flooded to all other subinterfaces in the usual way.

LSPs first received on subinterfaces that are part of a mesh group are flooded to all interfaces except those in the same mesh group. If the **blocked** keyword is configured on a subinterface, then a newly received LSP is not flooded out over that interface.

To minimize the possibility of incomplete flooding, you should allow unrestricted flooding over at least a minimal set of links in the mesh. Selecting the smallest set of logical links that covers all physical paths results in very low flooding, but less robustness. Ideally you should select only enough links to ensure that LSP flooding is not detrimental to scaling performance, but enough links to ensure that under most failure scenarios, no router is logically disconnected from the rest of the network. In other words, blocking flooding on all links permits the best scaling performance, but there is no flooding. Permitting flooding on all links results in very poor scaling performance.



Note See RFC 2973 for details about the mesh group specification.

Task ID

Task ID	Operations
isis	read, write

Examples

In the following example, six interfaces are configured in three mesh groups. LSPs received are handled as follows:

- LSPs first received by GigabitEthernet interface 0/1/0/0 are flooded to all interfaces except GigabitEthernet 0/1/0/1 (which is part of the same mesh group) and GigabitEthernet 0/3/0/0 (which is blocked).
- LSPs first received by GigabitEthernet 0/2/0/1 are flooded to all interfaces except GigabitEthernet 0/2/0/0 (which is part of the same mesh group) and GigabitEthernet 0/3/0/0 (which is blocked).
- LSPs first received by GigabitEthernet 0/3/0/0 are not ignored, but flooded as usual to all interfaces.
- LSPs received first through GigabitEthernet 0/3/0/1 are flooded to all interfaces, except GigabitEthernet 0/3/0/0 (which is blocked).

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet 0/1/0/0
RP/0/RSP0/CPU0:router(config-isis-if)# mesh-group 10
RP/0/RSP0/CPU0:router(config-isis-if)# exit
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet 0/1/0/1
RP/0/RSP0/CPU0:router(config-isis-if)# mesh-group 10
RP/0/RSP0/CPU0:router(config-isis-if)# exit
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet 0/2/0/0
RP/0/RSP0/CPU0:router(config-isis-if)# mesh-group 11
RP/0/RSP0/CPU0:router(config-isis-if)# exit
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet 0/2/0/1
RP/0/RSP0/CPU0:router(config-isis-if)# mesh-group 11
RP/0/RSP0/CPU0:router(config-isis-if)# exit
RP/0/RSP0/CPU0:routerconfig-isis)# interface GigabitEthernet 0/3/0/1
RP/0/RSP0/CPU0:router(config-isis-if)# mesh-group 12
RP/0/RSP0/CPU0:router(config-isis-if)# exit
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet 0/3/0/0
RP/0/RSP0/CPU0:router(config-isis-if)# mesh-group blocked
```

metric (IS-IS)

To configure the metric for an Intermediate System-to-Intermediate System (IS-IS) interface, use the **metric** command in address family or interface address family configuration mode. To restore the default metric value, use the **no** form of this command.

metric { *default-metric* | **maximum** | **fallback anomaly** [**delay**] [**te-metric**] { **increment** *penalty_value* | **multiplier** *penalty_multiplier* | **maximum** } } [**level** { **1** | **2** }]

Syntax Description

default-metric	Metric assigned to the link and used to calculate the cost from each other router using the links in the network to other destinations. Range is 1 to 63 for narrow metric and 1 to 16777214 for wide metric. **Note** Setting the default metric under address family results in setting the same metric for all interfaces that is associated with the address family. Setting a metric value under an interface overrides the default metric
maximum	Specifies maximum wide metric. All routers exclude this link from their shortest path first (SPF).
fallback	Increases the link metric when an event occurs.
anomaly	Increases the link metric when a delay or loss anomaly occurs.
delay	Increases the link metric only when a delay anomaly occurs.
te-metric	Modifies the TE metric.
increment <penalty_value>	Increments the link metric by the specified amount. The range is from 1 to 16777213.
multiplier <penalty_multiplier>	Multiplies the link metric by the specified amount. The range is from 2 to 100000.
level { **1** | **2** }	(Optional) Specifies the SPF calculation for Level 1 or Level 2 independently.

Command Default

default-metric : Default is 10.

Both Level 1 and Level 2 are configured if no level is specified.

Command Modes

Address family configuration

Interface address family configuration

Command History

Release	Modification
Release 7.4.1	The **fallback anomaly** keywords was introduced.
Release 3.7.2	This command was introduced.

Usage Guidelines

Specifying the **level** keyword resets the metric only for the specified level. We highly recommend that you configure metrics on all interfaces.

Set the default metric under address family to set the same metric for all interfaces that is associated with the address family. Set a metric value under an interface to override the default metric.

We highly recommend that you configure metrics on all interfaces.

Metrics of more than 63 cannot be used with narrow metric style.

Use the **fallback anomaly** options to increase the metric when you configure link delay anomaly detection in Segment Routing Performance Measurement (SR-PM).

When you configure link delay anomaly detection, SR-PM sends an anomaly bit (A-bit) when the upper bound of the anomaly threshold is exceeded. When an anomaly is received for an interface, IS-IS can increase the IGP metric or TE metric to make the link less attractive for traffic.

You can specify how to increase the metric in the following ways:

- As a factor by which the base metric is multiplied
- As an increment that is added to the base metric
- As the maximum value. All routers will exclude this link from their SPF.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure Packet-over-SONET/SDH 0/1/0/1 interface with a default link-state metric cost of 15 for Level 1:

```
Router(config)# router isis isp
Router(config-isis)# interface GigabitEthernet /1/0/1
Router(config-isis-if)# address-family ipv4 unicast
Router(config-isis-if-af)# metric 15 level 1
```

The following example shows how to configure a metric cost of 15 for all interfaces under address family IPv4 unicast for level 2:

```
Router# configure
Router(config)# router isis isp
Router(config-isis)# address-family ipv4 unicast
Router(config-isis-af)# metric 15 level 2
```

In the following example, the base IGP metric value is 10. This example shows how to increase the IGP metrics for an interface. The IGP metric will be increased by 50. When an anomalous bit notification comes for interface HundredGigE 0/1/0/0, the value advertised in the TLVs will be IGP metric 60.

```
Router(config)# router isis 1
Router(config-isis)# interface HundredGigE 0/1/0/0
```

```
Router(config-isis-if)# address-family ipv4 unicast
Router(config-isis-if-af)# metric fallback anomaly delay increment 50
```

Related Commands

Command	Description
metric-style narrow, on page 104	Configures a router running IS-IS so that it generates and accepts old-style TLV objects.
metric-style transition, on page 106	Configures the software to generate and accept both old-style and new-style TLV objects.
metric-style wide, on page 108	Configures the software to generate and accept only new-style TLV objects objects.

metric-style narrow

To configure the Intermediate System-to-Intermediate System (IS-IS) software to generate and accept old-style type, length, and value (TLV) objects, use the **metric-style narrow** command in address family configuration mode. To remove the **metric-style narrow** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

metric-style narrow [**transition**] [**level** {**1** | **2**}]
no metric-style narrow [**transition**] [**level** {**1** | **2**}]

Syntax Description

transition	(Optional) Instructs the router to generate and accept both old-style and new-style TLV objects. It generates only old-style TLV objects.
level { **1** | **2** }	(Optional) Specifies routing Level 1 or Level 2 independently.

Command Default

Old-style TLVs are generated.

Both Level 1 and Level 2 are configured if no level is specified.

Command Modes

Address family configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

IS-IS traffic engineering extensions include new-style TLV objects with wider metric fields than old-style TLV objects. By default, the router generates old-style TLV objects only. To perform Multiprotocol Label Switching traffic engineering (MPLS TE), a router must generate new-style TLV objects.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure the router to generate and accept only old-style TLV objects on router Level 1:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-af)# metric-style narrow level 1
```

Related Commands

Command	Description
metric-style transition, on page 106	Configures a router to generate and accept both old-style and new-style TLV objects.
metric-style wide, on page 108	Configures a router to generate and accept only new-style TLV objects.

metric-style transition

To configure the Intermediate System-to-Intermediate System (IS-IS) software to generate and accept both old-style and new-style type, length, and value (TLV) objects, use the **metric-style transition** command in address family configuration mode. To remove the **metric-style transition** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

metric-style transition [**level** {**1** | **2**}]
no metric-style transition [**level** {**1** | **2**}]

Syntax Description

transition	Instructs the router to generate and accept both old-style and new-style TLV objects.
level { **1** | **2** }	(Optional) Specifies routing Level 1 or Level 2 independently.

Command Default

Old-style TLVs are generated, if this command is not configured.

Both Level 1 and Level 2 are configured if no level is specified.

Command Modes

Address family configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

IS-IS traffic engineering extensions include new-style TLV objects which have wider metric fields than old-style TLV objects. By default, the router generates old-style TLV objects only. To perform Multiprotocol Label Switching traffic engineering (MPLS TE), a router needs to generate new-style TLV objects.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure the router to generate and accept both old-style and new-style TLV objects on Level 2:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-af)# metric-style transition level 2
```

Related Commands

Command	Description
metric-style narrow, on page 104	Configures a router to generate and accept only old-style TLV objects.
metric-style wide, on page 108	Configures a router to generate and accept only new-style TLV objects.

metric-style wide

To configure the Intermediate System-to-Intermediate System (IS-IS) software to generate and accept only new-style type, length, and value (TLV) objects, use the **metric-style wide** command in address family configuration mode. To remove the **metric-style wide** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

metric-style wide [**transition**] [**level** {**1** | **2**}]
no metric-style wide [**transition**] [**level** {**1** | **2**}]

Syntax Description

transition	(Optional) Instructs the router to generate and accept both old-style and new-style TLV objects. It generates only new-style TLV objects.
level { **1** | **2** }	(Optional) Specifies routing Level 1 or Level 2 independently.

Command Default

Old-style TLV lengths are generated, if this command is not configured.

Both Level 1 and Level 2 are configured if no level is specified.

Command Modes

Address family configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

IS-IS traffic engineering extensions include new-style TLV objects with wider metric fields than old-style TLV objects. If you enter the **metric-style wide** command, a router generates and accepts only new-style TLV objects. Therefore, the router uses less memory and fewer other resources rather than generating both old-style and new-style TLV objects.

To perform MPLS traffic engineering, a router needs to generate new-style TLV objects.



Note This discussion of metric styles and transition strategies is oriented toward traffic engineering deployment. Other commands and models might be appropriate if the new-style TLV objects are desired for other reasons. For example, a network may require wider metrics, but might not use traffic engineering.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure a router to generate and accept only new-style TLV objects on Level 1:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-af)# metric-style wide level 1
```

Related Commands

Command	Description
metric-style narrow, on page 104	Configures a router to generate and accept only old-style TLV objects.

microloop avoidance (IS-IS)

To avoid micro-loops by delaying the convergence of all or protected prefixes, use the **microloop avoidance** command. Valid triggers for microloop avoidance feature are local link-down events only, such as link down, BFD down, and IS-IS adjacency down. Microloops caused by other triggers are not avoided by this feature. Consider `microloop avoidance segment-routing` command for extended trigger coverage.

To disable this function, use the **no** prefix for this command.

microloop avoidance [**protected** | **rib-update-delay** *delay*]
no microloop avoidance

Syntax Description

(none)	Delays convergence of all prefixes.
protected	(Optional) Delays convergence of protected prefixes.
rib-update-delay *delay*	(Optional) Delays convergence of all prefixes and updates RIB after the configured delay. The range is 1 to 60000 milliseconds. The default is 5000ms (for both the flavours of uloop avoidance).

Command Default

Micro-loop avoidance is disabled by default.

Command Modes

router isis configuration

Command History

Release	Modification
Release 4.3.1	This command was introduced.

Usage Guidelines

When the network converges after a link failure restoration, micro-loops can form due to inconsistencies in the forwarding tables of different routers. By delaying the convergence of prefixes, you can avoid the formation of micro-loops.

You can delay the convergence of all or protected prefixes by using the **microloop avoidance** command. When configured, the command applies to all prefixes by default. To enable it for only protected prefixes, use the **protected** option.

If another event occurs when the microloop avoidance timer is running, the microloop avoidance process is cancelled, and RIB delay timer is cancelled and prefixes are sent to RIB immediately.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure micro-loop avoidance with IS-IS:

```
Router# configure
```

```
Router(config)# router isis 50
Router(config-isis)# microloop avoidance rib-update-delay 400
```

min-lsp-arrivaltime

To control the rate of incoming LSPs (link-state packets) LSPs, use the **min-lsp-arrivaltime** command in router configuration mode. To remove this function use the **no** form of this command.

min-lsp-arrivaltime [**initial-wait initial**] [**secondary-wait secondary**] [**maximum-wait maximum**] [**level** {**1** | **2**}]
no min-lsp-arrivaltime [**initial-wait initial**] [**secondary-wait secondary**] [**maximum-wait maximum**] [**level** {**1** | **2**}]

Syntax Description

initial-wait initial	Initial LSP calculation delay (in milliseconds). Range is 0 to 120000.
secondary-wait *secondary*	Hold time between the first and second LSP calculations (in milliseconds). Range is 0 to 120000.
maximum-wait *maximum*	Maximum interval (in milliseconds) between two consecutive LSP calculations. Range is 0 to 120000.
level { **1** | **2** }	(Optional) Enables the LSP interval configuration for Level 1 or Level 2 independently.

Command Default

Both Level 1 and Level 2 are configured if no level is specified.

Command Modes

Router configuration mode

Command History

Release	Modification
Release 3.9.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

This command can be used to protect a router against the possible instability of its neighbor's LSPs.

The command parameters are similair to **lsp-gen-interval**command and neighbors lsp-gen-interval values can be used to set the **min-lsp-arrivaltime**

Note The initial-wait of minimum-lsp-arrival has no use in computing maximum counts and maximum window sizes of the LSP arrival time parameter.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure min-lsp-arrival time commands:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config)# router isis isp min-lsp-arrivaltime
RP/0/RSP0/CPU0:router(config)# router isis 1 min-  lsp-arrivaltime initial-wait
RP/0/RSP0/CPU0:router(config)#router isis 1 min-lsp-arrivaltime maximum-wait
RP/0/RSP0/CPU0:router(config)#router isis 1 min-lsp-arrivaltime secondary-wait
```

mpls ldp auto-config

To enable Label Distribution Protocol (LDP) Interior Gateway Protocol (IGP) interface auto-configuration, use the **mpls ldp auto-config** command in IPv4 address family configuration mode. To disable LDP IGP auto-configuration, use the **no** form of this command.

mpls ldp auto-config
no mpls ldp auto-config

Syntax Description

This command has no keywords or arguments.

Command Default

LDP IGP auto-configuration is disabled.

Command Modes

IPv4 address family configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **mpls ldp auto-config** command to automatically configure LDP on a set of interfaces associated with a specified IGP instance. Further, LDP IGP auto-configuration provides a means to block LDP from being enabled on a specified interface. If you do not want an IS-IS interface to have LDP enabled, use the **igp auto-config disable** command.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to enable LDP IGP auto-configuration:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-af)# mpls ldp auto-config
```

Related Commands

Command	Description
igp auto-config disable	Disables LDP IGP auto-configuration for a specific interface.

mpls ldp sync (IS-IS)

To configure Label Distribution Protocol (LDP) IS-IS synchronization, use the **mpls ldp sync** command in interface address family configuration mode. To disable LDP synchronization, use the **no** form of this command.

mpls ldp sync [**level** {**1** | **2**}]
no mpls ldp sync [**level** {**1** | **2**}]

Syntax Description

level { **1 | 2** }	(Optional) Sets LDP synchronization for the specified level.

Command Default

If a level is not specified, LDP synchronization is set for both levels.

Command Modes

Interface address family configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

MPLS VPN traffic forwarded using LDP labels can be dropped in the following instances:

- A new link is introduced in the network and IS-IS has converged before LDP establishes labels.
- An existing LDP session goes down while IS-IS adjacency is intact over the link.

In both instances, outbound LDP labels are not available for forwarding MPLS traffic. LDP IS-IS synchronization addresses the traffic drop. When the **mpls ldp sync** command is configured, IS-IS advertises the maximum possible link metric until LDP has converged over the link. The link is less preferred and least used in forwarding MPLS traffic. When LDP establishes the session and exchanges labels, IS-IS advertises the regular metric over the link.



Note IS-IS advertises the maximum metric –1 (16777214) if wide metrics are configured since the maximum wide metric is specifically used for link exclusion from the shortest path first algorithm (SPF) (RFC 3784). However, the maximum narrow metric is unaffected by this definition.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to enable LDP IS-IS synchronization:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet 0/3/0/0
RP/0/RSP0/CPU0:router(config-isis-if)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-if-af)# mpls ldp sync
```

Related Commands

Command	Description
show isis interface, on page 181	Displays information about the IS-IS interfaces

mpls traffic-eng (IS-IS)

To configure a router running the Intermediate System-to-Intermediate System (IS-IS) protocol to flood Multiprotocol Label Switching traffic engineering (MPLS TE) link information into the indicated IS-IS level, use the **mpls traffic-eng** command in IPv4 address family configuration mode. To disable this feature, use the **no** form of this command.

mpls traffic-eng {**level-1** | **level-1-2** | **level-2-only**}
no mpls traffic-eng [**level-1** | **level-1-2** | **level-2-only**]

Syntax Description

level-1	Specifies routing level 1.
level-1-2	Specifies routing levels 1 and 2.
level-2-only	Specifies routing level 2.

Command Default

Flooding is disabled.

Command Modes

IPv4 address family configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **mpls traffic-eng** command, which is part of the routing protocol tree, to flood link resource information (such as available bandwidth) for appropriately configured links in the link-state packet (LSP) of the router.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to turn on MPLS traffic engineering for IS-IS level 1:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-af)# mpls  traffic-eng level-1
```

Related Commands

Command	Description
mpls traffic-eng router-id (IS-IS), on page 122	Specifies that the traffic engineering router identifier for the node is the IP address associated with a given interface.

mpls traffic-eng multicast-intact (IS-IS)

To enable multicast-intact for Intermediate System-to-Intermediate System (IS-IS) routes with Protocol-Independent Multicast (PIM) and Multiprotocol Label Switching (MPLS) traffic engineering, use the **mpls traffic-eng multicast-intact** command in IPv4 address family configuration mode. To disable this feature, use the **no** form of this command.

mpls traffic-eng multicast-intact
no mpls traffic-eng [**multicast-intact**]

Syntax Description

This command has no keywords or arguments.

Command Default

Multicast-intact is disabled.

Command Modes

IPv4 address family configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If Multiprotocol Label Switching Traffic Engineering (MPLS-TE) is configured through the IS-IS routing domain and multicast protocols (like Protocol Independent Multicast [PIM]) are also enabled, then use the **mpls traffic-end multicast-intact** command to install nontraffic engineering next hops in the Routing Information Base (RIB) for use by multicast. The installation of IP-only next hops is in addition to the installation of the standard set of paths for a prefix, which might be through traffic engineered tunnels.

The **mpls traffic-eng multicast-intact** command allows PIM to use the native hop-by-hop neighbors even though the unicast routing is using MPLS TE tunnels.

Examples

The following example shows how to enable the multicast-intact feature:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-af)# mpls  traffic-engmulticast-intact
```

Related Commands

Command	Description
show isis route, on page 200	Displays IP reachability information for an IS-IS instance, optionally for multicast-intact.
show isis topology, on page 214	Displays a list of connected IS-IS routers in all areas, optionally for multicast-intact.

mpls traffic-eng path-selection ignore overload

To ensure that label switched paths (LSPs) are not disabled when routers have the Intermediate System-to-Intermediate System (IS-IS) overload bit set, use the **mpls traffic-eng path-selection ignore overload** command in global configuration mode. To disable this override, use the **no** form of this command.

mpls traffic-eng path-selection ignore overload
no mpls traffic-eng path-selection ignore overload

Command Default

No default behavior or values

Command Modes

Global configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

When the IS-IS overload bit avoidance feature is activated, which means that they are still available for use label switched paths (LSPs), all nodes with the overload bit set, including the following nodes, are ignored:

- head nodes
- mid nodes
- tail nodes

Task ID

Task ID	Operations
mpls-te	read, write

Examples

The following example shows how to activate IS-IS overload bit avoidance:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# mpls traffic-eng path-selection ignore overload
```

The following example shows how to deactivate IS-IS overload bit avoidance:

```
RP/0/RSP0/CPU0:router# configure
RP/0/RSP0/CPU0:router(config)# no mpls traffic-eng path-selection ignore overload
```

Related Commands

Command	Description
set-overload-bit, on page 157	Configures a router to signal other routers not to use it as an intermediate hop in their shortest path first (SPF) calculations.

mpls traffic-eng router-id (IS-IS)

To specify the Multiprotocol Label Switching traffic engineering (MPLS TE) router identifier for the node, use the **mpls traffic-eng router-id** command in IPv4 address family configuration mode. To disable this feature, use the **no** form of this command.

mpls traffic-eng router-id {*ip-address* | *type* *interface-path-id*}
no mpls traffic-eng [**router-id**]

Syntax Description

ip-address	IP address in four-part, dotted-decimal notation.
type	Interface type. For more information, use the question mark (?) online help function.
interface-path-id	Physical interface or virtual interface. **Note** Use the **show interfaces** command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.

Command Default

Global router identifier is used.

Command Modes

IPv4 address family configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The identifier of the router acts as a stable IP address for the traffic engineering configuration. This IP address is flooded to all nodes. For all traffic engineering tunnels originating at other nodes and ending at this node, you must set the tunnel destination to the traffic engineering router ID of the destination node, because that is the address used by the traffic engineering topology database at the tunnel head for its path calculation.

Note We recommend that loopback interfaces be used for MPLS TE, because they are more stable than physical interfaces.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to specify the traffic engineering router identifier as the IP address associated with loopback interface 0:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-af)# mpls traffic-eng router-id Loopback0
```

Related Commands

Command	Description
mpls traffic-eng (IS-IS), on page 117	Turns on flooding of MPLS traffic engineering link information in the indicated IGP level or area.

net

To configure an Intermediate System-to-Intermediate System (IS-IS) network entity title (NET) for the routing instance, use the **net** command in router configuration mode. To remove the **net** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

net *network-entity-title*
no net *network-entity-title*

Syntax Description

network-entity-title	NET that specifies the area address and the system ID for an ISIS routing process.

Command Default

No NET is configured. The IS-IS instance is not operational, because a NET is mandatory.

Command Modes

Router configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

Under most circumstances, one and only one NET should be configured.

A NET is a network service access point (NSAP) where the last byte is always 0. On a Cisco router running IS-IS, a NET can be 8 to 20 bytes in length. The last byte is always the n-selector and must be 0. The n-selector indicates to which transport entity the packet is sent. An n-selector of 0 indicates no transport entity and means that the packet is for the routing software of the system.

The six bytes directly preceding the n-selector are the system ID. The system ID length is a fixed size and cannot be changed. The system ID must be unique throughout each area (Level 1) and throughout the backbone (Level 2).

All bytes preceding the system ID are the area ID.

A maximum of three NETs for each router is allowed. In rare circumstances, it is possible to configure two or three NETs. In such a case, the area this router is in has three area addresses. Only one area still exists, but it has more area addresses.

Configuring multiple NETs can be temporarily useful in network reconfiguration in which multiple areas are merged, or in which one area is split into more areas. Multiple area addresses enable you to renumber an area individually as needed.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure a router with NET area ID 47.0004.004d.0001 and system ID 0001.0c11.1110:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# net 47.0004.004d.0001.0001.0c11.1110.00
```

Related Commands

Command	Description
log adjacency changes (IS-IS), on page 74	Configures the routing level for an instance of the IS-IS routing process.
router isis, on page 152	Enables the IS-IS routing protocol and specifies an IS-IS instance.

nsf (IS-IS)

To enable nonstop forwarding (NSF) on the next restart, use the **nsf** command in router configuration mode. To restore the default setting, use the **no** form of this command.

nsf {**cisco** | **ietf**}
no nsf {**cisco** | **ietf**}

Syntax Description

cisco	Specifies Cisco-proprietary NSF restart.
ietf	Specifies Internet Engineering Task Force (IETF) NSF restart.

Command Default

NSF is disabled.

Command Modes

Router configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

NSF allows an Intermediate System-to-Intermediate System (IS-IS) instance to restart using checkpointed adjacency and link-state packet (LSP) information, and to perform restart with no impact on its neighbor routers. In other words, there is no impact on other routers in the network due to the destruction and recreation of adjacencies and the system LSP.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to enable Cisco proprietary NSF:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# nsf cisco
```

Related Commands

Command	Description
nsf interface-expires, on page 128	Configures the number of resends of an an acknowledged NSF-restart acknowledgment.

Command	Description
nsf interface-timer, on page 130	Configures the time interval after which an unacknowledged IETF NSF restart attempt is repeated.
nsf lifetime (IS-IS), on page 132	Configures the maximum route lifetime following an NSF restart.

nsf interface-expires

To configure the number of resends of an acknowledged nonstop forwarding (NSF)-restart acknowledgment, use the **nsf interface-expires** command in router configuration mode. To restore the default value, use the **no** form of this command.

nsf interface-expires *number*
no nsf interface-expires

Syntax Description

number	Number of resends. Range is 1 to 3.

Command Default

number : 3 resends

Command Modes

Router configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

When a hello packet sent with the NSF restart flag set is not acknowledged, it is re-sent. Use the **nsf interface-expires** command to control the number of times the NSF hello is re-sent. When this limit is reached on an interface, any neighbor previously known on that interface is assumed to be down and the initial shortest path first (SPF) calculation is permitted, provided that all other necessary conditions are met.

The total time period available for adjacency reestablishment (interface-timer * interface-expires) should be greater than the expected total NSF restart time.

The **nsf interface-expires** command applies only to Internet Engineering Task Force (IETF)-style NSF. It has no effect if Cisco-proprietary NSF is configured.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to allow only one retry attempt on each interface if an IETF NSF restart signal is not acknowledged:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# nsf ietf
RP/0/RSP0/CPU0:router(config-isis)# nsf interface-expires 1
```

Related Commands

Command	Description
hello-multiplier, on page 50	Specifies the number of IS-IS hello packets a neighbor must miss before the router should declare the adjacency as down.
nsf interface-timer, on page 130	Configures the time interval after which an unacknowledged IETF NSF restart attempt is repeated.

nsf interface-timer

To configure the time interval after which an unacknowledged Internet Engineering Task Force (IETF) nonstop forwarding (NSF) restart attempt is repeated, use the **nsf interface-timer** command in router configuration mode. To restore the default value, use the **no** form of this command.

nsf interface-timer *seconds*
no nsf interface-timer

Syntax Description

seconds	NSF restart time interval (in seconds). Range is 3 to 20 seconds.

Command Default

seconds : 10 seconds

Command Modes

Router configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

When the IETF NSF restart process begins, hello packets send an NSF restart flag that must be acknowledged by the neighbors of the router. Use the **nsf interface-timer** command to control the restart time interval after the hello packet is re-sent. The restart time interval need not match the hello interval.

The **nsf interface-timer** command applies only to IETF-style NSF. It has no effect if Cisco proprietary NSF is configured.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to ensure that a hello packet with the NSF restart flag set is sent again every 5 seconds until the flag is acknowledged:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# nsf ietf
RP/0/RSP0/CPU0:router(config-isis)# nsf interface-timer 5
```

Related Commands

Command	Description
nsf interface-expires, on page 128	Configures the number of resends of an acknowledged NSF-restart acknowledgment.
hello-interval (IS-IS), on page 48	Specifies the length of time between hello packets that the software sends.

nsf lifetime (IS-IS)

To configure the maximum route lifetime following a nonstop forwarding (NSF) restart, use the **nsf lifetime** command in router configuration mode. To restore the default value, use the **no** form of this command.

nsf lifetime *seconds*
no nsf lifetime

Syntax Description

seconds	Maximum route lifetime (in seconds) following an NSF restart. Range is 5 to 300 seconds.

Command Default

seconds : 60 seconds (1 minute)

Command Modes

Router configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **nsf lifetime** command to set the maximum available time for the reacquisition of checkpointed adjacencies and link-state packets (LSPs) during a Cisco proprietary NSF restart. LSPs and adjacencies not recovered during this time period are abandoned, thus causing changes to the network topology.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure the router to allow only 20 seconds for the entire NSF process:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# nsf cisco
RP/0/RSP0/CPU0:router(config-isis)# nsf lifetime 20
```

oor-set-overload-bit disable

To prevent the setting of the overload bit during out-of-resource (OOR) conditions, use **oor-set-overload-bit disable** command in router configuration mode. To allow the setting of the overload bit during OOR conditions, use the **no** form of the command.

oor-set-overload-bit disable

no oor-set-overload-bit disable

Syntax Description

This command has no keywords or arguments.

Command Default

The overload bit is set.

Command Modes

Router configuration

Command History

Release	Modification
Release 24.2.1	This command was introduced.

Usage Guidelines

The setting of the overload bit is typically allowed only when a router experiences issues, such as memory shortages, which might result in an incomplete link-state database and inaccurate routing tables. When the overload bit is set in the link-state packets (LSPs) of an unreliable router, other routers can ignore this router in their shortest path first (SPF) calculations until it recovers. Consequently, no paths through the unreliable router are visible to other routers in the IS-IS area, though IP prefixes directly connected to this router remain reachable.

We recommend not disabling the setting of the overload-bit during OOR conditions. IS-IS will continue to forward traffic but will base decisions on an incomplete link-state database, potentially causing routing loops and other forwarding failures.

Task ID

Task ID	Operation
isis	read, write

Example

The following example shows how to disable the overload bit:

```
Router# router isis 1
Router# (config-isis)# oor-set-overload-bit disable
```

passive (IS-IS)

To suppress Intermediate System-to-Intermediate System (IS-IS) packets from being transmitted to the interface and received packets from being processed on the interface, use the **passive** command in interface configuration mode. To restore IS-IS packets coming to an interface, use the **no** form of this command.

passive
no passive

Command Default

Interface is active.

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure the router to suppress IS-IS packets on GigabitEthernet interface 0/1/0/1:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet 0/1/0/1
RP/0/RSP0/CPU0:router(config-isis-if)# passive
```

Related Commands

Command	Description
suppressed, on page 232	Allows the IS-IS interface to participate in forming adjacencies without advertising connected prefixes in the LSPs.

point-to-point

To configure a network of only two networking devices that use broadcast media and the integrated Intermediate System-to-Intermediate System (IS-IS) routing protocol to function as a point-to-point link instead of a broadcast link, use the **point-to-point** command in interface configuration mode. To disable the point-to-point usage, use the **no** form of this command.

point-to-point
no point-to-point

Syntax Description

This command has no keywords or arguments.

Command Default

Interface is treated as broadcast if connected to broadcast media.

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **point-to-point** command only on broadcast media in a network with two networking devices. The command causes the system to issue packets point-to-point rather than as broadcasts. Configure the command on both networking devices in the network.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure a 10-Gb Ethernet interface to act as a point-to-point interface:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# interface TenGigE 0/6/0/0
RP/0/RSP0/CPU0:router(config-isis-if)# point-to-point
```

priority (IS-IS)

To configure the priority of designated routers, use the **priority** command in interface configuration mode. To reset the default priority, use the **no** form of this command.

priority *value* [**level** {**1** | **2**}]
no priority [*value*] [**level** {**1** | **2**}]

Syntax Description

value	Priority of a router. Range is 0 to 127.
level { **1** | **2** }	(Optional) Specifies routing Level 1 or Level 2 independently.

Command Default

value : 64

Both Level 1 and Level 2 are configured if no level is specified.

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Priorities can be configured for Level 1 and Level 2 independently. Specifying Level 1 or Level 2 resets priority only for Level 1 or Level 2 routing, respectively. Specifying no level allows you to configure all levels.

The priority is used to determine which router on a LAN is the designated router or Designated Intermediate System (DIS). The priorities are advertised in the hello packets. The router with the highest priority becomes the DIS.

In the Intermediate System-to-Intermediate System (IS-IS) protocol, there is no backup designated router. Setting the priority to 0 lowers the chance of this system becoming the DIS, but does not prevent it. If a router with a higher priority comes online, it takes over the role from the current DIS. For equal priorities, the higher MAC address breaks the tie.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to give Level 1 routing priority by setting the priority level to 80. This router is now more likely to become the DIS.

```
RP/0/RSP0/CPU0:router(config)# router isis isp
```

```
RP/0/RSP0/CPU0:router(config-isis)# interface TenGigE0/6/0/0
RP/0/RSP0/CPU0:router(config-isis-if)# priority 80 level 1
```

propagate level

To propagate routes from one Intermediate System-to-Intermediate System (IS-IS) level into another level, use the **propagate level** command in address family configuration mode. To disable propagation, use the **no** form of this command.

propagate level {**1** | **2**} **into level** {**1** | **2**} **route-policy** *route-policy-name*
no propagate level {**1** | **2**} **into level** {**1** | **2**}

Syntax Description

level { **1** | **2** }	Propagates from routing Level 1 or Level 2 routes.
into	Propagates from Level 1 or Level 2 routes into Level 1 or Level 2 routes.
route-policy *route-policy-name*	Specifies a configured route policy.

Command Default

Route leaking (Level 2 to Level 1) is disabled.

Command Modes

Address family configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

In general, route propagation from Level 1 to Level 2 is automatic. You might want to use this command to better control which Level 1 routes can be propagated into Level 2.

Propagating Level 2 routes into Level 1 is called *route leaking*. Route leaking is disabled by default. That is, Level 2 routes are not automatically included in Level 1 link-state packets (LSPs). If you want to leak Level 2 routes into Level 1, you must enable that behavior by using this command.

Propagation from Level 1 into Level 1 and from Level 2 into Level 2 is not allowed.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to redistribute Level 2 routes to Level 1:

```
RP/0/RSP0/CPU0:router(config)# ipv4 access-list 101 permit ip 10.0.0.0 255.0.0.0 10.1.0.1
0.255.255.255
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# net 49.1234.2222.2222.2222.00
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-af)# propagate level 2 into level 1 route-policy policy_a
```

Related Commands

Command	Description
redistribute (IS-IS), on page 142	Redistributes routes from one routing domain into a specified IS-IS instance.

protocol shutdown (IS-IS)

To disable an instance of the Intermediate System-to-Intermediate System (IS-IS) protocol, so that it cannot form an adjacency on any interface, use the **protocol shutdown** command in the isis configuration mode. To re-enable the IS-IS protocol, use the **no** form of this command.

protocol shutdown
no protocol shutdown

Command Default

None

Command Modes

isis configuration

Command History

Release	Modification
Release 24.4.1	This command was introduced.

Usage Guidelines

Use the **protocol shutdown** command to disable the IS-IS protocol for a specific routing instance without removing any existing IS-IS configuration parameters.

This command is similar to executing the following sample configuration:

```
router isis 1
 set-overload-bit
 exit
router isis 1
 interface HundredGigE 0/1/0/3
  shutdown
```

Task ID

Task ID	Operations
isis	read, write

Examples

This example shows how to disable the IS-IS.

```
Router# config
Router(config)# router isis 1
Router(config-isis)# protocol shutdown
```

psnp-interval

To configure the interval at which the Intermediate System to Intermediate System (IS-IS) protocol sends Partial Sequence Number PDUs (PSNPs) to acknowledge received Link State PDUs (LSPs), use the **psnp-interval** in router configuration mode.

psnp-interval *milliseconds*

Syntax Description

milliseconds	The interval, specified in milliseconds, at which PSNPs are sent to acknowledge received LSPs. The range is from 1 to 5000 milliseconds. The default value is 50 milliseconds.

Command Default

This command is disabled by default.

Command Modes

Router configuration

Command History

Release	Modification
Release 24.3.1	This command was introduced.

Usage Guidelines

None

Task ID

Task ID	Operation
isis	read, write

Example

This example shows how to configure the PSNP interval to 100 milliseconds for an IS-IS process tagged 1:

```
Router(config)# router isis 1
Router(config-isis)# psnp-interval 100
```

redistribute (IS-IS)

To redistribute routes from one routing protocol into Intermediate System-to-Intermediate System (IS-IS), use the **redistribute** command in address family configuration mode. To remove the **redistribute** command from the configuration file and restore the system to its default condition in which the software does not redistribute routes, use the **no** form of this command.

Border Gateway Protocol (BGP)
redistribute bgp *process-id* [**level-1** | **level-2** | **level-1-2**] [**metric** *metric-value*] [**metric-type** {**internal** | **external**}] [**route-policy** *route-policy-name*]
no redistribute

Connected Routes
redistribute connected [**level-1** | **level-2** | **level-1-2**] [**metric** *metric-value*] [**metric-type** {**internal** | **external**}] [**route-policy** *route-policy-name*]
no redistribute

Intermediate System-to-Intermediate System (IS-IS)
redistribute isis *process-id* [**level-1** | **level-2** | **level-1-2**] [**metric** *metric-value*] [**metric-type** {**internal** | **external**}] [**route-policy** *route-policy-name*] [**down-flag-clear**]
no redistribute

Open Shortest Path First (OSPF)
redistribute ospf *process-id* [**level-1** | **level-2** | **level-1-2**] [**match** {**external** [**1** | **2**] | **internal** | **nssa-external** [**1** | **2**]}] [**metric** *metric-value*] [**metric-type** {**internal** | **external**}] [**route-policy** *route-policy-name*]
no redistribute

Open Shortest Path First Version 3 (OSPFv3)
redistribute ospfv3 *process-id* [**level-1** | **level-2** | **level-1-2**] [**match** {**external** [**1** | **2**] | **internal** | **nssa-external** [**1** | **2**]}] [**metric** *metric-value*] [**metric-type** {**internal** | **external**}] [**route-policy** *route-policy-name*]
no redistribute

Static Routes
redistribute static [**level-1** | **level-2** | **level-1-2**] [**metric** *metric-value*] [**metric-type** {**1** | **2** }] [**route-policy** *route-policy-name*]
no redistribute

Syntax Description

process-id	For the **bgp** keyword, an autonomous system number has the following ranges: • Range for 2-byte Autonomous system numbers (ASNs) is 1 to 65535. • Range for 4-byte Autonomous system numbers (ASNs) in asplain format is 1 to 4294967295. • Range for 4-byte Autonomous system numbers (ASNs) is asdot format is 1.0 to 65535.65535. For the **isis** keyword, an IS-IS instance identifier from which routes are to be redistributed. For the **ospf** keyword, an OSPF process name from which routes are to be redistributed. The value takes the form of a string. A decimal number can be entered, but it is stored internally as a string. For the **ospfv3** keyword, an OSPFv3 process name from which routes are to be redistributed. The value takes the form of a string. A decimal number can be entered, but it is stored internally as a string.
level-1	(Optional) Specifies that redistributed routes are advertised in the Level-1 LSP of the router.
level-1-2	(Optional) Specifies that redistributed routes are advertised in the Level-1-2 LSP of the router.
level-2	(Optional) Specifies that redistributed routes are advertised in the Level-2 LSP of the router.
metric *metric-value*	(Optional) Specifies the metric used for the redistributed route. Range is 0 to 16777215. The *metric-value* must be consistent with the IS-IS metric style of the area and topology into which the routes are being redistributed.
metric-type { **internal** | **external** }	(Optional) Specifies the external link type associated with the route advertised into the ISIS routing domain. It can be one of two values: • external • **internal** –Use the **internal** keyword to set IS-IS internal metric-type • **external** –Use the **external** keyword to set IS-IS external metric-type Any route with an internal metric (however large the metric is) is preferred over a route with external metric (however small the metric is).
route-policy *route-policy-name*	(Optional) Specifies the identifier of a configured policy. A policy is used to filter the importation of routes from this source routing protocol to IS-IS.

match { **internal** | **external** [**1** | **2**] | **nsaa-external** [**1** | **2**]}	(Optional) Specifies the criteria by which OSPF routes are redistributed into other routing domains. It can be one or more of the following: • **internal** —Routes that are internal to a specific autonomous system (intra- and interarea OSPF routes). • **external** [**1 | 2**]—Routes that are external to the autonomous system, but are imported into OSPF as Type 1 or Type 2 external routes. • **nssa-external** [**1 | 2**]—Routes that are external to the autonomous system, but are imported into OSPF as Type 1 or Type 2 not-so-stubby area (NSSA) external routes. For the **external** and **nssa-external** options, if a type is not specified, then both Type 1 and Type 2 are assumed.
down-flag-clear	(Optional) Specifies that routes redistributed from another IS-IS instance should be advertised with the up/down bit set to zero. This is contrary to the behavior specified by RFC 5305 and RFC 7775 and can lead to route loops.

Command Default

Level 2 is configured if no level is specified.

metric-type: internal

match : If no match keyword is specified, all OSPF routes are redistributed.

Command Modes

Address family configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	Asplain format for 4-byte Autonomous system numbers notation was supported.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Note When redistributing routes (into IS-IS) using both command keywords for setting or matching of attributes and a route policy, the routes are run through the route policy first, followed by the keyword matching and setting.

Use the **redistribute** command to control the redistribution of routes between separate IS-IS instances. To control the propagation of routes between the levels of a single IS-IS instance, use the propagate level, on page 138 command.

Only IPv4 OSPF addresses can be redistributed into IS-IS IPv4 address families.

Task ID

Task ID	Operations
isis	read, write

Examples

In this example, IS-IS instance isp_A readvertises all of the routes of IS-IS instance isp_B in Level 2 LSP. Note that the **level-2** keyword affects which levels instance isp_A advertises the routes in and has no impact on which routes from instance isp_B are advertised. (Any Level 1 routes from IS-IS instance isp_B are included in the redistribution.

```
RP/0/RSP0/CPU0:router(config)# router isis isp_A
RP/0/RSP0/CPU0:router(config-isis)# net 49.1234.2222.2222.2222.00
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-af)# redistribute isis isp_B level-2
!
RP/0/RSP0/CPU0:router(config)# router isis isp_B
RP/0/RSP0/CPU0:router(config-isis)# is-type level 1
RP/0/RSP0/CPU0:router(config-isis)# net 49.4567.2222.2222.2222.00
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 unicast
```

Related Commands

Command	Description
propagate level, on page 138	Propagates routes from one IS-IS level into another level.

remote-psnp-delay

To specify the maximum delay, in milliseconds, that the router should wait for a Partial Sequence Number Protocol (PSNP) acknowledgment from neighbors after sending a Link State Packet (LSP), use the **remote-psnp-delay** command in appropriate mode. To remove the configured maximum delay, use the **no** form of this command.

remote-psnp-delay *milliseconds*

Syntax Description

milliseconds	Maximum delay, in milliseconds, that the router should wait for a PSNP acknowledgment from neighbors after sending a LSP. The range is from 1 through 5000 ms.

Command Default

The command is disabled by default.

Command Modes

IS-IS router lsp-fast-flooding configuration

Interface configuration

Command History

Release	Modification
Release 24.3.1	This command was introduced.

Usage Guidelines

The order of precedence of the configuration using the **remote-psnp-delay** command is as follows:

1. The **remote-psnp-delay** command in interface configuration mode.
2. The value in the PSNP sub-TLV received from the neighbour, if any.
3. The **remote-psnp-delay** command in router configuration mode.

Task ID

Task ID	Operation
isis	read, write

Example

This example shows how to set the PSNP acknowledgment delay to 600 milliseconds on a device.

```
Router# configure terminal
Router(config)# router isis 1
Router(config-isis)# lsp-fast-flooding
Router(config-isis-lsp-fast-flooding)# remote-psnp-delay 600
Router(config-isis-lsp-fast-flooding)# commit
```

This example shows how to set the PSNP acknowledgment delay to 600 milliseconds on an interface.

```
Router# configure terminal
Router(config)# router isis 1
Router(config-isis)# interface GigabitEthernet0/0/0/0
Router(config-isis-if)# remote-psnp-delay 600
```

retransmit-interval (IS-IS)

To configure the amount of time between retransmission of each Intermediate System-to-Intermediate System (IS-IS) link-state packet (LSP) on a point-to-point link, use the **retransmit-interval** command in interface configuration mode. To restore the default value, use the **no** form of this command.

retransmit-interval *seconds* [**level** {**1** | **2**}]
no retransmit-interval [*seconds* [**level** {**1** | **2**}]]

Syntax Description

seconds	Time (in seconds) between consecutive retransmissions of each LSP. It is an integer that should be greater than the expected round-trip delay between any two networking devices on the attached network. Range is 0 to 65535 seconds.
level { **1** | **2** }	(Optional) Specifies routing Level 1 or Level 2 independently.

Command Default

seconds : 5 seconds

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **retransmit-interval** command has no effect on LAN (multipoint) interfaces. On point-to-point links, the value can be increased to enhance network stability.

Because retransmissions occur only when LSPs are dropped, setting this command to a higher value has little effect on reconvergence. The more neighbors networking devices have, and the more paths over which LSPs can be flooded, the higher this value can be made.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure GigabitEthernet interface 0/2/0/1 for retransmission of IS-IS LSPs every 60 seconds for a large serial line:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet 0/2/0/1
RP/0/RSP0/CPU0:router(config-isis-if)# retransmit-interval 60
```

Related Commands

Command	Description
retransmit-throttle-interval, on page 150	Configures the amount of time between retransmissions of any IS-IS LSPs on a point-to-point interface.

retransmit-throttle-interval

To configure minimum interval between retransmissions of different Intermediate System-to-Intermediate System (IS-IS) link-state packets (LSPs) on a point-to-point interface, use the **retransmit-throttle-interval** command in interface configuration mode. To remove the command from the configuration file and restore the system to its default condition, use the **no** form of this command.

retransmit-throttle-interval *milliseconds* [**level** {**1** | **2**}]
no retransmit-throttle-interval [*milliseconds* [**level** {**1** | **2**}]]

Syntax Description

milliseconds	Minimum delay (in milliseconds) between LSP retransmissions on the interface. Range is 0 to 65535.
level { **1** | **2** }	(Optional) Specifies routing Level 1 or Level 2 independently.

Command Default

Default is 0.

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **retransmit-throttle-interval** command to define the minimum period of time that must elapse between retransmitting any two consecutive LSPs on an interface. The **retransmit-throttle-interval** command may be useful in very large networks with many LSPs and many interfaces as a way of controlling LSP retransmission traffic. This command controls the rate at which LSPs can be re-sent on the interface.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure GigabitEthernet interface 0/2/0/1 to limit the rate of LSP retransmissions to one every 300 milliseconds:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet 0/2/0/1
RP/0/RSP0/CPU0:router(config-isis-if)# retransmit-throttle-interval 300
```

Related Commands

Command	Description
lsp-gen-interval, on page 79	Configures the minimum interval time between regenerating the same LSP.
retransmit-interval (IS-IS), on page 148	Configures the amount of time between retransmission of each IS-IS LSP over a point-to-point link.

router isis

To enable the Intermediate System-to-Intermediate System (IS-IS) routing protocol and to specify an IS-IS instance, use the **router isis** command in global configuration mode. To disable IS-IS routing, use the **no** form of this command.

router isis *instance-id*
no router isis *instance-id*

Syntax Description

instance-id	Name of the routing process. Maximum number of characters is 40.

Command Default

An IS-IS routing protocol is not enabled.

Command Modes

Global configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

Use the **router isis** command to create an IS-IS routing process. An appropriate network entity title (NET) must be configured to specify the address of the area (Level 1) and system ID of the router. Routing must be enabled on one or more interfaces before adjacencies may be established and dynamic routing is possible.

Multiple IS-IS processes can be configured. Up to eight processes are configurable. A maximum of five IS-IS instances on a system are supported.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure IS-IS for IP routing:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# net 49.0001.0000.0001.00
```

Related Commands

Command	Description
net, on page 124	Configures an IS-IS NET for the routing process.

router isis static neighbor

To enable the Intermediate System-to-Intermediate System (IS-IS) static neighbor and to configure its attributes, use the **router isis static-neighbor** command in Global Configuration mode. To disable IS-IS static neighbor, use the **no** form of this command.

router isis *instance-id* **static-neighbor**

Syntax Description

instance-id	Name of the routing process. Maximum number of characters is 40.

Command Default

None

Command Modes

Global Configuration mode

Command History

Release	Modification
25.2.1	This command was introduced.

Usage Guidelines

You can configure the following attributes by using the **static-neighbor** configuration mode.

system-id	ISIS System-id of the static neighbor.
remote ipv4/ipv6 address	Remote IPv4/IPv6 addresses.
affinity	Affinity link to advertise.
log advertisement changes	Enable logging static neighbor advertisement changes.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure IS-IS static neighbor and its attributes for a router:

```
Router#config
Router(config)#router isis 1
Router(config-isis)#interface GigabitEthernet0/2/0/7
Router(config-isis-if)#static-neighbor
Router(config-isis-static-nbr)#system-id 0001.0002.0007
Router(config-isis-static-nbr)#remote ipv4 address 2.2.2.2
Router(config-isis-static-nbr)#affinity RED
Router(config-isis-static-nbr)#log-advertisement-changes
```

route source first-hop

To replace the originating route with first-hop for multicast traffic, use the **route source first-hop** command in ISIS address-family submode. To remove the first-hop for multicast traffic, use the **no** form of this command.

routesourcefirst-hop

This command has no keywords or arguments.

Command Default

no route source first-hop is enabled.

Command Modes

ISIS address-family submode

Command History

Release	Modification
Release 6.0	This command was introduced.

Usage Guidelines

This command replaces the originating router address with first-hop router address in the RIB table and facilitates computing alternate paths for multicast traffic. This feature is incompatible with other IOS-XR features, such as MPLS-TE inter-area tunnels. You must use the **route source first-hop** command only to support MoFRR with multicast multipath.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to replace the originating route with first-hop:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 multicast
RP/0/RSP0/CPU0:router(config-isis-af)# route source first-hop
```

Related Commands

Command	Description
net, on page 124	Configures an IS-IS NET for the routing process.

set default-isis-instance

When multiple IS-IS instances are configured on a router, by default, **show isis** commands display information from all IS-IS instances. To display information from only one specific IS-IS instance, use the **set default-isis-instance** *instance-name* command in the EXEC mode.

When the default IS-IS instance is set, all the show IS-IS commands during the terminal session display only information from that default IS-IS instance. To revert back to the default behaviour of displaying information from all IS-IS instances, use the **set default-isis-instance all** command.

set default-isis-instance { *instance-name* | **all** }

Syntax Description

instance-name	Displays information for the specified *instance-name* when running **show isis** commands.
all	Displays information from all configured IS-IS instances when running **show isis** commands.

Command Default

By default, all configured IS-IS instances are displayed when you run any **show isis** command.

Command Modes

EXEC mode

Command History

Release	Modification
Release 24.2.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
isis	read, write

Examples

Example 1: This example shows how to set a specific IS-IS instance as the default instance.

```
RP/0/1/CPU0:ios#set default-isis-instance india
Tue Apr 23 11:47:04.353 CEST
%% Default isis instance is set to  india
```

Example 2: This example uses the **show isis summary** command to display information from the default instance set in Example 1.

```
RP/0/1/CPU0:ios#show isis summary
Tue Apr 23 11:47:10.802 CEST

                                 (L1/L2)     (L1/L2)       (L1/L2)       (IPv4/IPv6)
Tag                    Level     Adj         Routers       LSPs          Routes
---                    -----     ---         -------       ----          ------
```

```
india                  L2      0/1         0/2           0/2           0/0
RP/0/1/CPU0:ios#
```

Example 3: This example shows how to set all configured IS-IS instances as default instances.

```
RP/0/1/CPU0:ios#set default-isis-instance all
Tue Apr 23 11:47:19.308 CEST
%% Default isis instance is set to  all
```

Example 4: This example uses the **show isis summary** command to display information from all the configured instances set in Example 3.

```
RP/0/1/CPU0:ios#show isis summary
Tue Apr 23 11:47:24.697 CEST

                                (L1/L2)     (L1/L2)       (L1/L2)       (IPv4/IPv6)
Tag                    Level    Adj         Routers       LSPs          Routes
---                    -----    ---         -------       ----          ------
eu                     L2       0/2         0/6           0/6           5/5
india                  L2       0/1         0/2           0/2           0/0
RP/0/1/CPU0:ios#
```

set-overload-bit

To configure the router to signal other routers not to use it as an intermediate hop in their shortest path first (SPF) calculations, use the **set-overload-bit** command in router configuration mode. To remove the designation, use the **no** form of this command.

set-overload-bit [**on-startup** {*delay* | **wait-for-bgp**}] [**level** {**1** | **2**}] [**advertise** {**external** | **interlevel**}]
no set-overload-bit [**on-startup** {*delay* | **wait-for-bgp**}] [**level** {**1** | **2**}]

Syntax Description

on-startup	(Optional) Sets the overload bit only temporarily after reboot.
delay	(Optional) Time (in seconds) to advertise when the router is overloaded after reboot. Range is 5 to 86400 seconds (86400 seconds = 1 day).
wait-for-bgp	(Optional) Sets the overload bit on startup until the Border Gateway Protocol (BGP) signals converge or time out.
level { **1** | **2** }	(Optional) Specifies the overload bit for Level 1 or Level 2 independently.

Command Default

The overload bit is not set.

Both Level 1 and Level 2 are configured if no level is specified.

Command Modes

Router configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **set-overload-bit** command to force the router to set the overload bit in its nonpseudonode link-state packets (LSPs). Normally the setting of the overload bit is allowed only when a router experiences problems. For example, when a router is experiencing a memory shortage, the reason might be that the link-state database is not complete, resulting in an incomplete or inaccurate routing table. If the overload bit is set in the LSPs of the unreliable router, other routers can ignore the router in their SPF calculations until it has recovered from its problems. The result is that no paths through the unreliable router are seen by other routers in the Intermediate System-to-Intermediate System (IS-IS) area. However, IP prefixes directly connected to this router are still reachable.

The **set-overload-bit** command can be useful when you want to connect a router to an IS-IS network, but do not want real traffic flowing through it under any circumstances.

Routers with overload bit set are:

- A test router in the lab, connected to a production network.
- A router configured as an LSP flooding server, for example, on a nonbroadcast multiaccess (NBMA) network, in combination with the mesh group feature.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to configure the overload bit:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# set-overload-bit
```

set-attached-bit

To configure an Intermediate System-to-Intermediate System (IS-IS) instance with an attached bit in the Level 1 link-state packet (LSP), use the **set-attached-bit** command in address family configuration mode. To remove the **set-attached-bit** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

set-attached-bit
no set-attached-bit

Command Default

Attached bit is not set in the LSP.

Command Modes

Address family configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **set-attached bit** command to set an IS-IS instance with an attached bit in the Level 1 LSP that allows another IS-IS instance to redistribute Level 2 topology. The attached bit is used when the Level 2 connectivity from another IS-IS instance is advertised by the Level 1 attached bit.

Cisco IOS XR software does not support multiple Level 1 areas in a single IS-IS routing instance. But the equivalent functionality is achieved by redistribution of routes between two IS-IS instances by using the redistribute (IS-IS), on page 142 command.

The attached bit is configured for a specific address family only if the **single-topology** command is not configured.

Note If connectivity for the Level 2 instance is lost, the attached bit in the Level 1 instance LSP continues sending traffic to the Level 2 instance and causes the traffic to be dropped.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to set the attached bit for a Level 1 instance that allows the Level 2 instance to redistribute routes from the Level 1 instance:

```
RP/0/RSP0/CPU0:router(config)# router isis 1
RP/0/RSP0/CPU0:router(config-isis)# net 49.0001.0001.0001.0001.00
```

```
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-af)# redistribute isis 2 level 2
!
RP/0/RSP0/CPU0:router(config-isis-af)# interface GigabitEthernet 0/3/0/0
RP/0/RSP0/CPU0:router(config-isis-af-if)# address-family ipv4 unicast
!
!
RP/0/RSP0/CPU0:router(config)# router isis 2
RP/0/RSP0/CPU0:router(config-isis)# is-type level-1
RP/0/RSP0/CPU0:router(config-isis)# net 49.0002.0001.0001.0002.00
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-af)# set-attached-bit
!
RP/0/RSP0/CPU0:routerfig-isis-af)# interface GigabitEthernet 0/1/0/0
RP/0/RSP0/CPU0:router(config-isis-af-if)# address-family ipv4 unicast
```

Related Commands

Command	Description
redistribute (IS-IS), on page 142	Redistributes routes from one IS-IS instance into another instance.
single-topology, on page 222	Configures the link topology for IPv4 when IPv6 is configured.

show isis

The **show isis** command displays general information about an IS-IS instance and protocol operation. If the instance ID is not specified, the command shows information about all IS-IS instances.

show isis [**instance** *instance-id*]

Syntax Description

instance *instance-id*	(Optional) Displays the IS-IS adjacencies for the specified IS-IS instance only.

Note
The instance-id argument is the instance identifier (alphanumeric) defined by the **router isis** command.

Command Default

No instance ID specified displays IS-IS adjacencies for all the IS-IS instances.

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

For each instance, the first line of output lists the IS-IS instance ID with the following lines identifying the IS-IS system ID, supported levels (level 1, level 2, or level-1-2), configured area addresses, active area addresses, status (enabled or not) and type (Cisco or IETF) of nonstop forwarding (NSF), and the mode in which the last IS-IS process startup occurred.

Next, the status of each configured address family (or just IPv4 unicast if none are configured) is summarized. For each level (level 1 or level 2), the metric style (narrow or wide) generated and accepted is listed along with the status of incremental shortest path first (iSPF) computation (enabled or not). Then redistributed protocols are listed, followed by the administrative distance applied to the redistributed routes.

Finally, the running state (active, passive, or disabled) and configuration state (active or disabled) of each IS-IS interface is listed.

Task ID

Task ID	Operations
isis	read

Examples

The following is sample output from the **show isis** command:

```
Router# show isis
Wed Aug 20 23:54:55.043 PST DST

IS-IS Router: lab
```

```
System Id: 0000.0000.0002
IS Levels: level-2-only
Manual area address(es):
  49.1122
Routing for area address(es):
  49.1122
Non-stop forwarding: Disabled
Most recent startup mode: Cold Restart
Topologies supported by IS-IS:
  IPv4 Unicast
    Level-2
      Metric style (generate/accept): Narrow/Narrow
      Metric: 10
      ISPF status: Disabled
    No protocols redistributed
    Distance: 115
Interfaces supported by IS-IS:
  Loopback0 is running passively (passive in configuration)
  POS0/1/0/2 is running actively (active in configuration)
  POS0/1/0/3 is running actively (active in configuration
```

This table describes the significant fields shown in the display.

Table 3: show isis Field Descriptions

Field	Description
IS-IS Router	IS-IS instance ID.
System Id	IS-IS system ID.
IS Levels	Supported levels for the instance.
Manual area address(es)	Domain and area.
Routing for area address(es):	Configured area addresses and active area addresses.
Non-stop forwarding	Status (enabled or not) and type (Cisco or IETF) of nonstop forwarding (NSF).
Most recent startup mode	The mode in which the last IS-IS process startup occurred.
Topologies supported by IS-IS	The summary of the status of each configured address family (or just IPv4 unicast if none are configured).
Redistributed protocols	List of redistributed protocols, followed by the administrative distance applied to the redistributed routes.
Metric style (generate/accept)	The status of each configured address family (or just IPv4 unicast if none are configured) is summarized. For each level (level 1 or level 2), the metric style (narrow or wide) generated and accepted is listed along with the status of incremental shortest path first (iSPF) computation (enabled or not).
Interfaces supported by IS-IS	The running state (active, passive, or disabled) and configuration state (active or disabled) of each IS-IS interface.

show isis adjacency

To display Intermediate System-to-Intermediate System (IS-IS) adjacencies, use the **show isis adjacency** command in EXEC mode.

show isis [**instance** *instance-id*] **adjacency** [**level** {**1** | **2**}] [*type interface-path-id*] [**detail**] [**systemid** *system-id*]

Syntax Description

instance *instance-id*	(Optional) Displays the IS-IS adjacencies for the specified IS-IS instance only. • The *instance-id* argument is the instance identifier (alphanumeric) defined by the **router isis** command.
level { **1** | **2** }	(Optional) Displays the IS-IS adjacencies for Level 1 or Level 2 independently.
type	Interface type. For more information, use the question mark (**?**) online help function.
interface-path-id	Physical interface or virtual interface. **Note** Use the **show interfaces** command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (**?**) online help function.
detail	(Optional) Displays neighbor IP addresses and active topologies.
systemid *system-id*	(Optional) Displays the information for the specified router only.

Command Default

No instance ID specified displays IS-IS adjacencies for all the IS-IS instances.

Both Level 1 and Level 2 are configured if no level is specified.

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
isis	read

Examples

The following is sample output from the **show isis adjacency** command:

```
RP/0/RSP0/CPU0:router# show isis adjacency

IS-IS p Level-1 adjacencies:
System Id      Interface        SNPA           State Hold     Changed  NSF      BFD
12a4           PO0/1/0/1        *PtoP*         Up    23       00:00:06 Capable  Init
12a4           Gi0/6/0/2        0004.2893.f2f6 Up    56       00:04:01 Capable  Up

Total adjacency count: 2

IS-IS p Level-2 adjacencies:
System Id      Interface        SNPA           State Hold     Changed  NSF      BFD
12a4           PO0/1/0/1        *PtoP*         Up    23       00:00:06 Capable  None
12a4           Gi0/6/0/2        0004.2893.f2f6 Up    26       00:00:13 Capable  Init

Total adjacency count: 2
```

This table describes the significant fields shown in the display.

Table 4: show isis adjacency Field Descriptions

Field	Description
Level-1	Level 1 adjacencies.
Level-2	Level 2 adjacencies.
System ID	Dynamic hostname of the system. The hostname is specified using the **hostname** command. If the dynamic hostname is not known or the **hostname dynamic disable** command has been executed, the 6-octet system ID is used.
Interface	Interface used to reach the neighbor.
SNPA	Data-link address (also known as the Subnetwork Point of Attachment [SNPA]) of the neighbor.
State	Adjacency state of the neighboring interface. Valid states are Down, Init, and Up.
Holdtime	Hold time of the neighbor.
Changed	Time the neighbor has been up (in hours:minutes:seconds).
NSF	Specifies whether the neighbor can adhere to the IETF-NSF restart mechanism.
BFD	Specifies the Bidirectional Forwarding Detection (BFD) status for the interface. Valid status are • None—BFD is not configured. • Init—BFD session is not up. One reason is that other side is not yet enabled. • Up—BFD session has been established. • Down—BFD session holdtime expired.

Related Commands

Command	Description
show isis neighbors, on page 194	Displays information about IS-IS neighbors.

show isis adjacency-log

To display the Intermediate System-to-Intermediate System (IS-IS) adjacency log, use the **show isis adjacency-log** command in EXEC mode.

show isis adjacency-log [**level** {**1** | **2**}] [**last** *number* | **first** *number*]

Syntax Description

level { **1** | **2** }	(Optional) Displays the IS-IS adjacency log for Level 1 or Level 2 independently.
last *number*	(Optional) Specifies that the output is restricted to the last *number* of entries. Range is 1 to 100.
first *number*	(Optional) Specifies that the output is restricted to the first *number* of entries. Range is 1 to 100.

Command Default

No default behavior or values

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
isis	read

Examples

The following is sample output from the **show isis adjacency-log** command:

```
RP/0/RSP0/CPU0:router# show isis adjacency-log

   IS-IS 10 Level 1 Adjacency log
When           System          Interface          State   Details
4d00h          12a1            PO0/5/0/0          d -> i
4d00h          12a1            PO0/5/0/0          i -> u  New adjacency
                                                          IPv4 Unicast Up
4d00h          12a1            Gi0/6/0/0          d -> u  New adjacency
4d00h          12a1            Gi0/6/0/0          u -> d  Interface state
down
3d17h          12a1            Gi0/6/0/0          d -> u  New adjacency
3d17h          12a1            Gi0/6/0/0          u -> d  Interface state
down
01:44:07       12a1            Gi0/6/0/0          d -> u  New adjacency

   IS-IS 10 Level 2 Adjacency log
When           System          Interface          State   Details
```

```
4d00h          12a1            PO0/5/0/0          d -> i
4d00h          12a1            PO0/5/0/0          i -> u  New adjacency
                                                         IPv4 Unicast Up
4d00h          12a1            Gi0/6/0/0          d -> u  New adjacency
4d00h          12a1            Gi0/6/0/0          u -> d  Interface state
down
3d17h          12a1            Gi0/6/0/0          d -> u  New adjacency
3d17h          12a1            Gi0/6/0/0          u -> d  Interface state
down
01:44:07       12a1            Gi0/6/0/0          d -> u  New adjacency
```

This table describes the significant fields shown in the display.

Table 5: show isis adjacency-log Field Descriptions

Field	Description
When	Elapsed time (in hh:mm:ss) since the event was logged.
System	System ID of the adjacent router.
Interface	Specific interface involved in the adjacency change.
State	State transition for the logged event.
Details	Description of the adjacency change.

show isis checkpoint adjacency

To display the Intermediate System-to-Intermediate System (IS-IS) checkpoint adjacency database, use the **show isis checkpoint adjacency** command in EXEC mode.

show isis [**instance** *instance-id*] **checkpoint adjacency**

Syntax Description

instance *instance-id*	(Optional) Displays the IS-IS checkpoint adjacencies for the specified IS-IS instance only. • The *instance-id* argument is the instance identifier (alphanumeric) defined by the **router isis** command.

Command Default

No instance ID specified displays IS-IS checkpoint adjacencies for all the IS-IS instances.

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show isis checkpoint adjacency** command to display the checkpointed adjacencies. With this information you can restore the adjacency database during a Cisco proprietary nonstop forwarding (NSF) restart. This command, with the **show isis adjacency** command, can be used to verify the consistency of the two databases.

Task ID

Task ID	Operations
isis	read

Examples

The following is sample output from the **show isis checkpoint adjacency** command:

```
RP/0/RSP0/CPU0:router# show
          isis
          checkpoint
          adjacency

 Interface        Level  System ID        State  Circuit ID          Chkpt ID
 Gi3/0/0/1           1    router-gsr8       Up     0001.0000.0008.04   80011fec
 Gi0/4/0/1           1    router-gsr9       Up     0001.0000.0006.01   80011fd8
 Gi/0/0/1           2    router-gsr8      Up     0001.0000.0008.04   80011fc4
```

This table describes the significant fields shown in the display.

Table 6: show isis checkpoint adjacency Field Descriptions

Field	Description
Interface	Interface used to reach the neighbor.
Level	Lists either routers with Level 1 or Level 2 adjacency configured.
System ID	Dynamic hostname of the system. The hostname is specified using the **hostname** command. If the dynamic hostname is not known or **hostname dynamic disable** command has been executed, the 6-octet system ID is used.
State	State of the neighboring interface.
Circuit ID	Unique ID issued to a circuit at its creation.
Chkpt ID	Unique ID issued to the checkpoint at its creation.

Related Commands

Command	Description
show isis adjacency, on page 163	Displays IS-IS adjacencies.
show isis checkpoint lsp, on page 171	Displays the IS-IS checkpoint LSP database.

show isis checkpoint interface

To display the Intermediate System-to-Intermediate System (IS-IS) checkpoint interfaces, use the **show isis checkpoint interface** command in EXEC mode.

show isis checkpoint interface

This command has no keywords or arguments.

Command Default

No default behavior or values

Command Modes

EXEXEC EC

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
isis	read

Examples

The following is sample output from the **show isis checkpoint interface** command:

```
RP/0/RSP0/CPU0:router# show isis checkpoint interface

IS-IS 10 checkpoint interface
Interface         Index  CircNum  DIS Areas    Chkpt ID
PO0/5/0/0         0      0        NONE         80002fe8
Gi0/6/0/0         1      3        L1L2         80002fd0
```

This table describes the significant fields shown in the display.

Table 7: show isis checkpoint interface Field Descriptions

Field	Description
Interface	Interface used to reach the neighbor.
Index	Interface index assigned to an interface upon its creation.
CircNum	Unique ID issued to a circuit internally.
DIS Areas	Designated Intermediate System area.

Field	Description
Chkpt ID	Unique ID issued to the checkpoint at its creation.

show isis checkpoint lsp

To display the Intermediate System-to-Intermediate System (IS-IS) checkpoint link-state packet (LSP) protocol data unit (PDU) identifier database, use the **show isis checkpoint lsp** command in EXEC mode.

show isis [**instance** *instance-id*] **checkpoint lsp**

Syntax Description

instance *instance-id*	(Optional) Displays the IS-IS checkpoint LSPs for the specified instance only. • The *instance-id* argument is the instance identifier (alphanumeric) defined by the **router isis** command.

Command Default

No instance ID specified displays IS-IS checkpoint LSPs for all the IS-IS instances.

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The checkpointed LSPs displayed by this command are used to restore the LSP database during a Cisco-proprietary nonstop forwarding (NSF) restart. The **show isis checkpoint lsp** command, with the **show isis database** command, may be used to verify the consistency of the two databases.

Task ID

Task ID	Operations
isis	read

Examples

The following is sample output from the **show isis checkpoint lsp** command:

```
RP/0/RSP0/CPU0:router#
            show isis checkpoint lsp


Level  LSPID              Chkpt ID
1      router-gsr6.00-00  80011f9c
1      router-gsr6.01-00  80011f88
1      router-gsr8.00-00  80011f74
1      router-gsr9.00-00  80011f60
2      router-gsr6.00-00  80011f4c
2      router-gsr6.01-00  80011f38
2      router-gsr8.00-00  80011f24
2      router-gsr9.00-00  80011f10
Total LSP count: 8 (L1: 4, L2 4, local L1: 2, local L2 2)
```

This table describes the significant fields shown in the display.

Table 8: show isis checkpoint lsp Field Descriptions

Field	Description
Level	Routers with Level 1 or Level 2 adjacency configured.
LSPID	LSP identifier. The first six octets form the system ID of the router that originated the LSP. The next octet is the pseudonode ID. When this byte is 0 , the LSP describes links from the system. When it is nonzero, the LSP is a so-called nonpseudonode LSP. This is similar to a router link-state advertisement (LSA) in the Open Shortest Path First (OSPF) protocol. The LSP describes the state of the originating router. For each LAN, the designated router for that LAN creates and floods a pseudonode LSP, describing all systems attached to that LAN. The last octet is the LSP number. If there is more data than can fit in a single LSP, the LSP is divided into multiple LSP fragments. Each fragment has a different LSP number. An asterisk (*) indicates that the LSP was originated by the system on which this command is issued.
Chkpt ID	Unique ID issued to the checkpoint at its creation.

Related Commands

Command	Description
show isis checkpoint adjacency, on page 167	Displays the IS-IS checkpoint adjacency database.
show isis database, on page 173	Displays the IS-IS link-state database.

show isis database

To display the Intermediate System-to-Intermediate System (IS-IS) link-state packet (LSP) database, use the **show isis database** command in EXEC mode.

show isis [**instance** *instance-id*] **database** [**level** {**1** | **2**}] [**update**] [**summary**] [**detail**] [**verbose**] [***lsp-id***]

Syntax Description

instance *instance-id*	(Optional) Displays the IS-IS LSP database for the specified instance only. • The *instance-id* argument is the instance identifier (alphanumeric) defined by the **router isis** command.
level { **1** | **2** }	(Optional) Displays the IS-IS LSP database for Level 1 or Level 2 independently.
update	(Optional) Displays contents of LSP database managed by update thread.
summary	(Optional) Displays the LSP ID number, sequence number, checksum, hold time, and bit information.
detail	(Optional) Displays the contents of each LSP.
verbose	(Optional) Displays the contents of each LSP.
* | *lsp-id*	(Optional) LSP protocol data units (PDUs) identifier. Displays the contents of a single LSP by its ID number or may contain an * as a wildcard character.

Command Default

No instance ID specified displays the IS-IS LSP database for all the IS-IS instances.

Both Level 1 and Level 2 is configured if no level is specified.

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

Each of the options for the **show isis database** command can be entered in an arbitrary string within the same command entry. For example, the following are both valid command specifications and provide the same output: **show isis database detail level 2** and **show isis database level 2 detail** .

The **summary** keyword used with this command allows you to filter through a large IS-IS database and quickly identify problematic areas.

Task ID

Task ID	Operations
isis	read

show isis database-log

To display the entries in the Intermediate System-to-Intermediate System (IS-IS) database log, use the **show isis database-log** command in EXEC mode.

show isis database-log [**level** {**1** | **2**}] [**last** *number* | **first** *number*]

Syntax Description

level { **1** | **2** }	(Optional) Displays the database log for Level 1 or Level 2 independently.
last *number*	(Optional) Specifies that the output be restricted to the last *number* of entries. Range is 1 to 1000.
first *number*	(Optional) Specifies that the output be restricted to the first *number* of entries. Range is 1 to 1000.

Command Default

Both Level 1 and Level 2 are configured if no level is specified.

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
isis	read

Examples

The following is sample output from the **show isis database-log** command:

```
RP/0/RSP0/CPU0:router# show isis database-log

   IS-IS 10 Level 1 Link State Database Log
                                 New LSP                 Old LSP
WHEN     LSPID                Op  Seq Num    Holdtime OL  Seq Num    Holdtime OL
01:17:19 12b1.03-00           REP 0x00000003 1200      0  0x00000002 340       0
001:06:20 12b1.00-00          REP 0x000001d8 1200      0  0x000001d7 375       0
01:06:00 12b1.03-00           REP 0x00000004 1200      0  0x00000003 520       0
01:05:46 12a1.00-00           REP 0x000001fc 1200      0  0x000001fb 425       0
00:55:01 12b1.00-00           REP 0x000001d9 1200      0  0x000001d8 520       0
00:53:39 12b1.03-00           REP 0x00000005 1200      0  0x00000004 459       0
00:53:19 12a1.00-00           REP 0x000001fd 1200      0  0x000001fc 453       0
00:42:12 12b1.00-00           REP 0x000001da 1200      0  0x000001d9 431       0
00:39:56 12b1.03-00           REP 0x00000006 1200      0  0x00000005 376       0
00:38:54 12a1.00-00           REP 0x000001fe 1200      0  0x000001fd 334       0
00:29:10 12b1.00-00           REP 0x000001db 1200      0  0x000001da 418       0
00:27:22 12b1.03-00           REP 0x00000007 1200      0  0x00000006 446       0
```

```
00:25:10 12a1.00-00           REP 0x000001ff 1200      0  0x000001fe 375       0
00:17:04 12b1.00-00           REP 0x000001dc 1200      0  0x000001db 473
```

This table describes the significant fields shown in the display.

Table 9: show isis database-log Field Descriptions

Field	Description
WHEN	Elapsed time (in hh:mm:ss) since the event was logged.
LSPID	LSP identifier. The first six octets form the system ID of the router that originated the LSP. The next octet is the pseudonode ID. When this byte is 0 , the LSP describes links from the system. When it is nonzero, the LSP is a so-called nonpseudonode LSP. This is similar to a router link-state advertisement (LSA) in the Open Shortest Path First (OSPF) protocol. The LSP describes the state of the originating router. For each LAN, the designated router for that LAN creates and floods a pseudonode LSP, describing all systems attached to that LAN. The last octet is the LSP number. If there is more data than can fit in a single LSP, the LSP is divided into multiple LSP fragments. Each fragment has a different LSP number. An asterisk (*) indicates that the LSP was originated by the system on which this command is issued.
New LSP	New router or pseudonode appearing in the topology.
Old LSP	Old router or pseudonode leaving the topology.
Op	Operation on the database: inserted (INS) or replaced (REP).
Seq Num	Sequence number for the LSP that allows other systems to determine if they have received the latest information from the source.
Holdtime	Time the LSP remains valid (in seconds). An LSP hold time of 0 indicates that this LSP was purged and is being removed from the link-state database (LSDB) of all routers. The value indicates how long the purged LSP stays in the LSDB before being completely removed.
OL	Overload bit. Determines if the IS is congested. If the Overload bit is set, other routers do not use this system as a transit router when calculating routers. Only packets for destinations directly connected to the overloaded router are sent to this router.

Related Commands

Command	Description
show isis database, on page 173	Displays the IS-IS link-state packet (LSP) database.

show isis fast-reroute

To display per-prefix LFA information, use the **show isis fast-reroute** command in EXEC mode.

show isis fast-reroute
A.B.C.D/length | **detail** | **summary** | **sr-only**

Syntax Description

A.B.C.D/length	Network to show per-prefix LFA information.
detail	Use to display tiebreaker information about the backup.
summary	Use to display the number of prefixes having protection per priority.
sr-only	Use to display SR-labeled prefixes only.

Command Default

None

Command History

Release	Modification
Release 4.0.1	This command was introduced.
Release 6.3.2	The **sr-only** keyword was added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
isis	read

The following is sample output from **show isis fast-reroute** command that displays per-prefix LFA information:

```
RP/0/RSP0/CPU0:router# show isis fast-reroute 10.1.6.0/24

L1 10.1.6.0/24 [20/115]
     via 10.3.7.47, POS0/3/0/1, router2
       FRR backup via 10.1.7.145, GigabitEthernet0/1/0/3, router3
```

The following is sample output from **show isis fast-reroute detail** command that displays tie-breaker information about the backup:

```
RP/0/RSP0/CPU0:router# show isis fast-reroute 10.1.6.0/24 detail

L1 10.1.6.0/24 [20/115] low priority
     via 10.3.7.47, POS0/3/0/1, router2
       FRR backup via 10.1.7.145, GigabitEthernet0/1/0/3, router3
       P: No, TM: 30, LC: Yes, NP: No, D: No
     src router2.00-00, 192.168.0.47
```

```
   L2 adv [20] native, propagated
```

The following is sample output from **show isis fast-reroute summary** command that displays the number of prefixes having protection per priority:

```
RP/0/RSP0/CPU0:router#show isis fast-reroute summary
IS-IS frr IPv4 Unicast FRR summary

                                    Critical   High       Medium     Low        Total

                                    Priority   Priority   Priority      Priority

Prefixes reachable in L1
  All paths protected     0              0             2                8               10

  Some paths protected 0               0             1                3               4

  Unprotected                0              0             1                3
 4
  Protection coverage    0.00%     0.00%     75.00%     78.57%     77.78%
Prefixes reachable in L2
  All paths protected     0              0             0                0               0

  Some paths protected 0               0             1                0               1

  Unprotected                0              0             0                0
 0
  Protection coverage    0.00%     0.00%     100.00%   0.00%      100.00%
```

The following is sample output from **show isis fast-reroute sr-only** command that displays fast-reroute repair paths for prefixes associated with a segment routing prefix SID:

```
RP/0/RSP0/CPU0:router#show isis fast-reroute sr-only
IS-IS 1 IPv4 Unicast FRR backups

Codes: L1 - level 1, L2 - level 2, ia - interarea (leaked into level 1)
       df - level 1 default (closest attached router), su - summary null
       C - connected, S - static, R - RIP, B - BGP, O - OSPF
       E - EIGRP, A - access/subscriber, M - mobile, a - application
       i - IS-IS (redistributed from another instance)
       D - Downstream, LC - Line card disjoint, NP - Node protecting
       P - Primary path, SRLG - SRLG disjoint, TM - Total metric via backup

Maximum parallel path count: 8

L2 20.1.0.101/32 [10/115]
     via 10.1.1.101, GigabitEthernet0/0/0/2, r101, SRGB Base: 16000, Weight: 0
        Backup path: TI-LFA (link), via 10.4.1.103, GigabitEthernet0/0/0/1 r103, SRGB Base:
 16000, Weight: 0
          P node: r103.00 [20.1.0.103], Label: ImpNull
          Q node: r102.00 [20.1.0.102], Label: 24001
          Prefix label: 16101
          Backup-src: r101.00
L2 20.1.0.102/32 [30/115]
     via 10.1.1.101, GigabitEthernet0/0/0/2, r101, SRGB Base: 16000, Weight: 0
        Backup path: TI-LFA (link), via 10.4.1.103, GigabitEthernet0/0/0/1 r103, SRGB Base:
 16000, Weight: 0
          P node: r103.00 [20.1.0.103], Label: ImpNull
          Q node: r102.00 [20.1.0.102], Label: 24001
          Prefix label: ImpNull
          Backup-src: r102.00
L2 20.1.0.103/32 [20/115]
```

```
    via 10.4.1.103, GigabitEthernet0/0/0/1, r103, SRGB Base: 16000, Weight: 0
       Backup path: TI-LFA (link), via 10.1.1.101, GigabitEthernet0/0/0/2 r101, SRGB Base:
16000, Weight: 0
          P node: r102.00 [20.1.0.102], Label: 16102
          Q node: r103.00 [20.1.0.103], Label: 24001
          Prefix label: ImpNull
          Backup-src: r103.00
```

show isis hostname

To display the entries in the Intermediate System-to-Intermediate System (IS-IS) router name-to-system ID mapping table, use the **show isis hostname** command in EXEC mode.

show isis [**instance** *instance-id*] **hostname**

Syntax Description

instance *instance-id*	(Optional) Displays the IS-IS router name-to-system ID mapping table for the specified IS-IS instance only. The *instance-id* argument is the instance identifier (alphanumeric) defined by the **router isis** command.

Command Default

No instance ID specified displays the IS-IS router name-to-system ID mapping table for all the IS-IS instances.

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show isis hostname** command does not display entries if the dynamic hostnames are disabled.

Task ID

Task ID	Operations
isis	read

Examples

The following is sample output from the **show isis hostname** command with the **instance** and *instance-id* values specified:

```
RP/0/RSP0/CPU0:router# show isis instance isp hostname

ISIS isp hostnames
    Level  System ID      Dynamic Hostname
     1     0001.0000.0005 router
     2   * 0001.0000.0011 router-11
```

This table describes the significant fields shown in the display.

Table 10: show isis instance isp hostname Field Descriptions

Field	Description
Level	IS-IS level of the router.
System ID	Dynamic hostname of the system. The hostname is specified using the **hostname** command. If the dynamic hostname is not known or **hostname dynamic disable** command has been executed, the 6-octet system ID is used.
Dynamic Hostname	Hostname of the router.
*	Local router.

Related Commands

Command	Description
hostname	Specifies the name of the local router.
hostname dynamic disable, on page 60	Enables the IS-IS routing protocol to dynamically update the mapping of router names to system IDs.

show isis interface

To display information about the Intermediate System-to-Intermediate System (IS-IS) interfaces, use the **show isis interface** command in EXEC mode.

show isis interface [*type interface-path-id* | **level** {**1** | **2**}] [**brief**]

Syntax Description

type	Interface type. For more information, use the question mark (**?**) online help function.
interface-path-id	Physical interface or virtual interface. **Note** Use the **show interfaces** command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (**?**) online help function.
level { **1** | **2** }	(Optional) Displays IS-IS interface information for Level 1 or Level 2 independently.
brief	(Optional) Displays brief interface output.

Command Default

Displays all IS-IS interfaces.

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
isis	read

Examples

The following is sample output from the **show isis interface** command:

```
RP/0/RSP0/CPU0:router#show isis interface
          GigabitEthernet 0/3/0/2
 Gi /3/0/2                  Enabled
  Adjacency Formation:      Enabled
  Prefix Advertisement:     Enabled
  BFD:                      Disabled
  BFD Min Interval:         150
  BFD Multiplier:           3
```

```
Circuit Type:             level-2-only
Media Type:               P2P
Circuit Number:           0
Extended Circuit Number:  67111168
Next P2P IIH in:          4 s
LSP Rexmit Queue Size:    0

Level-2
  Adjacency Count:        1
  LSP Pacing Interval:    33 ms
  PSNP Entry Queue Size:  0

CLNS I/O
  Protocol State:         Up
  MTU:                    4469

IPv4 Unicast Topology:    Enabled
  Adjacency Formation:    Running
  Prefix Advertisement:   Running
  Metric (L1/L2):         10/100
  MPLS LDP Sync (L1/L2):  Disabled/Disabled
IPv6 Unicast Topology:    Disabled (Not cfg on the intf)

IPv4 Address Family:      Enabled
  Protocol State:         Up
  Forwarding Address(es): 10.3.10.143
  Global Prefix(es):      10.3.10.0/24
IPv6 Address Family:      Disabled (No topology enabled which uses IPv6)

LSP transmit timer expires in 0 ms
LSP transmission is idle
Can send up to 9 back-to-back LSPs in the next 0 ms
```

This table describes the significant fields shown in the display.

Table 11: show isis interface Field Descriptions

Field	Description
GigabitEthernet0/6/0/0	Status of the interface, either enabled or disabled.
Adjacency formation	Status of adjacency formation, either enabled or disabled.
Prefix Advertisement	Status of advertising connected prefixes, either enabled or disabled.
BFD	Status of Bidirectional Forwarding Detection (BFD), either enabled or disabled.
BFD Min Interval	BFD minimum interval.
BFD Multiplier	BFD multiplier.
Circuit Type	Levels the interface is running on (circuit-type configuration) which may be a subset of levels on the router.
Media Type	Media type on which IS-IS is running.
Circuit Number	Unique ID assigned to a circuit internally (8-bit integer).
Extended Circuit Number	Valid only for point-to-point interfaces (32-bit integer).

Field	Description
LSP Rexmit Queue Size	Number of LSPs pending retransmission on the interface.
Adjacency Count	Number of adjacencies formed with a neighboring router that supports the same set of protocols.
PSNP Entry Queue Size	Number of SNP entries pending inclusion in the next PSNP.
LAN ID	ID of the LAN.
Priority (Local/DIS)	Priority of this interface or priority of the Designated Intermediate System.
Next LAN IIH in	Time (in seconds) in which the next LAN hello message is sent.
LSP Pacing Interval	Interval at which the link-state packet (LSP) transmission rate (and by implication the reception rate of other systems) is to be reduced.
Protocol State	Running state of the protocol (up or down).
MTU	Link maximum transmission unit (MTU).
SNPA	Data-link address (also known as the Subnetwork Point of Attachment [SNPA]) of the neighbor.
All Level-n ISs	Status of interface membership in Layer 2 multicast group. The status options are Yes or reason for not being a member of the multicast group.
IPv4 Unicast Topology	Status of the topology, either enabled or disabled.
Adjacency Formation	Status of adjacency formation. The status options are Running or a reason for not being ready to form adjacencies.
Prefix Advertisement	Status of advertising prefixes, either enabled or disabled.
Metric (L1/L2)	IS-IS metric for the cost of the adjacency between the originating router and the advertised neighbor, or the metric of the cost to get from the advertising router to the advertised destination (which can be an IP address, an end system (ES), or a connectionless network service (CLNS) prefix).
MPLS LDP Sync (L1/L2)	Status of LDP IS-IS synchronization, either enabled or disabled. When enabled, the state of synchronization (Sync Status) is additionally displayed as either achieved or not achieved.
IPv4 Address Family	Status of the address family, either enabled or disabled.
Protocol State	State of the protocol.
Forwarding Address(es)	Addresses on this interface used by the neighbor for next-hop forwarding.
Global Prefix(es)	Prefixes for this interface included in the LSP.
LSP transmit timer expires in	LSP transmission expiration timer interval (in milliseconds).

Field	Description
LSP transmission is	State of LSP transmission. Valid states are • idle • in progress • requested • requested and in progress

The following is sample output from the **show isis interface** command with the **brief** keyword:

```
RP/0/0/CPU0:router# show isis interface brief

    Interface      All     Adjs    Adj Topos  Adv Topos  CLNS   MTU    Prio
                   OK    L1   L2    Run/Cfg    Run/Cfg                L1   L2
-----------------  ---  ---------  ---------  ---------  ----  ----  --------
PO0/5/0/0          Yes    1    1       1/1        1/1     Up    4469    -    -
Gi0/6/0/0          Yes    1*   1*      1/1        1/1     Up    1497   64   64
```

This table describes the significant fields shown in the display.

Table 12: show isis interface brief Field Descriptions

Field	Description
Interface	Name of the interface.
All OK	Everything is working as expected for this interface.
Adjs L1 L2	Number of L1 and L2 adjacencies over this interface.
Adj Topos Run/Cfg	Number of topologies that participate in forming adjacencies. Number of topologies that were configured to participate in forming adjacencies.
Adv Topos Run/Cfg	Number of topologies that participate in advertising prefixes. Number of topologies that were configured to participate in advertising prefixes.
CLNS	Status of the Connectionless Network Service. Status options are Up or Down.
MTU	Maximum transfer unit size for the interface.
Prio L1 L2	Interface L1 priority. Interface L2 priority.

show isis lsp-log

To display link-state packet (LSP) log information, use the **show isis lsp-log** command in EXEC mode.

show isis [**instance** *instance-id*] **lsp-log** [**level** {**1** | **2**}] [**last** *number* | **first** *number*]

Syntax Description

instance *instance-id*	(Optional) Displays the LSP log information for the specified IS-IS instance only. • The *instance-id* argument is the instance identifier (alphanumeric) defined by the **router isis** command.
level { **1** | **2** }	(Optional) Displays the Intermediate System-to-Intermediate System (IS-IS) link-state database for Level 1 or Level 2 independently.
last *number*	(Optional) Specifies that the output be restricted to the last *number* of entries. Range is 1 to 20.
first *number*	(Optional) Specifies that the output be restricted to the first *number* of entries. Range is 1 to 20.

Command Default

No instance ID specified displays the LSP log information for all the IS-IS instances.

Both Level 1 and Level 2 are configured if no level is specified.

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
isis	read

Examples

The following is sample output from the **show isis lsp-log** command with the **instance** and *instance-id* values specified:

```
RP/0/RSP0/CPU0:router# show isis instance isp lsp-log

ISIS isp Level 1 LSP log
  When       Count      Interface       Triggers
00:02:36         1
00:02:31         1                       LSPREGEN
00:02:26         1      PO4/1            DELADJ
00:02:24         1      PO4/1            NEWADJ
```

```
00:02:23         1      Gi5/0           DIS
00:01:27         1      Lo0             IPDOWN
00:01:12         1      Lo0             IPUP


ISIS isp Level 2 LSP log
  When       Count      Interface       Triggers
00:02:36         1
00:02:30         1                      LSPREGEN
00:02:26         1      PO4/1           DELADJ
00:02:24         1      PO4/1           NEWADJ
00:02:23         1      Gi5/0           DIS
00:02:21         1                      AREASET
00:01:27         1      Lo0             IPDOWN
00:01:12         1      Lo0             IPUP
```

This table describes the significant fields shown in the display.

Table 13: show isis instance isp lsp-log Field Descriptions

Field	Description
Level	IS-IS level of the router.
When	How long ago (in hh:mm:ss) an LSP rebuild occurred. The last 20 occurrences are logged.
Count	Number of events that triggered this LSP run. When there is a topology change, often multiple LSPs are received in a short period. A router waits 5 seconds before running a full LSP, so it can include all new information. This count denotes the number of events (such as receiving new LSPs) that occurred while the router was waiting its 5 seconds before running full LSP.
Interface	Interface that corresponds to the triggered reasons for the LSP rebuild.
Triggers	A list of all reasons that triggered an LSP rebuild. The triggers are • AREASET—area set changed • ATTACHFLAG—bit attached • CLEAR— **clear** command • CONFIG—configuration change • DELADJ—adjacency deleted • DIS—DIS changed • IFDOWN—interface down • IPADDRCHG—IP address change • IPDEFORIG—IP def-orig • IPDOWN—connected IP down • IFDOWN—interface down • IPEXT—external IP • IPIA—nterarea IP • IPUP—connected IP up • LSPDBOL—LSPDBOL bit • LSPREGEN—LSP regeneration • NEWADJ— new adjacency

show isis mesh-group

To display Intermediate System-to-Intermediate System (IS-IS) mesh group information, use the **show isis mesh-group** command in EXEC mode.

show isis [**instance** *instance-id*] **mesh-group**

Syntax Description

instance *instance-id*	(Optional) Displays the mesh group information for the specified IS-IS instance only. • The *instance-id* argument is the instance identifier (alphanumeric) defined by the **router isis** command.

Command Default

No instance ID specified displays the IS-IS mesh group information for all the IS-IS instances.

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
isis	read

Examples

The following is sample output from the **show isis mesh-group** command with the **instance** and *instance-id* values specified:

```
RP/0/RSP0/CPU0:router# show isis instance isp mesh-group

 ISIS isp Mesh Groups

 Mesh group 6:
 GigabitEthernet 0/4/0/1
```

This table describes the significant fields shown in the display.

Table 14: show isis instance isp mesh-group Field Descriptions

Field	Description
Mesh group	Mesh group number to which this interface is a member. A mesh group optimizes link-state packet (LSP) flooding in nonbroadcast multiaccess (NBMA) networks with highly meshed, point-to-point topologies. LSPs that are first received on interfaces that are part of a mesh group are flooded to all interfaces except those in the same mesh group.
GigabitEthernet0/4/0/1	Interface belonging to mesh group 6.

show isis mpls traffic-eng adjacency-log

To display a log of Multiprotocol Label Switching traffic engineering (MPLS TE) adjacency changes for an Intermediate System-to-Intermediate System (IS-IS) instance, use the **show isis mpls traffic-eng adjacency-log** command in EXEC mode.

show isis [**instance** *instance-id*] **mpls traffic-eng adjacency-log** [**last** *number* | **first** *number*]

Syntax Description

instance *instance-id*	(Optional) Displays the MPLS TE adjacency changes for the specified IS-IS instance only. • The *instance-id* argument is the instance identifier (alphanumeric) defined by the **router isis** command.
last *number*	(Optional) Specifies that the output is restricted to last *number* of entries. Range is 1 to 20.
first *number*	(Optional) Specifies that the output is restricted to first *number* of entries. Range is 1 to 20.

Command Default

No instance ID specified displays MPLS TE adjacency changes for all the IS-IS instances.

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show isis mpls traffic-eng adjacency-log** command to display the status of MPLS TE adjacencies.

Task ID

Task ID	Operations
isis	read

Examples

The following is sample output from the **show isis mpls traffic-eng adjacency-log** command with the **instance** and *instance-id* values specified:

```
RP/0/RSP0/CPU0:router# show isis instance isp mpls traffic-eng adjacency-log

IS-IS isp Level-2 MPLS Traffic Engineering adjacency log
When      Neighbor ID        IP Address       Interface Status
00:03:36  router-6           172.17.1.6         PO0/3/0/1 Up
00:03:36  router-6           172.17.1.6         PO0/3/0/1 Down
00:02:38  router-6           172.17.1.6         PO0/3/0/1 Up
```

This table describes the significant fields shown in the display.

Table 15: show isis instance isp mpls traffic-eng adjacency-log Field Descriptions

Field	Description
When	Time (in hh:mm:ss) since the entry was recorded in the log.
Neighbor ID	Identification value of the neighbor.
IP Address	Neighbor IP Version 4 (IPv4) address.
Interface	Interface from which a neighbor is learned.
Status	Up (active) or Down (disconnected).

Related Commands

Command	Description
show isis mpls traffic-eng advertisements, on page 191	Displays the last flooded record from MPLS traffic engineering.

show isis mpls traffic-eng advertisements

To display the latest flooded record from Multiprotocol Label Switching traffic engineering (MPLS TE) for an Intermediate System-to-Intermediate System (IS-IS) instance, use the **show isis mpls traffic-eng advertisements** command in EXEC mode.

show isis [**instance** *instance-id*] **mpls traffic-eng advertisements**

Syntax Description

instance	*instance-id*	(Optional) Displays the latest flooded record from MPLS TE for the specified IS-IS instance only. • The *instance-id* argument is the instance identifier (alphanumeric) defined by the **router isis** command.

Command Default

No instance ID specified displays the latest flooded record from MPLS TE for all the IS-IS instances.

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show isis mpls traffic-eng advertisements** command to verify that MPLS TE is flooding its record and that the bandwidths are correct.

Task ID

Task ID	Operations
isis	read

Examples

The following is sample output from the **show isis mpls traffic-eng advertisements** command with the **instance** and *instance-id* values specified:

```
RP/0/RSP0/CPU0:router# show isis instance isp mpls traffic-eng advertisements

 ISIS isp Level-2 MPLS Traffic Engineering advertisements
       System ID: router-9
       Router ID: 172.18.0.9
       Link Count: 1
         Link[0]
           Neighbor System ID: router-gsr6 (P2P link)
           Interface IP address: 172.18.0.9
           Neighbor IP Address: 172.18.0.6
           Admin. Weight: 0
           Physical BW: 155520000 bits/sec
```

```
Reservable BW global: 10000000 bits/sec
Reservable BW sub: 0 bits/sec
Global pool BW unreserved:
  [0]: 10000000 bits/sec, [1]: 10000000 bits/sec
  [2]: 10000000 bits/sec, [3]: 10000000 bits/sec
  [4]: 10000000 bits/sec, [5]: 10000000 bits/sec
  [6]: 10000000 bits/sec, [7]: 10000000 bits/sec
Sub pool BW unreserved:
  [0]: 0 bits/sec, [1]: 0 bits/sec
  [2]: 0 bits/sec, [3]: 0 bits/sec
  [4]: 0 bits/sec, [5]: 0 bits/sec
  [6]: 0 bits/sec, [7]: 0 bits/sec
Affinity Bits: 0x00000000
```

This table describes the significant fields shown in the display.

Table 16: show isis instance isp mpls traffic-eng advertisements Field Descriptions

Field	Description
System ID	Dynamic hostname of the system. The hostname is specified using the **hostname** command. If the dynamic hostname is not known or if the **hostname dynamic disable** command has been executed, the 6-octet system ID is used.
Router ID	MPLS TE router ID.
Link Count	Number of links that MPLS TE advertised.
Neighbor System ID	System ID of a neighbor number in an area. The six bytes directly preceding the n-selector are the system ID. The system ID length is a fixed size and cannot be changed. The system ID must be unique throughout each area (Level 1) and throughout the backbone (Level 2). In an IS-IS routing domain, each router is represented by a 6-byte hexadecimal system ID. When network administrators maintain and troubleshoot networking devices, they must know the router name and corresponding system ID.
Interface IP address	IP address of the interface.
Neighbor IP Address	IP address of the neighbor.
Admin. Weight	Administrative weight associated with this link.
Physical BW	Link bandwidth capacity (in bits per second).
Reservable BW	Reservable bandwidth on this link.
Global pool BW unreserved	Unreserved bandwidth that is available in the global pool.
Sub pool BW unreserved	Amount of unreserved bandwidth that is available in the subpool.
Affinity Bits	Link attribute flags being flooded. Bits are MPLS-TE specific.

Related Commands

Command	Description
show isis mpls traffic-eng adjacency-log, on page 189	Displays a log of MPLS TE adjacency changes for IS-IS.

show isis neighbors

To display information about Intermediate System-to-Intermediate System (IS-IS) neighbors, use the **show isis neighbors** command in EXEC mode.

show isis [**instance** *instance-id*] **neighbors** [*type interface-path-id* | **summary**] [**detail**] [**systemid** *system-id*]

Syntax Description

instance *instance-id*	(Optional) Displays the IS-IS neighbor information for the specified IS-IS instance only. • The *instance-id* argument is the instance identifier (alphanumeric) defined by the **router isis** command.
type	Interface type. For more information, use the question mark (**?**) online help function.
interface-path-id	Physical interface or virtual interface. **Note** Use the **show interfaces** command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (**?**) online help function.
summary	(Optional) Displays neighbor status count for each level.
detail	(Optional) Displays additional details.
systemid *system-id*	(Optional) Displays the information for the specified neighbor only.

Command Default

No instance ID specified displays neighbor information for all the IS-IS instances.

Both Level 1 and Level 2 are configured if no level is specified.

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
isis	read

Examples

The following is sample output from the **show isis neighbors** command with the **instance** and *instance-id* values specified:

```
Total neighbor count: 3
RP/0/RSP0/CPU0:router# show isis instance isp neighbors detail

IS-IS isp neighbors:
System Id      Interface        SNPA           State Holdtime Type IETF-NSF
e222e          Gi0/1/0/0        *PtoP*         Up    23       L1   Capable
  Area Address(es): 00
  IPv4 Address(es): 10.1.0.45*
  IPv6 Address(es): fe80::212:daff:fe6b:68a8*
    Topologies: 'IPv4 Unicast'
  Uptime: 01:09:44
  IPFRR: LFA Neighbor: elise
         LFA IPv4 address: 10.100.1.2
         LFA Router address: 192.168.0.45
e333e Gi0/1/0/0.1      0012.da6b.68a8 Up    8        L1   Capable
e333e          Gi0/1/0/0.1      0012.da6b.68a8 Up    8        L1   Capable
  Area Address(es): 00
  IPv4 Address(es): 10.100.1.2*
  Topologies: 'IPv4 Unicast'
  Uptime: 01:09:46
  IPFRR: LFA Neighbor: elise
         LFA IPv4 address: 10.1.0.45
         LFA Router address: 192.168.0.45
         LFA Interface: Gi0/1/0/0
m44i           Gi0/1/0/1        0012.da62.e0a8 Up    7        L1   Capable
  Area Address(es): 00 11
  IPv4 Address(es): 10.1.2.47*
  IPv6 Address(es): fe80::212:daff:fe62:e0a8*
    Topologies: 'IPv4 Unicast'
  Uptime: 01:09:33

Total neighbor count: 3
```

This table describes the significant fields shown in the display.

Table 17: show isis instance isp neighbors Field Descriptions

Field	Description
System ID	Dynamic hostname of the system. The hostname is specified using the **hostname** command. If the dynamic hostname is not known or **hostname dynamic disable** command has been executed, the 6-octet system ID is used.
Interface	Interface through which the neighbor is reachable.
SNPA	Data-link address (also known as the Subnetwork Point of Attachment [SNPA]) of the neighbor.
State	Adjacency state of the neighboring interface. Valid states are: Down, Init, and Up.
Holdtime	Hold time of the neighbor.
Type	Type of adjacency.

Field	Description
IETF-NSF	Specifies whether the neighbor can adhere to the IETF-NSF restart mechanism. Valid states are Capable and Unable.
Area Address(es)	Number of area addresses on this router.
IPv4 Address(es)	IPv4 addresses configured on this router.
Topologies	Address and subaddress families for which IS-IS is configured.
Uptime	Time (in hh:mm:ss) that the neighbor has been up.
IPFRR: LFA Neighbor	IP fast reroute (IPFRR) loop-free alternate (LFA) neighbor.
LFA IPv4 address:	Address of the LFA.
LFA Interface:	LFA interface.

The following is sample output from the **show isis neighbors** command with the **summary** keyword specified:

```
RP/0/RSP0/CPU0:router# show isis instance isp neighbors summary

ISIS isp neighbor summary:
    State          L1       L2     L1L2
    Up              0        0        2
    Init            0        0        0
    Failed          0        0        0
```

This table describes the significant fields shown in the display.

Table 18: show isis neighbors summary Field Descriptions

Field	Description
State	State of the neighbor is up, initialized, or failed.
L1	Number of Level 1 neighbors.
L2	Number of Level 2 neighbors.
LlL2	Number of Level 1 and 2 neighbors.

Related Commands

Command	Description
show isis adjacency, on page 163	Displays IS-IS adjacencies.

show isis protocol

To display summary information about an Intermediate System-to-Intermediate System (IS-IS) instance, use the **show isis protocol** command in EXEC mode.

show isis [**instance** *instance-id*] **protocol**

Syntax Description

instance *instance-id*	(Optional) Displays the IS-IS adjacencies for the specified IS-IS instance only. • The *instance-id* argument is the instance identifier (alphanumeric) defined by the **router isis** command.

Command Default

No instance ID specified displays IS-IS adjacencies for all the IS-IS instances.

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 24.2.1	This command was was modified. The fields to indicate the memory state of the IS-IS protocol were included.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
isis	read

Examples

The following is sample output from the **show isis protocol** command:

```
Router# show isis protocol

IS-IS Router: isp
      System Id: 0001.0000.0011
      IS Levels: level-1-2
      Manual area address(es):
        49

      Routing for area address(es):
        49
      Non-stop forwarding: Cisco Proprietary NSF Restart enabled
      Process startup mode: Cold Restart
      Topologies supported by IS-IS:
        IPv4 Unicast
          Level-1 iSPF status: Dormant (awaiting initial convergence)
              Level-2 iSPF status: Dormant (awaiting initial convergence)
          No protocols redistributed
```

```
            Distance: 115
          Interfaces supported by IS-IS:
            Loopback0 is running passively (passive in configuration)
            GigabitEthernet 0/4/0/1 is running actively (active in configuration)
            GigabitEthernet 0/5/0/1 is running actively (active in configuration)
Memory state: Normal
     Last change: 2024 Jan 27 23:05:48.952
     Last memory usage/limit: 608032/1610612400 0%
   Memory state monitoring interval: 60 s
   Memory usage/limit: 19983152/1610612400 1%
   Memory usage specifics (count/bytes):
     Nodes: 3/1104     /* Nodes are using 1,104 bytes across 3 nodes.*/
     LSPs: 3/1248      /* LSPs are using 1,248 bytes across 3 LSPs.*/
     Links: 12/14592   /* Links are using 14,592 bytes across 12 links.*/
     Prefixes: 12/3264 /* Prefixes are using 3,264 bytes across 12 prefixes. */
     Nets: 8/4640      /* Nets are using 4,640 bytes across 8 nets.*/
    Paths: 0/0        /* Paths are currently not using any memory (0 bytes across 0 paths).
 */
```

This table describes the significant fields shown in the display.

Table 19: show isis protocol Field Descriptions

Field	Description
System ID:	Dynamic hostname of the system. The hostname is specified using the **hostname** command. If the dynamic hostname is not known or **hostname dynamic disable** command has been executed, the 6-octet system ID is used.
IS Levels:	IS-IS level of the router.
Manual area address(es)	Area addresses that are manually configured.
Routing for areaaddress(es)	Area addresses for which this router provides the routing.
Non-stop forwarding:	Status and name of nonstop forwarding (NSF).
Process startup mode:	Mode in which the last process startup occurred. Valid modes are: • Cisco Proprietary NSF Restart • IETF NSF Restart • Cold Restart

Field	Description
iSPF status:	State of incremental shortest path first (iSPF) configuration for this IS-IS instance. Four states exist: Disabled if iSPF has not been configured but is awaiting a full SPF to compile the topology for use by the iSPF algorithm. Dormant if iSPF has been configured but is awaiting initial convergence before initializing. Awake if iSPF has been configured but is awaiting a full SPF to compile the topology for use by the iSPF algorithm. Active if IS-IS is ready to consider using the iSPF algorithm whenever a new route calculation needs to be run.
No protocols redistributed:	No redistributed protocol information exists to be displayed.
Distance:	Administrative distance for this protocol.
Memory state	Current status of memory usage for IS-IS process.
Last change	Timestamp of the last change in memory state.
Last memory usage/limit	The previous recorded memory usage in bytes and the maximum memory limit. The percentage shows the proportion of the limit used.
Memory state monitoring interval	The frequency at which the memory state is checked for the IS-IS process.
Memory usage/limit	The current memory usage against the maximum memory limit for the IS-IS process. The percentage shows the current proportion of the limit used.
Memory usage specifics (count/bytes)	A detailed breakdown of memory usage by various components or functions within the IS-IS process, indicating the count and memory consumption.
Nodes	Number of nodes and memory in bytes used by the nodes.
LSPs	Number of nodes and memory in bytes used by the LSPs.
Links	Number of nodes and memory in bytes used by the links.
Prefixes	Number of nodes and memory in bytes used by the prefixes.
Nets	Number of nodes and memory in bytes used by the network entities.
Paths	Number of nodes and memory in bytes used by the paths.

show isis route

To display IP reachability information for an Intermediate System-to-Intermediate System (IS-IS) instance, use the **show isis route** command in EXEC mode.

show isis [**instance** *instance-id*] [**ipv4** | **ipv6** | **afi-all**] [**unicast** | **multicast** [**topology** {**all***topo-name*}] | **safi-all**] **route** [*ip-address mask* | *ip-address*/*length* [**longer-prefixes**]] [**summary**] **[multicast-intact]** [**backup**] [**detail**] [**sr-only**]

Syntax Description

instance *instance-id*	(Optional) Displays the IP reachability information for the specified IS-IS instance only. • The *instance-id* argument is the instance identifier (alphanumeric) defined by the **router isis** command.
ipv4	(Optional) Specifies IP Version 4 address prefixes.
ipv6	(Optional) Specifies IP Version 6 address prefixes.
afi-all	(Optional) Specifies all address prefixes.
unicast	(Optional) Specifies unicast address prefixes.
multicast	(Optional) Specifies multicast address prefixes.
topology	(Optional) Specifies IS-IS paths to intermediate systems.
all	(Optional) Specifies all topologies.
topology *topo-name*	(Optional) Specifies topology table information and name of the topology table.
safi-all	(Optional) Specifies all secondary address prefixes.
ip-address	(Optional) Network IP address about which routing information should be displayed.
mask	(Optional) Network mask specified in either of two ways: • Network mask can be a four-part, dotted decimal address. For example, 255.0.0.0 indicates that each bit equal to 1 means the corresponding address bit is a network address. • Network mask can be indicated as a slash (/) and number. For example, /8 indicates that the first 8 bits of the mask are ones, and the corresponding bits of the address are the network address.
/ length	(Optional) Length of the IP prefix. A decimal value that indicates how many of the high-order contiguous bits of the address compose the prefix (the network portion of the address). A slash must precede the decimal value. Range is 0 to 32.
longer-prefixes	(Optional) Displays route and more-specific routes.
summary	(Optional) Displays topology summary information.

multicast-intact	(Optional) Displays multicast intact information for this entry.
systemid	(Optional) Displays multicast information by system ID.
backup	(Optional) Displays information about ISIS routes not selected for installation in the RIB.
detail	(Optional) Displays link-state packet (LSP) details.
sr-only	(Optional) Displays SR-labeled prefixes only.

Command Default

No instance ID specified displays the IP reachability information for all the IS-IS instances.

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	Support for IPv6 was added.
Release 6.3.2	The **sr-only** keyword was added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
isis	read

Examples

The following is sample output from the **show isis route** command:

```
RP/0/RSP0/CPU0:router# show isis route

IS-IS isp IPv4 Unicast routes
Codes: L1 - level 1, L2 - level 2, ia - interarea (leaked into level 1)
df - level 1 default (closest attached router), su - summary null
C - connected, S - static, R - RIP, B - BGP, O - OSPF
i - IS-IS (redistributed from another instance)

Maximum parallel path count: 8

L2 10.76.240.6/32 [4/115]
via 10.76.245.252, SRP0/1/0/2, isp2
via 10.76.246.252, SRP0/1/0/0, isp2
C 10.76.240.7/32
is directly connected, Loopback0
L2 10.76.240.9/32 [256/115]
via 10.76.249.2, GigabitEthernet 0/3/0/0, isp3
L2 10.76.240.10/32 [296/115]
via 10.76.249.2, GigabitEthernet 0/3/0/0, isp3
C 10.76.245.0/24
```

```
  is directly connected, SRP0/1/0/2
  C 10.76.246.0/24
  is directly connected, SRP0/1/0/0
  C 10.76.249.0/26
  is directly connected, GigabitEthernet 0/3/0/0
  L2 10.101.10.0/24 [296/115]
  via 10.76.249.2, GigabitEthernet 0/3/0/0, isp3
```

This table describes the significant fields shown in the display.

Table 20: show isis route ipv4 unicast Field Descriptions

Field	Description
C172.18.0.0/24	Connected route for GigabitEthernet interface 0/5/0/0.
C 172.19.1.0/24	Connected route for GigabitEthernet interface 0/4/0/1.
L1 172.35.0.0/24 [10]	Level 1 route to network 172.35.0.0/24.
C 172.18.0/24	Connected route for loopback interface 0.

This is sample output from the **show isis route** command with **sr-only** keyword that shows only routes associated with a segment routing prefix SID:

```
RP/0/RSP0/CPU0:router# show isis route sr-only

IS-IS 1 IPv4 Unicast routes

Codes: L1 - level 1, L2 - level 2, ia - interarea (leaked into level 1)
       df - level 1 default (closest attached router), su - summary null
       C - connected, S - static, R - RIP, B - BGP, O - OSPF
       E - EIGRP, A - access/subscriber, M - mobile, a - application
       i - IS-IS (redistributed from another instance)

Maximum parallel path count: 8

C  20.1.0.100/32
     is directly connected, Loopback0
L2 20.1.0.101/32 [10/115]
     via 10.1.1.101, GigabitEthernet0/0/0/2, r101, SRGB Base: 16000, Weight: 0
L2 20.1.0.102/32 [30/115]
     via 10.1.1.101, GigabitEthernet0/0/0/2, r101, SRGB Base: 16000, Weight: 0
L2 20.1.0.103/32 [20/115]
     via 10.4.1.103, GigabitEthernet0/0/0/1, r103, SRGB Base: 16000, Weight: 0
```

show isis spf-log

To display how often and why the router has run a full shortest path first (SPF) calculation, use the **show isis spf-log** command in EXEC mode.

show isis [**instance** *instance-id*] [[**ipv4** | **ipv6** | **afi-all**] [**unicast** | **multicast** [**topology** { **all** *topo-name* }] | **safi-all**]] **spf-log** [**level** { **1** | **2** }] [**ispf** | **fspf** | **prc** | **nhc**] [**detail** | **verbose** | **plfrr** | **ppfrr**] [**last** *number* | **first** *number*]

Syntax Description

instance *instance-id*	(Optional) Displays the IS-IS SPF log for the specified IS-IS instance only.
ipv4	(Optional) Specifies IP Version 4 address prefixes.
ipv6	(Optional) Specifies IP Version 6 address prefixes.
afi-all	(Optional) Specifies all address prefixes.
unicast	(Optional) Specifies unicast address prefixes.
multicast	(Optional) Specifies multicast address prefixes.
topology all | *topo-name*	(Optional) Specifies topology table information for all topologies or for the specified topology table (*top-name*).
safi-all	(Optional) Specifies all secondary address prefixes.
level { **1** | **2** }	(Optional) Displays the IS-IS SPF log for Level 1 or Level 2 independently.
ispf	(Optional) Specifies incremental SPF entries only.
fspf	(Optional) Specifies full SPF entries only.
prc	(Optional) Specifies partial route calculations only.
nhc	(Optional) Specifies next-hop route calculations only.
detail	(Optional) Specifies detailed output. Includes a breakdown of the time taken to perform the calculation and changes resulting from the calculation.
verbose	(Optional) Specifies verbose output.
last *number*	(Optional) Specifies that the output is restricted to the last *number* of entries. Range is 1 to 210.
first *number*	(Optional) Specifies that the output is restricted to the first *number* of entries. Range is 1 to 210.

Command Default

No instance ID specified displays IS-IS adjacencies for all the IS-IS instances.

Both Level 1 and Level 2 are configured if no level is specified.

Displays all types of route calculation (not just fspf, ispf, and prc).

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	Support for IPv6 was added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
isis	read

Examples

The following is sample output from the **show isis spf-log** command:

```
Router# show isis spf-log

      IS-IS 1 Level 1 IPv4 Unicast Route Calculation Log
                  Time  Total Trig
 Timestamp   Type (ms)  Nodes Count First Trigger LSP Triggers
 ----------- ---- ----  ----- ----- ----- ------- --- --------
 --- Thurs Aug 19 2004 ---
 12:00:50.787  FSPF  1    1     3   ensoft-grs7.00-00 LSPHEADER TLVCODE
 12:00:52.846  FSPF  1    1     1   ensoft-grs7.00-00 LSPHEADER
 12:00:56.049  FSPF  1    1     1   ensoft-grs7.00-00 TLVCODE
 12:01:02.620  FSPF  1    1     2   ensoft-grs7.00-00 NEWADJ LINKTLV

      IS-IS 1 Level 1 IPv4 Unicast Route Calculation Log
                  Time  Total Trig
 Timestamp   Type (ms)  Nodes Count First Trigger LSP Triggers
 ----------- ---- ----  ----- ----- ----- ------- --- --------
 --- Mon Aug 19 2004 ---
 12:00:50.790  FSPF  0    1     4   ensoft-grs7.00-00 LSPHEADER TLVCODE
 12:00:54.043  FSPF  1    1     2   ensoft-grs7.00-00 NEWADJ LSPHEADER
 12:00:55.922  FSPF  1    2     1   ensoft-grs7.00-00 NEWLSPO
 12:00:56.724  FSPF  1    13    1   ensoft-grs7.00-00 NEWLSPO
```

This table describes the significant fields shown in the display.

Table 21: show isis spf-log ipv4 unicast Field Descriptions

Field	Description
Level	IS-IS level of the router.
Timestamp	Time when the SPF calculation started.
Duration	Number of milliseconds taken to complete this SPF run. Elapsed time is wall clock time, not CPU time.

Field	Description
Nodes	Number of routers and pseudonodes (LANs) that make up the topology calculated in this SPF run.
Trig Count	Number of events that triggered this SPF run. When there is a topology change, often multiple link-state packets (LSPs) are received in a short time. Depending on the configuration of the **spf-interval** command, a router may wait for a fixed period of time before running a router calculation. This count denotes the number of triggering events that occurred while the router was waiting to run the calculation. For a full description of the triggering events, see *List of Triggers*.
First Trigger LSP	LSP ID stored by the router whenever a full SPF calculation is triggered by the arrival of a new LSP. The LSP ID can suggest the source of routing instability in an area. If multiple LSPs are causing an SPF run, only the LSP ID of the first received LSP is remembered.
Triggers	List of all reasons that triggered a full SPF calculation. For a list of possible triggers, see *List of Triggers*.

This table lists triggers of a full SPF calculation.

Table 22: List of Triggers

Trigger	Description
PERIODIC	Runs a full SPF calculation very 15 minutes.
NEWLEVEL	Configured new level (using is-type) on this router.
RTCLEARED	Cleared IS-IS topology on the router.
MAXPATHCHANGE	Changed IP maximum parallel path.
NEWMETRIC	Changed link metric.
ATTACHFLAG	Changed Level 2 Attach bit.
ADMINDIST	Configured another administrative distance for the IS-IS instance on this router.
NEWADJ	Created a new adjacency to another router.
DELADJ	Deleted adjacency.
BACKUP	Installed backup route.
SEEDISPF	Seed incremental SPF.
NEXTHOP	Changed IP next-hop address.
NEWLSP0	New LSP 0 appeared in the topology.
LSPEXPIRED	Some LSP in the link-state database (LSDB) has expired.
LSPHEADER	Changed important LSP header fields.

Trigger	Description
TLVCODE	Type, length, and value (TLV) objects code mismatch, indicating that different TLV objects are included in the newest version of an LSP.
LINKTV	Changed Link TLV content.
PREFIXTLV	Changed Prefix TLV content.
AREAADDRTLV	Changed Area address TLV content.
IP ADDRTLV	Changed IP address TLV content.
TUNNEL	Changed RRR tunnel.

The following is sample output from the **show isis spf-log** command with the **first** keyword specified:

```
Router# show isis spf-log first 2

    IISIS isp Level 1 IPv4 Unicast Route Calculation Log
                 Time  Total Trig
Timestamp   Type (ms)  Nodes Count First Trigger LSP   Triggers
  Mon Aug 16 2004
19:25:35.140  FSPF  1    1     1             12a5.00-00 NEWLSP0
19:25:35.646  FSPF  1    1     1                         NEWADJ


   IISIS isp Level 2  IPv4 Unicast Route Calculation Log
                 Time  Total Trig
Timestamp   Type (ms)  Nodes Count First Trigger LSP   Triggers
  Mon Aug 16 2004
19:25:35.139  FSPF  1    1     1             12a5.00-00 NEWLSP0
19:25:35.347  FSPF  1    1     2             12a5.00-00 NEWSADJ TLVCODE
```

This table describes the significant fields shown in the display.

Table 23: show isis spf-log first Field Descriptions

Field	Description
Level	IS-IS level of the router.
Timestamp	Time at which the SPF calculation started.
Type	Type of route calculation. The possible types are incremental SPF (iSPF),full SPF (FSPF), or partial route calculation (PRC).
Time (ms)	Number of milliseconds taken to complete this SPF run. Elapsed time is wall clock time, not CPU time.
Nodes	Number of routers and pseudonodes (LANs) that make up the topology calculated in this SPF run.

Field	Description
Trig Count	Number of events that triggered this SPF run. When there is a topology change, often multiple link-state packets (LSPs) are received in a short time. Depending on the configuration of the **spf-interval** command, a router may wait for a fixed period of time before running a router calculation. This count denotes the number of triggering events that occurred while the router was waiting to run the calculation. For a full description of the triggering events, see *List of Triggers*.
First Trigger LSP	LSP ID stored by the router whenever a full SPF calculation is triggered by the arrival of a new LSP. The LSP ID can suggest the source of routing instability in an area. If multiple LSPs are causing an SPF run, only the LSP ID of the first received LSP is remembered.
Triggers	List of all reasons that triggered a full SPF calculation. For a list of possible triggers, see *List of Triggers*.

The following is sample output from the **show isis spf-log** command with the **detail** keyword specified:

```
Router# show isis spf-log detail

    IISIS isp Level 1 IPv4 Unicast Route Calculation Log
                Time  Total Trig
Timestamp   Type (ms)  Nodes Count First Trigger LSP   Triggers
  Mon Aug 16 2004
19:25:35.140  FSPF  1    1     1             12a5.00-00 NEWLSP0
  Delay:              51ms (since first trigger)
  SPT Calculation
    CPU Time:         0ms
    Real Time:        0ms
  Prefix Updates
    CPU Time:         1ms
    Real Time:        1ms
  New LSP Arrivals:    0
  Next Wait Interval: 200ms
                            Results
                       Reach Unreach Total
   Nodes:                  1       0     1
   Prefixes (Items)
     Critical Priority:    0       0     0
     High Priority:        0       0     0
     Medium Priority       0       0     0
     Low Priority          0       0     0

     All Priorities        0       0     0
   Prefixes (Routes)
     Critical Priority:    0       -     0
     High Priority:        0       -     0
     Medium Priority       0        -    0
     Low Priority:         0        -    0

     All Priorities        0        -    0
```

This table describes the significant fields shown in the display.

Table 24: show isis spf-log detail Field Descriptions

Field	Description
Level	IS-IS level of the router.
Timestamp	Time at which the SPF calculation started.
Type	Type of route calculation. The possible types are incremental ispf, full SPF (FSPF), or partial route calculation (PRC).
Time (ms)	Number of milliseconds taken to complete this SPF run. Elapsed time is wall clock time, not CPU time.
Nodes	Number of routers and pseudonodes (LANs) that make up the topology calculated in this SPF run.
Trig Count	Number of events that triggered this SPF run. When there is a topology change, often multiple link-state packets (LSPs) are received in a short time. Depending on the configuration of the **spf-interval** command, a router may wait for a fixed period of time before running a router calculation. This count denotes the number of triggering events that occurred while the router was waiting to run the calculation. For a full description of the triggering events, see *List of Triggers*.
First Trigger LSP	LSP ID stored by the router whenever a full SPF calculation is triggered by the arrival of a new LSP. The LSP ID can suggest the source of routing instability in an area. If multiple LSPs are causing an SPF run, only the LSP ID of the first received LSP is remembered.
Triggers	List of all reasons that triggered a full SPF calculation. For a list of possible triggers, see *List of Triggers*.
Delay	Two different delays exist: **1.** The delay between the time when the route calculation was first triggered and the time when it was run. **2.** The delay between the end of the last route calculation and the start of this one. This is used to verify that the SPF-interval timers are working correctly, and is only reported for calculations after the first delay.
CPU Time	Two different CPU times exist: **1.** CPU time (in milliseconds) taken to calculate the shortest path tree (SPT). **2.** CPU time (in milliseconds) taken to perform the prefix updates.
Real Time	Two different real times exist: **1.** Real time (in milliseconds) taken to calculate the shortest path tree (SPT). **2.** Real time (in milliseconds) taken to perform the prefix updates.
New LSP Arrivals	Number of LSP arrivals since the start of this route calculation.

Field	Description
Next Wait Interval	Enforced delay until the next route calculation can be run, based on the **spf-interval** command configuration.
Reach	Number of reachable nodes or prefixes.
Unreach	Number of unreachable nodes or prefixes.
Total	Total number of nodes or prefixes at various priorities.

Related Commands

Command	Description
spf-interval, on page 224	Sets IS-IS throttling of shortest path first (SPF) calculations.

show isis statistics

To display Intermediate System-to-Intermediate System (IS-IS) traffic counters, use the **show isis statistics** command in EXEC mode.

show isis [**instance** *instance-id*] **statistics** [*type interface-path-id*]

Syntax Description

instance *instance-id*	(Optional) Displays the IS-IS traffic statistics for the specified IS-IS instance only. • The *instance-id* argument is the instance identifier (alphanumeric) defined by the **router isis** command.
type	Interface type. For more information, use the question mark (**?**) online help function.
interface-path-id	Physical interface or virtual interface. **Note** Use the **show interfaces** command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (**?**) online help function.

Command Default

No instance ID specified displays IS-IS traffic statistics for all the IS-IS instances.

IS-IS traffic statistics are displayed for all interfaces.

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

The **show isis statistics** command displays IS-IS traffic counters for the specified interface or all traffic counters if no interface is specified.

Task ID

Task ID	Operations
isis	read

Examples

The following is sample output from the **show isis statistics** command that shows all traffic counters:

```
Router#show isis statistics
IS-IS isp statistics:
  Fast PSNP cache (hits/tries): 164115/301454
```

```
Fast CSNP cache (hits/tries): 41828/43302
Fast CSNP cache updates: 2750
LSP checksum errors received: 0
LSP Dropped: 1441
SNP Dropped: 1958
UPD Max Queue size: 2431
Average transmit times and rate:
  Hello:          0 s,     987947 ns,          4/s
  CSNP:           0 s,    1452987 ns,          0/s
  PSNP:           0 s,    1331690 ns,          0/s
  LSP:            0 s,    1530018 ns,          1/s
Average process times and rate:
  Hello:          0 s,     874584 ns,         41/s
  CSNP:           0 s,     917925 ns,         29/s
  PSNP:           0 s,    1405458 ns,          0/s
  LSP:            0 s,    4352850 ns,          0/s
Level-1:
  LSPs sourced (new/refresh): 3376/2754
  IPv4 Unicast
    SPF calculations           : 520
    ISPF calculations          : 0
    Next-hop Calculations      : 0
    Partial Route Calculations : 0
Level-2:
  LSPs sourced (new/refresh): 4255/3332
  IPv4 Unicast
    SPF calculations           : 432
    ISPF calculations          : 0
    Next-hop Calculations      : 8
    Partial Route Calculations : 0
Interface GigabitEthernet0/1/0/1.1:
Level-1 Hellos (sent/rcvd): 22398/25633
Level-1 DR Elections      : 66
Level-1 LSPs (sent/rcvd)  : 246/7077
Level-1 CSNPs (sent/rcvd) : 0/33269
Level-1 PSNPs (sent/rcvd) : 22/0
Level-1 LSP Flooding Duplicates  : 25129
Level-2 Hellos (sent/rcvd): 22393/67043
Level-2 DR Elections      : 55
Level-2 LSPs (sent/rcvd)  : 265/437
Level-2 CSNPs (sent/rcvd) : 0/86750
Level-2 PSNPs (sent/rcvd) : 0/0
Level-2 LSP Flooding Duplicates  : 78690
```

This table describes the significant fields shown in the display.

Table 25: show isis statistics Field Descriptions

Field	Description
Fast PSNP cache (hits/tries)	Number of successful lookups (hits) along with the number of lookup attempts (tries). To save time or processing power when receiving multiple copies of the same LSP, IS-IS attempts to look up incoming LSPs to see if they have been received recently.
Fast CSNP cache (hits/tries)	Number of successful lookups (hits) along with the number of lookup attempts (tries). To reduce CSNP construction time, IS-IS maintains a cache of CSNPs and attempts to look up CSNP in this cache before transmission on the interface.

Field	Description
Fast CSNP cache updates	Number of times the CSNP cache has been updated since the last clearing of statistics. The cache is updated on LSP addition or removal from the database.
LSP checksum errors received	Number of internal checksum errors received in LSPs.
IIH (LSP/SNP) dropped	Number of hello, LSP, and SNP messages dropped.
IIH (UPD) Max Queue size	Maximum number of queued packets.
Average transmit times and rate	Average time taken to transmit the pdu type across all interfaces and the corresponding rate at which the pdu type is being transmitted.
Average process times and rate	Average time taken to process an incoming pdu type across all interfaces and the corresponding rate at which the pdu type is being received.
LSPs sourced (new/refresh)	Number of LSPs this IS-IS instance has created or refreshed. To find more details on these LSPs, use the **show isis lsp-log** command.
SPF calculations	Number of shortest path first (SPF) calculations. SPF calculations are performed only when the topology changes. They are not performed when external routes change. The interval at which SPF calculations are performed is configured using the **spf-interval** command.
iSPF calculations	Number of incremental shortest path first (iSPF) calculations. iSPF calculations are performed only when ISPF has been configured in the isis address family configuration submode.
Partial Route Calculations	Number of partial route calculations (PRCs). PRCs are processor intensive. Therefore, it may be useful to limit their number, especially how often a PRC is done, especially on slower networking devices. Increasing the PRC interval reduces the processor load on the router, but might slow the rate of convergence. The interval at which PRC calculations are performed is configured using the **spf-interval** command.
Level-(1/2) (LSPs/CSNPs/PSNPs/Hellos) (sent/rcvd)	Number of LSPs, Complete Sequence Number Packets (CSNPs), Partial Sequence Number Packets (PSNPs), and hello packets sent or received on this interface.
PTP Hellos (sent/rcvd)	Point-to-point (PTP) hellos sent and received.
LSP Retransmissions	Total number of retransmissions on each IS-IS LSP on a point-to-point interface. The LSP retransmission interval can be configured using the **retransmit-throttle-interval** command.
Level-(1.2) DRElections	Total number of Designated Intermediate System elections that have taken place. These counts are maintained on an individual level basis.
LSP Flooding Duplicates	Number of duplicate LSPs filtered from flooding to the neighbor. In case of parallel interfaces to the same neighbor, IS-IS optimizes the flooding by avoiding sending the same LSP copy on other interfaces.

Related Commands

Command	Description
show isis spf-log, on page 203	Displays how often and why the router has run a full SPF calculation.
spf-interval, on page 224	Sets IS-IS throttling of shortest path first (SPF) calculations.

show isis topology

To display a list of connected Intermediate System-to-Intermediate System (IS-IS) routers in all areas, use the **show isis topology** command in EXEC mode.

show isis [**instance instance-id**] [[**ipv4** | **ipv6** | **afi-all**] [**unicast** | **multicast** [**topology** {**all** | **topo-name**}] | **safi-all**]] | **summary** | **level** {**1** | **2**} **[multicast-intact]** [**systemid system-id**] [**detail**]

Syntax Description

instance *instance-id*	(Optional) Displays the IS-IS topology for the specified IS-IS instance only. • The *instance-id* argument is the instance identifier (alphanumeric) defined by the **router isis** command.
ipv4	(Optional) Specifies IP Version 4 address prefixes.
ipv6	(Optional) Specifies IP Version 6 address prefixes.
afi-all	(Optional) Specifies all address prefixes.
unicast	(Optional) Specifies unicast address prefixes.
multicast	(Optional) Specifies multicast address prefixes.
topology *topo-name*	(Optional) Specifies topology table information and name of the topology table.
safi-all	(Optional) Specifies all secondary address prefixes.
summary	(Optional) Displays a brief list of the IS-IS topology.
level { **1** | **2** }	(Optional) Displays the IS-IS link-state topology for Level 1 or Level 2 independently.
multicast-intact	(Optional) Displays multicast intact information on the IS-IS topology.
systemid *system-id*	(Optional) Displays the information for the specified router only.
detail	(Optional) Displays detailed information on the IS-IS topology.

Command Default

No instance ID specified displays a list of connected routers in all areas for all the IS-IS instances.

Both Level 1 and Level 2 is configured if no level is specified.

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	Support for IPv6 was added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **show isis topology** command to verify the presence and connectivity among all routers in all areas.

Use the **show isis topology flex-algo dataplane** command to display information on Flexible Algorithms.

Task ID

Task ID	Operations
isis	read

Examples

The following is sample output from the **show isis topology** command:

```
RP/0/RSP0/CPU0:router# show isis topology

IS-IS isp paths to (Level-1) routers
    System Id       Metric  Next-hop Interface       SNPA
    ensoft-5        10      ensoft-5        PO0/4/0/1       *PtoP*
    ensoft-5        10      ensoft-5        Gi0/5/0/0       0003.6cff.0680
    ensoft-11       --

    IS-IS isp paths to (Level-2) routers
    System Id       Metric  Next-hop Interface       SNPA
    ensoft-5        10      ensoft-5        PO0/4/0/1       *PtoP*
    ensoft-5        10      ensoft-5        Gi0/5/0/0       0003.6cff.0680
    ensoft-11       --
```

This table describes the significant fields shown in the display.

Table 26: show isis topology ipv4 unicast Field Descriptions

Field	Description
System ID	Dynamic hostname of the system. The hostname is specified using the **hostname** command. If the dynamic hostname is not known or **hostname dynamic disable** command has been executed, the 6-octet system ID is used.
Metric	Metric assigned to the link and used to calculate the cost from each router using the links in the network to other destinations. Range is 1 to 16777214. Default is 1 to 63 for narrow metric and 1 to 16777214 for wide metric. 0 is set internally if no metric has been specified by the user.
Next-hop	Address of the next-hop.
Interface	Interface used to reach the neighbor.
SNPA	Data-link address (also known as the Subnetwork Point of Attachment [SNPA]) of the neighbor.

The following is sample output from the **show isis topology** command with the **summary** keyword specified:

```
RP/0/RSP0/CPU0:router# show isis topology summary
```

```
IS-IS 10 IS Topology Summary IPv4 Unicast
                        L1                          L2
               Reach  UnReach  Total      Reach  UnReach  Total
              ------- ------- -------    ------- ------- -------
Router nodes:        1       1       2          1       1       2
Pseudo nodes:        0       0       0          0       0       0

 Total nodes:        1       1       2          1       1       2
```

This table describes the significant fields shown in the display.

Table 27: show isis topology summary Field Descriptions

Field	Description
L1/L2	IS-IS level of the router.
Reach	Number of router nodes or pseudonodes that are reachable.
UnReach	Number of router nodes or pseudonodes that are unreachable.
Total	Total number of reachable and unreachable nodes.

show protocols (IS-IS)

To group a number of protocol show commands according to the specified address family, use the **show protocols** command in EXEC mode.

show protocols [**afi-all** | **ipv4** | **ipv6**] [**all***protocol*]

Syntax Description

afi-all	(Optional) Specifies all address families.
ipv4	(Optional) Specifies an IPv4 address family.
ipv6	(Optional) Specifies an IPv6 address family.
all	(Optional) Specifies all protocols for a given address family.
protocol	(Optional) Specifies a routing protocol. For the IPv4 address family, the options are: • **bgp** • **isis** • **ospf** • **rip** • **eigrp** For the IPv6 address family, the options are: • **bgp** • **isis** • **ospfv3**

Command Default

If no address family is specified, the default is IPv4.

Command Modes

EXEC

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	Support for IPv6 was added

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

If IPv6 is enabled on an IS-IS instance, the instance is displayed in the **show protocols ipv6** command output. IPv4 IS-IS instances are displayed in the **show protocols ipv4** command output.

When using the **show protocols** command with the **ipv6** or **ipv4** keyword, you get all routing instances in that particular address family—not only IS-IS instances.

Task ID

Task ID	Operations
isis	read
rib	read

Examples

The following example shows the output for the **show protocols** command :

```
Router# show protocols ipv4

IS-IS Router: uut
  System Id: 0000.0000.12a8
  IS Levels: level-1-2
  Manual area address(es):
    49.1515.1515
  Routing for area address(es):
    49.1515.1515
  Non-stop forwarding: Disabled
  Most recent startup mode: Cold Restart
  Topologies supported by IS-IS:
    IPv4 Unicast
      Level-1
        Metric style (generate/accept): Narrow/Narrow
        ISPF Status: Disabled
      Level-2
        Metric style (generate/accept): Narrow/Narrow
        ISPF Status: Disabled
      Redistributing:
        static
      Distance: 115
    IPv6 Unicast
      Level-1
        ISPF Status: Disabled
      Level-2
        ISPF Status: Disabled
      No protocols redistributed
      Distance: 45
  Interfaces supported by IS-IS:
    GigabitEthernet 0/6/0/0 is running actively (active in configuration)
```

This table describes the significant fields shown in the display.

Table 28: show protocols ipv4 Field Descriptions

Field	Description
System ID	Dynamic hostname of the system. The hostname is specified using the **hostname** command. If the dynamic hostname is not known or **hostname dynamic disable** command has been executed, the 6-octet system ID is used.
IS Levels	IS-IS level of the router.
Manual area address(es)	Area addresses configured manually on the originating router.

Field	Description
Routing for area address(es)	Area addresses for which this router provides the routing.
Non-stop forwarding	Status and name of NSF.
Most recent startup mode	Mode in which the most recent startup was performed.
Topologies supported by IS-IS	Address and subaddress family IS-IS are configured.
Metric style	Type, length, and value (TLV) objects accepted by IS-IS. To configure this value, see the metric-style narrow, on page 104, metric-style transition, on page 106, or metric-style wide, on page 108 command.
ISPF status	State of iSPF configuration for this IS-IS instance. Four states exist: • Disabled if iSPF has not been configured but is awaiting a full SPF to compile the topology for use by the iSPF algorithm. • Dormant if iSPF has been configured but is awaiting initial convergence before initializing. • Awake if iSPF has been configured but is awaiting a full SPF to compile the topology for use by the iSPF algorithm. • Active if IS-IS is ready to consider using the iSPF algorithm whenever a new route calculation needs to be run.
Redistributing	IS-IS is configured to redistribute IP static routes into Level 1 or Level 2. The **redistribute** command is used to configure redistribution.
Distance	Administrative distance.
Interfaces supported by IS-IS	Interfaces and their states currently supported by IS-IS. Both operational and configuration status are displayed.

The following example shows how to disable the IPv4 address family, with no output shown for IS-IS IPv4 instances from the **show protocols ipv4** command:

```
Router# configure
Router(config)# router isis uut
Router(config-isis)# no address-family ipv4 unicast
Router(config-isis)# commit

Router# show protocols ipv4
```

Related Commands

Command	Description
metric-style narrow, on page 104	Configures the IS-IS software to generate and accept old-style type, length, and value (TLV) objects.
metric-style transition, on page 106	Configures the IS-IS software to generate and accept both old-style and new-style type length, and value (TLV) objects.
metric-style wide, on page 108	Configures the IS-IS software to generate and accept only new-style type, length, and value (TLV) objects.

Command	Description
redistribute (IS-IS), on page 142	Redistributes routes from one IS-IS instance into another instance.

shutdown (IS-IS)

To disable the Intermediate System-to-Intermediate System (IS-IS) protocol on a particular interface, use the **shutdown** command in interface configuration mode. To re-enable the IS-IS protocol, use the **no** form of this command.

shutdown
no shutdown

Command Default

IS-IS protocol is enabled.

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example disables the IS-IS protocol on GigabitEthernet interface 0/1/0/1:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet0/1/0/1
RP/0/RSP0/CPU0:router(config-isis-if)# shutdown
```

single-topology

To configure the link topology for IP Version 4 (IPv4) when IP Version 6 (IPv6) is configured, use the **single-topology** command in address family configuration mode. To remove the **single-topology** command from the configuration file and restore the system to its default condition, use the **no** form of this command.

single-topology
no single-topology

Command Default

Performs in multitopology mode in which independent topologies for IPv4 and IPv6 are running in a single area or domain.

Command Modes

IPv6 address family configuration

Command History

Release	Modification
Release 3.9.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **single-topology** command to allow Intermediate System-to-Intermediate System (IS-IS) for IPv6 to be configured on interfaces along with an IPv4 network protocol. All interfaces must be configured with the identical set of network protocols, and all routers in the IS-IS area (for Level 1 routing) or the domain (for Level 2 routing) must support the identical set of network layer protocols on all interfaces.

When single-topology support for IPv6 is being used, only old-style type, length, and value (TLV) objects may be used and a single shortest path (SPF) individual level is used to compute IPv4 (if configured) and IPv6 routes. The use of a single SPF means that both IPv4 IS-IS and IPv6 IS-IS routing protocols must share a network topology.

To allow link information to be shared between IPv4 and IPv6, you must configure the **single-topology** command for an address family. In single-topology IPv6 mode, the configured metric is always the same for both IPv4 and IPv6.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to enable single-topology mode for IPv6:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# net 49.0000.0000.0001.00
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv6 unicast
RP/0/RSP0/CPU0:router(config-isis-af)# single-topology
```

snmp-server traps isis

snmp-server traps isis {**all** | *traps set*}
no snmp-server traps isis {**all** | *traps set*}

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Examples

```
RP/0/RSP0/CPU0:router(config)# snmp-server traps isis

  adjacency-change                isisAdjacencyChange
  all                             Enable all IS-IS traps
  area-mismatch                   isisAreaMismatch
  attempt-to-exceed-max-sequence  isisAttemptToExceedMaxSequence
  authentication-failure          isisAuthenticationFailure
  authentication-type-failure     isisAuthenticationTypeFailure
  corrupted-lsp-detected          isisCorruptedLSPDetected
  database-overload               isisDatabaseOverload
  id-len-mismatch                 isisIDLenMismatch
  lsp-error-detected              isisLSPErrorDetected
  lsp-too-large-to-propagate      isisLSPTooLargeToPropagate
  manual-address-drops            isisManualAddressDrops
  max-area-addresses-mismatch     isisMaxAreaAddressesMismatch
  orig-lsp-buff-size-mismatch     isisOrigLSPBuffSizeMismatch
  own-lsp-purge                   isisOwnLSPPurge
  protocols-supported-mismatch    isisProtocolsSupportedMismatch
  rejected-adjacency              isisRejectedAdjacency
  sequence-number-skip            isisSequenceNumberSkip
  version-skew                    isisVersionSkew

RP/0/RSP0/CPU0:router(config)#snmp-server traps isis all
```

```
RP/0/RSP0/CPU0:router(config)# snmp-server traps isis area-mismatch
lsp-error-detected
```

spf-interval

To customize IS-IS throttling of shortest path first (SPF) calculations, use the **spf-interval** command in address family configuration mode. To restore default values, use the **no** form of this command.

spf-interval [**initial-wait** *initial* | **secondary-wait** *secondary* | **maximum-wait** *maximum*] **. . .** [**level** {**1** | **2**}]
no spf-interval [[**initial-wait** *initial* | **secondary-wait** *secondary* | **maximum-wait** *maximum*] **. . .**] [**level** {**1** | **2**}]

Syntax Description

initial-wait *initial*	Initial SPF calculation delay (in milliseconds) after a topology change. Range is 0 to 120000.
secondary-wait *secondary*	Hold time between the first and second SPF calculations (in milliseconds). Range is 0 to 120000.
maximum-wait *maximum*	Maximum interval (in milliseconds) between two consecutive SPF calculations. Range is 0 to 120000.
level { **1** | **2** }	(Optional) Enables the SPF interval configuration for Level 1 or Level 2 independently.

Command Default

initial-wait *initial* : 50 milliseconds

secondary-wait *secondary* : 200 milliseconds

maximum-wait *maximum* : 5000 milliseconds

Command Modes

Address family configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

SPF calculations are performed only when the topology changes. They are not performed when external routes change.

Use the **spf-interval** command to control how often the software can perform the SPF calculation. The SPF calculation is processor intensive. Therefore, it may be useful to limit how often this calculation is done, especially when the area is large and the topology changes often. Increasing the SPF interval reduces the processor load of the router, but potentially slows the rate of convergence.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to set the initial SPF calculation delay to 10 milliseconds and the maximum interval between two consecutive SPF calculations to 5000 milliseconds:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-af)# spf-interval initial-wait 10 maximum-wait 5000
```

spf-interval ietf

To set an shortest path first (SPF) interval in IS-IS for SPF calculations, use the **spf-interval ietf** command in the System Admin Config mode. Use the **no** form of this command to enable the fabric bundle port.

spf-interval ietf [**initial-wait** *msec* | **short-wait** *msec* | **long-wait** *msec* | **learn-interval** *msec* | **holddown-interval** *msec*] [**level** { **1** | **2** }]

Syntax Description

spf-interval	Specifies the number of seconds between two consecutive SPF calculations.
ietf	Specifies Internet Engineering Task Force (IETF) RFC standard 8405.
initial-wait *msec*	Initial SPF calculation delay before running a route calculation. The initial-wait must be less than or equal to short-wait. Range is 0 to 120000. The default value is 50 milliseconds.
short-wait *msec*	Short SPF calculation delay before running a route calculation. The short-wait must be less than or equal to long-wait. Range is 0 to 120000. The default value is 200 milliseconds.
long-wait *msec*	Long SPF calculation delay before running a route calculation. Range is 0 to 120000. The default value is 5000 milliseconds.
learn-interval *msec*	Time To Learn interval for running a route calculation. The learn-interval must be less than or equal to holddown-interval. Range is 0 to 120000. The default value is 500 milliseconds.
holddown-interval *msec*	Hold-down interval for running a route calculation. Range is 0 to 120000. The default value is 10000 milliseconds.
level { **1** | **2** }	(Optional) Enables the SPF interval configuration for Level 1 or Level 2 independently.

Command Default

None

Command Modes

System Admin Config mode

Command History

Release	Modification
Release 7.7.1	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

SPF calculations are performed only when the topology changes. They are not performed when external routes change.

Task ID

Task ID	Operations
is-is	read, write

Example

The following example shows how to configure IETF to set an SPF interval in IS-IS for SPF calculations.

```
Router# configure
Router(config)# router isis isp
Router(config-isis)# address-family ipv4 unicast
Router(config-isis-af)# spf-interval ietf?
initial-wait   Initial delay before running a route calculation [50]
short-wait     Short delay before running a route calculation [200]
long-wait      Long delay before running a route calculation [5000]
learn-interval Time To Learn interval for running a route calculation [500]
holddown-interval  Holddown interval for running a route calculation [10000]
level             Set SPF interval for one level only
Router(config-isis-af)# spf-interval ietf
Router(config-isis-af)#commit
```

The following **show** command displays the output with the new spf-interval algorithm. The output displays the actual delay taken to compute the SPF.

```
Router# show isis ipv4 spf-log last 5 detail
   IS-IS 1 Level 2 IPv4 Unicast Route Calculation Log
                   Time Total Trig.
Timestamp    Type   (ms) Nodes Count First Trigger LSP    Triggers
------------ ----- ----- ----- ----- -------------------- -----------------------
--- Wed Mar 16 2022 ---
15:31:49.763  FSPF     1     6     3         tb5-r4.00-00 LINKBAD PREFIXBAD
  Delay:                 101ms (since first trigger)
                         261177ms (since end of last calculation)
  Trigger Link:          tb5-r2.00
  Trigger Prefix:        34.1.24.0/24
  New LSP Arrivals:      0
  SR uloop:              No
  Next Wait Interval:    200ms
  RIB Batches:           1 (0 critical, 0 high, 0 medium, 1 low)
  Timings (ms):          +--Total--+
                          Real   CPU
    SPT Calculation:         1     1
    Route Update:            0     0
                         ----- -----
```

spf prefix-priority (IS-IS)

To assign a priority to an ISIS prefix for customizing the RIB update sequence, use the**spf prefix-priority** command in address family configuration mode. To restore default values, use the **no** form of this command.

spf prefix-priority [**level** {**1** | **2**}] {**critical** | **high** | **medium**} {*access-list-name* | **tag** *tag*}
no spf prefix-priority [**level** {**1** | **2**}] {**critical** | **high** | **medium**} [*access-list-name* | **tag** *tag*]

Syntax Description

level { **1** | **2** }	(Optional) Enables the assignment of a priority to Level 1 or Level 2 independently.
critical	Assigns a critical priority.
high	Assigns a high priority.
medium	Assigns a medium priority.
access-list-name	Name of an access list.
tag *tag*	Specifies a tag to indicate priority. The *tag* argument range is 1 to 4294967295.

Command Default

By default, IPv4 prefixes with a length of 32 and IPv6 prefixes with a length of 128 are given medium priority. The remaining prefixes are given low priority.

Command Modes

Address family configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **spf prefix-priority** command to change the sequence of prefix updates to the RIB after an SPF is run. ISIS installs prefixes in the RIB according to the following priority order:

Critical > High > Medium > Low

The **spf prefix-priority** command supports prefix lists for the first three priorities. The unmatched prefixes are updated with low priority.

If a **spf prefix-priority** is specified, the default behavior of prioritizing either length 32 or 128 prefixes for IPv4 or IPv6, respectively, as **medium** is disabled.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to set the prefix priorities:

```
RP/0/RSP0/CPU0:router(config)# ipv4 prefix-list isis-critical-acl
RP/0/RSP0/CPU0:router(config-ipv4_pfx)# 10 permit 0.0.0.0/0 eq 32
!
RP/0/RSP0/CPU0:router(config)# ipv4 prefix-list isis-med-acl
RP/0/RSP0/CPU0:router(config-ipv4_pfx)# 10 permit 0.0.0.0/0 eq 29
!
RP/0/RSP0/CPU0:router(config)# ipv4 prefix-list isis-high-acl
RP/0/RSP0/CPU0:router(config-ipv4_pfx)# 10 permit 0.0.0.0/0 eq 30
!
RP/0/RSP0/CPU0:router(config)# router isis ring
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-af)# spf prefix-priority critical isis-critical-acl
RP/0/RSP0/CPU0:router(config-isis-af)# spf prefix-priority high isis-high-acl
RP/0/RSP0/CPU0:router(config-isis-af)# spf prefix-priority medium isis-med-acl
```

summary-prefix (IS-IS)

To create aggregate addresses for the Intermediate System-to-Intermediate System (IS-IS) protocol, use the **summary-prefix** command in address family configuration mode. To restore the default behavior, use the **no** form of this command.

Syntax Description

address	Summary address designated for a range of IPv4 addresses. The *address* argument must be in four-part, dotted-decimal notation.
/ *prefix-length*	Length of the IPv4 or IPv6 prefix. A decimal value that indicates how many of the high-order contiguous bits of the address compose the prefix (the network portion of the address). A slash must precede the decimal value.
ipv6-prefix	Summary prefix designated for a range of IPv6 prefixes. The *ipv6-prefix* argument must be in the form documented in RFC 2373, in which the address is specified in hexadecimal using 16-bit values between colons.
level { **1** | **2** }	(Optional) Redistributes routes into Level 1 or Level 2 and summarizes them with the configured address and mask value.
tag *tag*	Sets a tag value. The value range is 1- 4294967295.

Command Default

All redistributed routes are advertised individually.

Both Level 1 and Level 2 are configured if no level is specified.

Command Modes

Address family configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.
Release 3.9.0	Tag keyword and IPv6 support was added.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Multiple groups of addresses can be summarized for a given level. Routes learned from other routing protocols can also be summarized. The metric used to advertise the summary is the smallest metric of all the more-specific routes. Use the **summary-prefix** command to help reduce the size of the routing table.

This command also reduces the size of the link-state packets (LSPs) and thus the link-state database. It also helps ensure stability, because a summary advertisement depends on many more specific routes. If one more-specific route flaps, in most cases, this flap does not cause a flap of the summary advertisement.

The drawback of summary addresses is that other routes might have less information to calculate the most optimal routing table for all individual destinations.

Note When IS-IS advertises a summary prefix, it automatically inserts the summary prefix into the IP routing table but labels it as a “discard” route entry. Any packet that matches the entry is discarded to prevent routing loops. When IS-IS stops advertising the summary prefix, the routing table entry is removed.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to redistribute Open Shortest Path First (OSPF) routes into IS-IS:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 ipv6 unicast
RP/0/RSP0/CPU0:router(config-isis-af)# redistribute ospf 2 level-2
RP/0/RSP0/CPU0:router(config-isis-af)# summary-prefix 10.10.10.10 level-2
RP/0/RSP0/CPU0:router(config-isis-af)# summary-prefix 10.10.10.10
```

suppressed

To allow an IS-IS interface to participate in forming adjacencies without advertising connected prefixes in the system link-state packets (LSPs), use the **suppressed** command in interface configuration mode. To enable advertising connected prefixes, use the **no** form of this command.

suppressed
no suppressed

Command Default

Interface is active.

Command Modes

Interface configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the **suppressed** command to reduce the number of routes that IS-IS has to maintain, improving convergence times after an isolated failure. Improvement is noticeable if the command is used widely throughout the network. Other routers in the domain do not install routes to the affected connected prefixes.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to disable the advertisement of connected prefixes on GigabitEthernet interface 0/1/0/1:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet /1/0/1
RP/0/RSP0/CPU0:router(config-isis-if)# suppressed
```

Related Commands

Command	Description
passive (IS-IS), on page 134	Suppresses S-IS packets on an interface.

tag (IS-IS)

To associate and advertise a tag with the prefix of an IS-IS interface, use the **tag** command in interface address family configuration mode. To restore the default behavior, use the **no** form of this command.

tag *tag*
no tag [*tag*]

Syntax Description

tag	Interface tag. Range is 1 to 4294967295.

Command Default

Default is that no tag is associated and advertised.

Command Modes

Interface address family configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to associate and advertise an interface tag:

```
RP/0/RSP0/CPU0:router(config)# router isis isp
RP/0/RSP0/CPU0:router(config-isis)# interface GigabitEthernet 0/3/0/0
RP/0/RSP0/CPU0:router(config-isis-if)# address-family ipv4 unicast
RP/0/RSP0/CPU0:router(config-isis-if-af)# tag 234
```

Related Commands

Command	Description
spf prefix-priority (IS-IS), on page 228	Assigns a priority to an ISIS prefix for customizing the RIB update sequence.

topology-id

To differentiate one topology in the domain from another while configuring a multicast routing table, use the **topology-id** command in Intermediate System-to-Intermediate System (IS-IS) address family configuration submode. To disable the topology use the **no** form of the command.

topology-id *isis-multicast-topology-id-number*
no topology-id *isis-multicast-topology-id-number*

Syntax Description

isis-multicast-topology-id-number	ID number for a specific IS-IS multicast topology. Range is 6 to 4095.

Command Default

No topology is associated with a routing table by default.

Command Modes

IS-IS address family configuration

Command History

Release	Modification
Release 3.7.2	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operations
isis	read, write

Examples

The following example shows how to differentiate a topology from another in the multicast routing table in IS-IS routing:

```
RP/0/RSP0/CPU0:router(config)# router  isis isp
RP/0/RSP0/CPU0:router(config-isis)# address-family ipv4 multicast topology   green
RP/0/RSP0/CPU0:router(config-isis-af)# topology-id 2666
```

Related Commands

Command	Description
address-family multicast topology (IS-IS), on page 7	Used in conjunction with the **topology-id** command, enables a multicast topology globally when configuring Intermediate System-to-Intermediate System (IS-IS) routing.

trace (IS-IS)

To set the the IS-IS buffer size, use the **trace** command in router configuration mode. To return to the default value, use the **no** form of this command.

trace [**detailed** | **severe** | **standard**] *max-trace-entries*
no trace [**detailed** | **severe** | **standard**]

Syntax Description

detailed	Specifies the buffer size for detailed traces. Range is
severe	Specifies the buffer size for severe traces. Range is
standard	Specifies the buffer size for standard traces. Range is
max-trace-entries	Sets the maximum number of trace entries. Range is 1-20000

Command Default

None

Command Modes

Router IS-IS configuration

Command History

Release	Modification
Release 3.9.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operation
isis	read, write

Examples

The following example shows how to set the isis buffer size for severe traces to 1200:

```
RP/0/RSP0/CPU0:router(config)#router isis isp
RP/0/RSP0/CPU0:router(config-isis)#trace sever 1200
```

ucmp (IS-IS)

To enable unequal cost multipath (UCMP) calculation for Intermediate System-to-Intermediate System (IS-IS), use the **ucmp** command in IS-IS address family configuration mode. To disable UCMP for IS-IS, use the **no** form of this command.

ucmp [**prefix-list** *prefix-list-name*] [**variance** *value*]
no ucmp

Syntax Description

prefix-list	(Optional) Specifies prefix-list name to filter UCMP paths based on prefixes.
prefix-list-name	Name of the prefix-list to be specified to filter UCMP paths.
variance	(Optional) Specifies variance parameter to filter UCMP paths based on cost.
variance-value	Variance value. The variance value is expressed in terms of percentage of the Primary path metric. Range is 101 to 10000. Default variance value is 200.

Command Default

UCMP is disabled.

Command Modes

IS-IS IPv4 address family

IS-IS IPv6 address family

Command History

Release	Modification
Release 4.3.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Enabling the **ucmp** command will make the router calculate UCMP nexthops for all the prefixes in the routing table.

The UCMP path calculation can be controlled such that UCMP nexthops are calculated only for a certain set of prefixes. Use the **ucmp** command with the **prefix-set** option to enable this functionality.

If there are multiple UCMP nexthops with various metrics, then the selection of the number of UCMP nexthops is controlled by the **variance** option in the UCMP command. The variance value is expressed in terms of percentage of the primary path metric. For example, if variance value is 150 and primary path metric is 100, then select all the UCMP nexthops with metrics from 101 to 150.

Task ID

Task ID	Operation
isis	read, write

This example shows how to enable calculation of UCMP nexthops for all the prefixes in the routing table:

```
Router#configure
Router(config)#router isis isp
Router(config-isis)#address-family ipv6 unicast
Router(config-isis-af)#ucmp
```

This example shows how to enable calculation of UCMP nexthops for a set of prefixes in the prefix-list *list1*:

```
Router#configure
Router(config)#router isis isp
Router(config-isis)#address-family ipv6 unicast
Router(config-isis-af)#ucmp prefix-list list1
```

This example shows how to enable calcualtion of UCMP mexthops with variance value *120*:

```
Router#configure
Router(config)#router isis isp
Router(config-isis)#address-family ipv6 unicast
Router(config-isis-af)#ucmp variance 120
```

Related Commands

Command	Description
ucmp delay-interval	Specifies delay between primary SPF completion and start of UCMP computation.
ucmp exclude interface	Excludes an interface from unequal cost multipath (UCMP) computation.
bandwidth	Configures the bandwidth of an interface.

ucmp delay-interval

To specify delay between primary SPF completion and start of UCMP computation, use the **ucmp delay-interval** command in IS-IS address family configuration mode. To disable this functionality, use the **no** form of this command.

ucmp delay-interval *delay-interval*
no ucmp delay-interval

Syntax Description

delay-interval	Delay interval value in milliseconds. Range is 100 to 65535 milliseconds. The default value for the interval is 100 milliseconds.

Command Default

UCMP delay interval is set to 100 milliseconds.

Command Modes

IS-IS IPv4 address family

IS-IS IPv6 address family

Command History

Release	Modification
Release 4.3.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Task ID

Task ID	Operation
isis	read, write

This example shows how to set the delay between primary SPF completion and the start of UCMP computation, to 800 milliseconds:

```
Router#configure
Router(config)#router isis isp
Router(config-isis)#address-family ipv6 unicast
Router(config-isis-af)#ucmp delay-interval 800
```

Related Commands

Command	Description
ucmp is-is	Enables unequal cost multipath (UCMP) calculation for Intermediate System-to-Intermediate System (IS-IS).

Command	Description
ucmp exclude interface	Excludes an interface from unequal cost multipath (UCMP) computation.
bandwidth	Configures the bandwidth of an interface.

ucmp exclude interface

To exclude an interface from unequal cost multipath (UCMP) computation, use the **ucmp exclude interface** command in IS-IS address family configuration mode. To disable this functionality, use the **no** form of this command.

ucmp exclude interface *type interface-path-id*
no ucmp exclude interface *type interface-path-id*

Syntax Description

type	Interface type. For more information, use the question mark (?) online help function.
interface-path-id	Physical interface or virtual interface. **Note** Use the show interfaces command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (?) online help function.

Command Default

None

Command Modes

IS-IS IPv4 address family

IS-IS IPv6 address family

Command History

Release	Modification
Release 4.3.0	This command was introduced.

Usage Guidelines

To use this command, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using a command, contact your AAA administrator for assistance.

Use the ucmp exclude interface command to exclude an interface from being selected as a UCMP backup path.

Task ID

Task ID	Operation
isis	read, write

This example shows how to exclude interface POS 0/3/0/1 from UCMP computation:

```
Router#configure
Router(config)#router isis isp
Router(config-isis)#address-family ipv6 unicast
Router(config-isis-af)#ucmp exclude interface POS 0/3/0/1
```

Related Commands

Command	Description
ucmp is-is	Enables unequal cost multipath (UCMP) calculation for Intermediate System-to-Intermediate System (IS-IS).
ucmp delay-interval	Specifies delay between primary SPF completion and start of UCMP computation.
bandwidth	Configures the bandwidth of an interface.