

Cisco Catalyst IR8340 Rugged Series Router Software Configuration Guide, Cisco IOS XE Release 17.14.x

First Published: 2024-03-27

Americas Headquarters
Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
http://www.cisco.com
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED “AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: https://www.cisco.com/c/en/us/about/legal/trademarks.html. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2024 Cisco Systems, Inc. All rights reserved.



CONTENTS

Full Cisco Trademarks with Software License ?

CHAPTER 1

Overview 1

Introduction 1

Accessing the CLI Using a Router Console 2

Using the Console Interface 5

Initial Bootup Security 6

Enforce Changing Default Password 6

Telnet and HTTP 7

Accessing the CLI from a Remote Console 8

Preparing to Connect to the Router Console 8

Setting Up the IR8340 to Run SSH 9

Using Telnet to Access a Console Interface 10

CLI Session Management 11

Information About CLI Session Management 11

Changing the CLI Session Timeout 11

Locking a CLI Session 11

Communications, services, and additional information 12

Cisco Bug Search Tool 12

Documentation feedback 12

CHAPTER 2

Using Cisco IOS XE Software 13

Understanding Command Modes 13

Keyboard Shortcuts 15

Using the no and default Forms of Commands 15

Using the History Buffer to Recall Commands 16

Managing Configuration Files 16
Saving Configuration Changes 16
Filtering Output from the show and more Commands 17
Finding Support Information for Platforms and Cisco Software Images 18
Using Cisco Feature Navigator 18
Getting Help 18
Finding Command Options: Example 19
Using Software Advisor 24
Using Software Release Notes 24

CHAPTER 3 **Basic Router Configuration** 25
IR8340 Interface Naming 25
Basic Configuration 26
Configuring Global Parameters 31
Configuring the Gigabit Ethernet Interface 32
Support for sub-interface on GigabitEthernet0/0/0 33
Configuring a Loopback Interface 33
Configuring CPU Allocation 34
Enabling Cisco Discovery Protocol 35
Configuring Command-Line Access 35
Configuring Static Routes 37
Configuring Dynamic Routes 39
Configuring Routing Information Protocol 39
Configuring Enhanced Interior Gateway Routing Protocol 40
Modular QoS (MQC) 40

CHAPTER 4 **Configuring Secure Shell** 41
Information About Secure Shell 41
Prerequisites for Configuring Secure Shell 41
Restrictions for Configuring Secure Shell 41
SSH And Router Access 42
SSH Servers, Integrated Clients, and Supported Versions 42
SSH Configuration Guidelines 43
How to Configure Secure Shell 43

Setting Up the IR8340 to Run SSH 43
Configuring the SSH Server 44
Monitoring the SSH Configuration and Status 46
Configuring the Router for Local Authentication and Authorization 46
Information about Secure Copy 47
Prerequisites for Secure Copy 48
Restrictions for Configuring Secure Copy 48
Configuring Secure Copy 48
Additional References 49

CHAPTER 5 **Installing the Software** 51
Installing the Software 51
Cisco Software Licensing 51
Consolidated Packages 51
Network-Essentials 52
Network-Advantage 52
Related Documentation 52
Installing the Cisco IOS XE Release 52
ROMMON Images 53
File Systems 53
Option to Enable or Disable USB Access 54
Autogenerated File Directories and Files 55
Flash Storage 56
Related Documentation 56

CHAPTER 6 **Software Maintenance Upgrade (SMU)** 57
Software Maintenance Upgrade (SMU) 57
SMU Workflow and Basic Requirements 58
SMU Example 58
Installing a Patch Image 58
Uninstalling the Patch Image 60
Uninstalling the Patch Image Using Rollback 60
Uninstalling the Patch Image Using Deactivate, Commit, and Remove 62

CHAPTER 7 **Smart Licensing Using Policy (SLP)** 65

Smart Licensing Using Policy 65

CHAPTER 8 **Configuring Ethernet Switch Ports** 67

Configuring VLANs 67

Creating a VLAN 68

Configuring LAN Ports for Layer 2 Switching 69

Layer 2 LAN Port Modes 70

Default Layer 2 LAN Interface Configuration 70

Configuring LAN Interfaces for Layer 2 Switching 71

Configuring Private VLANs 71

Information About Private VLANs 71

Primary and Secondary VLANs in Private VLANs 72

Private VLAN Ports 72

Guidelines and Limitations for Private VLANs 72

Configuring a Private VLAN 73

Configuring a VLAN as a Private VLAN 73

Associating Secondary VLANs with a Primary Private VLAN 75

Configuring a Layer 2 Interface as a Private VLAN Host Port 76

Configuring a Layer 2 Interface as a Private VLAN Promiscuous Port 77

Configuring Voice VLANs 79

Limitations and Restrictions 79

How to Configure Voice VLANs 79

Configuring Cisco IP Phone Voice Traffic 79

Removing Voice VLAN 80

Monitoring Voice VLAN 81

Configuring VXLAN Tunneling 81

IEEE 802.1x Protocol 82

Configuring IEEE 802.1X Port-Based Authentication 82

Enabling AAA Authorization for VLAN Assignment 83

Enabling IEEE 802.1X Authentication and Authorization 83

Spanning Tree Protocol Overview 86

Default STP Configuration 87

Enabling STP 87
Configuring Optional STP Features 89
Enabling PortFast 89
Configuring PortFast BPDU Filtering 90
Enabling BPDU Guard 92
Enabling UplinkFast 92
Enabling BackboneFast 93
MAC Table Manipulation 94
Creating a Static Entry in the MAC Address Table 94
MAC Address-Based Traffic Blocking 95
Configuring and Verifying the Aging Timer 96
MAC Learning on a Vlan 96
Assigning IP Addresses to Switch Virtual Interfaces 97
SVI Supported Features 98
IGMP Snooping for IPv4 100
IGMP Filtering and Throttling 100
Default IGMP Filtering and Throttling Configuration 101
Configuring IGMP Profiles 101
Applying IGMP Profiles 102
Setting the Maximum Number of IGMP Groups 103
Configuring the IGMP Throttling Action 104
MLD Snooping 104
MLD Snooping Configuration Guidelines 105
Default MLD Snooping Configuration 105
Enabling or Disabling MLD Snooping on a VLAN 106
Configuring UniDirectional Link Detection 107
Enabling UDLD Globally 107
Enabling UDLD on an Interface 108
Configuring the Switched Port Analyzer 108
SPAN and RSPAN 109
Creating a Local SPAN Session 109
Creating a Local SPAN with Incoming Traffic Allowed on Destination 111
Specifying VLANs to Filter 113
Verifying the SPAN Session 115

Removing a SPAN Session 115
Configuring a VLAN as an RSPAN VLAN 116
Creating an RSPAN Source Session 117
Specifying VLANs to Filter on RSPAN Source Session 119
Creating an RSPAN Destination Session and Configuring Incoming Traffic 120
EtherChannel Overview 122
Channel Groups and Port-Channel Interfaces 123
Port Aggregation Protocol 123
Link Aggregation Control Protocol 123
Configuring Layer 2 EtherChannels 123
Configuring EtherChannel Load-Balancing 125
Configuring the PAgP Learn Method and Priority 126
Configuring the LACP Port Channel Min-Links Feature 127
Configuring LACP Fast Rate Timer 128
Modular Quality of Service Command-Line Interface 129
Creating a Traffic Class 130
Creating a Traffic Policy 132
Configuring Class-Based Packet Marking 135
Attaching a Traffic Policy to an Interface 140
Classifying, Policing, and Marking Traffic on Physical Ports by Using Policy Maps 141

CHAPTER 9 **Configuring Switchport Blocking** 145
About Switchport Blocking 145
Configuring Switchport Blocking 145

CHAPTER 10 **Configuring Storm Control** 149
Information About Storm Control 149
Configuring Storm Control 150

CHAPTER 11 **Configuring MAC Address Notification** 153
MAC Address Notification 153
Configuring MAC Address Notification 153

CHAPTER 12 **Configuring Q-in-Q and Layer 2 Protocol Tunneling** 155

Information About Q-in-Q Tunnels 155
Information About Layer 2 Protocol Tunneling 156
Configuring VLAN Mapping for Selective Q-in-Q on a 802.1Q Tunnel Port 156
Enabling the Layer 2 Protocol Tunnel 158
Configuring Thresholds for Layer 2 Protocol Tunnel Ports 159
Verifying the Q-in-Q Configuration 160
VLAN Translation One-to-One Mapping 160

CHAPTER 13 **Power over Ethernet** 161
Power over Ethernet 161
Device Detection and Power Allocation 162
Configuring Power Over Ethernet 162
Configuring Universal PoE 163
PoE Debug Commands 164

CHAPTER 14 **Configuring the T1/E1 Network Interface Module** 165
Information About T1/E1 Network Interface Module 165
Configuring T1/E1 Network Interface Module 165
Configuring the Card Type 165
Changing the Card Type 166
Configuring the T1/E1 Network Interface Module for Data Support 167
Example of T1/E1 Network Interface Module Configuration 170

CHAPTER 15 **Configuring the Serial Network Interface Module** 173
About the Asynchronous/Synchronous Serial Network Interface Module 173
Configuring the Serial Interface to Sync or Async Mode 173
Configuring Synchronous Serial Ports 174
Checking DCE and DTE Cable Type 174
Specifying Synchronous Serial Encapsulation 174
DCE and DTE Configuration for HDLC Encapsulation 175
DCE and DTE Configuration for PPP (CHAP) Encapsulation 176
DCE and DTE Configuration for PPP (PAP) Encapsulation 177
DCE and DTE Configuration for Frame Relay Encapsulation 178
Serial Synchronous Show and Debug Commands 180

Configuring Asynchronous Serial Ports 181
Specifying Asynchronous Serial Encapsulation 181

CHAPTER 16 Cellular Pluggable Interface Modules 183

CHAPTER 17 Information About SCADA 185
SCADA Overview 185
Role of the IR8340 185
Key Terms 186
Protocol Translation Application 186
Prerequisites 187
Guidelines and Limitations 188
Default Settings 188
Configuring Protocol Translation 188
Enabling the IR8340 Serial Port and SCADA Encapsulation 188
EXAMPLE 189
Configuring T101 and T104 Protocol Stacks 189
Prerequisites 189
Configuring the T101 Protocol Stack 190
EXAMPLE 192
Configuring the T104 Protocol Stack 192
EXAMPLE 194
Configuration Example 195
Configuring the DNP3 Protocol Stacks 197
Configuring DNP3 Serial 197
EXAMPLE 198
Configuring DNP3 IP 199
EXAMPLE 200
Starting and Stopping the Protocol Translation Engine 201
EXAMPLE 201
Verifying Configuration 202
Debug Commands 203

CHAPTER 18 Raw Socket Transport 205

Information About Raw Socket Transport 205
TCP Transport 206
UDP Transport 206
Serial Data Processing 207
VRF-Aware Raw Socket 207
Prerequisites 208
Guidelines and Limitations 208
Default Settings 208
Configuring Raw Socket Transport 208
Enabling Raw Socket Transport on the Serial Interface 208
Configuring Common Raw Socket Line Options 209
Configuring Raw Socket TCP 210
Configuring the Raw Socket TCP Server 210
Configuring the Raw Socket TCP Client 212
Configuring a Raw Socket UDP Peer-to-Peer Connection 213
Verifying Configuration 214
Configuration Example 215
Raw Socket TCP 215
Raw Socket UDP 216
Raw Socket VRF 217
Show Line Details for Configuring Raw-TCP/UDP 218
Raw-Socket Show and Debug Commands 219

CHAPTER 19 **Configuring MODBUS TCP 221**
Understanding MODBUS TCP 221
MODBUS and Security 221
Multiple Request Messages 222
Configuring the Router as the MODBUS TCP Server 223
Defaults 223
Enabling MODBUS TCP on the Switch 223
MODBUS TCP Registers 223
System Information Registers 224
Port Information Registers 225
Interpreting the Port State 234

CHAPTER 20 VLAN Access Control Lists 235
Information About VLAN Access Control Lists 235
VLAN Maps 235
Configuring VACLs 235
Defining a VLAN Access Map 236
Configuring a Match Clause in a VLAN Access Map Sequence 236
Configuring an Action Clause in a VLAN Access Map Sequence 237
Applying a VLAN Access Map 237
Verifying VLAN Access Map Configuration 237
Debugging VACLs 237

CHAPTER 21 Configuring MACsec 239
MACsec Encryption Overview 239
Limitations and Restrictions 239
Media Access Control Security and MACsec Key Agreement 240
Configuring MACsec Encryption 241
Configuring MKA and MACsec 241
Configuring an MKA Policy 241
Configuring MACsec MKA using PSK 242
Configuring MACsec MKA on an Interface using PSK 243
Example: Sample Configuration of Switch-to-Switch MACsec 244
Example: Sample Configuration of Switch-to-Host MACsec 244
Verifying the Configuration 246

CHAPTER 22 WAN MACSEC and MKA Support Enhancements 251
MACsec and MKA Overview 251
Benefits of WAN MACsec and MKA Support Enhancements 252
Best Practices for Implementing WAN MACsec and MKA Support Enhancements 252
MKA Policy Inheritance 253
Key Lifetime and Hitless Key Rollover 253
Encryption Algorithms for Protocol Packets 253
Access Control Option for Smoother Migration 254
Extensible Authentication Protocol over LAN Destination Address 254

Replay Protection Window Size 255
How to Configure WAN MACsec and MKA Support Enhancements 255
Configuring MKA 255
Configuring MKA Pre-Shared Key 257
Configuring an Option to Change the EAPoL Ethernet Type 258
Sample Configuration for Point-to-Point WAN MACsec 258
Example: Port Based WAN MACsec 258
Example: VLAN Based WAN MACsec 259
Sample Show Command Output for Port Based WAN MACsec 260
Sample Show Command Output for VLAN Based WAN MACsec 262

CHAPTER 23 **Configuring IPv6 First Hop Security** 265
IPv6 First Hop Security Overview 265
Overview of DHCPv6 Guard 265
Restrictions of DHCPv6 Guard 265
Overview of IPv6 RA Guard 265
Limitations and Restrictions of IPv6 RA Guard 266
Configuring an IPv6 DHCP Guard Policy 266
Attaching an IPv6 DHCP Guard Policy to an Interface or a VLAN 267
Configuring an IPv6 Router Advertisement Guard Policy 268
Attaching an IPv6 Router Advertisement Guard Policy to an Interface or a VLAN 270

CHAPTER 24 **Configuring IP Device Tracking** 273
Information About IP Device Tracking 273
Overview of SISF-Based Device Tracking 274
Options to Enable SISF-Based Device Tracking 274
Manually Enabling SISF-Based Device Tracking 274
Programmatically Enabling SISF-Based Device Tracking 275
How to Configure SISF-Based Device Tracking 275
Manually Enabling SISF-Based Device Tracking 275
Applying the Default Device Tracking Policy to a Target 275
Creating a Custom Device Tracking Policy with Custom Settings 276
Attaching a Device Tracking Policy to an Interface 280
Attaching a Device Tracking Policy to a VLAN 281

Configuring a Multi-Switch Network to Stop Creating Binding Entries from a Trunk Port 282
Enabling SISF Syslogs 283
Example: DHCP Snooping Auto Enabling DT PROGRAMMATIC Policy 283

CHAPTER 25 Configuring Security for VPNs with IPsec 285
Information About Configuring Security for VPNs with IPsec 285
Supported Standards 285
Supported Encapsulation 287
IPsec Functionality Overview 287
IKEv1 Transform Sets 288
IKEv2 Transform Sets 288
How to Configure IPsec VPNs 288
Creating Crypto Access Lists 288
Configuring Transform Sets for IKEv1 and IKEv2 Proposals 289
Configuring Transform Sets for IKEv1 290
Configuring Transform Sets for IKEv2 291
Creating Crypto Map Sets 293
Creating Static Crypto Maps 293
Creating Dynamic Crypto Maps 296
Creating Crypto Map Entries to Establish Manual SAs 299
Applying Crypto Map Sets to Interfaces 301

CHAPTER 26 Configuring High-availability Seamless Redundancy (HSR) 303
Information About HSR 303
Loop Avoidance 304
HSR RedBox Modes of Operation 305
HSR-SAN Mode 305
HSR-SAN Interfaces 306
Configuring an HSR Ring 306
Configuring Interface Sub-Mode 306
Clearing All Node Table and VDAN Table Dynamic Entries 307
Verifying Configuration 307

CHAPTER 27 Configuring Parallel Redundancy Protocol (PRP) 309

Information About PRP 309
PRP Channels 310
Creating a PRP Channel and Group 310
Clearing All Node Table and VDAN Table Dynamic Entries 312
Disabling the PRP Channel and Group 312
PRP Mode LED 312
Verifying Configuration 313

CHAPTER 28 **Configuring Resilient Ethernet Protocol (REP)** 315

CHAPTER 29 **System Messages** 317
Information About Process Management 317
How to Find Error Message Details 317

CHAPTER 30 **Environmental Monitoring** 323
Environmental Monitoring 323
Environmental Monitoring and Reporting Functions 323
Environmental Monitoring Functions 324
Environmental Reporting Functions 325
Additional References 325
Technical Assistance 326

CHAPTER 31 **IOx Application Hosting** 327
Application Hosting 327
Information About Application Hosting 327
Need for Application Hosting 327
IOx Overview 328
Cisco Application Hosting Overview 328
IOXMAN 328
Application Hosting on the IR8340 Router 329
Application Hosting on Layer 2 and Layer 3 Interfaces 329
VirtualPortGroup 330
vNIC 330
How to Configure Application Hosting 331


Enabling IOx 331
Configuring Application Hosting to Layer 2 Interfaces 332
Configuring a VirtualPortGroup to a Layer 3 Data Port 333
Configuring Docker Run Time Options 335
Installing and Uninstalling Apps 336
Overriding the App Resource Configuration 337
Verifying the Application Hosting Configuration 338
IOx Configuration with ERSPAN 340
Configuration Examples for Application Hosting 341
Example: Enabling IOx 341
Example: Configuring a VirtualPortGroup to a Layer 3 Data Port 341
Example: Installing and Uninstalling Apps 341
Example: Overriding the App Resource Configuration 341
Signed Application Support 342
Cisco Cyber Vision 342

CHAPTER 32 **ROM Monitor Overview** 343
ROM Monitor Overview 343
Access ROM Monitor Mode 344
Checking the Current ROMMON Version 344
Commonly Used ROM Monitor Commands 345
Examples 346
Changing the ROM Monitor Prompt 346
Displaying the Configuration Register Setting 346
Environment Variable Settings 347
Frequently Used Environmental Variables 347
Displaying Environment Variable Settings 347
Entering Environment Variable Settings 348
Saving Environment Variable Settings 348
Exiting ROM Monitor Mode 348
Configuration Example 349
Upgrading the ROMmon for a Router 349

CHAPTER 33 **Process Health Monitoring** 351

Monitoring Control Plane Resources 351
Avoiding Problems Through Regular Monitoring 351
Cisco IOS Process Resources 351
Overall Control Plane Resources 361
Monitoring Hardware Using Alarms 363
Router Design and Monitoring Hardware 363
BootFlash Disk Monitoring 363
Approaches for Monitoring Hardware Alarms 363
Viewing the Console or Syslog for Alarm Messages 363
Network Management System Alerts a Network Administrator when an Alarm is Reported Through SNMP 364

CHAPTER 34 **Troubleshooting** 365
Troubleshooting 365
Understanding Diagnostic Mode 365
Before Contacting Cisco or Your Reseller 366
show interfaces Troubleshooting Command 366
Software Upgrade Methods 366
Change the Configuration Register 367
Configuring the Configuration Register for Autoboot 368
Reset the Router 369
Recovering a Lost Password 370
Reset the Configuration Register Value 370
Configuring a Console Port Transport Map 371
Viewing Console Port, SSH, and Telnet Handling Configurations 373
Using the factory reset Commands 374



CHAPTER 1

Overview

- Introduction, on page 1
- Accessing the CLI Using a Router Console, on page 2
- Initial Bootup Security, on page 6
- Accessing the CLI from a Remote Console , on page 8
- CLI Session Management, on page 11
- Communications, services, and additional information, on page 12

Introduction

The Cisco Catalyst IR8340 Rugged Series Router is Cisco's first industrial-grade fully integrated routing and switching platform. IR8340 is designed to provide outstanding flexibility and adaptability to address the latest needs of the network evolution.

Note The terms *IR8340* and *router* are used throughout this document in text and CLI examples to refer to the Cisco Catalyst IR8340 Rugged Series Router, unless otherwise noted.

Note The documentation set for this product strives to use bias-free language. For purposes of this documentation set, bias-free is defined as language that does not imply discrimination based on age, disability, gender, racial identity, ethnic identity, sexual orientation, socioeconomic status, and intersectionality. Exceptions may be present in the documentation due to language that is hardcoded in the user interfaces of the product software, language used based on RFP documentation, or language that is used by a referenced third-party product.

The IR8340 Router features 2 Pluggable Interface Module (PIM) slots, 2 single-wide IRM-NIM slots, 1 timing module slot, plus 12 onboard LAN ports and 2 WAN ports, and supports the following:

- 150W/250W PSU, Low Voltage DC and High Voltage AC/DC options
- Timing and SyncE support–IRIG-B (Analog & Digital), GNSS, and PTP

Note For more information about timing related configuration, see *Timing and Synchronization Configuration Guide, Cisco IOS XE 17 (Cisco Catalyst IR8340 Rugged Series Router)*.

- LTE PIM modules
- Network Interface Modules (NIMs)
- mSATA module
- 2 x 1G Combo WAN ports
- 4 x 1G Copper LAN Ports
- 4 x 1G Combo LAN ports
- 4 x 1G SFP LAN Ports
- PoE/PoE+/UPoE (up to 120w) support on LAN port 1-4
- 2 x IN and 1 x OUT Alarm ports (RJ45)

Accessing the CLI Using a Router Console

Cisco IR8340 routers have an RJ45 RS232 serial console port located on the router front panel. The default baud rate is 9600. You can use an RJ45 Roll Over console cable that is available in the market.

On a device fresh from the factory, you are greeted with a System Configuration Dialog. If the router was ordered for the use of Cisco PnP connect services, in the case of centralized provisioning, the router skips the initial dialog. The following is an example, and names and IP addresses are shown as examples.

Note Autoinstall will terminate if any input is detected on console.

```
--- System Configuration Dialog ---

Would you like to enter the initial configuration dialog? [yes/no]:

WARNING: ** NOTICE ** This is the final IOS XE release to provide support for the H.323
protocol. Consider switching to SIP for multimedia applications before upgrading to 17.7.1.
*Jan 27 23:51:55.579: %TAMPER_ALARM-0-TAMPER_ALARM_ASSERT: Tamper alarm slot (Tamper alarm
 slot 2) asserted

*Jan 27 23:51:55.579: %TAMPER_ALARM-0-TAMPER_ALARM_ASSERT: Tamper alarm slot (Tamper alarm
 slot 3) asserted

Autoinstall trying DHCPv6 on GigabitEthernet0/0/0,GigabitEthernet0/0/1

Autoinstall trying DHCPv4 on GigabitEthernet0/0/0,GigabitEthernet0/0/1

AUTO IP is starting!!!!

start Autoip process
```

```
Acquired IPv4 address 192.168.0.202 on Interface GigabitEthernet0/0/0
Received following DHCPv4 options:
dns-server-ip : 192.168.0.2
si-addr : 192.168.0.2
hostname : Router

stop Autoip process


Press RETURN to get started!


*Jan 27 23:53:08.903: %SYS-5-USERLOG_NOTICE: Message from tty0(user id: ): Device in day0
workflow, some non user-configured options may be enabled by default
*Jan 27 23:53:08.920: %SYS-5-CONFIG_P: Configured programmatically by process PnP Agent
Discovery from console as vty0
OK to enter CLI now...

pnp-discovery can be monitored without entering enable mode

Entering enable mode will stop pnp-discovery

*Jan 27 23:53:08.921: %PNP-6-HTTP_CONNECTING: PnP Discovery trying to connect to PnP server
 (https://devicehelper.cisco.com.:443/pnp/HELLO)
*Jan 27 23:53:09.788: AUTOINSTALL: Obtain siaddr 192.168.0.2 (as config server)
*Jan 27 23:53:09.788: AUTOINSTALL: Setting hostname Router from DHCP reply
*Jan 27 23:53:10.899: %LINK-5-CHANGED: Interface GigabitEthernet0/0/1, changed state to
administratively down
*Jan 27 23:53:11.899: %LINEPROTO-5-UPDOWN: Line protocol on Interface GigabitEthernet0/0/1,
 changed state to down
*Jan 27 23:53:29.880: %PNP-6-HTTP_CONNECTED: PnP Discovery connected to PnP server
(https://devicehelper.cisco.com.:443/pnp/HELLO)
*Jan 27 23:53:29.883: %PNP-6-PNP_PROFILE_CREATED: PnP profile (pnp_cco_profile) created
(1/3) by (pid=656, pname=PnP Agent Discovery, time=23:53:29 UTC Wed Jan 27 2021)
*Jan 27 23:53:30.893: %PNP-6-PNP_SUDI_UPDATE: Device SUDI [PID:IR8340-K9,SN:FDO2523J7GF]
identified
*Jan 27 23:53:30.893: %PNP-6-PNP_RELOAD_INFO_ENCODED: Reload reason (PnP Service Info
2408-Unknown reason) encoded (1/3) by (pid=656, pname=PnP Agent Discovery)
*Jan 27 23:53:30.894: %SYS-5-CONFIG_P: Configured programmatically by process PnP Agent
Discovery from console as vty0
*Jan 27 23:53:35.635: %PNP-6-PNP_RELOAD_INFO_STOPPED: Reload reason (PnP Service Info
2408-Unknown reason) stopped by (profile=pnp_cco_profile, host=devicehelper.cisco.com.,
port=443)
*Jan 27 23:53:56.755: %PNP-6-PNP_BACKOFF_NOW: PnP Backoff now for (60) seconds requested
(1/3) by (profile=pnp_cco_profile, host=devicehelper.cisco.com., port=443)
*Jan 27 23:54:07.900: %PNP-3-PNP_CCO_PROFILE_UNCONFIGURED: CCO Server profile
(pnp_cco_profile) unconfigured (1/10) by (pid=656, pname=PnP Agent Discovery, time=23:54:07
 UTC Wed Jan 27 2021)
*Jan 27 23:54:07.900: %PNP-6-PNP_PROFILE_DELETED: PnP profile (pnp_cco_profile) deleted
(1/3) by (pid=656, pname=PnP Agent Discovery, time=23:54:07 UTC Wed Jan 27 2021)
*Jan 27 23:54:07.901: %SYS-5-CONFIG_P: Configured programmatically by process PnP Agent
Discovery from console as vty0
*Jan 27 23:54:07.909: %SYS-5-CONFIG_P: Configured programmatically by process PnP Agent
Discovery from console as vty0
*Jan 27 23:54:13.907: %PNP-3-PNP_DOMAIN_NAME_NOT_FOUND: Domain name not found (4/10) on
(GigabitEthernet0/0/0) by (pid=656, pname=PnP Agent Discovery, time=23:54:13 UTC Wed Jan
27 2021)
*Jan 27 23:54:13.907: %PNP-3-PNP_DOMAIN_NAME_NOT_FOUND: Domain name not found (5/10) on
(WPAN0/1/0) by (pid=656, pname=PnP Agent Discovery, time=23:54:13 UTC Wed Jan 27 2021)
*Jan 27 23:54:29.911: %PNP-3-PNP_DOMAIN_NAME_NOT_FOUND: Domain name not found (6/10) on
(GigabitEthernet0/0/0) by (pid=656, pname=PnP Agent Discovery, time=23:54:29 UTC Wed Jan
27 2021)
*Jan 27 23:54:29.911: %PNP-3-PNP_DOMAIN_NAME_NOT_FOUND: Domain name not found (7/10) on
(WPAN0/1/0) by (pid=656, pname=PnP Agent Discovery, time=23:54:29 UTC Wed Jan 27 2021)
```

```
*Jan 27 23:54:37.911: %PNP-3-PNP_DOMAIN_NAME_NOT_FOUND: Domain name not found (8/10) on
(GigabitEthernet0/0/0) by (pid=656, pname=PnP Agent Discovery, time=23:54:37 UTC Wed Jan
27 2021)
*Jan 27 23:54:37.911: %PNP-3-PNP_DOMAIN_NAME_NOT_FOUND: Domain name not found (9/10) on
(WPAN0/1/0) by (pid=656, pname=PnP Agent Discovery, time=23:54:37 UTC Wed Jan 27 2021)
*Jan 27 23:54:53.914: %PNP-3-PNP_DOMAIN_NAME_NOT_FOUND: Domain name not found (10/10) on
(GigabitEthernet0/0/0) by (pid=656, pname=PnP Agent Discovery, time=23:54:53 UTC Wed Jan
27 2021)
*Jan 27 23:55:20.100: %PNP-6-PNP_CCO_SERVER_IP_RESOLVED: CCO server (devicehelper.cisco.com.)
 resolved to ip (18.205.166.131) by (pid=656, pname=PnP Agent Discovery, time=23:55:20 UTC
 Wed Jan 27 2021)
*Jan 27 23:55:20.100: %PNP-6-PNP_PROFILE_CREATED: PnP profile (pnp_cco_profile) created
(2/3) by (pid=656, pname=PnP Agent Discovery, time=23:55:20 UTC Wed Jan 27 2021)
*Jan 27 23:55:21.107: %PNP-6-PNP_RELOAD_INFO_ENCODED: Reload reason (PnP Service Info
2408-Unknown reason) encoded (2/3) by (pid=656, pname=PnP Agent Discovery)
*Jan 27 23:55:21.108: %SYS-5-CONFIG_P: Configured programmatically by process PnP Agent
Discovery from console as vty0
*Jan 27 23:55:32.751: %PNP-6-PNP_BACKOFF_NOW: PnP Backoff now for (60) seconds requested
(2/3) by (profile=pnp_cco_profile, host=devicehelper.cisco.com., port=443)
Autoinstall trying DHCPv6 on GigabitEthernet0/0/0

*Jan 27 23:55:43.108: %PNP-3-PNP_CCO_PROFILE_UNCONFIGURED: CCO Server profile
(pnp_cco_profile) unconfigured (2/10) by (pid=656, pname=PnP Agent Discovery, time=23:55:43
 UTC Wed Jan 27 2021)
*Jan 27 23:55:43.108: %PNP-6-PNP_PROFILE_DELETED: PnP profile (pnp_cco_profile) deleted
(2/3) by (pid=656, pname=PnP Agent Discovery, time=23:55:43 UTC Wed Jan 27 2021)
*Jan 27 23:55:43.109: %SYS-5-CONFIG_P: Configured programmatically by process PnP Agent
Discovery from console as vty0
*Jan 27 23:55:43.113: %SYS-5-CONFIG_P: Configured programmatically by process PnP Agent
Discovery from console as vty0
Autoinstall trying DHCPv6 on GigabitEthernet0/0/0

Autoinstall trying DHCPv6 on GigabitEthernet0/0/0

Autoinstall trying DHCPv6 on GigabitEthernet0/0/0

Autoinstall trying DHCPv6 on GigabitEthernet0/0/0

Autoinstall trying DHCPv6 on GigabitEthernet0/0/0

*Jan 27 23:56:55.316: %PNP-6-PNP_PROFILE_CREATED: PnP profile (pnp_cco_profile) created
(3/3) by (pid=656, pname=PnP Agent Discovery, time=23:56:55 UTC Wed Jan 27 2021)
*Jan 27 23:56:56.323: %PNP-6-PNP_RELOAD_INFO_ENCODED: Reload reason (PnP Service Info
2408-Unknown reason) encoded (3/3) by (pid=656, pname=PnP Agent Discovery)
*Jan 27 23:56:56.324: %SYS-5-CONFIG_P: Configured programmatically by process PnP Agent
Discovery from console as vty0
Autoinstall trying DHCPv6 on GigabitEthernet0/0/0

*Jan 27 23:57:09.810: AUTOINSTALL: script execution not successful for Gi0/0/0.
*Jan 27 23:57:10.829: %SYS-5-CONFIG_P: Configured programmatically by process DHCP Autoinstall
 from console as vty0
*Jan 27 23:58:10.003: %PNP-6-PNP_BACKOFF_NOW: PnP Backoff now for (60) seconds requested
(3/3) by (profile=pnp_cco_profile, host=devicehelper.cisco.com., port=443)
*Jan 27 23:58:21.323: %PNP-3-PNP_CCO_PROFILE_UNCONFIGURED: CCO Server profile
(pnp_cco_profile) unconfigured (3/10) by (pid=656, pname=PnP Agent Discovery, time=23:58:21
 UTC Wed Jan 27 2021)
*Jan 27 23:58:21.323: %PNP-6-PNP_PROFILE_DELETED: PnP profile (pnp_cco_profile) deleted
(3/3) by (pid=656, pname=PnP Agent Discovery, time=23:58:21 UTC Wed Jan 27 2021)
*Jan 27 23:58:21.324: %SYS-5-CONFIG_P: Configured programmatically by process PnP Agent
Discovery from console as vty0
*Jan 27 23:58:21.327: %SYS-5-CONFIG_P: Configured programmatically by process PnP Agent
Discovery from console as vty0
*Jan 27 23:59:34.507: %SYS-5-CONFIG_P: Configured programmatically by process PnP Agent
Discovery from console as vty0
```

```
*Jan 27 23:59:59.507: %PNP-3-PNP_CCO_PROFILE_UNCONFIGURED: CCO Server profile
(pnp_cco_profile) unconfigured (4/10) by (pid=656, pname=PnP Agent Discovery, time=23:59:59
 UTC Wed Jan 27 2021)
*Jan 27 23:59:59.508: %SYS-5-CONFIG_P: Configured programmatically by process PnP Agent
Discovery from console as vty0
*Jan 27 23:59:59.511: %SYS-5-CONFIG_P: Configured programmatically by process PnP Agent
Discovery from console as vty0
*Jan 28 00:01:12.715: %SYS-5-CONFIG_P: Configured programmatically by process PnP Agent
Discovery from console as vty0
*Jan 28 00:02:22.715: %PNP-3-PNP_CCO_PROFILE_UNCONFIGURED: CCO Server profile
(pnp_cco_profile) unconfigured (5/10) by (pid=656, pname=PnP Agent Discovery, time=00:02:22
 UTC Thu Jan 28 2021)
*Jan 28 00:02:22.716: %SYS-5-CONFIG_P: Configured programmatically by process PnP Agent
Discovery from console as vty0
*Jan 28 00:02:22.719: %SYS-5-CONFIG_P: Configured programmatically by process PnP Agent
Discovery from console as vty0
Router>en
Router#sh ip in
*Jan 28 00:02:42.724: %SYS-5-CONFIG_P: Configured programmatically by process PnP Agent
Discovery from console as console
*Jan 28 00:02:42.724: %PNP-6-PNP_SAVING_TECH_SUMMARY: Saving PnP tech summary
(/pnp-tech/pnp-tech-discovery-summary)... Please wait. Do not interrupt.t b
*Jan 28 00:02:42.877: %SYS-5-CONFIG_P: Configured programmatically by process PnP Agent
Discovery from console as vty0
*Jan 28 00:02:42.924: %SYS-5-CONFIG_P: Configured programmatically by process PnP Agent
Discovery from console as vty0
*Jan 28 00:02:43.394: %SYS-5-CONFIG_P: Configured programmatically by process PnP Agent
Discovery from console as vty0
*Jan 28 00:02:43.494: %PNP-6-PNP_TECH_SUMMARY_SAVED_OK: PnP tech summary
(/pnp-tech/pnp-tech-discovery-summary) saved successfully (elapsed time: 1 seconds).
*Jan 28 00:02:43.494: %PNP-6-PNP_DISCOVERY_STOPPED: PnP Discovery stopped (Config Wizard)
Interface IP-Address OK? Method Status Protocol
GigabitEthernet0/0/0 192.168.0.202 YES DHCP up up
GigabitEthernet0/0/1 unassigned YES unset administratively down down
WPAN0/1/0 unassigned YES unset up up
Router#
```

The device now has a basic configuration that you can build upon.

Using the Console Interface

Procedure

Step 1 Enter the following command:

```
Router > enable
```

Step 2 (Go to Step 3 if the enable password has not been configured.) At the password prompt, enter your system password:

```
Password: enablepass
```

When your password is accepted, the privileged EXEC mode prompt is displayed.

```
Router#
```

You now have access to the CLI in privileged EXEC mode and you can enter the necessary commands to complete your desired tasks.

Step 3 To exit the console session, enter the **quit** command:

```
Router# quit
```

Initial Bootup Security

This section contains the following:

Enforce Changing Default Password

When the device is first booted after factory reset or fresh from the factory, the following prompt is received on the console:

Would you like to enter the initial configuration dialog? [yes/no]:

In previous documentation, Cisco recommended using the **enable secret** command instead of the **enable password** command because this offers an improved encryption algorithm.

The initial dialog forces setting a new enable password, and also using the **enable secret** command instead. The following is an example:

```
Would you like to enter the initial configuration dialog? [yes/no]: no

Autoinstall trying DHCP on GigabitEthernet0/0/0
Autoinstall trying DHCPv6 on GigabitEthernet0/0/0

The enable secret is a password used to protect
access to privileged EXEC and configuration modes.
This password, after entered, becomes encrypted in
the configuration.
------------------------------------------------
secret should be of minimum 10 characters with
at least 1 upper case, 1 lower case, 1 digit and
should not contain [cisco]
------------------------------------------------
Enter enable secret: **********
Confirm enable secret: **********

The following configuration command script was created:

enable secret 9 $9$rDzH3rLqjlFhek$G9UDZE7moWqsKJEZfJAH2yO.SPhKZeKJsEe./CPEzl.
!
end


[0] Go to the IOS command prompt without saving this config.
[1] Return back to the setup without saving this config.
[2] Save this configuration to nvram and exit.

Enter your selection [2]: 2
Building configuration...
[OK]
Use the enabled mode 'configure' command to modify this configuration.



Press RETURN to get started!
*Feb 12 00:14:14.305: %LINK-5-CHANGED: Interface GigabitEthernet0/0/0, changed state to
```

```
administratively down
*Feb 12 00:14:14.308: %LINK-5-CHANGED: Interface GigabitEthernet0/0/1, changed state to
administratively down
*Feb 12 00:14:15.306: %LINEPROTO-5-UPDOWN: Line protocol on Interface GigabitEthernet0/0/0,
 changed state to down
Router>
*Feb 12 00:14:15.653: %PKI-6-TRUSTPOINT_CREATE: Trustpoint: SLA-TrustPoint created succesfully
*Feb 12 00:14:15.657: %PKI-6-CONFIGAUTOSAVE: Running configuration saved to NVRAM[OK]
Router>
Router>en
Password:
*Feb 12 00:14:18.878: %SYS-6-PRIVCFG_ENCRYPT_SUCCESS: Successfully encrypted private config
 file
*Feb 12 00:14:18.910: %CALL_HOME-6-CALL_HOME_ENABLED: Call-home is enabled by Smart Agent
for Licensing.
Router#sh run | inc sec
*Feb 12 00:14:26.299: %SYS-5-CONFIG_P: Configured programmatically by process PnP Agent
Discovery from console as vty0ret
enable secret 9 $9$rDzH3rLqjlFhek$G9UDZE7moWqsKJEZfJAH2yO.SPhKZeKJsEe./CPEzl.
Router#
```

After the enable secret is prompted during the first login, and the admin enters a password, the admin entered password will be always masked. If the admin enters a weak password, they will be prompted again to enter strong password (i.e. the standard mix of upper/lower case characters, special characters, numbers etc.). The prompting will continue until the admin enters a strong password. The admin will be prompted to enter the strong secret password twice for confirming that admin is sure that it is the secret that they want to configure.

Telnet and HTTP

When the device is first booted after factory reset or fresh from the factory, by default the following takes place:

- Disable telnet
- Disable http server. HTTP client works.
- Enable SSH
- Enable https server

Examples

From a freshly booted device, below configurations for HTTPS and SSH are enabled.

```
ip http server
ip http authentication local
ip http secure-server
.
.

line vty 0 4
login
transport input ssh
line vty 5 14
login
transport input ssh
```

To enable Telnet, use the **line vty** command.

```
R1>enable
R1#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
```

```
R1(config)#line vty 0
R1(config-line)#password Pass123
R1(config-line)#login
R1(config-line)#logging synchronous
R1(config-line)#exec-timeout 40
R1(config-line)#motd-banner
R1(config-line)#exit
R1(config)#
R1(config)#enable password Password
R1(config)#exit
```

To test the Telnet connectivity, from a client PC, type **telnet 192.168.10.1** and press **Enter**, then enter the telnet password. Execute the **enable** command and press **Enter**, then type the router password.

```
Packet Tracer PC Command Line 1.0
PC>telnet 192.168.10.1
Trying 192.168.10.1 …Open
User Access Verification
Password:
R1>enable
Password:
R1#
```

Now you are remotely connected to router R1 and you can execute all router commands through Telnet command line interface.

Accessing the CLI from a Remote Console

The remote console of the IR8340 can be accessed through Telnet or SSH. Telnet is disabled by default, and the more secure SSH should be used. For details on SSH access see the SSH chapter.

The following topics describe the procedure to access the CLI from a remote console:

Preparing to Connect to the Router Console

See the Cisco IOS-XE Device hardening guide at https://www.cisco.com/c/en/us/support/docs/ip/access-lists/13608-21.html for details.

Configuring the diagnostic and wait banners is optional, but recommended. The banners are especially useful as indicators to users about the status of their Telnet or SSH attempts.

To access the router remotely using Telnet from a TCP/IP network, configure the router to support virtual terminal lines using the **line vty** global configuration command. Configure the virtual terminal lines to require users to log in and specify a password.

See the Cisco IOS Terminal Services Command Reference document for more information about the line **vty global** configuration command.

To prevent disabling login on a line, specify a password with the **password** command when you configure the **login** command.

If you are using authentication, authorization, and accounting (AAA), configure the **login authentication** command. To prevent disabling login on a line for AAA authentication when you configure a list with the login authentication command, you must also configure that list using the **aaa authentication login** global configuration command.

For more information about AAA services, see the Cisco IOS XE Security Configuration Guide: Secure Connectivity and the Cisco IOS Security Command Reference documents. For more information about the **login line-configuration** command, see the Cisco IOS Terminal Services Command Reference document.

In addition, before you make a Telnet connection to the router, you must have a valid hostname for the router or have an IP address configured on the router. For more information about the requirements for connecting to the router using Telnet, information about customizing your Telnet services, and using Telnet key sequences, see the Cisco IOS Configuration Fundamentals Configuration Guide.

Setting Up the IR8340 to Run SSH

Follow the procedure given below to set up your device to run SSH:

Before you begin

Configure user authentication for local or remote access. This step is required.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:** `Router# configure terminal`	Enters global configuration mode.
Step 2	**hostname** *hostname* **Example:** `Router(config)# hostname your_hostname`	Configures a hostname and IP domain name for your device. **Note** Follow this procedure only if you are configuring the device as an SSH server.
Step 3	**ip domain-name** *domain_name* **Example:** `Router(config)# ip domain-name your_domain_name`	Configures a host domain for your device.
Step 4	**crypto key generate rsa modulus** *size* **Example:** `Router(config)# crypto key generate rsa modulus 2048`	Enables the SSH server for local and remote authentication on the device and generates an RSA key pair. Generating an RSA key pair for the device automatically enables SSH. We recommend that a minimum modulus size of 2048 bits. When you generate RSA keys, you are prompted to enter a modulus length. A longer modulus length might be more secure, but it takes longer to generate and to use. **Note**

	Command or Action	Purpose
		Follow this procedure only if you are configuring the device as an SSH server.
Step 5	**end** **Example:** `Router(config)# end`	Returns to privileged EXEC mode.

Using Telnet to Access a Console Interface

Procedure

Step 1 From your terminal or PC, enter one of the following commands:

- **connect host** [*port*] [*keyword*]
- **telnet host** [*port*] [*keyword*]

Here, *host* is the router hostname or IP address, *port* is a decimal port number (23 is the default), and *keyword* is a supported keyword. For more information about these commands, see the Cisco IOS Terminal Services Command Reference document.

The following example shows how to use the **telnet** command to connect to a router named **router**:

```
unix_host% telnet router
Trying 172.20.52.40...
Connected to 172.20.52.40.
Escape character is '^]'.
unix_host% connect
```

Step 2 Enter your login password:

```
User Access Verification
Password: mypassword
```

Note
If no password has been configured, press **Return**.

Step 3 From user EXEC mode, enter the **enable** command:

```
Router> enable
```

Step 4 At the password prompt, enter your system password:

```
Password: enablepass
```

Step 5 When the **enable** password is accepted, the privileged EXEC mode prompt is displayed:

```
Router#
```

Step 6 You now have access to the CLI in privileged EXEC mode and you can enter the necessary commands to complete your desired tasks.

Step 7 To exit the Telnet session, use the **exit** or **logout** command.

```
Router# logout
```

CLI Session Management

An inactivity timeout is configurable and can be enforced. Session locking provides protection from two users overwriting changes that the other has made. To prevent an internal process from using all the available capacity, some spare capacity is reserved for CLI session access. For example, this allows a user to remotely access a router.

Information About CLI Session Management

An inactivity timeout is configurable and can be enforced. Session locking provides protection from two users overwriting changes that each other has made. To prevent an internal process from using all the available capacity, some spare capacity is reserved for CLI session access. For example, this allows a user to remotely access the router.

Changing the CLI Session Timeout

Procedure

Step 1 `configure terminal`

Enters global configuration mode

Step 2 `line console 0`

Step 3 `session-timeout` *`minutes`*

The value of *`minutes`* sets the amount of time that the CLI waits before timing out. Setting the CLI session timeout increases the security of a CLI session. Specify a value of 0 for *`minutes`* to disable session timeout.

Step 4 `show line console 0`

Verifies the value to which the session timeout has been set, which is shown as the value for `"Idle Session"`.

Locking a CLI Session

Before you begin

To configure a temporary password on a CLI session, use the **lock** command in EXEC mode. Before you can use the **lock** command, you need to configure the line using the **lockable** command. In this example the line is configured as **lockable**, and then the **lock** command is used and a temporary password is assigned.

Procedure

Step 1 `Router# configure terminal`

Enters global configuration mode.

Step 2 Enter the line upon which you want to be able to use the **lock** command.

```
Router(config)# line console 0
```

Step 3 `Router(config)# lockable`

Enables the line to be locked.

Step 4 `Router(config)# exit`

Step 5 `Router# lock`

The system prompts you for a password, which you must enter twice.

```
Password: <password>
Again: <password>
Locked
```

Communications, services, and additional information


- To receive timely, relevant information from Cisco, sign up at Cisco Profile Manager.
- To get the business impact you're looking for with the technologies that matter, visit Cisco Services.
- To submit a service request, visit Cisco Support.
- To discover and browse secure, validated enterprise-class apps, products, solutions, and services, visit Cisco DevNet.
- To obtain general networking, training, and certification titles, visit Cisco Press.
- To find warranty information for a specific product or product family, access Cisco Warranty Finder.

Cisco Bug Search Tool

Cisco Bug Search Tool (BST) is a gateway to the Cisco bug-tracking system, which maintains a comprehensive list of defects and vulnerabilities in Cisco products and software. The BST provides you with detailed defect information about your products and software.

Documentation feedback

To provide feedback about Cisco technical documentation, use the feedback form available in the right pane of every online document.



CHAPTER 2

Using Cisco IOS XE Software

- Understanding Command Modes, on page 13
- Keyboard Shortcuts, on page 15
- Using the no and default Forms of Commands, on page 15
- Using the History Buffer to Recall Commands, on page 16
- Managing Configuration Files, on page 16
- Saving Configuration Changes, on page 16
- Filtering Output from the show and more Commands, on page 17
- Finding Support Information for Platforms and Cisco Software Images, on page 18

Understanding Command Modes

The command modes available in Cisco IOS XE are the same as those available in traditional Cisco IOS. Use the CLI to access Cisco IOS XE software. Because the CLI is divided into many different modes, the commands available to you at any given time depend on the mode that you are currently in. Entering a question mark (**?**) at the CLI prompt allows you to obtain a list of commands available for each command mode.

When you log in to the CLI, you are in user EXEC mode. User EXEC mode contains only a limited subset of commands. To have access to all commands, you must enter privileged EXEC mode, normally by using a password. From privileged EXEC mode, you can issue any EXEC command—user or privileged mode—or you can enter global configuration mode. Most EXEC commands are one-time commands. For example, **show** commands show important status information, and **clear** commands clear counters or interfaces. The EXEC commands are not saved when the software reboots.

Configuration modes allow you to make changes to the running configuration. If you later save the running configuration to the startup configuration, these changed commands are stored when the software is rebooted. To enter specific configuration modes, you must start at global configuration mode. From global configuration mode, you can enter interface configuration mode and a variety of other modes, such as protocol-specific modes.

ROM monitor mode is a separate mode used when the Cisco IOS XE software cannot load properly. If a valid software image is not found when the software boots or if the configuration file is corrupted at startup, the software might enter ROM monitor mode.

The following table describes how to access and exit various common command modes of the Cisco IOS XE software. It also shows examples of the prompts displayed for each mode.

Table 1: Accessing and Exiting Command Modes

Command Mode	Access Method	Prompt	Exit Method
User EXEC	Log in.	`Router>`	Use the **logout** command.
Privileged EXEC	From user EXEC mode, use the **enable** command.	`Router#`	To return to user EXEC mode, use the **disable** command.
Global configuration	From privileged EXEC mode, use the **configure terminal** command.	`Router(config)#`	To return to privileged EXEC mode from global configuration mode, use the **exit** or **end** command.
Interface configuration	From global configuration mode, specify an interface using an **interface** command.	`Router(config-if)#`	To return to global configuration mode, use the **exit** command. To return to privileged EXEC mode, use the **end** command.
Diagnostic	The router boots up or accesses diagnostic mode in the following scenarios: • In some cases, diagnostic mode will be reached when the Cisco IOS process or processes fail. In most scenarios, however, the router will reload. • A user-configured access policy is configured using the **transport-map** command that directs a user into diagnostic mode. • A break signal (**Ctrl-C**, **Ctrl-Shift-6**, or the **send break** command) is entered and the router is configured to go to diagnostic mode when the break signal is received.	`Router(diag)#`	If failure of the Cisco IOS process is the reason for entering diagnostic mode, the Cisco IOS problem must be resolved and the router rebooted to get out of diagnostic mode. If the router is in diagnostic mode because of a transport-map configuration, access the router through another port or by using a method that is configured to connect to the Cisco IOS CLI.

Command Mode	Access Method	Prompt	Exit Method
ROM monitor	From privileged EXEC mode, use the **reload** EXEC command. Press the **Break** key during the first 60 seconds while the system is booting.	`rommon#>`	To exit ROM monitor mode, manually boot a valid image or perform a reset with autoboot set so that a valid image is loaded.

Keyboard Shortcuts

Commands are not case sensitive. You can abbreviate commands and parameters if the abbreviations contain enough letters to be different from any other currently available commands or parameters.

The following table lists the keyboard shortcuts for entering and editing commands.

Table 2: Keyboard Shortcuts

Key Name	Purpose
Ctrl-B or the **Left Arrow** key	Move the cursor back one character.
Ctrl-F or the **Right Arrow** key	Move the cursor forward one character.
Ctrl-A	Move the cursor to the beginning of the command line.
Ctrl-E	Move the cursor to the end of the command line.
Esc B	Move the cursor back one word.
Esc F	Move the cursor forward one word.

Using the no and default Forms of Commands

Almost every configuration command has a **no** form. In general, use the **no** form to disable a function. Use the command without the **no** keyword to re-enable a disabled function or to enable a function that is disabled by default. For example, IP routing is enabled by default. To disable IP routing, use the **no ip routing** command; to re-enable IP routing, use the **ip routing** command. The Cisco IOS software command reference publications provide the complete syntax for the configuration commands and describe what the **no** form of a command does.

Many CLI commands also have a **default** form. By issuing the <*command*> **default** command-name, you can configure the command to its default setting. The Cisco IOS software command reference publications describe the function from a **default** form of the command when the **default** form performs a different function than the plain and **no** forms of the command. To see what default commands are available on your system, enter **default ?** in the appropriate command mode.

Using the History Buffer to Recall Commands

The history buffer stores the last 20 commands you entered. History substitution allows you to access these commands without retyping them, by using special abbreviated commands.

The following table lists the history substitution commands.

Table 3: History Substitution Commands

Command	Purpose
Ctrl-P or the **Up Arrow** key[1]	Recalls commands in the history buffer, beginning with the most recent command. Repeat the key sequence to recall successively older commands.
Ctrl-N or the **Down Arrow** key[1]	Returns to more recent commands in the history buffer after recalling commands with **Ctrl-P** or the **Up Arrow** key.
Router# **show history**	While in EXEC mode, lists the last few commands you entered.

[1] The arrow keys function only on ANSI-compatible terminals such as VT100s.

Managing Configuration Files

The startup configuration file is stored in the nvram: file system and the running configuration files are stored in the system: file system. This configuration file storage setup is also used on several other Cisco router platforms.

IOS XE provides encryption of the configuration file. Encryption is discussed in length in the IOS XE hardening device guide which can be found here:https://www.cisco.com/c/en/us/support/docs/ip/access-lists/13608-21.html

As a matter of routine maintenance on any Cisco router, users should back up the startup configuration file by copying the startup configuration file from NVRAM to one of the router's other file systems and, additionally, to a network server. Backing up the startup configuration file provides an easy method of recovering the startup configuration file if the startup configuration file in NVRAM becomes unusable for any reason.

The **copy** command can be used to back up startup configuration files.

For more detailed information on managing configuration files, see the "Managing Configuration Files" section in the Cisco IOS XE Configuration Fundamentals Configuration Guide.

Saving Configuration Changes

Use the **copy running-config startup-config** command to save your configuration changes to the startup configuration so that the changes will not be lost if the software reloads or a power outage occurs. For example:

```
Router# copy running-config startup-config
Destination filename [startup-config]?
```

```
Building configuration...
[OK]
Router#
*Sep 8 05:41:03.450: %SYS-6-PRIVCFG_ENCRYPT_SUCCESS: Successfully encrypted private config
 file
Router#
```



Note It may take a few minutes to save the configuration.

This task saves the configuration to the NVRAM.

Filtering Output from the show and more Commands

You can search and filter the output of **show** and **more** commands. This functionality is useful if you need to sort through large amounts of output or if you want to exclude output that you need not see.

To use this functionality, enter a **show** or **more** command followed by the "pipe" character (|); one of the keywords **begin**, **include**, or **exclude**; and a regular expression on which you want to search or filter (the expression is case sensitive):

show *command* | {**append** | **begin** | **exclude** | **include** | **redirect** | **section** | **tee**} *regular-expression*

The output matches certain lines of information in the configuration file.

Example

In this example, a modifier of the **show interface** command (**include protocol**) is used to provide only the output lines in which the expression **protocol** is displayed:

```
Router# show interface | include protocol
GigabitEthernet0/0/0 is up, line protocol is up
1401 unknown protocol drops
GigabitEthernet0/0/1 is up, line protocol is up
3073 unknown protocol drops
WPAN0/1/0 is up, line protocol is up
0 unknown protocol drops
Cellular0/4/0 is up, line protocol is up
0 unknown protocol drops
Cellular0/4/1 is up (spoofing), line protocol is up (spoofing)
0 unknown protocol drops
Cellular0/5/0 is up, line protocol is up
0 unknown protocol drops
Cellular0/5/1 is down, line protocol is down
0 unknown protocol drops
Loopback1 is up, line protocol is up
0 unknown protocol drops
Tunnel1 is up, line protocol is up
Tunnel protocol/transport GRE/IP
0 unknown protocol drops
Tunnel2 is up, line protocol is up
Tunnel protocol/transport GRE/IP
0 unknown protocol drops
VirtualPortGroup1 is up, line protocol is up
0 unknown protocol drops
```

Finding Support Information for Platforms and Cisco Software Images

The Cisco IOS XE software is packaged in feature sets consisting of software images that support specific platforms.

All of the Cisco IOS-XE configuration guides can be found here: https://www.cisco.com/c/en/us/support/ios-nx-os-software/ios-xe-17/series.html

The group of feature sets that are available for a specific platform depends on which Cisco software images are included in a release. To identify the set of software images available in a specific release or to find out if a feature is available in a given Cisco IOS XE software image, you can use Cisco Feature Navigator or see the https://www.cisco.com/c/en/us/support/ios-nx-os-software/ios-xe-17/series.html.

Using Cisco Feature Navigator

Use Cisco Feature Navigator to find information about platform support and software image support. Cisco Feature Navigator is a tool that enables you to determine which Cisco IOS XE software images support a specific software release, feature set, or platform. To use the navigator tool, an account on Cisco.com is not required.

Getting Help

Entering a question mark (**?**) at the CLI prompt displays a list of commands available for each command mode. You can also get a list of keywords and arguments associated with any command by using the context-sensitive help feature.

To get help that is specific to a command mode, a command, a keyword, or an argument, use one of the following commands.

Command	Purpose
`help`	Provides a brief description of the help system in any command mode.
`abbreviated-command-entry?`	Provides a list of commands that begin with a particular character string. **Note** There is no space between the command and the question mark.
`abbreviated-command-entry<Tab>`	Completes a partial command name.
`?`	Lists all the commands that are available for a particular command mode.

Command	Purpose
command ?	Lists the keywords or arguments that you must enter next on the command line. **Note** There is a space between the command and the question mark.

Finding Command Options: Example

This section provides information about how to display the syntax for a command. The syntax can consist of optional or required keywords and arguments. To display keywords and arguments for a command, enter a question mark (**?**) at the configuration prompt or after entering a part of a command followed by a space. The Cisco IOS XE software displays a list and brief descriptions of the available keywords and arguments. For example, if you are in global configuration mode and want to see all the keywords and arguments for the **arap** command, you should type **arap ?**.

The <cr> symbol in command help output stands for carriage return. On older keyboards, the carriage return key is the **Return** key. On most modern keyboards, the carriage return key is the **Enter** key. The <cr> symbol at the end of command help output indicates that you have the option to press **Enter** to complete the command and that the arguments and keywords in the list preceding the <cr> symbol are optional. The <cr> symbol by itself indicates that no more arguments or keywords are available, and that you must press **Enter** to complete the command.

The following table shows examples of using the question mark (**?**) to assist you in entering commands.

Table 4: Finding Command Options

Command	Comment
`Router> enable` `Password: <password>` `Router#`	Enter the **enable** command and password to access privileged EXEC commands. You are in privileged EXEC mode when the prompt changes to a " # " from the " > ", for example, `Router>` to `Router#`
`Router# configure terminal` `Enter configuration commands, one per line. End with CNTL/Z.` `Router(config)#`	Enter the **configure terminal** privileged EXEC command to enter global configuration mode. You are in global configuration mode when the prompt changes to `Router (config)#`
`Router(config)# interface GigabitEthernet ?` `<0-0> GigabitEthernet interface number` `Router(config)# interface GigabitEthernet 0/?` `<0-0> Port Adapter number` `Router (config)# interface GigabitEthernet 0/0/?` `<0-1> GigabitEthernet interface number` `Router (config)# interface GigabitEthernet 0/0/0?` `<0-1>` `Router(config-if)#`	Enter interface configuration mode by specifying the interface that you want to configure, using the **interface GigabitEthernet** global configuration command. Enter **?** to display what you must enter next on the command line. When the <cr> symbol is displayed, you can press **Enter** to complete the command. You are in interface configuration mode when the prompt changes to `Router(config-if)#`

Command	Comment
`Router(config-if)# ?` `Interface configuration commands:` `  .` `  .` `  .` `  ip  Interface Internet Protocol` `  config commands` `  keepalive  Enable keepalive` `  lan-name  LAN Name command` `  llc2  LLC2 Interface Subcommands` `  load-interval  Specify interval for load calculation` `  for an interface` `  locaddr-priority  Assign a priority group` `  logging  Configure logging for interface` `  loopback  Configure internal loopback on an` `  interface` `  mac-address  Manually set interface MAC address` `  mls  mls router sub/interface commands` `  mpoa  MPOA interface configuration commands` `  mtu  Set the interface Maximum Transmission Unit (MTU)` `  netbios  Use a defined NETBIOS access list` `  or enable name-caching` `  no  Negate a command or set its defaults` `  nrzi-encoding  Enable use of NRZI encoding` `  ntp  Configure NTP` `  .` `  .` `  .` `Router(config-if)#`	Enter **?** to display a list of all the interface configuration commands available for the interface. This example shows only some of the available interface configuration commands.

Command	Comment
	Enter the command that you want to configure for the interface. This example uses the **ip** command. Enter **?** to display what you must enter next on the command line. This example shows only some of the available interface IP configuration commands.

Command	Comment
Router(config-if)# **ip ?** Interface IP configuration subcommands: access-group Specify access control for packets address Set the IP address of an interface admission Apply Network Admission Control auth-proxy Apply authenticaton proxy authentication authentication subcommands bandwidth-percent Set EIGRP bandwidth limit bgp BGP interface commands broadcast-address Set the broadcast address of an interface cef Cisco Express Forwarding interface commands cgmp Enable/disable CGMP clear-dont-fragment Enable clear dont fragment (Currently Only SDWAN Tunnel Interface) dampening-change Percent interface metric must change to cause update dampening-interval Time in seconds to check interface metrics ddns Configure dynamic DNS dhcp Configure DHCP parameters for this interface directed-broadcast Enable forwarding of directed broadcasts dlep DLEP interface commands dns Configure DNS server flow NetFlow related commands flowspec FlowSpec configuration header-compression IPHC options hello-interval Configures EIGRP-IPv4 hello interval helper-address Specify a destination address for UDP broadcasts hold-time Configures EIGRP-IPv4 hold time igmp IGMP interface commands information-reply Enable sending ICMP Information Reply messages irdp ICMP Router Discovery Protocol load-sharing Style of load sharing local-proxy-arp Enable local-proxy ARP mask-reply Enable sending ICMP Mask Reply messages mfib Interface Specific MFIB Control mrm Configure IP Multicast Routing Monitor tester mroute-cache Enable switching cache for incoming multicast packets mtu Set IP Maximum Transmission Unit multicast IP multicast interface commands mux Enable IP multiplexing for outgoing packets nat NAT interface commands nbar Network-Based Application Recognition network-broadcast Accept and respond to network-prefix-directed broadcasts next-hop-self Configures EIGRP-IPv4 next-hop-self ospf OSPF interface commands pim PIM interface commands policy Enable policy routing portbundle IP Portbundle configuration	

Command	Comment
probe Enable HP Probe support proxy-arp Enable proxy ARP rarp-server Enable RARP server for static arp entries reassembly Reassembly redirects Enable sending ICMP Redirect messages rgmp Enable/disable RGMP rip Router Information Protocol route-cache Enable fast-switching cache for outgoing packets router IP router interface commands rsvp RSVP Interface Commands rtp RTP parameters sap Session Advertisement Protocol interface commands sdr Session Directory Protocol interface commands security DDN IP Security Option service IP service split-horizon Perform split horizon sticky-arp Allow the creation of sticky ARP entries subscriber IP session configuration options summary-address Perform address summarization tcp TCP interface commands topology-accounting Enable accounting for IP on all topologies of Router(config-if)# **ip**	
Router(config-if)# **ip address ?** A.B.C.D IP address dhcp IP Address negotiated via DHCP pool IP Address autoconfigured from a local DHCP pool Router(config-if)# **ip address**	Enter the command that you want to configure for the interface. This example uses the **ip address** command. Enter **?** to display what you must enter next on the command line. A carriage return (<cr>) is not displayed. Therefore, you must enter additional keywords or arguments to complete the command.
Router(config-if)# **ip address 172.16.0.1 ?** A.B.C.D IP subnet mask Router(config-if)# **ip address 172.16.0.1**	Enter the keyword or argument that you want to use. This example uses the 172.16.0.1 IP address. Enter **?** to display what you must enter next on the command line. In this example, you must enter an IP subnet mask. <cr> is not displayed. Therefore, you must enter additional keywords or arguments to complete the command.

Command	Comment
`Router(config-if)# ip address 172.16.0.1 255.255.255.0 ?` `  secondary  Make this IP address a secondary address` `  <cr>` `Router(config-if)# ip address 172.16.0.1 255.255.255.0`	Enter the IP subnet mask. This example uses the 255.255.255.0 IP subnet mask. Enter **?** to display what you must enter next on the command line. In this example, you can enter the **secondary** keyword, or you can press **Enter**. <cr> is displayed. Press **Enter** to complete the command, or enter another keyword.
`Router(config-if)# ip address 172.16.0.1 255.255.255.0` `Router(config-if)#`	Press **Enter** to complete the command.

Using Software Advisor


Cisco maintains the Software Advisor tool. See Tools and Resources. Use the Software Advisor tool to see if a feature is supported in a Cisco IOS XE release, to locate the software document for that feature, or to check the minimum software requirements of Cisco IOS XE software with the hardware installed on your router. You must be a registered user on Cisco.com to access this tool.

Using Software Release Notes

See the release notes for information about the following:

- Open and resolved severity 1 and 2 caveats

Release notes are intended to be release-specific for the most current release, and the information provided in these documents may not be cumulative in providing information about features that first appeared in previous releases. For cumulative feature information, refer to the Cisco Feature Navigator at: http://www.cisco.com/go/cfn/.



CHAPTER 3

Basic Router Configuration

This chapter contains the following sections:

- IR8340 Interface Naming, on page 25
- Basic Configuration, on page 26
- Configuring Global Parameters, on page 31
- Configuring the Gigabit Ethernet Interface, on page 32
- Support for sub-interface on GigabitEthernet0/0/0, on page 33
- Configuring a Loopback Interface, on page 33
- Configuring CPU Allocation, on page 34
- Enabling Cisco Discovery Protocol, on page 35
- Configuring Command-Line Access, on page 35
- Configuring Static Routes, on page 37
- Configuring Dynamic Routes, on page 39
- Modular QoS (MQC), on page 40

IR8340 Interface Naming

The supported hardware interfaces and their naming conventions are in the following table:

Hardware Interface	Naming Convention
Gigabit Ethernet WAN ports	GigabitEthernet0/0/0 GigabitEthernet0/0/1

Hardware Interface	Naming Convention
Gigabit Ethernet LAN ports	GigabitEthernet0/1/0 GigabitEthernet0/1/1 GigabitEthernet0/1/2 GigabitEthernet0/1/3 GigabitEthernet0/1/4 GigabitEthernet0/1/5 GigabitEthernet0/1/6 GigabitEthernet0/1/7 GigabitEthernet0/1/8 GigabitEthernet0/1/9 GigabitEthernet0/1/10 GigabitEthernet0/1/11
NIM Interface	0/2/0 0/2/1 0/3/0 0/3/1
Cellular Interface	cellular 0/4/0 cellular 0/4/1 cellular 0/5/0 cellular 0/5/1
mSATA SSD	msata
GPIO (External Alarm Interface)	alarm contact 1-2

Basic Configuration

The basic configuration is a result of the entries you made during the initial configuration dialog. This means the router has at least one interface set with an IP address to be reachable, either through WebUI or to allow the PnP process to work. Use the **show running-config** command to view the initial configuration, as shown in the following example:

```
IR8340#show running-config
Building configuration...

Current configuration : 6937 bytes
!
! Last configuration change at 17:35:35 UTC Wed Mar 23 2022
!
version 17.8
```

```
service timestamps debug datetime msec
service timestamps log datetime msec
! Call-home is enabled by Smart-Licensing.
service call-home
platform qfp utilization monitor load 80
platform punt-keepalive disable-kernel-core
!
hostname Sumatra-DUT
!
boot-start-marker
boot system flash
0081684787552360_ir8340-universalk9.BLD_V178_THROTTLE_LATEST_20220321_143500_V17_8_0_65.SSA.bin
boot-end-marker
!
!
! card type command needed for slot/bay 0/3
no aaa new-model
!
!
!
!
!
!
!
!
!
!
login on-success log
!
!
!
!
!
!
!
subscriber templating
!
!
!
!
vtp mode transparent
!
multilink bundle-name authenticated
!
!
!
!
!
!
!
!
!
crypto pki trustpoint TP-self-signed-829458546
 enrollment selfsigned
 subject-name cn=IOS-Self-Signed-Certificate-829458546
 revocation-check none
 rsakeypair TP-self-signed-829458546
!
crypto pki trustpoint SLA-TrustPoint
 enrollment pkcs12
 revocation-check crl
!
!
crypto pki certificate chain TP-self-signed-829458546
```

```
 certificate self-signed 01
  3082032E 30820216 A0030201 02020101 300D0609 2A864886 F70D0101 05050030
  30312E30 2C060355 04031325 494F532D 53656C66 2D536967 6E65642D 43657274
  69666963 6174652D 38323934 35383534 36301E17 0D323230 33323331 37333433
  395A170D 33323033 32323137 33343339 5A303031 2E302C06 03550403 1325494F
  532D5365 6C662D53 69676E65 642D4365 72746966 69636174 652D3832 39343538
  35343630 82012230 0D06092A 864886F7 0D010101 05000382 010F0030 82010A02
  82010100 90B8DF91 C27E2942 0C342B4E 5C7A03C5 91E9ACE7 C29E8D1B 291B8799
  3C468901 6B4DA7E9 E4480CC0 B4C2E1D9 918BBDB9 26EB7EE4 E3D7F76B 42FD0642
  D29E33DA 01ECAE68 2A7254DE 32163A82 959C75B7 DAA84B34 670B7CA3 F94B0803
  A9B11490 A350030D 5DD8178F 1579E30B 8D0B079A 090917F3 60031B68 F961A0CE
  9E958239 973E6B08 3D293F10 38136F15 83D8C801 A58D71E4 3CC128AE 8B9BF214
  AA4B09E2 CB9841E3 0F455D66 504F89E9 F6B70AC7 1B2C3C48 5ED5679C 121A5415
  198D7D0D 0AE444E1 76309174 67FF66E6 BBAFA506 EE10C77D EDD89004 BE72EC05
  F960AAC0 F7DD0A3E 7769C277 3529B0CC 06788C4C B0A82D51 F8A74DAB 997D6716
  3F0F694B 02030100 01A35330 51300F06 03551D13 0101FF04 05300301 01FF301F
  0603551D 23041830 16801439 96B67C33 D166686C 2C7A99C0 698D085E B69B0C30
  1D060355 1D0E0416 04143996 B67C33D1 66686C2C 7A99C069 8D085EB6 9B0C300D
  06092A86 4886F70D 01010505 00038201 01008D8D 7BED46B9 4DDF60D3 01BE178A
  D4B97142 9BF6991E 70693302 878693DE 5C39373B FE6D2D77 3B353F2C 21707C5F
  67C99A51 E07D5FF6 B59FCDF1 EC6751B0 8DB7ED72 FAD9AED5 7D7F7895 9DA6FAD5
  72304A73 869F4013 1559F607 7F8303E2 8E8F1011 525BC32B A32EF28A 7EC811C2
  45268BC9 225B65AB 94998717 0BFC0F4F C772233D 7B6635DB AA554FB4 67EC7F7B
  258BDD81 855B64A5 6236CE38 58B795D7 FD5096BE 8DA304CF 987450BE 4AD62994
  CCC2D3FB 540A8BA5 A8CE6109 4DAB37C4 A692F2C9 02B653F8 7B539BC1 5B338E26
  A71F8C43 192521BD F10401D8 0E23D095 1C943214 A01B9E48 40299F2C 35183755
  26956737 8CF47405 E7757043 80AA8C93 8B41
       quit
crypto pki certificate chain SLA-TrustPoint
 certificate ca 01
  30820321 30820209 A0030201 02020101 300D0609 2A864886 F70D0101 0B050030
  32310E30 0C060355 040A1305 43697363 6F312030 1E060355 04031317 43697363
  6F204C69 63656E73 696E6720 526F6F74 20434130 1E170D31 33303533 30313934
  3834375A 170D3338 30353330 31393438 34375A30 32310E30 0C060355 040A1305
  43697363 6F312030 1E060355 04031317 43697363 6F204C69 63656E73 696E6720
  526F6F74 20434130 82012230 0D06092A 864886F7 0D010101 05000382 010F0030
  82010A02 82010100 A6BCBD96 131E05F7 145EA72C 2CD686E6 17222EA1 F1EFF64D
  CBB4C798 212AA147 C655D8D7 9471380D 8711441E 1AAF071A 9CAE6388 8A38E520
  1C394D78 462EF239 C659F715 B98C0A59 5BBB5CBD 0CFEBEA3 700A8BF7 D8F256EE
  4AA4E80D DB6FD1C9 60B1FD18 FFC69C96 6FA68957 A2617DE7 104FDC5F EA2956AC
  7390A3EB 2B5436AD C847A2C5 DAB553EB 69A9A535 58E9F3E3 C0BD23CF 58BD7188
  68E69491 20F320E7 948E71D7 AE3BCC84 F10684C7 4BC8E00F 539BA42B 42C68BB7
  C7479096 B4CB2D62 EA2F505D C7B062A4 6811D95B E8250FC4 5D5D5FB8 8F27D191
  C55F0D76 61F9A4CD 3D992327 A8BB03BD 4E6D7069 7CBADF8B DF5F4368 95135E44
  DFC7C6CF 04DD7FD1 02030100 01A34230 40300E06 03551D0F 0101FF04 04030201
  06300F06 03551D13 0101FF04 05300301 01FF301D 0603551D 0E041604 1449DC85
  4B3D31E5 1B3E6A17 606AF333 3D3B4C73 E8300D06 092A8648 86F70D01 010B0500
  03820101 00507F24 D3932A66 86025D9F E838AE5C 6D4DF6B0 49631C78 240DA905
  604EDCDE FF4FED2B 77FC460E CD636FDB DD44681E 3A5673AB 9093D3B1 6C9E3D8B
  D98987BF E40CBD9E 1AECA0C2 2189BB5C 8FA85686 CD98B646 5575B146 8DFC66A8
  467A3DF4 4D565700 6ADF0F0D CF835015 3C04FF7C 21E878AC 11BA9CD2 55A9232C
  7CA7B7E6 C1AF74F6 152E99B7 B1FCF9BB E973DE7F 5BDDEB86 C71E3B49 1765308B
  5FB0DA06 B92AFE7F 494E8A9E 07B85737 F3A58BE1 1A48A229 C37C1E69 39F08678
  80DDCD16 D6BACECA EEBC7CF9 8428787B 35202CDC 60E4616A B623CDBD 230E3AFB
  418616A9 4093E049 4D10AB75 27E86F73 932E35B5 8862FDAE 0275156F 719BB2F0
  D697DF7F 28
       quit
!
!
no license feature hseck9
license udi pid IR8340-K9 sn FDO2523J7GF
memory free low-watermark processor 63132
!
diagnostic bootup level minimal
```

```
!
spanning-tree mode rapid-pvst
spanning-tree extend system-id
no power main redundant
!
!
!
!
redundancy
 mode none
!
!
!
!
controller Cellular 0/4/0
!
controller Cellular 0/5/0
!
!
vlan internal allocation policy ascending
!
!
!
!
!
!
!
!
!
!
!
!
!
!
!
!
!
!
!
!
interface GigabitEthernet0/0/0
 no ip address
 shutdown
 negotiation auto
!
interface GigabitEthernet0/0/1
 no ip address
 shutdown
 negotiation auto
!
interface GigabitEthernet0/1/0
!
interface GigabitEthernet0/1/1
!
interface GigabitEthernet0/1/2
!
interface GigabitEthernet0/1/3
!
interface GigabitEthernet0/1/4
!
interface GigabitEthernet0/1/5
!
interface GigabitEthernet0/1/6
!
interface GigabitEthernet0/1/7
```

```
!
interface GigabitEthernet0/1/8
!
interface GigabitEthernet0/1/9
!
interface GigabitEthernet0/1/10
!
interface GigabitEthernet0/1/11
!
interface Serial0/2/0
!
interface Serial0/2/1
!
interface Serial0/2/2
!
interface Serial0/2/3
!
interface Serial0/2/4
!
interface Serial0/2/5
!
interface Serial0/2/6
!
interface Serial0/2/7
!
interface Cellular0/4/0
 no ip address
 shutdown
!
interface Cellular0/4/1
 no ip address
 shutdown
!
interface Cellular0/5/0
 no ip address
 shutdown
!
interface Cellular0/5/1
 no ip address
 shutdown
!
interface Vlan1
 no ip address
!
ip http server
ip http authentication local
ip http secure-server
ip forward-protocol nd
!
!
!
!
!
!
control-plane
!
!
!
!
!
!
line con 0
 stopbits 1
line aux 0
```

```
line vty 0 4
 login
 transport input ssh
line vty 5 14
 login
 transport input ssh
!
call-home
 ! If contact email address in call-home is configured as sch-smart-licensing@cisco.com
 ! the email address configured in Cisco Smart License Portal will be used as contact email
 address to send SCH notifications.
 contact-email-addr sch-smart-licensing@cisco.com
 profile "CiscoTAC-1"
  active
  destination transport-method http
!
!
!
!
!
!
end
```

Configuring Global Parameters

To configure global parameters for your router, follow these steps.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:** `Router> enable` `Router# configure terminal` `Router(config)#`	Enters global configuration mode when using the console port. Use the following to connect to the router with a remote terminal: `telnet router-name or address` `Login: login-id` `Password: *********` `Router> enable`
Step 2	**hostname** *name* **Example:** `Router(config)# hostname Router`	Specifies the name for the router.
Step 3	**enable secret** *password* or **enable password** *password* **Example:** `Router(config)# enable secret password`	Specifies a password to prevent unauthorized access to the router.

Configuring the Gigabit Ethernet Interface

The router features two Gigabit Ethernet (GE) ports that can be used to enable WAN uplink connectivity:

- Two GigE Copper port (RJ45) on the midplane board. It supports standard 3-speed (10/100/1000) Ethernet features including auto-MDIX.
- Two SFP socket. It supports standard 1000Base-X or 100Base-FX Ethernet over single-mode or multi-mode fiber.

Note These ports are combo mode. Either copper or SFP can be used distinctly, but not at the same time for each interface.

To configure the Gigabit Ethernet interface, follow these steps:

Procedure

	Command or Action	Purpose
Step 1	**configure terminal**	
Step 2	**ipv6 unicast-routing** **Example:** `Router(config)# ipv6 unicast-routing`	Enables forwarding of IPv6 unicast data packets.
Step 3	**interface GigabitEthernet** *slot/bay/port* **Example:** `Router(config)# interface GigabitEthernet 0/0/0`	Enters the configuration mode for an interface on the router.
Step 4	**ip address** *ip-address mask* **Example:** `Router(config-if)# ip address 192.168.12.2 255.255.255.0`	Sets the IP address and subnet mask for the specified interface. Use this Step if you are configuring an IPv4 address.
Step 5	**ipv6 address** *ipv6-address/prefix* **Example:** `Router(config-if)# ipv6 address 2001.db8::ffff:1/128`	Sets the IPv6 address and prefix for the specified interface. Use this step instead of Step 2, if you are configuring an IPv6 address. IPv6 unicast-routing needs to be set-up as well, see further information in the IPv6 Addressing and Basic Connectivity Configuration Guide.
Step 6	**no shutdown** **Example:** `Router(config-if)# no shutdown`	Enables the interface and changes its state from administratively down to administratively up.

	Command or Action	Purpose
Step 7	**exit** **Example:** `Router(config-if)# exit`	Exits the configuration mode of interface and returns to the global configuration mode.

Support for sub-interface on GigabitEthernet0/0/0

Cisco IOS XE supports sub-interfaces and dot1q configuration on the g0/0/0 interface. For example:

```
Router(config)#interface g0/0/0.?
  <1-4294967295>  GigabitEthernet interface number
Router(config-subif)#encapsulation ?
  dot1Q           IEEE 802.1Q Virtual LAN
```

Configuring a Loopback Interface

Before you begin

The loopback interface acts as a placeholder for the static IP address and provides default routing information.

To configure a loopback interface, follow these steps.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal**	
Step 2	**interface** *type number* **Example:** `Router(config)# interface Loopback 0`	Enters configuration mode on the loopback interface.
Step 3	(Option 1) **ip address** *ip-address mask* **Example:** `Router(config-if)# ip address 192.0.2.0 255.255.0.0`	Sets the IP address and subnet mask on the loopback interface. (If you are configuring an IPv6 address, use the **ipv6 address** *ipv6-address/prefix* command described below.
Step 4	(Option 2) **ipv6 address** *ipv6-address/prefix* **Example:** `Router(config-if)# ipv6 address 2001:db8::ffff:1/128`	Sets the IPv6 address and prefix on the loopback interface.

	Command or Action	Purpose
Step 5	**exit** **Example:** `Router(config-if)# exit`	Exits configuration mode for the loopback interface and returns to global configuration mode.

Example

Verifying Loopback Interface Configuration

Enter the **show interface loopback** command. You should see an output similar to the following example:

```
Router# show interface loopback 0
Loopback0 is up, line protocol is up
  Hardware is Loopback
  Internet address is 192.0.2.0/16
  MTU 1514 bytes, BW 8000000 Kbit, DLY 5000 usec,
     reliability 255/255, txload 1/255, rxload 1/255
  Encapsulation LOOPBACK, loopback not set
  Last input never, output never, output hang never
  Last clearing of "show interface" counters never
  Queueing strategy: fifo
  Output queue 0/0, 0 drops; input queue 0/75, 0 drops
  5 minute input rate 0 bits/sec, 0 packets/sec
  5 minute output rate 0 bits/sec, 0 packets/sec
     0 packets input, 0 bytes, 0 no buffer
     Received 0 broadcasts, 0 runts, 0 giants, 0 throttles
     0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored, 0 abort
     0 packets output, 0 bytes, 0 underruns
     0 output errors, 0 collisions, 0 interface resets
     0 output buffer failures, 0 output buffers swapped out
```

Alternatively, use the **ping** command to verify the loopback interface, as shown in the following example:

```
Router# ping 192.0.2.0
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 192.0.2.0, timeout is 2 seconds:
!!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 1/2/4 ms
```

Configuring CPU Allocation

You can change allocation of the available 8 cores of the IR8340 router to different functions in a flexible way. The core allocation is based on the customer configuration of the different services.

From Cisco IOS XE Release 17.9 onwards, you can use the **platform resource {control-plane-heavy|data-plane-heavy|service-plane-heavy}** command to adjust the cores across control plane, service plane, and data plane. However, you have to save the configuration and reboot the device for the configured profile to take effect.

```
Router#configure terminal
Router#platform resource ?
  control-plane-heavy  Use Control Plane Heavy template
  data-plane-heavy     Use Data Plane Heavy template
  service-plane-heavy  Use Service Plane Heavy template
```

The following show command output shows the default CPU cores allocation:

```
Router#show platform software cpu alloc
CPU alloc information:
Control plane cpu alloc: 0
Data plane cpu alloc: 4-7
Service plane cpu alloc: 1-3
Slow control plane cpu alloc: 1-3
Template used: default-service_plane_heavy
```

The following show command output shows the CPU cores allocaiton for the service plane:

```
Router#show platform software cpu alloc
CPU alloc information:
Control plane cpu alloc: 0
Data plane cpu alloc: 4-7
Service plane cpu alloc: 1-3
Slow control plane cpu alloc: 1-3
Template used: CLI-service_plane_heavy
```

The following show command output shows the CPU cores allocaiton for the control plane:

```
Router#show platform software cpu alloc
CPU alloc information:
Control plane cpu alloc: 0
Data plane cpu alloc: 4-7
Service plane cpu alloc: 2-3
Slow control plane cpu alloc: 1-3
Template used: CLI-control_plane_heavy
```

The following show command output shows the CPU cores allocaiton for the data plane:

```
Router#show platform software cpu alloc
CPU alloc information:
Control plane cpu alloc: 0
Data plane cpu alloc: 2-7
Service plane cpu alloc: 1
Slow control plane cpu alloc: 1-2
Template used: CLI-data_plane_heavy
```

Enabling Cisco Discovery Protocol

Cisco Discovery Protocol (CDP) is enabled by default on the router. It may be disabled if needed for security purposes.

For more information on using CDP, see Cisco Discovery Protocol Configuration Guide, Cisco IOS XE Release 3S.

Configuring Command-Line Access

To configure parameters to control access to the router, follow these steps.

Note Transport input must be set as explained in the previous Telnet and SSH sections of the guide.

Procedure

	Command or Action	Purpose
Step 1	**line** [**aux** | **console** | **tty** | **vty**] *line-number* **Example:** `Router(config)# line console 0`	Enters line configuration mode, and specifies the type of line. The example provided here specifies a console terminal for access.
Step 2	**password** *password* **Example:** `Router(config-line)# password userpass`	Specifies a unique password for the console terminal line.
Step 3	**login** **Example:** `Router(config-line)# login`	Enables password checking at terminal session login.
Step 4	**exec-timeout** *minutes* [*seconds*] **Example:** `Router(config-line)# exec-timeout 5 30` `Router(config-line)#`	Sets the interval during which the EXEC command interpreter waits until user input is detected. The default is 10 minutes. Optionally, adds seconds to the interval value. The example provided here shows a timeout of 5 minutes and 30 seconds. Entering a timeout of **0 0** specifies never to time out.
Step 5	**exit** **Example:** `Router(config-line)# exit`	Exits line configuration mode to re-enter global configuration mode.
Step 6	**line** [**aux** | **console** | **tty** | **vty**] *line-number* **Example:** `Router(config)# line vty 0 4` `Router(config-line)#`	Specifies a virtual terminal for remote console access.
Step 7	**end** **Example:** `Router(config-line)# end`	Exits line configuration mode, and returns to privileged EXEC mode.

Example

The following configuration shows the command-line access commands. Note that transport input none is the default, but if SSH is enabled this must be set to ssh.

You do not have to input the commands marked **default**. These commands appear automatically in the configuration file that is generated when you use the **show running-config** command.

```
!
line console 0
exec-timeout 10 0
password 4youreyesonly
login
transport input none (default)
stopbits 1 (default)
line vty 0 4
password secret
login
!
```

Configuring Static Routes

Static routes provide fixed routing paths through the network. They are manually configured on the router. If the network topology changes, the static route must be updated with a new route. Static routes are private routes unless they are redistributed by a routing protocol.

To configure static routes, follow these steps.

Procedure

	Command or Action	Purpose
Step 1	(Option 1) **ip route** *prefix mask* {*ip-address* | *interface-type interface-number* [*ip-address*]} **Example:** `Router(config)# ip route 192.10.2.3 255.255.0.0 10.10.10.2`	Specifies a static route for the IP packets. (If you are configuring an IPv6 address, use the **ipv6 route** command described below.)
Step 2	(Option 2) **ipv6 route** *prefix/mask* {*ipv6-address* | *interface-type interface-number* [*ipv6-address*]} **Example:** `Router(config)# ipv6 route 2001:db8:2::/64 2001:db8:3::0`	Specifies a static route for the IP packets. See additional information for IPv6 here: https://www.cisco.com/c/en/us/td/docs/ios-xml/ios/ipv6_basic/configuration/xe-16-10/ip6b-xe-16-10-book/read-me-first.html
Step 3	(Option 3) **ip route vrf** *vrf-name ip-address*	Configure IP router vrf.

	Command or Action	Purpose
Step 4	**end** **Example:** `Router(config)# end`	Exits global configuration mode and enters privileged EXEC mode.

In the following configuration example, the static route sends out all IP packets with a destination IP address of 192.168.1.0 and a subnet mask of 255.255.255.0 on the Gigabit Ethernet interface to another device with an IP address of 10.10.10.2. Specifically, the packets are sent to the configured layer 3 adjacent device.

You do not have to enter the command marked **default**. This command appears automatically in the configuration file generated when you use the **running-config** command.

```
!
ip classless (default)
ip route 2001:db8:2::/64 2001:db8:3::0
```

Verifying Configuration

To verify that you have configured static routing correctly, enter the **show ip route** command (or **show ipv6 route** command) and look for static routes marked with the letter S.

When you use an IPv4 address, you should see verification output similar to the following:

```
Router# show ip route
Codes: C - connected, S - static, R - RIP, M - mobile, B - BGP
       D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2
       i - IS-IS, su - IS-IS summary, L1 - IS-IS level-1, L2 - IS-IS level-2
       ia - IS-IS inter area, * - candidate default, U - per-user static route
       o - ODR, P - periodic downloaded static route

Gateway of last resort is not set

     10.0.0.0/24 is subnetted, 1 subnets
C       10.108.1.0 is directly connected, Loopback0
S*   0.0.0.0/0 is directly connected, GigabitEthernet0/0/0
```

When you use an IPv6 address, you should see verification output similar to the following:

```
Router# show ipv6 route
IPv6 Routing Table - default - 5 entries
Codes: C - Connected, L - Local, S - Static, U - Per-user Static route
       B - BGP, R - RIP, H - NHRP, I1 - ISIS L1
       I2 - ISIS L2, IA - ISIS interarea, IS - ISIS summary, D - EIGRP
       EX - EIGRP external, ND - ND Default, NDp - ND Prefix, DCE -
Destination
       NDr - Redirect, O - OSPF Intra, OI - OSPF Inter, OE1 - OSPF ext 1
       OE2 - OSPF ext 2, ON1 - OSPF NSSA ext 1, ON2 - OSPF NSSA ext 2
       ls - LISP site, ld - LISP dyn-EID, a - Application

C   2001:DB8:3::/64 [0/0]
       via GigabitEthernet0/0/2, directly connected
S   2001:DB8:2::/64 [1/0]
       via 2001:DB8:3::1
```

Configuring Dynamic Routes

In dynamic routing, the network protocol adjusts the path automatically, based on network traffic or topology. Changes in dynamic routes are shared with other routers in the network.

All of the Cisco IOS-XE configuration guides can be found here: https://www.cisco.com/c/en/us/support/ios-nx-os-software/ios-xe-17/series.html

Configuring Routing Information Protocol

To configure the RIP on a router, follow these steps.

Procedure

	Command or Action	Purpose
Step 1	**router rip** **Example:** `Router(config)# router rip`	Enters router configuration mode, and enables RIP on the router.
Step 2	**version** {**1** | **2**} **Example:** `Router(config-router)# version 2`	Specifies use of RIP version 1 or 2.
Step 3	**network** *ip-address* **Example:** `Router(config-router)# network 192.168.1.1` `Router(config-router)# network 10.10.7.1`	Specifies a list of networks on which RIP is to be applied, using the address of the network of each directly connected network.
Step 4	**no auto-summary** **Example:** `Router(config-router)# no auto-summary`	Disables automatic summarization of subnet routes into network-level routes. This allows subprefix routing information to pass across classful network boundaries.
Step 5	**end** **Example:** `Router(config-router)# end`	Exits router configuration mode, and enters privileged EXEC mode.

Example

Verifying Configuration

To verify that you have configured RIP correctly, enter the **show ip route** command and look for RIP routes marked with the letter R. You should see an output similar to the one shown in the following example:

```
Router# show ip route
Codes: C - connected, S - static, R - RIP, M - mobile, B - BGP
       D - EIGRP, EX - EIGRP external, O - OSPF, IA - OSPF inter area
       N1 - OSPF NSSA external type 1, N2 - OSPF NSSA external type 2
       E1 - OSPF external type 1, E2 - OSPF external type 2
       i - IS-IS, su - IS-IS summary, L1 - IS-IS level-1, L2 - IS-IS level-2
       ia - IS-IS inter area, * - candidate default, U - per-user static route
       o - ODR, P - periodic downloaded static route

Gateway of last resort is not set

     10.0.0.0/24 is subnetted, 1 subnets
C       10.108.1.0 is directly connected, Loopback0
R    3.0.0.0/8 [120/1] via 2.2.2.1, 00:00:02, Ethernet0/0/0
```

Configuring Enhanced Interior Gateway Routing Protocol

The Enhanced Interior Gateway Routing Protocol (EIGRP) is an enhanced version of the Interior Gateway Routing Protocol (IGRP) developed by Cisco. The convergence properties and the operating efficiency of EIGRP have improved substantially over IGRP, and IGRP is now obsolete.


The convergence technology of EIGRP is based on an algorithm called the Diffusing Update Algorithm (DUAL). The algorithm guarantees loop-free operation at every instant throughout a route computation and allows all devices involved in a topology change to synchronize. Devices that are not affected by topology changes are not involved in recomputations

Details on configuring Enhanced Interior Gateway Routing Protocol (EIGRP), are found in the following guide: https://www.cisco.com/c/en/us/td/docs/ios-xml/ios/iproute_eigrp/configuration/xe-16-10/ire-xe-16-10-book/ire-enhanced-igrp.html

Modular QoS (MQC)

This section provides an overview of Modular QoS CLI (MQC), which is how all QoS features are configured on the IoT Integrated Services Router. MQC is a standardized approach to enabling QoS on Cisco routing and switching platforms.

Follow the procedures that are in the QoS Modular QoS Command-Line Interface Configuration Guide, Cisco IOS XE 17 guide.



CHAPTER 4

Configuring Secure Shell

This section contains the following topics:

- Information About Secure Shell , on page 41
- How to Configure Secure Shell, on page 43
- Information about Secure Copy, on page 47
- Additional References, on page 49

Information About Secure Shell

Secure Shell (SSH) is a protocol that provides a secure, remote connection to a device. SSH provides more security for remote connections than Telnet does by providing strong encryption when a device is authenticated. This software release supports SSH Version 1 (SSHv1) and SSH Version 2 (SSHv2).

Prerequisites for Configuring Secure Shell

The following are the prerequisites for configuring the device for secure shell (SSH):

- For SSH to work, the switch needs an RSA public/private key pair.
- The Secure Shell (SSH) server requires an IPsec (Data Encryption Standard [DES] or 3DES) encryption software image; the SSH client requires an IPsec (DES or 3DES) encryption software image.)
- Configure a hostname and host domain for your device by using the hostname and ip domain-name commands in global configuration mode. Use the **hostname** and **ip domain-name** commands in global configuration mode.

Restrictions for Configuring Secure Shell

The following are restrictions for configuring the IR8340 for secure shell.

- The router supports RSA authentication.
- SSH supports only the execution-shell application.
- The SSH server and the SSH client are supported only on Data Encryption Standard (DES) (56-bit) and 3DES (168-bit) data encryption software. In DES software images, DES is the only encryption algorithm available. In 3DES software images, both DES and 3DES encryption algorithms are available.

Note Cisco highly recommends the 3DES encryption as it is stronger.

See the Cisco IOS-XE Device hardening guide at https://www.cisco.com/c/en/us/support/docs/ip/access-lists/13608-21.html for details.

- This software release supports IP Security (IPSec).
- The IR8340 supports the Advanced Encryption Standard (AES) encryption algorithm with a 128-bit key, 192-bit key, or 256-bit key. However, symmetric cipher AES to encrypt the keys is not supported.
- The login banner is not supported in Secure Shell Version 1. It is supported in Secure Shell Version 2, which Cisco recommends due to its better security.
- The -l keyword and userid :{number} {ip-address} delimiter and arguments are mandatory when configuring the alternative method of Reverse SSH for console access.

SSH And Router Access

Secure Shell (SSH) is a protocol that provides a secure, remote connection to a device. SSH provides more security for remote connections than Telnet does by providing strong encryption when a device is authenticated. This software release supports SSH Version 1 (SSHv1) and SSH Version 2 (SSHv2). SSH functions the same in IPv6 as in IPv4. For IPv6, SSH supports IPv6 addresses and enables secure, encrypted connections with remote IPv6 nodes over an IPv6 transport.

SSH Servers, Integrated Clients, and Supported Versions

The Secure Shell (SSH) Integrated Client feature is an application that runs over the SSH protocol to provide device authentication and encryption. The SSH client enables a Cisco device to make a secure, encrypted connection to another Cisco device or to any other device running the SSH server. This connection provides functionality similar to that of an outbound Telnet connection except that the connection is encrypted. With authentication and encryption, the SSH client allows for secure communication over an unsecured network.

The SSH server and SSH integrated client are applications that run on the switch. The SSH server works with the SSH client supported in this release and with non-Cisco SSH clients. The SSH client works with publicly and commercially available SSH servers. The SSH client supports the ciphers of Data Encryption Standard (DES), 3DES, and password authentication.

Note The SSH client functionality is available only when the SSH server is enabled.

User authentication is performed like that in the Telnet session to the device. SSH also supports the following user authentication methods:

- TACACS+
- RADIUS
- Local authentication and authorization

SSH Configuration Guidelines

Follow these guidelines when configuring the device as an SSH server or SSH client:

- An RSA key pair generated by a SSHv1 server can be used by an SSHv2 server, and the reverse.
- If you get CLI error messages after entering the **crypto key generate rsa** global configuration command, an RSA key pair has not been generated. Reconfigure the hostname and domain, and then enter the **crypto key generate rsa** command.
- When generating the RSA key pair, the message *No hostname specified* might appear. If it does, you must configure an IP hostname by using the **hostname** global configuration command.
- When generating the RSA key pair, the message No domain specified might appear. If it does, you must configure an IP domain name by using the **ip domain-name** global configuration command.
- When configuring the local authentication and authorization authentication method, make sure that AAA is disabled on the console.

How to Configure Secure Shell

Setting Up the IR8340 to Run SSH

Follow the procedure given below to set up your device to run SSH:

Before you begin

Configure user authentication for local or remote access. This step is required.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:** `Router# configure terminal`	Enters global configuration mode.
Step 2	**hostname** *hostname* **Example:** `Router(config)# hostname your_hostname`	Configures a hostname and IP domain name for your device. **Note** Follow this procedure only if you are configuring the device as an SSH server.
Step 3	**ip domain-name** *domain_name* **Example:** `Router(config)# ip domain-name your_domain_name`	Configures a host domain for your device.

	Command or Action	Purpose
Step 4	**crypto key generate rsa modulus** *size* **Example:** `Router(config)# crypto key generate rsa modulus 2048`	Enables the SSH server for local and remote authentication on the device and generates an RSA key pair. Generating an RSA key pair for the device automatically enables SSH. We recommend that a minimum modulus size of 2048 bits. When you generate RSA keys, you are prompted to enter a modulus length. A longer modulus length might be more secure, but it takes longer to generate and to use. **Note** Follow this procedure only if you are configuring the device as an SSH server.
Step 5	**end** **Example:** `Router(config)# end`	Returns to privileged EXEC mode.

Configuring the SSH Server

Follow these steps to configure the SSH server:

Note This procedure is only required if you are configuring the device as an SSH server.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:** `IR8340# configure terminal`	Enters global configuration mode.
Step 2	**ip ssh version** [2] **Example:** `IR8340(config)# ip ssh version 2`	(Optional) Configures the device to run SSH Version 2. If you do not enter this command or do not specify a keyword, the SSH server selects the latest SSH version supported by the SSH client. For example, if the SSH client supports SSHv1 and SSHv2, the SSH server selects SSHv2.

	Command or Action	Purpose
Step 3	**ip ssh** {**timeout** *seconds* | **authentication-retries** *number*} **Example:** `IR8340(config)# ip ssh timeout 90` `ip ssh authentication-retries 2`	Configures the SSH control parameters: • Specify the time-out value in seconds; the default is 120 seconds. The range is 0 to 120 seconds. This parameter applies to the SSH negotiation phase. After the connection is established, the device uses the default time-out values of the CLI-based sessions. By default, up to five simultaneous, encrypted SSH connections for multiple CLI-based sessions over the network are available (session 0 to session 4). After the execution shell starts, the CLI-based session time-out value returns to the default of 10 minutes. • Specify the number of times that a client can re-authenticate to the server. The default is 3; the range is 0 to 5. Repeat this step when configuring both parameters.
Step 4	Use one or both of the following: • **line vty** *line_number* [*ending line number*] • **transport input ssh** **Example:** `IR8340(config)# line vty 1 10` or `IR8340(config-line)# transport input ssh`	(Optional) Configures the virtual terminal line settings. • Enters line configuration mode to configure the virtual terminal line settings. For the *line_number* and *ending_line_number* arguments, the range is from 0 to 15. • Specifies that the device prevents non-SSH Telnet connections, limiting the device to only SSH connections.
Step 5	**end** **Example:** `IR8340(config-line)# end`	Exits line configuration mode and returns to privileged EXEC mode.

Monitoring the SSH Configuration and Status

Table 5: Commands for Displaying the SSH Server Configuration and Status

Command	Purpose
show ip ssh	Shows the version and configuration information for the SSH server.
show ssh	Shows the status of the SSH server.

Configuring the Router for Local Authentication and Authorization

You can configure AAA to operate without a server by setting the switch to implement AAA in local mode. The router then handles authentication and authorization. No accounting is available in this configuration.

Follow these steps to configure AAA to operate without a server by setting the router to implement AAA in local mode:

Note To secure the router for HTTP access by using AAA methods, you must configure the router with the ip http authentication aaa global configuration command. Configuring AAA authentication does not secure the router for HTTP access by using AAA methods.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:** `IR8340# configure terminal`	Enters global configuration mode.
Step 2	**aaa new-model** **Example:** `IR8340(config)# aaa new-model`	Enables AAA
Step 3	**aaa authentication login default local** **Example:** `IR8340(config)# aaa authentication login default local`	Sets the login authentication to use the local username database. The default keyword applies the local user database authentication to all ports.
Step 4	**line vty** *line-number* **Example:** `IR8340(config)# line vty 0 4` `IR8340(config-line)#`	

	Command or Action	Purpose
Step 5	**aaa authorization exec default local** **Example:** `IR8340(config-line)# aaa authorization exec default local`	Configures user AAA authorization, check the local database, and allow the user to run an EXEC shell.
Step 6	**aaa authorization network local** **Example:** `IR8340(config-line)# aaa authorization network local`	Configures user AAA authorization for all network-related service requests.
Step 7	**username** *name* **privilege** *level* **password** *encryption-type password* **Example:** `IR8340(config-line)# username your_user_name privilege 1 password 7 secret567`	Enters the local database, and establishes a username-based authentication system. Repeat this command for each user. **a.** For *name*, specify the user ID as one word. Spaces and quotation marks are not allowed. **b.** (Optional) For *level*, specify the privilege level the user has after gaining access. The range is 0 to 15. Level 15 gives privileged EXEC mode access. Level 0 gives user EXEC mode access. **c.** For encryption-type, enter 0 to specify that an unencrypted password follows. Enter 7 to specify that a hidden password follows. **d.** For password, specify the password the user must enter to gain access to the switch. The password must be from 1 to 25 characters, can contain embedded spaces, and must be the last option specified in the username command.
Step 8	**end** **Example:** `IR8340(config-line)# end`	Exits line configuration mode and returns to privileged EXEC mode.

Information about Secure Copy

The Secure Copy Protocol (SCP) feature provides a secure and authenticated method for copying router configuration or router image files. SCP relies on Secure Shell (SSH), an application and a protocol that provide a secure replacement for the Berkeley r-tools.

Prerequisites for Secure Copy

The following are the prerequisites for configuring the device for secure shell (SSH):

- Before enabling SCP, you must correctly configure SSH, authentication, and authorization on the switch.
- Because SCP relies on SSH for its secure transport, the router must have an RSA key pair.
- SCP relies on SSH for security.
- SCP requires that authentication, authorization, and accounting (AAA) authorization be configured so the router can determine whether the user has the correct privilege level.
- A user must have appropriate authorization to use SCP.
- A user who has appropriate authorization can use SCP to copy any file in the Cisco IOS File System (IFS) to and from a switch by using the **copy** command. An authorized administrator can also do this from a workstation.

Restrictions for Configuring Secure Copy

- Before enabling SCP, you must correctly configure SSH, authentication, and authorization on the router.
- When using SCP, you cannot enter the password into the **copy** command. You must enter the password when prompted.

Configuring Secure Copy

To configure the Cisco IR8340 for Secure Copy (SCP) server-side functionality, perform the following steps.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Device> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Device# configure terminal`	Enters global configuration mode.
Step 3	**aaa new-model** **Example:** `Device(config)# aaa new-model`	Sets AAA authentication at login.
Step 4	**aaa authentication login** {**default** | *list-name*} *method1* [*method2...*]	Enables the AAA access control system.

	Command or Action	Purpose
	Example: `Device(config)# aaa authentication login default group tacacs+`	
Step 5	**username** *name* [**privilege** *level*] **password** *encryption-type encrypted-password* **Example:** `Device(config)# username superuser privilege 2 secret superpassword`	Establishes a username-based authentication system. **Note** You may omit this step if a network-based authentication mechanism, such as TACACS+ or RADIUS, has been configured.
Step 6	**ip scp server enable** **Example:** `Device(config)# ip scp server enable`	Enables SCP server-side functionality.
Step 7	**exit** **Example:** `Device(config)# exit`	Exits global configuration mode and returns to privileged EXEC mode.
Step 8	**show running-config** **Example:** `Device# show running-config`	(Optional) Displays the SCP server-side functionality.
Step 9	**debug ip scp** **Example:** `Device# debug ip scp`	(Optional) Troubleshoots SCP authentication problems.

Example


```
scp://your_username@remotehost:/some/remote/directory/file flash:
```

Additional References

The following sections provide references related to the SSH feature.

Related Topic	Document Title
Configuring Identity Control policies and Identity Service templates for Session Aware networking.	Session Aware Networking Configuration Guide, Cisco IOS XE Release 3SE: https://www.cisco.com/en/US/docs/ios-xml/ios/san/configuration/xe-3se/3850/san-xe-3se-3850-book.pdf

Related Topic	Document Title
Configuring RADIUS, TACACS+, Secure Shell, 802.1X and AAA.	Secure Shell Configuration Guide, Cisco IOS XE Gibraltar 16.11.x: https://www.cisco.com/c/en/us/td/docs/switches/lan/catalyst9500/software/release/16-11/configuration_guide/sec/b_1611_sec_9500_cg/configuring_secure_shell__ssh_.html



CHAPTER 5

Installing the Software

This chapter contains the following sections:

- Installing the Software, on page 51
- Installing the Cisco IOS XE Release, on page 52
- ROMMON Images, on page 53
- File Systems, on page 53
- Option to Enable or Disable USB Access, on page 54
- Autogenerated File Directories and Files, on page 55
- Flash Storage, on page 56
- Related Documentation, on page 56

Installing the Software

Installing software on the router involves installing a consolidated package (bootable image). This consists of a bundle of subpackages (modular software units), with each subpackage controlling a different set of functions.

It is better to upgrade software in a planned period of maintenance when an interruption in service is acceptable. The router needs to be rebooted for a software upgrade to take effect.

Cisco Software Licensing

Cisco software licensing consists of processes and components to activate Cisco IOS software feature sets by obtaining and validating Cisco software licenses.

The IR8340 uses Enhanced Smart Licensing, which is discussed in detail in Smart Licensing Using Policy (SLP), on page 65.

Consolidated Packages

To obtain software images for the router, go to: https://software.cisco.com/download/home/286200112

Note All of the IOS-XE feature set may not apply to the IR8340. Some features may not have been implemented yet, or are not appropriate for this platform.

An image-based license is used to help bring up all the subsystems that correspond to a license. This license is enforced only at boot time.

One of the following image-based licenses can be pre-installed on the IR8340 router:

- Network-Essentials
- Network-Advantage
- HSEC license

Note Details of the Network-Essentials and Network-Advantage contents can be found in the IR8340 product data sheet.

Network-Essentials

The **Network-Essentials** technology package includes the baseline features. It also supports security features.

The **Network-Essentials_npe** technology package (npe = No Payload Encryption) includes all the features in the Network-Essentials technology package without the payload encryption functionality. This is to fulfill export restriction requirements. The Network-Essentials_npe is available only in the Network-Essentials_npe image. The difference in features between the Network-Essentials package and the Network-Essentials_npe package is therefore the set of payload encryption features such as IPsec and Secure VPN.

Network-Advantage

The **Network-Advantage** technology package includes all crypto features.

The **Network-Advantage_npe** package (npe = No Payload Encryption) includes all the features in the **Network-Advantage** technology package without the payload-encryption functionality. This is to fulfill export restriction requirements. The **Network-Advantage_npe** package is available only in the **Network-Advantage_npe** image. The difference in features between the **Network-Advantage** package and the **Network-Advantage_npe** package is therefore the set of payload-encryption-enabling features such as IPsec and Secure VPN.

Related Documentation

For further information on software licenses, see the Smart Licensing chapter.

Installing the Cisco IOS XE Release

When the device boots up with Cisco IOS XE image for the first time, the device checks the installed version of the ROMMON, and upgrades if the system is running an older version. During the upgrade, do not power cycle the device. The system automatically power cycles the device after the new ROMMON is installed. After the installation, the system will boot up with the Cisco IOS XE image as normal.

Note When the device boots up for first time and if the device requires an upgrade, the entire boot process may take several minutes. This process will be longer than a normal boot due to the ROMMON upgrade.

The following example illustrates the boot process of a consolidated package:

```
Router# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
Router(config)#

Router#show running-config | i license
no license feature hseck9
license udi pid IR8340-K9 sn FDO2523J6N1
license boot level network-advantage
Router#

Router#reload
System configuration has been modified. Save? [yes/no]: yes
Building configuration...
[OK]
Proceed with reload? [confirm]
Sep 8 10:28:36.135: %PMAN-5-EXITACTION: R0/0: pvp: Process manager is exiting: process exit
 with reload chassis code

Initializing Hardware ...
Disable swap drive feature. Skip swap drive checking !!

System Bootstrap, Version v0.33, DEVELOPMENT SOFTWARE
Copyright (c) 1994-2021 by cisco Systems, Inc.
Compiled Mon Jul 12 22:57:23 2021 by gilchen

Current image running : Boot ROM1

Last reset cause (0x00000002): LocalSoft
IR8340-K9 platform with 8388608 Kbytes of main memory

.....
```

ROMMON Images

A ROMMON image is a software package used by ROM Monitor (ROMMON) software on a router. The software package is separate from the consolidated package normally used to boot the router.

An independent ROMMON image (software package) may occasionally be released and the router can be upgraded with the new ROMMON software. For detailed instructions, see the documentation that accompanies the ROMMON image.



Note A new version of the ROMMON image is not necessarily released at the same time as a consolidated package for a router.

File Systems

The following table provides a list of file systems that can be seen on the Cisco IR8340 router.

Table 6: Router File Systems

File System	Description
bootflash:	Boot flash memory file system.
cns:	Cisco Networking Services file directory.
crashinfo:	Directory or Filename
flash:	Alias to the boot flash memory file system above.
null:	Directory or Filename
nvram:	Router NVRAM. You can copy the startup configuration to NVRAM or from NVRAM.
sdcard:	SD card file system.
system:	System memory file system, which includes the running configuration.
tar:	Archive file system.
tmpsys:	Temporary system files file system.
usb:	USB file system.
webui:	Web UI file system.

Use the **?** help option if you find a file system that is not listed in the table above.

Option to Enable or Disable USB Access

USB flash drives offer inexpensive and easy storage space for the routers to store the images, configuration files and other files.



Note The IR8340 does not support ext3, ext4, and above for USB flash drives.

The IR8340 supports hot plug/unplug of USB flash drives. To access the USB flash drive, insert the device into router's USB interface.

While hot plug/unplug of a USB flash drive is supported, the functionality comes with security vulnerabilities. To prevent users from copying sensitive information to the USB flash drive, USB enable/disable functionality has been added.

By default, the USB flash drive is enabled. If you want to disable USB, use the following disable command:

```
Router#config terminal
Router(config)#platform usb disable
Router(config)#end
```

Once the USB flash drive has been disabled, the file system is not shown on the device and syslog messages will not be displayed when the USB is inserted. You will not be able to access the contents of the USB.

The USB is enabled by issuing a '**no** ' with the disable command:

```
Router#config terminal
Router(config)#no platform usb disable
Router(config)#end
```

The USB status can be displayed using the following command:

```
Router#show platform usb status
USB enabled
Router#
```

Autogenerated File Directories and Files

This section discusses the autogenerated files and directories that can be created, and how the files in these directories can be managed.

Table 7: Autogenerated Files

File or Directory	Description
crashinfo files	Crashinfo files may appear in the bootflash: file system. These files provide descriptive information of a crash and may be useful for tuning or troubleshooting purposes. However, the files are not part of router operations, and can be erased without impacting the functioning of the router.
core directory	The storage area for .core files. If this directory is erased, it will automatically regenerate itself at bootup. The .core files in this directory can be erased without impacting any router functionality, but the directory itself should not be erased.
managed directory	This directory is created on bootup if a system check is performed. Its appearance is completely normal and does not indicate any issues with the router.
tracelogs directory	The storage area for trace files. Trace files are useful for troubleshooting. If the Cisco IOS process fails, for instance, users or troubleshooting personnel can access trace files using diagnostic mode to gather information related to the Cisco IOS failure. Trace files, however, are not a part of router operations, and can be erased without impacting the router's performance.

Important Notes About Autogenerated Directories

Important information about autogenerated directories include:

- Autogenerated files on the bootflash: directory should not be deleted, renamed, moved, or altered in any way unless directed by Cisco customer support.

Note Altering autogenerating files on the bootflash: may have unpredictable consequences for system performance.

- Crashinfo files and files in the core and tracelogs directory can be deleted.

Flash Storage


Subpackages are installed to local media storage, such as flash. For flash storage, use the **dir bootflash:** command to list the file names.

Note Flash storage is required for successful operation of a router.

Related Documentation

For further information on software licenses, see Smart Licensing Using Policy (SLP), on page 65.

For further information on obtaining and installing feature licenses, see Configuring the Cisco IOS Software Activation Feature.



CHAPTER 6

Software Maintenance Upgrade (SMU)

Note SMU installation was supported in both bundle boot and install mode. From Cisco IOS XE Release 17.9.x, SMU installation will be stopped if the router is booted up in bundle mode. If the router is booted up in install mode, SMU installation will keep working as it is in previous releases.

- Software Maintenance Upgrade (SMU), on page 57
- SMU Workflow and Basic Requirements, on page 58
- SMU Example, on page 58
- Installing a Patch Image, on page 58
- Uninstalling the Patch Image, on page 60

Software Maintenance Upgrade (SMU)

The Software Maintenance Upgrade (SMU) is a package that can be installed on a system to provide a patch fix or security resolution to a released image for a specific defect in order to respond to immediate issues. It does not contain new features.

Some of the caveats of the SMU are:

- Provided on a per release, per component basis and is specific to the platform. SMU versions are synchronized to the package major, minor, and maintenance versions they upgrade.
- SMUs are not an alternative to maintenance releases. All defects fixed by SMUs are then automatically integrated into the upcoming maintenance releases.
- The Cisco IOS XE platform internally validates the SMU compatibility and does not allow you to install non-compatible SMUs. This is based on rules/limitations for a SMU change-set.
- An SMU provides a significant benefit over classic IOS software as it allows you to address the network issue quickly while reducing the time and scope of the testing required.
- SMU is a method to fix bugs in an existing release, and allows the application of a PSIRT fix in an existing release
- SMU is NOT an upgrade path from release X to maintenance release X.1
- SMU is NOT an upgrade path from release X to release Y

The device only supports “Hot Patching”. This means:

- The running image is modified in-place or in-service

- This avoids downtime and interruption of service
- The updated code to fix the defect is written in a different location, and where the patch redirects the program run

SMU Workflow and Basic Requirements

The workflow for the patch requires that you complete the following sequence of operation in exec mode:

1. Addition of the SMU to the file system.
2. Activation of the SMU onto the system.
3. Committing the SMU change.
4. Removal and uninstallation of the SMU.

The basic requirements for SMU are:

- The image where the defect was discovered.
- The patch file that contains the fix for the defect must be formatted as ir8340-image_name.release_version.CSCxxyyyyy.SPA.smu.bin.

SMU Example

This section shows an example of a patch created as a test. Your patch will have a name associated with a CDET to be installed as a fix.

Installing a Patch Image

Perform the following steps to install the patch image:

Procedure

Step 1 Show a standard command.

```
Router#show power
Main PSU :
    Total Power Consumed: 11.37 Watts
    Configured Mode : N/A
    Current runtime state same : N/A
    PowerSupplySource : External PS
POE Module :
    Configured Mode : N/A
    Current runtime state same : N/A
    Total power available : 30 Watts
Router#
```

Step 2 Add the image.

```
Router# install add file
sdcard:ir8340-universalk9.2021-06-14_14.55_suraiyer.0.cold.SSA.smu.bininstall_add: START
Wed Aug 11 17:05:59 UTC 2021
Copying sdcard:ir8340-universalk9.2021-06-14_14.55_suraiyer.0.cold.SSA.smu.bin to
bootflash:ir8340-universalk9.2021-06-14_14.55_suraiyer.0.cold.SSA.smu.bin
install_add: Adding SMU
install_add: Checking whether new add is allowed ....

--- Starting SMU Add operation ---
Performing SMU_ADD on Active/Standby
[1] SMU_ADD package(s) on R0
[1] Finished SMU_ADD on R0
Checking status of SMU_ADD on [R0]
SMU_ADD: Passed on [R0]
Finished SMU Add operation

SUCCESS: install_add Wed Aug 11 17:06:22 UTC 2021

Router#
```

Step 3 Activate the patch image.

```
Router# install activate file
bootflash:ir8340-universalk9.2021-06-14_14.55_suraiyer.0.cold.SSA.smu.bininstall_activate:
 START Thu Aug  6 11:53:59 PDT 2020
install_activate: START Wed Aug 11 17:06:35 UTC 2021

System configuration has been modified.
Press Yes(y) to save the configuration and proceed.
Press No(n) for proceeding without saving the configuration.
Press Quit(q) to exit, you may save configuration and re-enter the command. [y/n/q]
167: +++ SLE_Sumatra: receive +++
y

Building configuration...
[OK]Modified configuration has been saved
install_activate: Activating SMU

This operation may require a reload of the system. Do you want to proceed? [y/n]
```

Step 4 Commit the installation.

```
Router# install commitinstall_commit: START Wed Aug 11 17:12:40 UTC 2021
install_commit: Committing SMU
Executing pre scripts....
Executing pre sripts done.
--- Starting SMU Commit operation ---
Performing SMU_COMMIT on Active/Standby
[1] SMU_COMMIT package(s) on R0
[1] Finished SMU_COMMIT on R0
Checking status of SMU_COMMIT on [R0]
SMU_COMMIT: Passed on [R0]
Finished SMU Commit operation

SUCCESS: install_commit
/bootflash/ir8340-universalk9.2021-06-14_14.55_suraiyer.0.cold.SSA.smu.bin Wed Aug 11
17:13:24 UTC 2021
Router#
```

Step 5 Show the status summary of the installation procedure.

```
Router# show install summary[ R0 ] Installed Package(s) Information:
State (St): I - Inactive, U - Activated & Uncommitted,
```

```
C - Activated & Committed, D - Deactivated & Uncommitted
--------------------------------------------------------------------------------
Type St Filename/Version
--------------------------------------------------------------------------------
SMU C bootflash:ir8340-universalk9.2021-06-14_14.55_suraiyer.0.cold.SSA.smu.bin
IMG C 17.07.01.0.139972

--------------------------------------------------------------------------------
Auto abort timer: inactive
--------------------------------------------------------------------------------

Router#
```

Step 6 Verify the result of the patch by showing the same command.

```
Router#show power
Main PSU :
    Total Power Consumed: 11.04 Watts
Device HOT SMU works!

    Configured Mode : N/A
    Current runtime state same : N/A
    PowerSupplySource : External PS
POE Module :
    Configured Mode : N/A
    Current runtime state same : N/A
    Total power available : 0 Watts
Router#
```

Uninstalling the Patch Image

There are two methods to remove or uninstall the patch image.

- Restoring the image to its original version by using the following command:
  - **install rollback to base**
- Specific removal of a patch by using the following commands in sequence:
  - **install deactivate file flash:**<*file*>
  - **install commit**
  - **install remove file flash:**<*file*>

Uninstalling the Patch Image Using Rollback

This section shows an example of using the rollback method.

Show what patches are installed:

```
Router# show install summary
[ R0 ] Installed Package(s) Information:
State (St): I - Inactive, U - Activated & Uncommitted,
C - Activated & Committed, D - Deactivated & Uncommitted
--------------------------------------------------------------------------------
Type St Filename/Version
--------------------------------------------------------------------------------
```

```
SMU C bootflash:ir8340-universalk9.2021-06-14_14.55_suraiyer.0.cold.SSA.smu.bin
IMG C 17.07.01.0.139972

--------------------------------------------------------------------------------
Auto abort timer: inactive
--------------------------------------------------------------------------------

Router#
```

The following commands are available:

```
Router# install ?
  abort             Abort the current install operation
  activate          Activate an installed package
  add               Install a package file to the system
  auto-abort-timer  Install auto-abort-timer
  commit            Commit the changes to the loadpath
  deactivate        Deactivate an install package
  label             Add a label name to any installation point
  prepare           Prepare package for operation
  remove            Remove installed packages
  rollback          Rollback to a previous installation point
Router# install rollback to ?
  base       Rollback to the base image
  committed  Rollback to the last committed installation point
  id         Rollback to a specific install point id
  label      Rollback to a specific install point label
```

The **install rollback to base** command removes the entire patch and returns to the base image version with the found defect.

```
Router# install rollback to base

install_rollback: START Thu Aug  6 12:04:04 PDT 2020
install_rollback: Rolling back SMU
Executing pre scripts....
Executing pre sripts done.

--- Starting SMU Rollback operation ---
Performing SMU_ROLLBACK on Active/Standby
  [1] SMU_ROLLBACK package(s) on R0
  [1] Finished SMU_ROLLBACK on R0
Checking status of SMU_ROLLBACK on [R0]
SMU_ROLLBACK: Passed on [R0]
Finished SMU Rollback operation

CSCxx12345:SUCCESS
SUCCESS: install_rollback
/flash1/ir8300-universalk9.2020-08-06_10.38_shchang2.0.CSCxx12345.SSA.smu.bin Thu Aug  6
12:04:57 PDT 2020
Router#
```

Show what patches are installed:

```
Router# show install summary
[ R0 ] Installed Package(s) Information:
State (St): I - Inactive, U - Activated & Uncommitted,
C - Activated & Committed, D - Deactivated & Uncommitted
--------------------------------------------------------------------------------
Type St Filename/Version
--------------------------------------------------------------------------------
SMU C bootflash:ir8340-universalk9.2021-06-14_14.55_suraiyer.0.cold.SSA.smu.bin
IMG C 17.07.01.0.139972
```

```
--------------------------------------------------------------------------------
Auto abort timer: inactive
--------------------------------------------------------------------------------

Router#
```

Note In the above command output, the patch has been removed and the device returns to the base image version prior to the upgrade.

Uninstalling the Patch Image Using Deactivate, Commit, and Remove

Show what patches are installed.

```
Router# show install summary
[ R0 ] Installed Package(s) Information:
State (St): I - Inactive, U - Activated & Uncommitted,
C - Activated & Committed, D - Deactivated & Uncommitted
--------------------------------------------------------------------------------
Type St Filename/Version
--------------------------------------------------------------------------------
SMU C bootflash:ir8340-universalk9.2021-06-14_14.55_suraiyer.0.cold.SSA.smu.bin
IMG C 17.07.01.0.139972

--------------------------------------------------------------------------------
Auto abort timer: inactive
--------------------------------------------------------------------------------
```

Procedure

Step 1 Deactivate the patch.

```
Router# install deactivate file
bootflash:ir8340-universalk9.2021-06-14_14.55_suraiyer.0.cold.SSA.smu.bin
install_deactivate: START Wed Aug 11 17:14:35 UTC 2021

System configuration has been modified.
Press Yes(y) to save the configuration and proceed.
Press No(n) for proceeding without saving the configuration.
Press Quit(q) to exit, you may save configuration and re-enter the command. [y/n/q]
332: +++ SLE_Sumatra: receive +++
y

Building configuration...
[OK]Modified configuration has been saved
install_deactivate: Deactivating SMU

This operation may require a reload of the system. Do you want to proceed? [y/n]
```

Show what patches are installed:

```
Router# show install summary
[ R0 ] Installed Package(s) Information:
State (St): I - Inactive, U - Activated & Uncommitted,
C - Activated & Committed, D - Deactivated & Uncommitted
--------------------------------------------------------------------------------
Type St Filename/Version
```

```
--------------------------------------------------------------------------------
SMU D bootflash:ir8340-universalk9.2021-06-14_14.55_suraiyer.0.cold.SSA.smu.bin
IMG C 17.07.01.0.139972

--------------------------------------------------------------------------------
Auto abort timer: active on install_deactivate, time before rollback - 01:55:21
--------------------------------------------------------------------------------
```

Step 2 Commit the action.

```
Router# install commit
install_commit: START Wed Aug 11 17:21:23 UTC 2021
install_commit: Committing SMU
Executing pre scripts....
Executing pre sripts done.
--- Starting SMU Commit operation ---
Performing SMU_COMMIT on Active/Standby
[1] SMU_COMMIT package(s) on R0
[1] Finished SMU_COMMIT on R0
Checking status of SMU_COMMIT on [R0]
SMU_COMMIT: Passed on [R0]
Finished SMU Commit operation

SUCCESS: install_commit
/bootflash/ir8340-universalk9.2021-06-14_14.55_suraiyer.0.cold.SSA.smu.bin Wed Aug 11
17:21:53 UTC 2021
```

Show what patches are installed:

```
Router# show install summary
[ R0 ] Installed Package(s) Information:
State (St): I - Inactive, U - Activated & Uncommitted,
C - Activated & Committed, D - Deactivated & Uncommitted
--------------------------------------------------------------------------------
Type St Filename/Version
--------------------------------------------------------------------------------
SMU I bootflash:ir8340-universalk9.2021-06-14_14.55_suraiyer.0.cold.SSA.smu.bin
IMG C 17.07.01.0.139972

--------------------------------------------------------------------------------
Auto abort timer: inactive
--------------------------------------------------------------------------------
```

Step 3 Remove the patch.

```
Router# install remove file
bootflash:ir8340-universalk9.2021-06-14_14.55_suraiyer.0.cold.SSA.smu.bininstall_remove:
START Wed Aug 11 17:22:03 UTC 2021
install_remove: Removing SMU
Executing pre scripts....
Executing pre sripts done.


--- Starting SMU Remove operation ---
Performing SMU_REMOVE on Active/Standby
[1] SMU_REMOVE package(s) on R0
[1] Finished SMU_REMOVE on R0
Checking status of SMU_REMOVE on [R0]
SMU_REMOVE: Passed on [R0]
Finished SMU Remove operation

SUCCESS: install_remove
/bootflash/ir8340-universalk9.2021-06-14_14.55_suraiyer.0.cold.SSA.smu.bin Wed Aug 11
17:22:20 UTC 2021
```

Show what patches are installed:

```
Router# show install summary
[ R0 ] Installed Package(s) Information:
State (St): I - Inactive, U - Activated & Uncommitted,
C - Activated & Committed, D - Deactivated & Uncommitted
--------------------------------------------------------------------------------
Type St Filename/Version
--------------------------------------------------------------------------------
IMG C 17.07.01.0.139972

--------------------------------------------------------------------------------
Auto abort timer: inactive
--------------------------------------------------------------------------------
```




CHAPTER 7

Smart Licensing Using Policy (SLP)

- Smart Licensing Using Policy, on page 65

Smart Licensing Using Policy

The Smart Licensing Using Policy chapter has been replaced by a standalone guide called Smart Licensing Using Policy on the Cisco Catalyst IR1101, IR1800, IR8140, IR8340 and ESR6300 Routers.



CHAPTER 8

Configuring Ethernet Switch Ports

- Configuring VLANs, on page 67
- Configuring Private VLANs, on page 71
- Configuring Voice VLANs, on page 79
- Configuring VXLAN Tunneling, on page 81
- IEEE 802.1x Protocol, on page 82
- Spanning Tree Protocol Overview, on page 86
- MAC Table Manipulation, on page 94
- Assigning IP Addresses to Switch Virtual Interfaces, on page 97
- SVI Supported Features, on page 98
- IGMP Snooping for IPv4, on page 100
- IGMP Filtering and Throttling, on page 100
- MLD Snooping, on page 104
- Configuring UniDirectional Link Detection, on page 107
- Configuring the Switched Port Analyzer, on page 108
- EtherChannel Overview, on page 122
- Modular Quality of Service Command-Line Interface, on page 129

Configuring VLANs

A VLAN is a switched network that is logically segmented by function or application, without regard to the physical locations of the users. VLANs have the same attributes as physical LANs. However, you can group end-stations even if they are not physically located on the same LAN segment. Any device port can belong to a VLAN, unicast, broadcast, and multicast packets are forwarded and flooded only to end-stations in the VLAN. Each VLAN is considered a logical network, and packets destined for stations that do not belong to the VLAN must be forwarded through a router or a device supporting fallback bridging. In a device stack, VLANs can be formed with ports across the stack. Because a VLAN is considered a separate logical network, it contains its own bridge Management Information Base (MIB) information and can support its own implementation of spanning tree.

VLANs are often associated with IP subnetworks. For example, all the end stations in a particular IP subnet belong to the same VLAN. Interface VLAN membership on the device is assigned manually on an interface-by-interface basis. When you assign device interfaces to VLANs by using this method, it is known as interface-based, or static, VLAN membership.

The device can route traffic between VLANs by using device virtual interfaces (SVIs). An SVI must be explicitly configured and assigned an IP address to route traffic between VLANs.

Note IR8340 routers have reserved a set of VLANs (2350 to 2449) for additional usage. It is not allowed to add the reserved VLANs. You must ensure that these VLANs are not used in the network. VLAN range 2340-2349 is reserved exclusively for ERSPAN traffic. Do not assign these VLANs to the front panel ports.

Access Ports

An access port belongs to and carries the traffic of only one VLAN (unless it is configured as a voice VLAN port). Traffic is received and sent in native formats with no VLAN tagging. Traffic arriving on an access port is assumed to belong to the VLAN assigned to the port. If an access port receives a tagged packet IEEE 802.1Q tagged), the packet is dropped, and the source address is not learned.

Trunk Ports

A trunk port carries the traffic of multiple VLANs and by default is a member of all VLANs in the VLAN database. These trunk port types are supported:

- An IEEE 802.1Q trunk port supports simultaneous tagged and untagged traffic. An IEEE 802.1Q trunk port is assigned a default port VLAN ID (PVID), and all untagged traffic travels on the port default PVID. All untagged traffic and tagged traffic with a NULL VLAN ID are assumed to belong to the port default PVID. A packet with a VLAN ID equal to the outgoing port default PVID is sent untagged. All other traffic is sent with a VLAN tag.

Although by default, a trunk port is a member of every VLAN known to the VTP, you can limit VLAN membership by configuring an allowed list of VLANs for each trunk port. The list of allowed VLANs does not affect any other port but the associated trunk port. By default, all possible VLANs (VLAN ID 1 to 4094) are in the allowed list. A trunk port can become a member of a VLAN only if VTP knows of the VLAN and if the VLAN is in the enabled state. If VTP learns of a new, enabled VLAN and the VLAN is in the allowed list for a trunk port, the trunk port automatically becomes a member of that VLAN and traffic is forwarded to and from the trunk port for that VLAN. If VTP learns of a new, enabled VLAN that is not in the allowed list for a trunk port, the port does not become a member of the VLAN, and no traffic for the VLAN is forwarded to or from the port.

For more information on VLANs, see VLAN Configuration Guide, Cisco IOS XE Gibraltar 16.10.x.

Creating a VLAN

With VTP version 1 and 2, if the device is in VTP transparent mode, you can assign VLAN IDs greater than 1006, but they are not added to the VLAN database.

To configure the Vlan, perform these steps. You can configure the Vlan in access or trunk mode. The procedure is same for the both the modes.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:**	Enter global configuration mode.

	Command or Action	Purpose
	`Router# configure terminal`	
Step 2	**vlan** *vlan-id* **Example:** `Router(config)# vlan 20`	Enters a VLAN ID, and enters VLAN configuration mode. Enter a new VLAN ID to create a VLAN, or enter an existing VLAN ID to modify that VLAN. **Note** The available VLAN ID range for this command is 1 to 4094.
Step 3	**name** *vlan-name* **Example:** `Router(config-vlan)# name test20`	(Optional) Enters a name for the VLAN. If no name is entered for the VLAN, the default is to append the *vlan-id* value with leading zeros to the word VLAN. For example, VLAN0004 is a default VLAN name for VLAN 4.
Step 4	**exit** **Example:** `Router(config-vlan)# exit`	Returns to configuration mode.
Step 5	**interface** *interface-id* **Example:** `Router(config)# interface gigabitethernet 0/1/0`	Specifies the physical port to be configured, and enter interface configuration mode.
Step 6	**switchport mode access** **Example:** `Router(config-if)# switchport mode access`	Configures the interface as a VLAN access port.
Step 7	**switchport access vlan** *vlan id* **Example:** `Router(config-if)# switchport access vlan 20`	Specifies the VLAN for which this access port will carry traffic. If you do not enter this command, the access port carries traffic on VLAN1 only; use this command to change the VLAN for which the access port carries traffic.
Step 8	**end** **Example:** `Router(config-if)# end`	Returns to configuration mode.

Configuring LAN Ports for Layer 2 Switching

This section describes how configure all three types of ethernet LAN ports for Layer 2 switching on the Cisco IR8340 routers. The configuration tasks in this section apply to LAN ports on the router.

Layer 2 LAN Port Modes

The following table lists the Layer 2 LAN port modes and describes how they function on LAN ports.

Table 8: Layer 2 LAN Port Modes

Mode	Function
switchport mode access	Puts the LAN port into permanent nontrunking mode and negotiates to convert the link into a nontrunk link. The LAN port becomes a nontrunk port even if the neighboring LAN port does not agree to the change.
switchport mode dynamic desirable	Makes the LAN port actively attempt to convert the link to a trunk link. The LAN port becomes a trunk port if the neighboring LAN port is set to **trunk** , **desirable** , or **auto** mode. This is the default mode for all LAN ports.
switchport mode dynamic auto	Makes the LAN port willing to convert the link to a trunk link. The LAN port becomes a trunk port if the neighboring LAN port is set to **trunk** or **desirable** mode.
switchport mode trunk	Puts the LAN port into permanent trunking mode and negotiates to convert the link into a trunk link. The LAN port becomes a trunk port even if the neighboring port does not agree to the change.
switchport nonegotiate	Puts the LAN port into permanent trunking mode but prevents the port from generating DTP frames. You must configure the neighboring port manually as a trunk port to establish a trunk link.



Note DTP is a point-to-point protocol. However, some internetworking devices might forward DTP frames improperly. To avoid this problem, ensure that LAN ports connected to devices that do not support DTP are configured with the **access** keyword if you do not intend to trunk across those links. To enable trunking to a device that does not support DTP, use the **nonegotiate** keyword to cause the LAN port to become a trunk but not generate DTP frames.

Default Layer 2 LAN Interface Configuration

The following table shows the Layer 2 LAN port default configuration.

Table 9: Layer 2 LAN Interface Default Configuration

Feature	Default
Interface mode:	
• Before entering the **switchport** command	

Feature	Default
• After entering the **switchport** command	**switchport mode dynamic desirable**
Default access VLAN	VLAN 1
Native VLAN (for 802.1Q trunks)	VLAN 1

Configuring LAN Interfaces for Layer 2 Switching

These sections describe how to configure Layer 2 switching on the Cisco IR8340 routers:


Note Use the default **default interface** *interface -type slot/subslot/port* command to revert an interface to its default configuration.

Configuring Private VLANs

Information About Private VLANs

Using private VLANs addresses the scalability problem and provides IP address management benefits for service providers and Layer 2 security for customers. Private VLANs partition a regular VLAN domain into subdomains. A subdomain is represented by a pair of VLANs: a primary VLAN and a secondary VLAN. A private VLAN can have multiple VLAN pairs, one pair for each subdomain. All VLAN pairs in a private VLAN share the same primary VLAN. The secondary VLAN ID differentiates one subdomain from another.

Figure 1: Private VLAN Domain



Primary and Secondary VLANs in Private VLANs

A private VLAN domain has only one primary VLAN. Each port in a private VLAN domain is a member of the primary VLAN; the primary VLAN is the entire private VLAN domain.

Secondary VLANs provide isolation between ports within the same private VLAN domain. The following two types are secondary VLANs within a primary VLAN:

- Isolated VLANs—Ports within an isolated VLAN cannot communicate directly with each other at the Layer 2 level.
- Community VLANs—Ports within a community VLAN can communicate with each other but cannot communicate with ports in other community VLANs or in any isolated VLANs at the Layer 2 level.

Private VLAN Ports

The three types of PVLAN ports are as follows:

- Promiscuous port—A promiscuous port belongs to the primary VLAN. The promiscuous port can communicate with all interfaces, including the community and isolated host ports, that belong to those secondary VLANs associated to the promiscuous port and associated with the primary VLAN. You can have several promiscuous ports in a primary VLAN. Each promiscuous port can have several secondary VLANs or no secondary VLANs that are associated to that port. You can associate a secondary VLAN to more than one promiscuous port, as long as the promiscuous port and secondary VLANs are within the same primary VLAN. You may want to do this for load-balancing or redundancy purposes. You can also have secondary VLANs that are not associated to any promiscuous port.

  A promiscuous port can be configured as an access port.

- Isolated port—An isolated port is a host port that belongs to an isolated secondary VLAN. This port has complete isolation from other ports within the same PVLAN domain, except that it can communicate with associated promiscuous ports. PVLANs block all traffic to isolated ports except traffic from promiscuous ports. Traffic received from an isolated port is forwarded only to promiscuous ports. You can have more than one isolated port in a specified isolated VLAN. Each port is completely isolated from all other ports in the isolated VLAN.

  An isolated port can be configured an access port.

- Community port—A community port is a host port that belongs to a community secondary VLAN. Community ports communicate with other ports in the same community VLAN and with associated promiscuous ports. These interfaces are isolated from all other interfaces in other communities and from all isolated ports within the PVLAN domain.

  A community port must be configured as an access port.

Guidelines and Limitations for Private VLANs

The following are guidelines and limitations for configuring Private VLANs on IR8340:

- A primary VLAN can have only one isolated VLAN and multiple community VLANs.
- Secondary VLANs must be part of one and only one primary VLAN.
- SVI for secondary VLAN is disabled when primary-secondary VLAN association is configured. Deleting the association will bring back the secondary VLAN SVI.
- Deletion of a secondary VLAN puts the ports in that VLAN in inactive state.

- VLANs that cannot be configured as PVLAN—1, 1001-1005
- All switches in the network must be manually configured with the primary-secondary VLAN association. Otherwise, the MAC addresses will not be replicated from primary VLAN to secondary and vice versa, in that switch. That will lead to flooding of PVLAN traffic.
- Maximum number of primary or secondary VLANs that can be configured is limited by the number of VLANs that can be supported by the switch.
- Maximum number of end devices that can be configured in PVLAN is limited by the L2 TCAM entry limitation.

The following features are supported on IR8340:

- **Isolated access port**—Access port which can only communicate with promiscuous port
- **Promiscuous access port**—Access ports which can communicate with all ports in private VLAN
- **Community access port**—Access ports which can communicate with ports in same community and promiscuous ports
- **Private VLAN across switches**—Private VLAN traffic can be carried across normal trunk ports and the feature can span across switches
- **Multicast in Private VLAN**—Multicast communication in and out of private VLAN

The following features are not supported on IR8340:

- **2-way community VLAN**—The community ports send and receive traffic in the same VLAN
- **Promiscuous trunk port**—A trunk port carrying primary VLAN traffic for multiple private VLAN. The secondary VLANs are explicitly mapped to primary VLAN for multiple private VLAN
- **Trunk isolated/community ports**—Isolated and community ports are trunk with secondary VLANs of multiple private VLAN
- **Layer 3 communication between isolated ports**—Isolated ports can communicate at layer 3

Configuring a Private VLAN

Configuring a VLAN as a Private VLAN

To create a private VLAN, you first create a VLAN, and then configure that VLAN to be a private VLAN.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:** `Router# configure terminal`	Enters global configuration mode.

	Command or Action	Purpose
Step 2	**vlan** *vlan-id* **Example:** `Router(config)# vlan 202`	Enters VLAN configuration submode.
Step 3	[**no**] **private-vlan** {**community** | **isolated** | **primary**} **Example:** `Router(config-vlan)# private-vlan primary`	Configures a VLAN as a private VLAN. Use the no form of this command to clear the private VLAN configuration. **Note** These commands will not take effect until you exit VLAN configuration submode.
Step 4	**end** **Example:** `Router(config-vlan)# end`	Exits VLAN configuration mode.
Step 5	**show vlan private-vlan** [*type*] **Example:** `Router# show vlan private-vlan`	Verifies the configuration. **Note** When a VLAN is configured as part of a private VLAN, all the normal access ports belonging to the VLAN will be brought down, waiting for the configuration of their port roles in the PVLAN to take effect.

Example

The following example shows how to configure VLAN 202 as a primary VLAN and verify the configuration:

```
Router# configure terminal
Router(config)# vlan 202
Router(config-vlan)# private-vlan primary
Router(config-vlan)# end
Router# show vlan private-vlan
Primary Secondary Type              Interfaces
------- --------- ----------------- ------------------------------------------
202               primary
```

The following example shows how to configure VLAN 303 as a community VLAN and verify the configuration:

```
Router# configure terminal
Router(config)# vlan 303
Router(config-vlan)# private-vlan community
Router(config-vlan)# end
Router# show vlan private-vlan
Primary Secondary Type              Interfaces
------- --------- ----------------- ------------------------------------------
202               primary
        303       community
```

The following example shows how to configure VLAN 440 as an isolated VLAN and verify the configuration:

```
Router# configure terminal
Router(config)# vlan 440
Router(config-vlan)# private-vlan isolated
Router(config-vlan)# end
Router# show vlan private-vlan
Primary Secondary Type              Interfaces
------- --------- ----------------- ------------------------------------------
202               primary
        303       community
        440       isolated
```

Associating Secondary VLANs with a Primary Private VLAN

To associate secondary VLANs with a primary VLAN, perform this task:

Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:** `Router# configure terminal`	Enters global configuration mode.
Step 2	**vlan** *primary-vlan-id* **Example:** `Router(config)# vlan 202`	Enters VLAN configuration submode for the primary VLAN.
Step 3	**private-vlan association** {*secondary_vlan_list* | **add** *secondary_vlan_list* | **remove** *secondary_vlan_list*} **Example:** `Router(config-vlan)# private-vlan association 303-307,309,440`	Associates the secondary VLANs with the primary VLAN. Use **no private-vlan association** to clear all secondary VLAN associations.
Step 4	**end** **Example:** `Router(config-vlan)# end`	Exits VLAN configuration mode.
Step 5	**show vlan private-vlan** [*type*] **Example:** `Router# show vlan private-vlan`	Verifies the configuration.

Example

The following example shows how to associate community VLANs 303 through 307, 309, and isolated VLAN 440 with primary VLAN 202, and verify the configuration:

```
Router# configure terminal
Router(config)# vlan 202
Router(config-vlan)# private-vlan association 303-307,309,440
Router(config-vlan)# end
Router# show vlan private-vlan
Primary Secondary Type              Interfaces
------- --------- ----------------- ------------------------------------------
202     303       community
202     304       community
202     305       community
202     306       community
202     307       community
202     309       community
202     440       isolated
        308       community
```

Configuring a Layer 2 Interface as a Private VLAN Host Port

To configure a Layer 2 interface as a private VLAN host port, perform this task:

Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:** `Router# configure terminal`	Enters global configuration mode.
Step 2	**interface** *type slot/port* **Example:** `Router(config)# interface gigabitethernet 0/1/0`	Selects the LAN interface to configure.
Step 3	**switchport** **Example:** `Router(config-if)# switchport`	Configures the LAN interface for Layer 2 switching.
Step 4	**switchport mode private-vlan host** **Example:** `Router(config-if)# switchport mode private-vlan host`	Configures the Layer 2 port as a private VLAN host port. Use **no switchport mode private-vlan host** to clears private VLAN port configuration.
Step 5	**switchport private-vlan host host-association** *primary_vlan_ID secondary_vlan_ID* **Example:** `Router(config-if)# switchport private-vlan host-association 202 303`	Associates the Layer 2 port with a private VLAN. Use **no switchport private-vlan host host-association** to clear the association.
Step 6	**end** **Example:** `Router(config-if)# end`	Exits interface configuration mode.

	Command or Action	Purpose
Step 7	**show interface** *type slot/port* **switchport** **Example:** `Router# show interface gigabitethernet 0/1/0 switchport`	Verifies the configuration.

Example

This example shows how to configure interface gigabitethernet 0/1/0 as a private VLAN host port and verify the configuration:

```
Router# configure terminal
Router(config)# interface gigabitethernet 0/1/0
Router(config-if)# switchport mode private-vlan host
Router(config-if)# switchport private-vlan host-association 202 303
Router(config-if)# end
Router# show interfaces gigabitethernet 0/1/0 switchport
Name: Ge0/1/0
Switchport: Enabled
 Administrative Mode: private-vlan host
Operational Mode: down
Administrative Trunking Encapsulation: negotiate
Negotiation of Trunking: On
Access Mode VLAN: 1 (default)
Trunking Native Mode VLAN: 1 (default)
 Administrative private-vlan host-association: 202 (VLAN0202) 303 (VLAN0303)
Administrative private-vlan mapping: none
 Operational private-vlan: 202 (VLAN0202)
Trunking VLANs Enabled: ALL
Pruning VLANs Enabled: 2-1001
Capture Mode Disabled
```

Configuring a Layer 2 Interface as a Private VLAN Promiscuous Port

To configure a Layer 2 interface as a private VLAN promiscuous port, perform this task:

Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:** `Router# configure terminal`	Enters global configuration mode.
Step 2	**interface** *type slot/port* **Example:** `Router(config)# interface gigabitethernet 0/1/0`	Selects the LAN interface to configure.
Step 3	**switchport** **Example:**	Configures the LAN interface for Layer 2 switching.

	Command or Action	Purpose
	`Router(config-if)# switchport`	
Step 4	**switchport mode private-vlan promiscuous** **Example:** `Router(config-if)# switchport mode private-vlan promiscuous`	Configures the Layer 2 port as a private VLAN promiscuous port. Use **no switchport mode private-vlan** to clear the private VLAN port configuration.
Step 5	**switchport private-vlan mapping** *primary_vlan_ID* {*secondary_vlan_list* | **add** *secondary_vlan_list* | **remove** *secondary_vlan_list*} *secondary_vlan_ID* **Example:** `Router(config-if)# switchport private-vlan mapping 202 303,440`	Maps the private VLAN promiscuous port to a primary VLAN and to selected secondary VLANs. Use **no switchport private-vlan mapping** to clear all mapping between the private VLAN promiscuous port and the primary VLAN and any secondary VLANs.
Step 6	**end** **Example:** `Router(config-if)# end`	Exits interface configuration mode.
Step 7	**show interface** *type slot/port* **switchport** **Example:** `Router# show interface gigabitethernet 0/1/0 switchport`	Verifies the configuration.

Example

The following example shows how to configure interface gigabitethernet 0/1/0 as a private VLAN promiscuous port and map it to a private VLAN:

```
Router# configure terminal
Router(config)# interface gigabitethernet 0/1/0
Router(config-if)# switchport mode private-vlan promiscuous
Router(config-if)# switchport private-vlan mapping 202 303,440
Router(config-if)# end
```

The following example shows how to verify the configuration:

```
Router# show interfaces gigabitethernet 0/1/0 switchport
Name: Ge0/1/0
Switchport: Enabled
 Administrative Mode: private-vlan promiscuous
Operational Mode: down
Administrative Trunking Encapsulation: negotiate
Negotiation of Trunking: On
Access Mode VLAN: 1 (default)
Trunking Native Mode VLAN: 1 (default)
Administrative private-vlan host-association: none ((Inactive))
 Administrative private-vlan mapping: 202 (VLAN0202) 303 (VLAN0303) 440 (VLAN0440)
 Operational private-vlan: 202 (VLAN0202)
Trunking VLANs Enabled: ALL
Pruning VLANs Enabled: 2-1001
Capture Mode Disabled
```

Configuring Voice VLANs

The voice VLAN feature provides support for connecting an IP phone to an access switch port. Voice VLAN on an access port is desirable so that feature like port security, dot1x, dynamic access port, protected port can be configured.

The voice VLAN requires the access port to support dedicated VLAN for voice traffic (as the data traffic on the phone link might deteriorate the voice traffic quality) thus the device can differentiate voice traffic from data traffic and provide QoS for voice traffic and ensure quality.

The Ethernet port will be associated with two VLANs on a voice VLAN port as following:

1. A native VLAN to carry data traffic
2. An auxiliary or Voice VLAN to carry voice traffic

The data traffic will be sent either tagged or untagged with the access VLAN id. The phone will send voice traffic tagged with configured voice VLAN id. The voice VLAN id used by phone can either configured manually or learned through CDP. When voice VLAN is configured on the access port, the device will instruct IP phone to send voice traffic over the configured voice VLAN. This is achieved through sending CDP messages to IP phone indicating the same. QoS configurations can be done on the voice VLAN port in order to provide predictable forwarding of voice traffic and thus ensure voice quality.

Limitations and Restrictions

- Voice VLAN configuration is only supported on device access ports.
- Voice VLAN configuration will not be applicable to port channels.
- Private VLAN configuration will not be allowed on a voice VLAN port and vice versa.

How to Configure Voice VLANs

The following sections provide information about configuring Voice VLANs:

Configuring Cisco IP Phone Voice Traffic

You can configure a port connected to the Cisco IP Phone to send CDP packets to the phone to configure the way in which the phone sends voice traffic. The phone can carry voice traffic in IEEE 802.1Q frames for a specified voice VLAN with a Layer 2 CoS value. It can use IEEE 802.1p priority tagging to give voice traffic a higher priority and forward all voice traffic through the native (access) VLAN. The Cisco IP Phone can also send untagged voice traffic or use its own configuration to send voice traffic in the access VLAN. In all configurations, the voice traffic carries a Layer 3 IP precedence value (the default is 5).

Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:**	Enters global configuration mode.

	Command or Action	Purpose
	`Router# configure terminal`	
Step 2	**interface** *interface-id* **Example:** `Router(config)# interface gigabitethernet 0/1/0`	Specifies the interface connected to the phone, and enters interface configuration mode.
Step 3	**switchport voice vlan** {*vlan-id* | **dot1p** | **none** | **untagged**} **Example:** `Router(config-if)# switchport voice vlan dot1p`	Configures the voice VLAN. • *vlan-id* —Configures the phone to forward all voice traffic through the specified VLAN. By default, the Cisco IP Phone forwards the voice traffic with an IEEE 802.1Q priority of 5. Valid VLAN IDs are 1 to 4094. • **dot1p** —Configures the phone to use IEEE 802.1p priority tagging for voice traffic and to use the default native VLAN (VLAN 0) to carry all traffic. By default, the Cisco IP Phone forwards the voice traffic with an IEEE 802.1p priority of 5. • **none** —Allows the phone to use its own configuration to send untagged voice traffic. • **untagged** —Configures the phone to send untagged voice traffic.
Step 4	**end** **Example:** `Router(config-if)# end`	Exits interface configuration mode.

What to do next

To configure port security for Voice VLAN:

```
Router#configure terminal
Router(config)#interface <interface-id>
Router(config-if)# switchport mode access
Router(config-if)# switchport voice vlan vlan-id
Router(config-if)# switchport port-security
Router(config-if)# switchport port-security [maximum value [vlan {access | voice}}]]
Router(config-if)# switchport port-security violation {protect | restrict | shutdown}
Router(config-if)# switchport port-security [mac-address mac-address [vlan {access | voice}]]
Router(config-if)#end
Router#show port-security
```

Removing Voice VLAN

To remove the voice VLAN configuration, use the **no switchport voice vlan** command.

Monitoring Voice VLAN

To display voice VLAN configuration for an interface, use the **show interfaces** *interface-id* **switchport** privileged EXEC command.

Configuring VXLAN Tunneling

VXLAN is an extension to the Layer 2 VLAN. It was designed to provide the same VLAN functionality with greater extensibility and flexibility. VXLAN offers the following benefits:

- VLAN flexibility in multitenant segments: It provides a solution to extend Layer 2 segments over the underlying network infrastructure so that tenant workload can be placed across physical pods in the data center.
- Higher scalability: VXLAN uses a 24-bit segment ID known as the VXLAN network identifier (VNID), which enables up to 16 million VXLAN segments to coexist in the same administrative domain.
- Improved network utilization: VXLAN solved Layer 2 STP limitations. VXLAN packets are transferred through the underlying network based on its Layer 3 header and can take complete advantage of Layer 3 routing, equal-cost multipath (ECMP) routing, and link aggregation protocols to use all available paths.

VXLAN uses the VXLAN tunnel endpoint (VTEP) to map tenants' end devices to VXLAN segments and to perform VXLAN encapsulation and decapsulation. Each VTEP function has two interfaces: one is a switch interface on the local LAN segment to support local endpoint communication, and the other is an IP interface to the transport IP network.

Infrastructure VLAN is a unique IP address that identifies the VTEP device on the transport IP network. The VTEP device uses this IP address to encapsulate Ethernet frames and transmits the encapsulated packets to the transport network through the IP interface.

A VTEP device also discovers the remote VTEPs for its VXLAN segments and learns remote MAC Address-to-VTEP mappings through its IP interface.

The following example shows that two IR8340 routers act as VTEPs:




Table 10: VXLAN Configuration

IR8340-1	IR8340-2
bridge-domain 1 member vni 6001 member Vlan100 service-instance 1 ! interface Loopback1 ip address 200.200.200.200 255.255.255.255 ! interface GigabitEthernet0/0/1 ip address 192.168.1.2 255.255.255.0 media-type rj45 ! Interface GigabitEthernet0/1/2 switchport access vlan 100 ! interface Vlan100 no ip address service instance 1 ethernet encapsulation dot1q 100 ! interface nve1 no ip address source-interface Loopback1 member vni 6001 ingress-replication 100.100.100.100 ! ip forward-protocol nd ip pim rp-address 200.200.200.200 ip http server ip http secure-server ip route 0.0.0.0 0.0.0.0 192.168.1.3 !	bridge-domain 1 member vni 6001 member Vlan100 service-instance 1 ! interface Loopback1 ip address 100.100.100.100 255.255.255.255 ! interface GigabitEthernet0/0/1 ip address 192.168.1.3 255.255.255.0 media-type rj45 ! interface GigabitEthernet0/1/2 switchport access vlan 100 ! interface Vlan100 no ip address service instance 1 ethernet encapsulation dot1q 100 ! interface nve1 no ip address source-interface Loopback1 member vni 6001 ingress-replication 200.200.200.200 ! ip forward-protocol nd ip pim rp-address 100.100.100.100 no ip http server ip http secure-server ip route 0.0.0.0 0.0.0.0 192.168.1.2 !

For more details and multiple VTEP configuration with multicast, see https://www.cisco.com/c/en/us/support/docs/ip/multicast/200791-Configuration-and-Troubleshooting-of-VxL.html.

IEEE 802.1x Protocol

The IEEE 802.1x standard defines a client/server-based access control and authentication protocol that prevents clients from connecting to a LAN through publicly accessible ports unless they are authenticated. The authentication server authenticates each client connected to a port before making available any services offered by the router or the LAN.

Until the client is authenticated, IEEE 802.1x access control allows only Extensible Authentication Protocol over LAN (EAPOL), Cisco Discovery Protocol (CDP), and Spanning Tree Protocol (STP) traffic through the port to which the client is connected. After authentication, normal traffic can pass through the port. For more information on IEEE 802.1x port-based authentication, see the Configuring IEEE 802.1x Port-Based Authentication chapter of the *Security Configuration Guide, Cisco IOS XE Gibraltar 16.10.x*.

Configuring IEEE 802.1X Port-Based Authentication

IEEE 802.1X port-based authentication is configured on a device to prevent unauthorized devices (supplicants) from gaining access to the network. The device can combine the function of a router, switch, and access point,

depending on the fixed configuration or installed modules. The switch functions are provided by either built-in switch ports or a plug-in module with switch ports. This feature supports both access ports and trunk ports. For more information on 802.1X port-based authentication, see the Configuring IEEE 802.1X Port-Based Authentication Guide.

Enabling AAA Authorization for VLAN Assignment

AAA authorization limits the services available to a user. When AAA authorization is enabled, the device uses information retrieved from the user's profile, which is in the local user database or on the security server, to configure the user's session. The user is granted access to a requested service only if the information in the user profile allows it.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**aaa new-model** **Example:** `Router(config)# aaa new-model`	Enables AAA.
Step 4	**aaa authorization network radius if-authenticated** **Example:** `Router(config)# aaa authorization network radius if-authenticated`	Configures the device for user RADIUS authorization for all network-related service requests. RADIUS authorization succeeds if the user has authenticated.
Step 5	**aaa authorization exec radius if-authenticated** **Example:** `Router(config)# aaa authorization exec radius if-authenticated`	Configures the device for user RADIUS authorization if the user has privileged EXEC access. RADIUS authorization succeeds if the user has authenticated.
Step 6	**end** **Example:** `Router(config)# end`	Returns to privileged EXEC mode.

Enabling IEEE 802.1X Authentication and Authorization

Follow these steps to enable IEEE 802.1X authentication and authorization.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**aaa authentication dot1x** {**default** | **listname**} **method1** [**method2**...] **Example:** `Router(config)# aaa authentication dot1x default group radius`	Creates a series of authentication methods that are used to determine user privilege to access the privileged command level so that the device can communicate with the AAA server.
Step 4	**dot1x system-auth-control** **Example:** `Router(config)# dot1x system-auth-control`	Globally enables 802.1X port-based authentication.
Step 5	**identity profile default** **Example:** `Router(config)# identity profile default`	Creates an identity profile and enters dot1x profile configuration mode.
Step 6	**exit** **Example:** `Router(config-identity-prof)# exit`	Exits dot1x profile configuration mode and returns to global configuration mode.
Step 7	**interface** *type slot/port* **Example:** `Router(config)# interface Gigabitethernet 0/1/0`	Enters interface configuration mode and specifies the interface to be enabled for 802.1X authentication.
Step 8	**access-session port-control** {**auto** | **force-authorized** | **force-unauthorized**} **Example:** `Router(config-if)# access-session port-control auto`	Enables 802.1X port-based authentication on the interface. • **auto** —Enables IEEE 802.1X authentication and causes the port to begin in the unauthorized state, allowing only EAPOL frames to be sent and received through the port. The authentication process begins when the link state of the port changes from down to up or when an EAPOL-start frame is received. The Device requests the identity

	Command or Action	Purpose
		of the supplicant and begins relaying authentication messages between the supplicant and the authentication server. Each supplicant attempting to access the network is uniquely identified by the Device by using the supplicant MAC address. • **force-authorized** -—Disables IEEE 802.1X authentication and causes the port to change to the authorized state without any authentication exchange required. The port sends and receives normal traffic without IEEE 802.1X-based authentication of the client. This is the default setting. • **force-unauthorized** —Causes the port to remain in the unauthorized state, ignoring all attempts by the supplicant to authenticate. The Device cannot provide authentication services to the supplicant through the port.
Step 9	**dot1x pae** [**supplicant** | **authenticator** | **both**] **Example:** `Device(config-if)# dot1x pae authenticator`	Sets the Port Access Entity (PAE) type. • **supplicant** —The interface acts only as a supplicant and does not respond to messages that are meant for an authenticator. • **authenticator** -—The interface acts only as an authenticator and does not respond to any messages meant for a supplicant. • **both** —The interface behaves both as a supplicant and as an authenticator and thus does respond to all dot1x messages.
Step 10	**end** **Example:** `router(config)# end`	Returns to privileged EXEC mode.
Step 11	**show dot1x** **Example:** `Router# show dot1x`	Displays whether 802.1X authentication has been configured on the device.

Spanning Tree Protocol Overview

Spanning Tree Protocol (STP) is a Layer 2 link management protocol that provides path redundancy while preventing loops in the network. For a Layer 2 Ethernet network to function properly, only one active path can exist between any two stations. Multiple active paths among end stations cause loops in the network. If a loop exists in the network, end stations might receive duplicate messages. Device might also learn end-station MAC addresses on multiple Layer 2 interfaces. These conditions result in an unstable network. Spanning-tree operation is transparent to end stations, which cannot detect whether they are connected to a single LAN segment or a switched LAN of multiple segments.

The STP uses a spanning-tree algorithm to select one device of a redundantly connected network as the root of the spanning tree. The algorithm calculates the best loop-free path through a switched Layer 2 network by assigning a role to each port based on the role of the port in the active topology:

- Root—A forwarding port elected for the spanning-tree topology
- Designated—A forwarding port elected for every switched LAN segment
- Alternate—A blocked port providing an alternate path to the root bridge in the spanning tree
- Backup—A blocked port in a loopback configuration

The device that has *all* of its ports as the designated role or as the backup role is the root device. The device that has at least *one* of its ports in the designated role is called the designated device.

Spanning tree forces redundant data paths into a standby (blocked) state. If a network segment in the spanning tree fails and a redundant path exists, the spanning-tree algorithm recalculates the spanning-tree topology and activates the standby path. Device send and receive spanning-tree frames, called bridge protocol data units (BPDUs), at regular intervals. The device do not forward these frames but use them to construct a loop-free path. BPDUs contain information about the sending device and its ports, including device and MAC addresses, device priority, port priority, and path cost. Spanning tree uses this information to elect the root device and root port for the switched network and the root port and designated port for each switched segment.

When two ports on a device are part of a loop, the spanning-tree and path cost settings control which port is put in the forwarding state and which is put in the blocking state. The spanning-tree port priority value represents the location of a port in the network topology and how well it is located to pass traffic. The path cost value represents the media speed.



Note By default, the device sends keepalive messages (to ensure the connection is up) only on interfaces that do not have small form-factor pluggable (SFP) modules. You can change the default for an interface by entering the [**no**] **keepalive** interface configuration command with no keywords.

IR8340 uses STP (the IEEE 802.1D bridge protocol) on all VLANs. By default, a single instance of STP runs on each configured VLAN (provided you do not manually disable STP). You can enable and disable STP on a per-VLAN basis.

For more information on STP, see the **Configuring Spanning Tree Protocol** chapter of the Layer 2 Configuration Guide.

Default STP Configuration

The following table shows the default STP configuration.

Table 11: STP Default Configuration

Feature	Default Value
Disable state	STP disabled for all VLANs
Bridge priority	32768
STP port priority (configurable on a per-port basis—used on LAN ports configured as Layer 2 access ports)	128
STP port cost (configurable on a per-port basis—used on LAN ports configured as Layer 2 access ports)	Gigabit Ethernet: 4
STP VLAN port priority (configurable on a per-VLAN basis—used on LAN ports configured as Layer 2 trunk ports)	128
STP VLAN port cost (configurable on a per-VLAN basis—used on LAN ports configured as Layer 2 trunk ports)	Gigabit Ethernet:1000000000
Hello time	2 seconds
Forward delay time	15 seconds
Maximum aging time	20 seconds
Mode	PVST

Enabling STP



Note STP is disabled by default on all VLANs.

You can enable STP on a per-VLAN basis. The Cisco SM-X-16G4M2X or SM-X-40G8M2X Layer 2 Gigabit EtherSwitch Service Module maintain a separate instance of STP for each VLAN (except on VLANs on which you disable STP).

If you want to enable a mode that is different from the default mode, this procedure is required.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.

	Command or Action	Purpose
Step 2	**spanning-tree mode** {**pvst** | **mst** | **rapid-pvst**}	Configures a spanning-tree mode. All stack members run the same version of spanning tree. • Select **pvst** to enable PVST+. • Select **mst** to enable MSTP. • Select **rapid-pvst** to enable rapid PVST+.
Step 3	**interface** *interface-id*	Specifies an interface to configure, and enters interface configuration mode. Valid interfaces include physical ports, VLANs, and port channels. The VLAN ID range is 1 to 4094. The port-channel range is 1 to 48.
Step 4	**spanning-tree link-type point-to-point** **Example:** `Device(config-if)# spanning-tree link-type point-to-point`	Specifies that the link type for this port is point-to-point. If you connect this port (local port) to a remote port through a point-to-point link and the local port becomes a designated port, the negotiates with the remote port and rapidly changes the local port to the forwarding state.
Step 5	**end** **Example:** `Router(config)# end`	Returns to privileged EXEC mode.
Step 6	**clear spanning-tree detected-protocols** **Example:** `Router# clear spanning-tree detected-protocols`	If any port on the device is connected to a port on a legacy IEEE 802.1D device, this command restarts the protocol migration process on the entire device. This step is optional if the designated device detects that this device is running rapid PVST+.
Step 7	**show spanning-tree vlan** *vlan_ID*	Verifies that STP is enabled.

What to do next

Caution Do not disable spanning tree on a VLAN unless all switches and bridges in the VLAN have spanning tree disabled. You cannot disable spanning tree on some switches and bridges in a VLAN and leave it enabled on other switches and bridges in the VLAN. This action can have unexpected results because switches and bridges with spanning tree enabled will have incomplete information regarding the physical topology of the network.

Caution We do not recommend disabling spanning tree, even in a topology that is free of physical loops. Spanning tree serves as a safeguard against misconfigurations and cabling errors. Do not disable spanning tree in a VLAN without ensuring that there are no physical loops present in the VLAN.

This example shows how to enable STP on VLAN 200:

```
Device# configure terminal
Device(config)# spanning-tree vlan 200
Device(config)# end
Device#
```

Note STP is disabled by default.

This example shows how to verify the configuration:

```
Device# show spanning-tree vlan 200

G0:VLAN0200
  Spanning tree enabled protocol ieee
  Root ID    Priority    32768
             Address     00d0.00b8.14c8
             This bridge is the root
             Hello Time   2 sec  Max Age 20 sec  Forward Delay 15 sec
  Bridge ID  Priority    32768
             Address     00d0.00b8.14c8
             Hello Time   2 sec  Max Age 20 sec  Forward Delay 15 sec
             Aging Time 300
Interface        Role Sts Cost      Prio.Nbr Status
---------------- ---- --- --------- -------- --------------------------------
Gi1/4            Desg FWD 200000    128.196  P2p
Gi1/5            Back BLK 200000    128.197  P2p
Device#
```

You must have at least one interface that is active in VLAN 200 to create a VLAN 200 spanning tree. In this example, two interfaces are active in VLAN 200.

Configuring Optional STP Features

This section describes how to configure the following optional STP features:

Enabling PortFast

Caution Use PortFast *only* when connecting a single end station to a Layer 2 access port. Otherwise, you might create a network loop.

To enable PortFast on a Layer 2 access port, perform this task:

Procedure

	Command or Action	Purpose
Step 1	Router(config)# **interface** {*type slot/port*}	Selects a port to configure.
Step 2	Router(config-if)# **spanning-tree portfast**	Enables PortFast on a Layer 2 access port connected to a single workstation or server.
Step 3	Router(config-if)# **spanning-tree portfast default**	Enables PortFast.
Step 4	Router(config-if)# **end**	Exits configuration mode.
Step 5	Router# **show running interface** {*type slot/port*}	Verifies the configuration.

Configuring PortFast BPDU Filtering

These sections describe how to configure PortFast BPDU filtering.

To enable PortFast BPDU filtering globally, perform this task:

Procedure

	Command or Action	Purpose
Step 1	**spanning-tree portfast bpdufilter default** **Example:** `Router(config)# spanning-tree portfast bpdufilter default`	Enables BPDU filtering globally on the router.
Step 2	**show spanning-tree summary totals** **Example:** `Router(config)# show spanning-tree summary totals`	Verifies the configuration.

Enabling PortFast BPDU Filtering

BPDU filtering is set to default on each port. This example shows how to enable PortFast BPDU filtering on the port and verify the configuration in PVST+ mode:

```
Router(config)# spanning-tree portfast bpdufilter default

Router(config)# ^Z
Router# show spanning-tree summary totals

Switch is in pvst mode
Root bridge for: G0:VLAN0013, G0:VLAN0020, G1:VLAN0020
EtherChannel misconfig guard is enabled
Extended system ID           is enabled
Portfast Default             is disabled
PortFast BPDU Guard Default  is disabled
Portfast BPDU Filter Default is disabled
```

```
Loopguard Default            is disabled
UplinkFast                   is disabled
BackboneFast                 is disabled
Pathcost method used         is short
Name                   Blocking Listening Learning Forwarding STP Active
---------------------- -------- --------- -------- ---------- ----------
3 vlans                       0         0        0          3          3
```

To enable PortFast BPDU filtering on a nontrunking port, perform this task:

Procedure

	Command or Action	Purpose
Step 1	**interface** *interface-id* **Example:** `Router(config)# interface gigabitethernet 0/1/0`	Selects the interface to configure.
Step 2	**spanning-tree bpdufilter enable** **Example:** `Router(config-if)# spanning-tree bpdufilter enable`	Enables BPDU filtering.
Step 3	**show spanning-tree interface** *interface-id* **Example:** `Router# show spanning-tree interface gigabitethernet 0/1/0`	Verifies the configuration.

What to do next

This example shows how to enable PortFast BPDU filtering on a nontrunking port:

```
Router(config)# interface gigabitethernet 0/1/0
Router(config-if)# spanning-tree bpdufilter enable

Router(config-if)# ^Z
Router# show spanning-tree interface gigabitethernet 0/1/0
Vlan             Role Sts Cost      Prio.Nbr Status
---------------- ---- --- --------- -------- --------------------------------
VLAN0010         Desg FWD 1000      160.196  Edge P2p
Router# show spanning-tree interface gigabitethernet 0/1/0 detail

 Port 196 (gigabitethernet 0/1/0) of VLAN0010 is forwarding
   Port path cost 1000, Port priority 160, Port Identifier 160.196.
   Designated root has priority 32768, address 00d0.00b8.140a
   Designated bridge has priority 32768, address 00d0.00b8.140a
   Designated port id is 160.196, designated path cost 0
   Timers:message age 0, forward delay 0, hold 0
   Number of transitions to forwarding state:1
   The port is in the portfast mode by portfast trunk configuration
   Link type is point-to-point by default
   Bpdu filter is enabled
   BPDU:sent 0, received 0
Router#
```

Enabling BPDU Guard

To enable BPDU Guard globally, perform this task:

Procedure

	Command or Action	Purpose
Step 1	**spanning-tree portfast bpduguard default** **Example:** `Router(config)# no spanning-tree portfast bpduguard default`	Enables BPDU Guard globally. Disables BPDU Guard globally.
Step 2	**end** **Example:** `Router(config)# end`	Exits configuration mode.
Step 3	**show spanning-tree summary totals** **Example:** `Router# show spanning-tree summary totals`	Verifies the configuration.

What to do next

This example shows how to enable BPDU Guard:

```
Router# configure terminal
Router(config)# spanning-tree portfast bpduguard
Router(config)# end
Router#
```

This example shows how to verify the configuration:

```
Router# show spanning-tree summary totals
 default
Root bridge for:VLAN0010
EtherChannel misconfiguration guard is enabled
Extended system ID   is disabled
Portfast             is enabled by default
PortFast BPDU Guard  is disabled by default
Portfast BPDU Filter is enabled by default
Loopguard            is disabled by default
UplinkFast           is disabled
BackboneFast         is disabled
Pathcost method used is long
Name                   Blocking Listening Learning Forwarding STP Active
---------------------- -------- --------- -------- ---------- ----------
2 vlans                   0        0         0        3          3
Router#
```

Enabling UplinkFast

UplinkFast increases the bridge priority to 49152 and adds 3000 to the STP port cost of all Layer 2 LAN interfaces on the device, decreasing the probability that the router will become the root bridge. The *max_update_rate* value represents the number of multicast packets transmitted per second (the default is 150 packets per second). UplinkFast cannot be enabled on VLANs that have been configured for bridge priority.

To enable UplinkFast on a VLAN with bridge priority configured, restore the bridge priority on the VLAN to the default value by entering a **no spanning-tree vlan** *vlan_ID* **priority** command in global configuration mode.

Note When you enable UplinkFast, it affects all VLANs on the device. You cannot configure UplinkFast on an individual VLAN.

To enable UplinkFast, perform this task:

Procedure

	Command or Action	Purpose
Step 1	Router(config)# **spanning-tree uplinkfast** [**max-update-rate** *max_update_rate*]	Enables UplinkFast.
Step 2	Router(config)# **no spanning-tree uplinkfast max-update-rate**	Reverts to the default rate.
Step 3	Router(config)# **no spanning-tree uplinkfast**	Disables UplinkFast.
Step 4	Router(config)# **end**	Exits configuration mode.
Step 5	Router# **show spanning-tree vlan** *vlan_ID*	Verifies that UplinkFast is enabled.

What to do next

This example shows how to enable UplinkFast with an update rate of 400 packets per second:

```
Router# configure terminal
Router(config)# spanning-tree uplinkfast max-update-rate 400
Router(config)# exit
Router#
```

This example shows how to verify that UplinkFast is enabled:

```
Router# show spanning-tree uplinkfast

UplinkFast is enabled
Router#
```

Enabling BackboneFast

Note BackboneFast operates correctly only when enabled on all network devices in the network. BackboneFast is not supported on Token Ring VLANs. This feature is supported for use with third-party network devices.

To enable BackboneFast, perform this task:

Procedure

	Command or Action	Purpose
Step 1	Router(config)# **spanning-tree backbonefast**	Enables backbonefast.
Step 2	Router(config)# **no spanning-tree backbonefast**	Disables BackboneFast.
Step 3	Router(config)# **end**	Exits configuration mode.
Step 4	Router# **show spanning-tree vlan** *vlan_ID*	Verifies that BackboneFast is enabled.

What to do next

This example shows how to enable BackboneFast:

```
Router# configure terminal
Router(config)# spanning-tree backboneFast
Router(config)# end
Router#
```

This example shows how to verify that BackboneFast is enabled:

```
Router# show spanning-tree backbonefast

BackboneFast is enabled
BackboneFast statistics
-----------------------
Number of transition via backboneFast (all VLANs) : 0
Number of inferior BPDUs received (all VLANs)     : 0
Number of RLQ request PDUs received (all VLANs)   : 0
Number of RLQ response PDUs received (all VLANs)  : 0
Number of RLQ request PDUs sent (all VLANs)       : 0
Number of RLQ response PDUs sent (all VLANs)      : 0
Router#
```

MAC Table Manipulation

This section includes the following:

Creating a Static Entry in the MAC Address Table

Perform the following task to create a static entry in the MAC address table.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.

	Command or Action	Purpose
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**mac address-table static mac-address vlan** *vlan-id* **interface** *Interface-id* **Example:** `Router(config)# mac address-table static 00ff.ff0d.2dc0 vlan 1 interface gigabitethernet 0/1/0`	Creates a static entry in the MAC address table.
Step 4	**end** **Example:** `Router(config)# end`	Returns to privileged EXEC mode.
Step 5	**show mac address-table** **Example:** `Router# show mac address-table`	Verifies the MAC address table.

MAC Address-Based Traffic Blocking

Perform the following task to block all traffic to or from a MAC address in a specified VLAN.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**mac address-table static mac-address vlan** *vlan-id* **drop** **Example:** `Router(config)# mac address-table static 00ff.ff0d.2dc0 vlan 1 drop`	Creates a static entry with drop action in the MAC address table.
Step 4	**end** **Example:** `router(config)# end`	Returns to privileged EXEC mode.

	Command or Action	Purpose
Step 5	**show mac address-table** **Example:** `Router# show mac address-table`	Verifies the MAC address table.

Configuring and Verifying the Aging Timer

Perform this task to configure the aging timer.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**mac address-table aging-time** *time* **Example:** `Router(config)# mac address-table aging-time 600` `Or` `Router(config)# mac address-table aging-time 0`	Configures the MAC address aging timer age in seconds. • The accept value is either 0 or 10-1000000 seconds. Default value is 300 seconds. • The maximum aging timer supported by switch chipset is 634 seconds. If configure greater than 634 seconds, MAC address will age out after 634 seconds. • The value 0 means dynamic MAC entries will never age out.
Step 4	**end** **Example:** `router(config)# end`	Returns to privileged EXEC mode.
Step 5	**show mac address-table aging-time** **Example:** `Router# show mac address-table aging-time`	Verifies the MAC address table.

MAC Learning on a Vlan

To disable or enable MAC learning on specified vlan, perform these steps.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**mac address-table learning vlan** *vlan-id* **interface** *Interface-id* **Example:** `Router(config)# mac address-table learning vlan 10`	Creates a static entry in the MAC address table.
Step 4	**end** **Example:** `router(config)# end`	Returns to privileged EXEC mode.

Assigning IP Addresses to Switch Virtual Interfaces

To configure IP routing, you need to assign IP addresses to Layer 3 network interfaces. This enables communication with the hosts on those interfaces that use IP. IP routing is disabled by default, and no IP addresses are assigned to Switch Virtual Interfaces (SVIs).

An IP address identifies a destination for IP packets. Some IP addresses are reserved for special uses and cannot be used for host, subnet, or network addresses. RFC 1166, “Internet Numbers,” contains the official description of these IP addresses.

An interface can have one primary IP address. A a subnet mask identifies the bits that denote the network number in an IP address.

Beginning in privileged EXEC mode, follow these steps to assign an IP address and a network mask to an SVI.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal**	Enter global configuration mode.
Step 2	**interface vlan** *vlan-id*	Enter interface configuration mode, and specify the Layer 3 VLAN to configure.
Step 3	**ip address** *ip-address subnet-mask*	Configure the IP address and IP subnet mask.

	Command or Action	Purpose
Step 4	**end**	Returns to privileged EXEC mode.
Step 5	**show interfaces** [*interface-id*] **show ip interface** [*interface-id*] **show running-config interface** [*interface-id*]	Verify your entries.
Step 6	**copy running-config startup-config**	(Optional) Save your entries in the configuration file.

SVI Supported Features

The following table provided the supported features on the SVI.

Table 12: SVI Supported Features

Techolongy	Feature	Use Case
Routing	Routing Protocol	Interconnects Layer 3 networks using protocols such as Routing Information Protocol (RIP), Open Shortest Path First (OSPF) Protocol, and Enhanced Interior Gateway Routing Protocol (EIGRP) configured under SVI. For more informaton on routing protocol, see the IP Routing: Protocol-Independent Configuration Guide.
	Hot Standby Router Protocol (HSRP)	Supports redundancy and high availability with a secondary device connected to the LAN with SVI, using HSRP. For more informaton on HSRP, see the First Hop Redundancy Protocols Configuration Guide.
	DHCP	Cisco devices running Cisco software include Dynamic Host Configuration Protocol (DHCP) server and the relay agent software. The Cisco IOS DHCP server is a full DHCP server implementation that assigns and manages IP addresses from specified address pools within the device to DHCP clients. The DHCP server can be configured to assign additional parameters such as the IP address of the Domain Name System (DNS) server and the default device. For more informaton on HSRP, see the, IP Addressing: DHCP Configuration Guide
	Multicast (IPv4)	Provides multicast support for clients connected to the switch ports. For more informaton on HSRP, see the, IP Multicast: PIM Configuration Guide
	VRF	Associates a VRF instance with an SVI to map VLANs to different logical or physical VPN WAN connections. For more informaton on VRF protocol, see the IP Routing: Protocol-Independent Configuration Guide.
Security	ACL	Provides packet filtering to control network traffic and restrict the access of users and devices to the network For more informaton on ACL protocol, see the Security Configuration Guide: Access Control Lists.
	NAT	Provides NAT under SVI. For more information on NAT, see the IP Addressing: NAT Configuration Guide.

Techolongy	Feature	Use Case
Qos	Classification with standard and extended access list	Provides QoS classification with standard and extended access lists. For more informtion on QoS, see the Security Configuration Guide: Access Control Lists.
	Class-based marking	Provides QoS marking based on user-defined traffic class with DSCP and IP precedence values. For more information on QoS Marking, see the QoS: Classification Configuration Guide.
	Policing	Limits the input or output transmission rate on SVI and specifies traffic handling policies when the traffic either conforms to or exceeds the specified rate limits. For more informtion on Policing, see the QoS: Policing and Shaping Configuration Guide
Bridging	EVC under SVI	Supports a default encapsulation EFP under SVI, to have VLAN/BD integrated.
	EVC with MAC ACL under SVI	For more information on EVC, see *Layer 2 Configuration Guide, Cisco IOS XE Gibraltar 16.11*.

IGMP Snooping for IPv4

IGMP snooping allows switches to examine IGMP packets and make forwarding decisions based on their content. You can configure the switch to use IGMP snooping in subnets that receive IGMP queries from either IGMP or the IGMP snooping querier. IGMP snooping constrains IPv4 multicast traffic at Layer 2 by configuring Layer 2 LAN ports dynamically to forward IPv4 multicast traffic only to those ports that want to receive it.

Layer 2 switches can use IGMP snooping to constrain the flooding of multicast traffic by dynamically configuring Layer 2 interfaces so that multicast traffic is forwarded to only those interfaces associated with IP multicast devices. As the name implies, IGMP snooping requires the LAN switch to snoop on the IGMP transmissions between the host and the router and to keep track of multicast groups and member ports. When the switch receives an IGMP report from a host for a particular multicast group, the switch adds the host port number to the forwarding table entry; when it receives an IGMP Leave Group message from a host, it removes the host port from the table entry. It also periodically deletes entries if it does not receive IGMP membership reports from the multicast clients. For more information on this feature, see https://www.cisco.com/c/en/us/td/docs/routers/7600/ios/15S/configuration/guide/7600_15_0s_book/snooigmp.html.

IGMP Filtering and Throttling

In some environments, for example, metropolitan or multiple-dwelling unit (MDU) installations, you might want to control the set of multicast groups to which a user on a switch port can belong. You can control the distribution of multicast services, such as IP/TV, based on some type of subscription or service plan. You might also want to limit the number of multicast groups to which a user on a switch port can belong.

With the IGMP filtering feature, you can filter multicast joins on a per-port basis by configuring IP multicast profiles and associating them with individual switch ports. An IGMP profile can contain one or more multicast groups and specifies whether access to the group is permitted or denied. If an IGMP profile denying access to a multicast group is applied to a switch port, the IGMP join report requesting the stream of IP multicast traffic is dropped, and the port is not allowed to receive IP multicast traffic from that group. If the filtering action permits access to the multicast group, the IGMP report from the port is forwarded for normal processing. You can also set the maximum number of IGMP groups that a Layer 2 interface can join.

IGMP filtering controls only group-specific query and membership reports, including join and leave reports. It does not control general IGMP queries. IGMP filtering has no relationship with the function that directs the forwarding of IP multicast traffic. The filtering feature operates in the same manner whether CGMP or MVR is used to forward the multicast traffic.

IGMP filtering applies only to the dynamic learning of IP multicast group addresses, not static configuration.

With the IGMP throttling feature, you can set the maximum number of IGMP groups that a Layer 2 interface can join. If the maximum number of IGMP groups is set, the IGMP snooping forwarding table contains the maximum number of entries, and the interface receives an IGMP join report, you can configure an interface to drop the IGMP report or to replace the randomly selected multicast entry with the received IGMP report.

Default IGMP Filtering and Throttling Configuration

The following table displays the default IGMP filtering and throttling configuration for the device.

Table 13: Default IGMP Filtering Configuration

Feature	Default Setting
IGMP filters	None applied.
IGMP maximum number of IGMP groups	No maximum set. **Note** When the maximum number of groups is in the forwarding table, the default IGMP throttling action is to deny the IGMP report.
IGMP profiles	None defined.
IGMP profile action	Deny the range addresses.

Configuring IGMP Profiles

To configure an IGMP profile, use the **ip igmp profile** global configuration command with a profile number to create an IGMP profile and to enter IGMP profile configuration mode. From this mode, you can specify the parameters of the IGMP profile to be used for filtering IGMP join requests from a port.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:** `Router# configure terminal`	Enters global configuration mode.
Step 2	**ip igmp profile** *profile-number* **Example:** `Router(config)# ip igmp profile 3`	Enters IGMP profile configuration mode, and assigns a number to the profile you are configuring. The range is from 1 to 4294967295.
Step 3	**permit** | **deny** **Example:** `Router(config-igmp-profile)# permit`	(Optional) Sets the action to permit or deny access to the IP multicast address. If no action is configured, the default for the profile is to deny access.
Step 4	**range** *ip multicast address* **Example:** `Router(config-igmp-profile)# range 229.9.9.0`	Enter the IP multicast address or range of IP multicast addresses to which access is being controlled. If entering a range, enter the low IP multicast address, a space, and the high IP multicast address. You can use the **range** command multiple times to enter multiple addresses or ranges of addresses.
Step 5	**end** **Example:** `Router(config-igmp-profile)# end`	Returns to privileged EXEC mode.

Applying IGMP Profiles

To control access as defined in an IGMP profile, use the ip igmp filter interface configuration command to apply the profile to the appropriate interfaces. You can apply IGMP profiles to layer 2 access ports only; you cannot apply IGMP profiles to routed ports or SVIs. You cannot apply profiles to ports that belong to an EtherChannel port group. You can apply a profile to multiple interfaces, but each interface can only have one profile applied to it.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:** `Router# configure terminal`	Enters global configuration mode.

	Command or Action	Purpose
Step 2	**interface** *interface-id* **Example:** `Router(config)# interface GigabitEthernet0/1/0`	Specifies the physical interface, and enters interface configuration mode. The interface must be a Layer 2 port that does not belong to an EtherChannel port group.
Step 3	**ip igmp filter** *profile-number* **Example:** `Router(config-if)# ip igmp filter 123`	Applies the specified IGMP profile to the interface. The range is 1 to 4294967295.
Step 4	**end** **Example:** `Router(config-if)# end`	Returns to privileged EXEC mode.

Setting the Maximum Number of IGMP Groups

You can set the maximum number of IGMP groups that a Layer 2 interface can join by using the **ip igmp max-groups interface** configuration command. Use the **no** form of this command to set the maximum back to the default, which is no limit. This restriction can be applied to Layer 2 ports only; you cannot set a maximum number of IGMP groups on routed ports or SVIs. You also can use this command on a logical EtherChannel interface but cannot use it on ports that belong to an EtherChannel port group.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:** `Router# configure terminal`	Enters global configuration mode.
Step 2	**interface** *interface-id* **Example:** `Router(config)# interface GigabitEthernet0/1/0`	Specifies the physical interface to be configured, and enters interface configuration mode. The interface must be a Layer 2 port that does not belong to an EtherChannel port group.
Step 3	**ip igmp max-groups** *number* **Example:** `Router(config-if)# ip igmp max-groups 20`	Sets the maximum number of IGMP groups that the interface can join. The range is 0 to 4294967294. The default is to have no maximum set.
Step 4	**end** **Example:** `Router(config-if)# end`	Returns to privileged EXEC mode.

Configuring the IGMP Throttling Action

After you set the maximum number of IGMP groups that a Layer 2 interface can join, you can configure an interface to remove a randomly selected multicast entry in the forwarding table and to add the next IGMP group to it by using the ip igmp max-groups action replace interface configuration command.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:** `Router# configure terminal`	Enters global configuration mode.
Step 2	**interface** *interface-id* **Example:** `Router(config)# interface GigabitEthernet0/1/0`	Specifies the physical interface to be configured, and enters interface configuration mode. The interface must be a Layer 2 port that does not belong to an EtherChannel port group.
Step 3	**ip igmp max-groups action** {**deny** | **replace**} **Example:** `Router(config-if)# ip igmp max-groups action replace`	When an interface receives an IGMP report and the maximum number of entries is in the forwarding table, specifies the action that the interface takes: • **deny** —Drop the report. • **replace** —Remove a randomly selected multicast entry in the forwarding table, and add the IGMP group in the report. To prevent the device from removing the forwarding-table entries, you can configure the IGMP throttling action before an interface adds entries to the forwarding table.
Step 4	**end** **Example:** `Router(config-if)# end`	Returns to privileged EXEC mode.

MLD Snooping

In IP Version 4 (IPv4), Layer 2 switches can use Internet Group Management Protocol (IGMP) snooping to limit the flooding of multicast traffic by dynamically configuring Layer 2 interfaces so that multicast traffic is forwarded to only those interfaces associated with IP multicast devices. In IPv6, MLD snooping performs a similar function. With MLD snooping, IPv6 multicast data is selectively forwarded to a list of ports that want to receive the data, instead of being flooded to all ports in a VLAN. This list is constructed by snooping IPv6 multicast control packets.

MLD is a protocol used by IPv6 multicast routers to discover the presence of multicast listeners (nodes wishing to receive IPv6 multicast packets) on the links that are directly attached to the routers and to discover which multicast packets are of interest to neighboring nodes. MLD is derived from IGMP; MLD Version 1 (MLDv1) is equivalent to IGMPv2, and MLD Version 2 (MLDv2) is equivalent to IGMPv3. MLD is a subprotocol of Internet Control Message Protocol Version 6 (ICMPv6), and MLD messages are a subset of ICMPv6 messages, identified in IPv6 packets by a preceding Next Header value of 58.

MLD Snooping Configuration Guidelines

When configuring MLD snooping, consider these guidelines:

- You can configure MLD snooping characteristics at any time, but you must globally enable MLD snooping by using the **ipv6 mld snooping** global configuration command for the configuration to take effect.
- MLD snooping and IGMP snooping act independently of each other. You can enable both features at the same time on the switch.

Default MLD Snooping Configuration

Table 14: Default MLD Snooping Configuration

Feature	Default Setting
MLD snooping (Global)	Disabled.
MLD snooping (per VLAN)	Enabled. MLD snooping must be globally enabled for VLAN MLD snooping to take place.
IPv6 Multicast addresses	None configured.
IPv6 Multicast router ports	None configured.
MLD snooping Immediate Leave	Disabled.
MLD snooping robustness variable	Global: 2; Per VLAN: 0. **Note** The VLAN value overrides the global setting. When the VLAN value is 0, the VLAN uses the global count.
Note	The VLAN value overrides the global setting. When the VLAN value is 0, the VLAN uses the global count.
Last listener query count	Global: 2; Per VLAN: 0. **Note** The VLAN value overrides the global setting. When the VLAN value is 0, the VLAN uses the global count.
Note	The VLAN value overrides the global setting. When the VLAN value is 0, the VLAN uses the global count.

Feature	Default Setting
Last listener query interval	Global: 1000 (1 second); VLAN: 0. **Note** The VLAN value overrides the global setting. When the VLAN value is 0, the VLAN uses the global interval.
Note	The VLAN value overrides the global setting. When the VLAN value is 0, the VLAN uses the global interval.
TCN query solicit	Disabled.
TCN query count	2
MLD listener suppression	

Enabling or Disabling MLD Snooping on a VLAN

To enable MLD snooping on a VLAN, perform this procedure:

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**ipv6 mld snooping** **Example:** `Router(config)# ipv6 mld snooping`	Enables MLD snooping on the switch.
Step 4	**ipv6 mld snooping vlan** *vlan-id* **Example:** `Device(config)# ipv6 mld snooping vlan 1`	Enables MLD snooping on the VLAN. The VLAN ID range is 1 to 1001 and 1006 to 4094. **Note** MLD snooping must be globally enabled for VLAN snooping to be enabled.
Step 5	**end** **Example:** `Router(config)# end`	Returns to privileged EXEC mode.

Configuring UniDirectional Link Detection

UniDirectional Link Detection (UDLD) is a Layer 2 protocol that enables devices connected through fiber-optic or twisted-pair Ethernet cables to monitor the physical configuration of the cables and detect when a unidirectional link exists. All connected devices must support UDLD for the protocol to successfully identify and disable unidirectional links. When UDLD detects a unidirectional link, it disables the affected port and alerts you. Unidirectional links can cause a variety of problems, including spanning-tree topology loops.

Enabling UDLD Globally

Follow these steps to enable UDLD in the aggressive or normal mode and to set the configurable message timer on all fiber-optic ports on the device.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 2	**udld** {**aggressive** | **enable** | **message time** *message-timer-interval*} **Example:** `Router(config)# udld enable message time 10`	Specifies the UDLD mode of operation: • **aggressive** —Enables UDLD in aggressive mode on all fiber-optic ports. • **enable** —Enables UDLD in normal mode on all fiber-optic ports on the . UDLD is disabled by default. An individual interface configuration overrides the setting of the **udld enable** global configuration command. • **message time** message-timer-interval —Configures the period of time between UDLD probe messages on ports that are in the advertisement phase and are detected to be bidirectional. The range is from 1 to 90 seconds; the default value is 15. **Note** This command affects fiber-optic ports only. Use the **udld** interface configuration command to enable UDLD on other port types. Use the **no** form of this command, to disable UDLD.

	Command or Action	Purpose
Step 3	**end** **Example:** `Router(config)# end`	Returns to privileged EXEC mode.

Enabling UDLD on an Interface

Follow these steps either to enable UDLD in the aggressive or normal mode or to disable UDLD on a port.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 2	**interface** *interface-id* **Example:** `Router(config)# interface gigabitethernet 0/1/0`	Specifies the port to be enabled for UDLD, and enters interface configuration mode.
Step 3	**udld port** [**aggressive**] **Example:** `Router(config-if)# udld port aggressive`	UDLD is disabled by default. • **udld port** —Enables UDLD in normal mode on the specified port. • **udld port aggressive** —(Optional) Enables UDLD in aggressive mode on the specified port. **Note** Use the **no udld port** interface configuration command to disable UDLD on a specified fiber-optic port.
Step 4	**end** **Example:** `Router(config-if)# end`	Returns to privileged EXEC mode.

Configuring the Switched Port Analyzer

This section describes how to configure a Switched Port Analyzer (SPAN) session.

- IR8340 can support 66 SPAN sessions in all ports. However, only eight of them can be used as source sessions which includes local SPAN sessions and remote SPAN source sessions. The remaining sessions can be used as remote SPAN destination sessions.
- The session ID range is from 1 to 66.



Note Tx, Rx, or both Tx and Rx monitoring is supported.

SPAN and RSPAN

You can analyze network traffic passing through ports or VLANs by using SPAN or RSPAN to send a copy of the traffic to another port on the device or on another device that has been connected to a network analyzer or other monitoring or security device. SPAN copies (or mirrors) traffic received or sent (or both) on source ports or source VLANs to a destination port for analysis. SPAN does not affect the switching of network traffic on the source ports or VLANs. You must dedicate the destination port for SPAN use. Destination ports do not receive or forward traffic by default. It can receive or forward traffic when ingress-forwarding is enabled on the destination ports.

Only traffic that enters or leaves source ports or traffic that enters or leaves source VLANs can be monitored by using SPAN; traffic routed to a source VLAN cannot be monitored. For example, if incoming traffic is being monitored, traffic that gets routed from another VLAN to the source VLAN cannot be monitored; however, traffic that is received on the source VLAN and routed to another VLAN can be monitored.

You can use the SPAN or RSPAN destination port to inject traffic from a network security device. For example, if you connect a Cisco Intrusion Detection System (IDS) sensor appliance to a destination port, the IDS device can send TCP reset packets to close down the TCP session of a suspected attacker.

Creating a Local SPAN Session

Follow these steps to create a SPAN session and specify the source (monitored) ports or VLANs and the destination (monitoring) ports.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**no monitor session** {*session_number* | **all** | **local** | **remote**} **Example:**	Removes any existing SPAN configuration for the session. • For *session_number*, the range is 1 to 66.

	Command or Action	Purpose
	`Router(config)# no monitor session all`	• **all** —Removes all SPAN sessions. • **local** —Removes all local sessions. • **remote** —Removes all remote SPAN sessions.
Step 4	**monitor session** *session_number* **source** {**interface** *interface-id* | **vlan** *vlan-id*} [, | -] [**both** | **rx** | **tx**] **Example:** `Router(config)# monitor session 1 source interface gigabitethernet 0/1/0`	Specifies the SPAN session and the source port/Vlan (monitored port). • For session_number , the range is 1 to 66. • For interface-id , specify the source port to monitor. Valid interfaces include physical interfaces and port-channel logical interfaces (**port-channel** port-channel-number). Valid port-channel numbers are 1 to 32. • For vlan-id , specify the source VLAN to monitor. The range is 1 to 4094 (excluding the RSPAN VLAN). **Note** A single session can include multiple sources (ports or VLANs) defined in a series of commands, but you cannot combine source ports and source VLANs in one session. • (Optional) [**,** | -] Specifies a series or range of interfaces. Enter a space before and after the comma; enter a space before and after the hyphen. • (Optional) **both** | **rx** | **tx** —Specifies the direction of traffic to monitor. If you do not specify a traffic direction, the source interface sends both sent and received traffic. • **both** —Monitors both received and sent traffic. • **rx** —Monitors received traffic. • **tx** —Monitors sent traffic. **Note** You can use the **monitor session** session_number **source** command multiple times to configure multiple source ports.

	Command or Action	Purpose
Step 5	**monitor session** *session_number* **destination** {**interface** *interface-id* [, | -] [**encapsulation** {**replicate** | **dot1q**}]} **Example:** `Router(config)# monitor session 1 destination interface gigabitethernet 0/1/0 encapsulation replicate`	**Note** For local SPAN, you must use the same session number for the source and destination interfaces. • For session_number , specify the session number entered in step 4. • (Optional) [**,** | -] Specifies a series or range of interfaces. Enter a space before and after the comma; enter a space before and after the hyphen. (Optional) **encapsulation replicate** specifies that the destination interface replicates the source interface encapsulation method. If not selected, the default is to send packets in native form (untagged). (Optional) **encapsulation dot1q** specifies that the destination interface accepts the source interface incoming packets with IEEE 802.1Q encapsulation. **Note** You can use **monitor session** session_number **destination** command multiple times to configure multiple destination ports.
Step 6	**end** **Example:** `Router(config)# end`	Returns to privileged EXEC mode.
Step 7	**show running-config** **Example:** `Router# show running-config`	Verifies your entries.
Step 8	**copy running-config startup-config** **Example:** `Router# copy running-config startup-config`	(Optional) Saves your entries in the configuration file.

Creating a Local SPAN with Incoming Traffic Allowed on Destination

Follow these steps to create a SPAN session, to specify the source ports or VLANs and the destination ports, and to enable incoming traffic on the destination port for a network security device (such as a Cisco IDS Sensor Appliance).

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**no monitor session** {*session_number* | **all** | **local** | **remote**} **Example:** `Router(config)# no monitor session all`	Removes any existing SPAN configuration for the session. • For *session_number*, the range is 1 to 66. • **all** —Removes all SPAN sessions. • **local** —Removes all local sessions. • **remote** —Removes all remote SPAN sessions.
Step 4	**monitor session** *session_number* **source** {**interface** *interface-id* | **vlan** *vlan-id*} [, | -] [**both** | **rx** | **tx**] **Example:** `Router(config)# monitor session 2 source gigabitethernet 0/1/0 rx`	Specifies the SPAN session and the source port (monitored port).
Step 5	**monitor session** *session_number* **destination** {**interface** *interface-id* [, | -] [**encapsulation** {**replicate**] [**ingress** {**dot1q vlan** *vlan-id* | **untagged vlan** *vlan-id* | **vlan** *vlan-id*}]} **Example:** `Router(config)# monitor session 2 destination interface gigabitethernet 0/1/0 encapsulation replicate ingress dot1q vlan 6`	Specifies the SPAN session, the destination port, the packet encapsulation, and the ingress VLAN and encapsulation. • For session_number , specify the session number entered in Step 4. • For interface-id , specify the destination port. The destination interface must be a physical port or port-channel; it cannot be an EtherChannel, and it cannot be a VLAN. • (Optional) [**,** | -] —Specifies a series or range of interfaces. Enter a space before and after the comma or hyphen. • (Optional) **encapsulation replicate** specifies that the destination interface replicates the source interface encapsulation method. If not selected, the

	Command or Action	Purpose
		default is to send packets in native form (untagged). • (Optional) **encapsulation dot1q** specifies that the destination interface accepts the source interface incoming packets with IEEE 802.1Q encapsulation. • **ingress** enables forwarding of incoming traffic on the destination port and to specify the encapsulation type: • **dot1q vlan** vlan-id— Accepts incoming packets with IEEE 802.1Q encapsulation with the specified VLAN as the default VLAN. • **untagged vlan** vlan-id or **vlan** vlan-id— Accepts incoming packets with untagged encapsulation type with the specified VLAN as the default VLAN.
Step 6	**end** **Example:** `Router(config)# end`	Returns to privileged EXEC mode.
Step 7	**show running-config** **Example:** `Router# show running-config`	Verifies your entries.
Step 8	**copy running-config startup-config** **Example:** `Router# copy running-config startup-config`	(Optional) Saves your entries in the configuration file.

Specifying VLANs to Filter

Follow these steps to limit SPAN source traffic to specific VLANs.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.

	Command or Action	Purpose
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**no monitor session** {*session_number* | **all** | **local** | **remote**} **Example:** `Router(config)# no monitor session all`	Removes any existing SPAN configuration for the session. • For *session_number*, the range is 1 to 66. • **all** —Removes all SPAN sessions. • **local** —Removes all local sessions. • **remote** —Removes all remote SPAN sessions.
Step 4	**monitor session** *session_number* **source** {**interface** *interface-id*] **Example:** `Router(config)# monitor session 2 source interface gigabitethernet 0/1/0 rx`	Specifies the characteristics of the source port (monitored port) and SPAN session. • For session_number , the range is 1 to 66. • For interface-id , specify the source port to monitor. The interface specified must already be configured as a trunk port.
Step 5	**monitor session** *session_number* **filter vlan** *vlan-id* [, | -] **Example:** `Router(config)# monitor session 2 filter vlan 1 - 5 , 9`	Limits the SPAN source traffic to specific VLANs. • For session_number , enter the session number specified in Step 4. • For vlan-id , the range is 1 to 4094. • (Optional) Use a comma (**,**) to specify a series of VLANs, or use a hyphen (**-**) to specify a range of VLANs. Enter a space before and after the comma; enter a space before and after the hyphen.
Step 6	**monitor session** *session_number* **destination** {**interface** *interface-id* [, | -] [**encapsulation replicate** | **encapsulation dot1q**}]} **Example:** `Router(config)# monitor session 2 destination interface gigabitethernet 0/1/0`	Specifies the SPAN session and the destination port (monitoring port). • For session_number , specify the session number entered in Step 4. • For interface-id , specify the destination port. The destination interface must be a physical port or port-channel; it cannot be an EtherChannel, and it cannot be a VLAN. • (Optional) [**,** | -] Specifies a series or range of interfaces. Enter a space before and after

	Command or Action	Purpose
		the comma; enter a space before and after the hyphen. • (Optional) **encapsulation replicate** specifies that the destination interface replicates the source interface encapsulation method. If not selected, the default is to send packets in native form (untagged). • (Optional) **encapsulation dot1q** IEEE 802.1Q is a standard protocol for interconnecting multiple switches and routers and for defining VLAN topologies. Applies a VLAN ID to the subinterface.
Step 7	**end** **Example:** `Router(config)# end`	Returns to privileged EXEC mode.
Step 8	**show running-config** **Example:** `Router# show running-config`	Verifies your entries.
Step 9	**copy running-config startup-config** **Example:** `Router# copy running-config startup-config`	(Optional) Saves your entries in the configuration file.

Verifying the SPAN Session

Use the **show monitor session** command to verify the sources and destinations configured for the SPAN session.

```
Router#show monitor session 1

Session 1
---------
Session 1
---------
Type : Local Session
Source Ports :
Both : Gi0/1/0
Destination Ports : Gi0/1/1
```

Removing a SPAN Session

To remove sources or destinations from the SPAN session, use the **no monitor session** session command in global configuration mode as shown in the following example:

```
Router(config)#no monitor session 1
```

Configuring a VLAN as an RSPAN VLAN

Follow these steps to create a new VLAN, then configure it to be the RSPAN VLAN for the RSPAN session.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**vlan** *vlan-id* **Example:** `Router(config)# vlan 100`	Enters a VLAN ID to create a VLAN, or enters the VLAN ID of an existing VLAN, and enters VLAN configuration mode. The range is 2 to 1001 and 1006 to 4094. The RSPAN VLAN cannot be VLAN 1 (the default VLAN) or VLAN IDs 1002 through 1005 (reserved for Token Ring and FDDI VLANs).
Step 4	**remote-span** **Example:** `Router(config)# remote-span`	Configures the VLAN as an RSPAN VLAN.
Step 5	**end** **Example:** `Router(config)# end`	Returns to privileged EXEC mode.
Step 6	**show running-config** **Example:** `Router# show running-config`	Verifies your entries.
Step 7	**copy running-config startup-config** **Example:** `Router# copy running-config startup-config`	(Optional) Saves your entries in the configuration file.

What to do next

You must create the RSPAN VLAN in all devices that will participate in RSPAN. If the RSPAN VLAN-ID is in the normal range (lower than 1005) and VTP is enabled in the network, you can create the RSPAN VLAN in one device, and VTP propagates it to the other devices in the VTP domain. For extended-range VLANs (greater than 1005), you must configure RSPAN VLAN on both source and destination devices and any intermediate devices.

Use VTP pruning to get an efficient flow of RSPAN traffic, or manually delete the RSPAN VLAN from all trunks that do not need to carry the RSPAN traffic.

To remove the remote SPAN characteristic from a VLAN and convert it back to a normal VLAN, use the **no remote-span** VLAN configuration command.

To remove a source port or VLAN from the SPAN session, use the **no monitor session** session_number **source** {**interface** interface-id | **vlan** vlan-id} global configuration command. To remove the RSPAN VLAN from the session, use the **no monitor session** session_number {**Source|destination**} **remote vlan** vlan-id .

Creating an RSPAN Source Session

Follow these steps to create and start an RSPAN source session and to specify the monitored source and the destination RSPAN VLAN.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**no monitor session** {*session_number* | **all** | **local** | **remote**} **Example:** `Router(config)# no monitor session all`	Removes any existing SPAN configuration for the session. • For *session_number*, the range is 1 to 66. • **all** —Removes all SPAN sessions. • **local** —Removes all local sessions. • **remote** —Removes all remote SPAN sessions.
Step 4	**monitor session** *session_number* **source** {**interface** *interface-id* | **vlan** *vlan-id*} [, | -] [**both** | **rx** | **tx**] **Example:**	Specifies the RSPAN session and the source port (monitored port). • For session_number , the range is 1 to 66. • Enter a source port or source VLAN for the RSPAN session:

	Command or Action	Purpose
	`Router(config)# monitor session 1 source interface gigabitethernet 0/1/0 tx`	• For interface-id , specifies the source port to monitor. Valid interfaces include physical interfaces and port-channel logical interfaces (**port-channel** port-channel-number). Valid port-channel numbers are 1 to 32. • For vlan-id , specifies the source VLAN to monitor. The range is 1 to 4094 (excluding the RSPAN VLAN). A single session can include multiple sources (ports or VLANs), defined in a series of commands, but you cannot combine source ports and source VLANs in one session. • (Optional) [**,** | -] —Specifies a series or range of interfaces. Enter a space before and after the comma; enter a space before and after the hyphen. • (Optional) **both** | **rx** | **tx** —Specifies the direction of traffic to monitor. If you do not specify a traffic direction, the source interface sends both sent and received traffic. • **both** —Monitors both received and sent traffic. • **rx** —Monitors received traffic. • **tx** —Monitors sent traffic.
Step 5	**monitor session** *session_number* **destination remote vlan** *vlan_id* **Example:** `Router(config)# monitor session 1 destination remote vlan 100`	Specifies the RSPAN session, the destination RSPAN VLAN, and the destination-port group. • For session_number , enter the number defined in Step 4. • For vlan-id , specify the RSPAN VLAN in source session, which will transport mirrored traffic to destination session.
Step 6	**end** **Example:** `Router(config)# end`	Returns to privileged EXEC mode.

	Command or Action	Purpose
Step 7	**show running-config** **Example:** `Router# show running-config`	Verifies your entries.
Step 8	**copy running-config startup-config** **Example:** `Router# copy running-config startup-config`	(Optional) Saves your entries in the configuration file.

Specifying VLANs to Filter on RSPAN Source Session

Follow these steps to configure the RSPAN source session to limit RSPAN source traffic to specific VLANs.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**no monitor session** {*session_number* | **all** | **local** | **remote**} **Example:** `Router(config)# no monitor session 2`	Removes any existing SPAN configuration for the session. • For *session_number*, the range is 1 to 66. • **all** —Removes all SPAN sessions. • **local** —Removes all local sessions. • **remote** —Removes all remote SPAN sessions.
Step 4	**monitor session** *session_number* **source interface** *interface-id* **Example:** `Router(config)# monitor session 2 source interface gigabitethernet 0/1/0 rx`	Specifies the characteristics of the source port (monitored port) and SPAN session. • For session_number , the range is 1 to 66. • For interface-id , specify the source port to monitor. The interface specified must already be configured as a trunk port.
Step 5	**monitor session** *session_number* **filter vlan** *vlan-id* [, | -]	Limits the SPAN source traffic to specific VLANs.

	Command or Action	Purpose
	Example: `Router(config)# monitor session 2 filter vlan 1 - 5 , 9`	• For session_number , enter the session number specified in step 4. • For vlan-id , the range is 1 to 4094. • (Optional) **,** | **-** Use a comma (**,**) to specify a series of VLANs or use a hyphen (**-**) to specify a range of VLANs. Enter a space before and after the comma; enter a space before and after the hyphen.
Step 6	**monitor session** *session_number* **destination remote vlan** *vlan-id* **Example:** `Router(config)# monitor session 2 destination remote vlan 902`	Specifies the RSPAN session and the destination remote VLAN (RSPAN VLAN). • For session_number , enter the session number specified in Step 4. • For vlan-id , specify the RSPAN VLAN to carry the monitored traffic to the destination port.
Step 7	**end** **Example:** `Router(config)# end`	Returns to privileged EXEC mode.
Step 8	**show running-config** **Example:** `Router# show running-config`	Verifies your entries.
Step 9	**copy running-config startup-config** **Example:** `Router# copy running-config startup-config`	(Optional) Saves your entries in the configuration file.

Creating an RSPAN Destination Session and Configuring Incoming Traffic

Follow these steps to create an RSPAN destination session, to specify the source RSPAN VLAN and the destination port, and to enable incoming traffic on the destination port for a network security device (such as a Cisco IDS Sensor Appliance).

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.

	Command or Action	Purpose
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**no monitor session** {*session_number* | **all** | **local** | **remote**} **Example:** `Router(config)# no monitor session 2`	Removes any existing SPAN configuration for the session. • For *session_number*, the range is 1 to 66. • **all** —Removes all SPAN sessions. • **local** —Removes all local sessions. • **remote** —Removes all remote SPAN sessions.
Step 4	**monitor session** *session_number* **source remote vlan** *vlan-id* **Example:** `Router(config)# monitor session 2 source remote vlan 901`	Specifies the RSPAN session and the source RSPAN VLAN. • For session_number , the range is 1 to 66. • For vlan-id , specify the RSPAN VLAN in destination session, which will receive mirrored traffic from the source session.
Step 5	**monitor session** *session_number* **destination** {**interface** *interface-id* [, | -] [**ingress** {**dot1q vlan** *vlan-id* | **untagged vlan** *vlan-id* | **vlan** *vlan-id*}]} **Example:** `Router(config)# monitor session 2 destination interface gigabitethernet 0/1/0 ingress vlan 6`	Specifies the SPAN session, the destination port, the packet encapsulation, and the incoming VLAN and encapsulation. • For session_number , enter the number defined in Step 5. In an RSPAN destination session, you must use the same session number for the source RSPAN VLAN and the destination port. • For interface-id , specify the destination interface. The destination interface must be a physical interface. • Though visible in the command-line help string, **encapsulation replicate** is not supported for RSPAN. The original VLAN ID is overwritten by the RSPAN VLAN ID, and all packets appear on the destination port as untagged. • (Optional) [**,** | **-**] Specifies a series or range of interfaces. Enter a space before and after the comma; enter a space before and after the hyphen.

	Command or Action	Purpose
		• Enter **ingress** with additional keywords to enable forwarding of incoming traffic on the destination port and to specify the encapsulation type: • **dot1q vlan** vlan-id— Forwards incoming packets with IEEE 802.1Q encapsulation with the specified VLAN as the default VLAN. • **untagged vlan** vlan-id or **vlan** vlan-id— Forwards incoming packets with untagged encapsulation type with the specified VLAN as the default VLAN.
Step 6	**end** **Example:** `Router(config)# end`	Returns to privileged EXEC mode.
Step 7	**show running-config** **Example:** `Router# show running-config`	Verifies your entries.
Step 8	**copy running-config startup-config** **Example:** `Router# copy running-config startup-config`	(Optional) Saves your entries in the configuration file.

EtherChannel Overview

EtherChannel provides fault-tolerant high-speed links between switches, routers, and servers. You can use the EtherChannel to increase the bandwidth between the wiring closets and the data center, and you can deploy it anywhere in the network where bottlenecks are likely to occur. EtherChannel provides automatic recovery for the loss of a link by redistributing the load across the remaining links. If a link fails, EtherChannel redirects traffic from the failed link to the remaining links in the channel without intervention.

An EtherChannel consists of individual Ethernet links bundled into a single logical link

The EtherChannel provides full-duplex bandwidth up to 4 Gb/s (Gigabit EtherChannel) between your switch and another switch or host.

Each EtherChannel can consist of up to four compatibly configured Ethernet ports.

Channel Groups and Port-Channel Interfaces

An EtherChannel comprises a channel group and a port-channel interface. The channel group binds physical ports to the port-channel interface. Configuration changes applied to the port-channel interface apply to all the physical ports bound together in the channel group. The channel-group command binds the physical port and the port-channel interface together. Each EtherChannel has a port-channel logical interface numbered from 1 to 32. This port-channel interface number corresponds to the one specified with the channel-group interface configuration command.

Port Aggregation Protocol

The Port Aggregation Protocol (PAgP) is a Cisco-proprietary protocol that can be run only on Cisco devices and on those devices licensed by vendors to support PAgP. PAgP facilitates the automatic creation of EtherChannels by exchanging PAgP packets between Ethernet ports.

By using PAgP, the device learns the identity of partners capable of supporting PAgP and the capabilities of each port. It then dynamically groups similarly configured ports (on a single device in the stack) into a single logical link (channel or aggregate port). Similarly configured ports are grouped based on hardware, administrative, and port parameter constraints. For example, PAgP groups the ports with the same speed, duplex mode, native VLAN, VLAN range, and trunking status and type. After grouping the links into an EtherChannel, PAgP adds the group to the spanning tree as a single device port.

Link Aggregation Control Protocol

The LACP is defined in IEEE 802.3ad and enables Cisco devices to manage Ethernet channels between devices that conform to the IEEE 802.3ad protocol. LACP facilitates the automatic creation of EtherChannels by exchanging LACP packets between Ethernet ports.

By using LACP, the switch learns the identity of partners capable of supporting LACP and the capabilities of each port. It then dynamically groups similarly configured ports into a single logical link (channel or aggregate port). Similarly configured ports are grouped based on hardware, administrative, and port parameter constraints. For example, LACP groups the ports with the same speed, duplex mode, native VLAN, VLAN range, and trunking status and type. After grouping the links into an EtherChannel, LACP adds the group to the spanning tree as a single device port.

Configuring Layer 2 EtherChannels

Configure Layer 2 EtherChannels by assigning ports to a channel group with the **channel-group** command in interface configuration mode. This command automatically creates the port-channel logical interface.

Use the **show etherchannel swport xxx** command to view the EtherChannels.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.

	Command or Action	Purpose
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**interface** [*interface-id*] **Example:** `Router(config)# interface gigabitethernet 0/1/0`	Specifies a physical port, and enters interface configuration mode. Valid interfaces are physical ports. For a PAgP EtherChannel, you can configure up to four ports of the same type and speed for the same group. For a LACP EtherChannel, you can configure up to 8 Ethernet ports of the same type. Up to eight ports can be active, and up to eight ports can be in standby mode.
Step 4	**switchport mode** {**access** | **trunk**} **Example:** `Router(config-if)# switchport mode access`	Assigns all ports as static-access ports in the same VLAN, or configure them as trunks. If you configure the port as a static-access port, assign it to only one VLAN. The range is 1 to 4094.
Step 5	**switchport access vlan** *vlan-id* **Example:** `Router(config-if)# switchport access vlan 22`	(Optional) If you configure the port as a static-access port, assign it to only one VLAN. The range is 1 to 4094.
Step 6	**channel-group channel-group-number mode {auto [non-silent] | desirable [non-silent] | on } | { active | passive}** **Example:** `Router(config-if)# channel-group 5 mode auto`	Assigns the port to a channel group, and specifies the PAgP or the LACP mode. For **mode** , select one of these keywords: • **auto —** Enables PAgP only if a PAgP device is detected. It places the port into a passive negotiating state, in which the port responds to PAgP packets it receives but does not start PAgP packet negotiation. • **desirable —** Unconditionally enables PAgP. It places the port into an active negotiating state, in which the port starts negotiations with other ports by sending PAgP packets. • **on —** Forces the port to channel without PAgP or LACP. In the **on** mode, an EtherChannel exists only when a port group in the **on** mode is connected to another port group in the **on** mode.

	Command or Action	Purpose
		• **non-silent —** (Optional) If your device is connected to a partner that is PAgP-capable, configures the device port for nonsilent operation when the port is in the **auto** or **desirable** mode. If you do not specify **non-silent** , silent is assumed. The silent setting is for connections to file servers or packet analyzers. This setting allows PAgP to operate, to attach the port to a channel group, and to use the port for transmission. • **active** —Enables LACP only if a LACP device is detected. It places the port into an active negotiating state in which the port starts negotiations with other ports by sending LACP packets. • **passive —** Enables LACP on the port and places it into a passive negotiating state in which the port responds to LACP packets that it receives, but does not start LACP packet negotiation.
Step 7	**end** **Example:** `Router(config)# end`	Returns to privileged EXEC mode.

Configuring EtherChannel Load-Balancing

You can configure EtherChannel load-balancing to use one of several different forwarding methods.

This task is optional.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 2	**port-channel swport load-balance { dst-ip | dst-mac | dst-mixed-ip-port | dst-port | extended [dst-ip | dst-mac | dst-port | ipv6-label | l3-proto | src-ip | src-mac | src-port] | src-dst-ip | src-dst-mac**	Configures an EtherChannel load-balancing method. Select one of these load-distribution methods: • **dst-ip** —Specifies destination-host IP address.

	Command or Action	Purpose
	src-dst-mixed-ip-port src-dst-portsrc-ip | src-mac | src-mixed-ip-port | src-port } **Example:** `Router(config)# port-channel swport load-balance src-mac`	• **dst-mac** —Specifies the destination-host MAC address of the incoming packet. • **dst-mixed-ip-port** —Specifies the host IP address and TCP/UDP port. • **dst-port** —Specifies the destination TCP/UDP port. • **extended** —Specifies extended load balance methods--combinations of source and destination methods beyond those available with the standard command. • **ipv6-label** —Specifies the IPv6 flow label. • **l3-proto** —Specifies the Layer 3 protocol. • **src-dst-ip** —Specifies the source and destination host IP address. • **src-dst-mac** —Specifies the source and destination host MAC address. • **src-dst-mixed-ip-port** —Specifies the source and destination host IP address and TCP/UDP port. • **src-dst-port** —Specifies the source and destination TCP/UDP port. • **src-ip** —Specifies the source host IP address. • **src-mac** —Specifies the source MAC address of the incoming packet. • **src-mixed-ip-port** —Specifies the source host IP address and TCP/UDP port. • **src-port** —Specifies the source TCP/UDP port.
Step 3	**end** **Example:** `Router(config)# end`	Returns to privileged EXEC mode.

Configuring the PAgP Learn Method and Priority

This task is optional.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**interface** [*interface-id*] **Example:** `Router(config)# interface gigabitethernet 0/1/0`	Specifies the port for transmission, and enters interface configuration mode.
Step 4	**pagp learn-method physical-port** **Example:** `Router(config-if)# pagp learn-method physical port`	Selects the PAgP learning method. By default, **aggregation-port learning** is selected, which means the device sends packets to the source by using any of the ports in the EtherChannel. With aggregate-port learning, it is not important on which physical port the packet arrives. Selects **physical-port** to connect with another device that **is** a physical learner. Make sure to configure the **port-channel load-balance** global configuration command to **src-mac** . The learning method must be configured the same at both ends of the link.
Step 5	**pagp port-priority priority** **Example:** `Router(config-if)# pagp port-priority 200`	Assigns a priority so that the selected port is chosen for packet transmission. For *priority*, the range is 0 to 255. The default is 128. The higher the priority, the more likely that the port will be used for PAgP transmission.
Step 6	**end** **Example:** `Router(config)# end`	Returns to privileged EXEC mode.

Configuring the LACP Port Channel Min-Links Feature

You can specify the minimum number of active ports that must be in the link-up state and bundled in an EtherChannel for the port channel interface to transition to the link-up state. Using EtherChannel min-links,

you can prevent low-bandwidth LACP EtherChannels from becoming active. Port channel min-links also cause LACP EtherChannels to become inactive if they have too few active member ports to supply the required minimum bandwidth.

To configure the minimum number of links that are required for a port channel. Perform the following tasks.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**interface port-channel** [*channel-number*] **Example:** `Router(config)# interface port-channel 2`	Enters interface configuration mode for a port-channel. For *channel-number*, the range is 1 to 63.
Step 4	**port-channel min-links** *min-links-number* **Example:** `Router(config-if)# port-channel min-links 3`	Specifies the minimum number of member ports that must be in the link-up state and bundled in the EtherChannel for the port channel interface to transition to the link-up state. For *min-links-number* , the range is 2 to 8.
Step 5	**end** **Example:** `Router(config)# end`	Returns to privileged EXEC mode.

Configuring LACP Fast Rate Timer

You can change the LACP timer rate to modify the duration of the LACP timeout. Use the **lacp rate** command to set the rate at which LACP control packets are received by an LACP-supported interface. You can change the timeout rate from the default rate (30 seconds) to the fast rate (1 second). This command is supported only on LACP-enabled interfaces.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.

	Command or Action	Purpose
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**interface** *type slot/port* **Example:** `Router(config)# interface gigabitEthernet 0/1/0`	Configures an interface and enters interface configuration mode.
Step 4	**lacp rate { normal | fast}** **Example:** `Router(config-if)# lacp rate fast`	Configures the rate at which LACP control packets are received by an LACP-supported interface. To reset the timeout rate to its default, use the **no lacp rate** command.
Step 5	**end** **Example:** `Router(config)# end`	Returns to privileged EXEC mode.
Step 6	**show lacp internal** **Example:** `Router# show lacp internal` `Router# show lacp counters`	Verifies your configuration.

Modular Quality of Service Command-Line Interface

The MQC (Modular Quality of Service (QoS) Command-Line Interface (CLI)) enables you to set packet classification and marking based on a QoS group value. ith the device, QoS features are enabled through the Modular QoS command-line interface (MQC). The MQC is a command-line interface (CLI) structure that allows you to create traffic policies and attach these policies to interfaces. A traffic policy contains a traffic class and one or more QoS features. A traffic class is used to classify traffic, while the QoS features in the traffic policy determine how to treat the classified traffic. One of the main goals of MQC is to provide a platform-independent interface for configuring QoS across Cisco platforms. For more infomraton on the Modular Quality of Service, see the Quality of Service Configuration Guide, Cisco IOS XE Fuji 16.9.x.

Note **QoS limitations on IR8340 platforms**

1. Quality of Service (QoS) is supported for traffic moving between switch ports.
2. For inter-vlan routing between switch ports, QoS limitations are:
   - It is supported only when a policy is applied on the Switch Virtual Interface (SVI).
   - Only marking and policing actions based on Differentiated Services Code Point (DSCP) match are supported on SVI.
   - Queuing and shaping actions are not supported on SVI.
3. For traffic moving from LAN to WAN port, QoS limitations are:
   - It is supported only when a policy is applied on SVI.
   - Only marking and policing actions based on Differentiated Services Code Point (DSCP) match are supported on SVI.
   - Queuing and shaping actions are not supported on SVI.

Creating a Traffic Class

To create a traffic class containing match criteria, use the **class-map** command to specify the traffic class name, and then use the following **match** commands in class-map configuration mode, as needed.

Before you begin

All match commands specified in this configuration task are considered optional, but you must configure at least one match criterion for a class.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 2	**class-map** *class-map name* {**match-any**} **Example:** `Router(config)# class-map type ngsw-qos test_1000` `Router(config-cmap)#`	Enters class map configuration mode. • Creates a class map to be used for matching packets to the class whose name you specify. • **match-any:** Any one of the match criteria must be met for traffic entering the traffic class to be classified as part of it.

	Command or Action	Purpose
Step 3	**match access-group** { *index number* | *name*} **Example:** `Router(config-cmap)# match access-group 100` `Router(config-cmap)#`	The following parameters are available for this command: • access-group • cos • dscp • group-object • ip • mpls • precedence • protocol • qos-group • vlan • wlan (Optional) For this example, enter the access-group ID: • Access list index (value from 1 to 2799) • Named access list
Step 4	**match cos** *cos value* **Example:** `Router(config-cmap)# match cos 2 3 4 5`	(Optional) Matches IEEE 802.1Q or ISL class of service (user) priority values. • Enters up to 4 CoS values separated by spaces (0 to 7).
Step 5	**match dscp** *dscp value* **Example:** `Router(config-cmap)# match dscp af11 af12`	(Optional) Matches the DSCP values in IPv4 and IPv6 packets.
Step 6	**match ip** { **dscp** *dscp value* | **precedence** *precedence value* } **Example:** `Router(config-cmap)# match ip dscp af11 af12`	(Optional) Matches IP values including the following: • **dscp**—Matches IP DSCP (DiffServ codepoints). • **precedence**—Matches IP precedence (0 to 7).
Step 7	**match qos-group** *qos group value* **Example:** `Router(config-cmap)# match qos-group 10`	(Optional) Matches QoS group value (from 0 to 31).

	Command or Action	Purpose
Step 8	**match vlan** *vlan value* **Example:** `Router(config-cmap)# match vlan 210`	(Optional) Matches a VLAN ID (from 1 to 4095).
Step 9	**end** **Example:** `Router(config)# end`	Saves the configuration changes.

What to do next

Configure the policy map.

Creating a Traffic Policy

To create a traffic policy, use the **policy-map** global configuration command to specify the traffic policy name.

The traffic class is associated with the traffic policy when the **class** command is used. The **class** command must be entered after you enter the policy map configuration mode. After entering the **class** command, the device is automatically in policy map class configuration mode, which is where the QoS policies for the traffic policy are defined.

The following policy map class-actions are supported:

- bandwidth—Bandwidth configuration options.
- exit—Exits from the QoS class action configuration mode.
- no—Negates or sets default values for the command.
- police—Policer configuration options.
- priority—Strict scheduling priority configuration options for this class.
- queue-buffers—Queue buffer configuration options.
- queue-limit—Queue maximum threshold for Weighted Tail Drop (WTD) configuration options.
- service-policy—Configures the QoS service policy.
- set—Sets QoS values using the following options:
  - CoS values
  - DSCP values
  - Precedence values
  - QoS group values
- shape—Traffic-shaping configuration options.

Before you begin

You should have first created a class map.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 2	**policy-map type** *policy-map name* **Example:** `Router(config)# policy-map type ngsw-qos test_1000`	Enters policy map configuration mode. Creates or modifies a policy map that can be attached to one or more interfaces to specify a service policy.
Step 3	**class** { *class-name* | **class-default**} **Example:** `Router(config-pmap)# class test_1000`	Specifies the name of the class whose policy you want to create or change. You can also create a system default class for unclassified packets.
Step 4	**bandwidth** { **kb/s** *kb/s value* | **percent** *percentage* | **remaining** {*percent* | *ratio*}} **Example:** `Router(config-pmap-c)# bandwidth 50`	(Optional) Sets the bandwidth using one of the following: • **kb/s**—Kilobits per second, enter a value between 20000 and 10000000 for Kb/s. • **percent**—Enter the percentage of the total bandwidth to be used for this policy map. • **remaining**—Enter the percentage ratio of the remaining bandwidth.
Step 5	**exit** **Example:** `Router(config-pmap-c)# exit`	(Optional) Exits from QoS class action configuration mode.
Step 6	**no** **Example:** `Router(config-pmap-c)# no`	(Optional) Negates the command.
Step 7	**police** { *target_bit_rate* | **cir** | **rate**} **Example:** `Router(config-pmap-c)# police 100000`	(Optional) Configures the policer: • *target_bit_rate*—Enter the bit rate per second, enter a value between 8000 and 10000000000. • **cir**—Committed Information Rate

	Command or Action	Purpose
		• **rate**—Specify police rate, PCR for hierarchical policies or SCR for single-level ATM 4.0 policer policies.
Step 8	**priority level** *level value* **Example:** `Router(config-pmap-c)# priority level 1`	(Optional) Sets the strict scheduling priority for this class. Command options include: • **level**—Establishes a multi-level priority queue. Enter a value (1 or 2).
Step 9	**queue-buffers ratio** *ratio limit* **Example:** `Router(config-pmap-c)# queue-buffers ratio 10`	(Optional) Configures the queue buffer for the class. Enter the queue buffers ratio limit (0 to 100).
Step 10	**queue-limit { packets | cos | dscp | percent}** **Example:** `Router(config-pmap-c)# queue-limit cos 7 percent 50`	(Optional) Specifies the queue maximum threshold for the tail drop: • *packets*—Packets by default, enter a value between 1 to 2000000. • **cos**—Enter the parameters for each COS value. • **dscp**—Enter the parameters for each DSCP value. • **percent**—Enter the percentage for the threshold.
Step 11	**service-policy** *policy-map name* **Example:** `Router(config-pmap-c)# service-policy test_2000`	(Optional) Configures the QoS service policy.
Step 12	**set { cos | dscp | ip | precedence | qos-group | wlan}** **Example:** `Router(config-pmap-c)# set cos 7`	(Optional) Sets the QoS values. Possible QoS configuration values include: • **cos**—Sets the IEEE 802.1Q/ISL class of service/user priority. • **dscp**—Sets DSCP in IP(v4) and IPv6 packets. • **ip**—Sets IP specific values. • **precedence**—Sets precedence in IP(v4) and IPv6 packet. • **qos-group**—Sets the QoS Group.

	Command or Action	Purpose
Step 13	**shape average** { *target _bit_rate* | **percent**} **Example:** `Router(config-pmap-c)# shape average percent 50`	(Optional) Sets the traffic shaping. Command parameters include: • *target_bit_rate*—Target bit rate. • **percent**—Percentage of interface bandwidth for Committed Information Rate.
Step 14	**end** **Example:** `Router(config)# end`	Saves the configuration changes.

What to do next

Configure the interface.

Configuring Class-Based Packet Marking

This is an important procedure that explains how to configure the following class-based packet marking features on your device:

- CoS value
- DSCP value
- IP value
- Precedence value
- QoS group value
- WLAN value

Before you begin

You should have created a class map and a policy map before beginning this procedure.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 2	**policy-map type** *policy-map name* **Example:**	Enters policy map configuration mode.

	Command or Action	Purpose
	`Router(config)# policy-map type ngsw-qos policy1` `Device(config-pmap)#`	Creates or modifies a policy map that can be attached to one or more interfaces to specify a service policy.
Step 3	**class** *class name* **Example:** `Router(config)# class class1` `Device(config-pmap)#`	Enters policy class map configuration mode. Specifies the name of the class whose policy you want to create or change. Command options for policy class map configuration mode include the following: • **bandwidth**—Bandwidth configuration options. • **exit**—Exits from the QoS class action configuration mode. • **no**—Negates or sets default values for the command. • **police**—Policer configuration options. • **priority**—Strict scheduling priority configuration options for this class. • **queue-buffers**—Queue buffer configuration options. • **queue-limit**—Queue maximum threshold for Weighted Tail Drop (WTD) configuration options. • **service-policy**—Configures the QoS service policy. • **set**—Sets QoS values using the following options: • CoS values • DSCP values • Precedence values • QoS group values • WLAN values • **shape**—Traffic-shaping configuration options. **Note** This procedure describes the available configurations using **set** command options. The other command options (**bandwidth**) are described in other sections of this guide.

	Command or Action	Purpose
		Although this task lists all of the possible **set** commands, only one **set** command is supported per class.
Step 4	**set cos** {*cos value* | **cos table** *table-map name* | **dscp table** *table-map name* | **precedence table** *table-map name* | **qos-group table** *table-map name* | **wlan user-priority table** *table-map name*} **Example:** `Router(config-pmap)# set cos 5`	(Optional) Sets the specific IEEE 802.1Q Layer 2 CoS value of an outgoing packet. Values are from 0 to7. You can also set the following values using the **set cos** command: • **cos table**—Sets the CoS value based on a table map. • **dscp table**—Sets the code point value based on a table map. • **precedence table**—Sets the code point value based on a table map. • **qos-group table**—Sets the CoS value from QoS group based on a table map. • **wlan user-priority table**—Sets the CoS value from the WLAN user priority based on a table map.
Step 5	**set dhcp** {*dhcp value* | **default** | **dscp table** *table-map name* | **ef** | **precedence table** *table-map name* | **qos-group table** *table-map name* | **wlan user-priority table** *table-map name*} **Example:** `Router(config-pmap)# set dscp af11`	(Optional) Sets the DSCP value. In addition to setting specific DSCP values, you can also set the following using the **set dscp** command: • **default**—Matches packets with default DSCP value (000000). • **dscp table**—Sets the packet DSCP value from DSCP based on a table map. • **ef**—Matches packets with EF DSCP value (101110). • **precedence table**—Sets the packet DSCP value from precedence based on a table map. • **qos-group table**—Sets the packet DSCP value from a QoS group based upon a table map. • **wlan user-priority table**—Sets the packet DSCP value based upon a WLAN user-priority based upon a table map.

	Command or Action	Purpose
Step 6	**set ip {dscp | precedence}** **Example:** `Router(config-pmap)# set ip dscp c3`	(Optional) Sets IP specific values. These values are either IP DSCP or IP precedence values. You can set the following values using the **set ip dscp** command: • *dscp value*—Sets a specific DSCP value. • **default**—Matches packets with default DSCP value (000000). • **dscp table**—Sets the packet DSCP value from DSCP based on a table map. • **ef**—Matches packets with EF DSCP value (101110). • **precedence table**—Sets the packet DSCP value from precedence based on a table map. • **qos-group table**—Sets the packet DSCP value from a QoS group based upon a table map. • **wlan user-priority table**—Sets the packet DSCP value based upon a WLAN user-priority based upon a table map. You can set the following values using the **set ip precedence** command: • *precedence value*—Sets the precedence value (from 0 to 7) . • **cos table**—Sets the packet precedence value from Layer 2 CoS based on a table map. • **dscp table**—Sets the packet precedence from DSCP value based on a table map. • **precedence table**—Sets the precedence value from precedence based on a table map • **qos-group table**—Sets the precedence value from a QoS group based upon a table map.
Step 7	**set precedence** {*precedence value* | **cos table** *table-map name* | **dscp table** *table-map name* | **precedence table** *table-map name* | **qos-group table** *table-map name*}	(Optional) Sets precedence values in IPv4 and IPv6 packets. You can set the following values using the **set precedence** command:

	Command or Action	Purpose
	Example: `Router(config-pmap)# set precedence 5`	• *precedence value*—Sets the precedence value (from 0 to 7) . • **cos table**—Sets the packet precedence value from Layer 2 CoS on a table map. • **dscp table**—Sets the packet precedence from DSCP value on a table map. • **precedence table**—Sets the precedence value from precedence based on a table map. • **qos-group table**—Sets the precedence value from a QoS group based upon a table map.
Step 8	**set qos-group** {*qos-group value* | **dscp table** *table-map name* | **precedence table** *table-map name*} **Example:** `Router(config-pmap)# set qos-group 10`	(Optional) Sets QoS group values. You can set the following values using this command: • *qos-group value*—A number from 1 to 31. • **dscp table**—Sets the code point value from DSCP based on a table map. • **precedence table**—Sets the code point value from precedence based on a table map.
Step 9	**set wlan user-priority table** {*wlan user-priority table value* | **cos table** *table-map name* | **dscp table** *table-map name* | **qos-group table** *table-map name* | **wlan table** *table-map name*} **Example:** `Router(config-pmap)# set wlan user-priority 1`	(Optional) Sets the WLAN user priority value. You can set the following values using this command: • *wlan user-priority value*—A value between 0 to 7. • **cos table**—Sets the WLAN user priority value from CoS based on a table map. • **dscp table**—Sets the WLAN user priority value from DSCP based on a table map. • **qos-group table**—Sets the WLAN user priority value from QoS group based on a table map. • **wlan table**—Sets the WLAN user priority value from the WLAN user priority based on a table map.
Step 10	**end** **Example:**	Saves the configuration changes.

	Command or Action	Purpose
	`Router(config)# end`	
Step 11	**show policy-map** **Example:** `Router(config)# show policy-map`	(Optional) Displays policy configuration information for all classes configured for all service policies.

What to do next

Attach the traffic policy to an interface using the **service-policy** command.

Attaching a Traffic Policy to an Interface

After the traffic class and traffic policy are created, you must use the **service-policy** interface configuration command to attach a traffic policy to an interface, and to specify the direction in which the policy should be applied (either on packets coming into the interface or packets leaving the interface).

Before you begin

A traffic class and traffic policy must be created before attaching a traffic policy to an interface.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 2	**interface** *type*	
Step 3	**service-policy** {**input** *policy-map* | **output** *policy-map*} **Example:** `Router(config-if)# service-policy output policy_map_01`	Attaches a policy map to an input or output interface. This policy map is then used as the service policy for that interface. In this example, the traffic policy evaluates all traffic leaving that interface.
Step 4	**end** **Example:** `Router(config)# end`	Saves the configuration changes.
Step 5	**show policy map** **Example:** `Router(config)# show policy map`	(Optional) Displays statistics for the policy on the specified interface.

Example

What to do next

Proceed to attach any other traffic policy to an interface, and to specify the direction in which the policy should be applied.

Classifying, Policing, and Marking Traffic on Physical Ports by Using Policy Maps

You can configure a nonhierarchical policy map on a physical port that specifies which traffic class to act on. Actions supported are remarking and policing.

Before you begin

You should have already decided upon the classification, policing, and marking of your network traffic by policy maps prior to beginning this procedure.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 2	**class-map** { *class-map name* | **match-any**} **Example:** `Device(config)# class-map ipclass1` `Device(config-cmap)# exit`	Enters class map configuration mode. • Creates a class map to be used for matching packets to the class whose name you specify. • If you specify **match-any**, one of the match criteria must be met for traffic entering the traffic class to be classified as part of the traffic class. This is the default.
Step 3	**match access-group** { *access list index* | *access list name* } **Example:** `Device(config-cmap)# match access-group 1000` `Device(config-cmap)# exit`	The following parameters are available for this command: • access-group • cos • dscp • group-object • ip


	Command or Action	Purpose
		• mpls • precedence • protocol • qos-group • vlan • wlan (Optional) For this example, enter the access-group ID: • Access list index (value from 1 to 2799) • Named access list
Step 4	**policy-map** *policy-map name* **Example:** `Router(config)# policy-map type ngsw-qos flowit` `Device(config-pmap)#`	Creates a policy map by entering the policy map name, and enters policy-map configuration mode. By default, no policy maps are defined.
Step 5	**class** {*class-map-name* | **class-default**} **Example:** `Device(config-pmap)# class ipclass1`	Defines a traffic classification, and enter policy-map class configuration mode. By default, no policy map class-maps are defined. If a traffic class has already been defined by using the **class-map** global configuration command, specify its name for class-map-name in this command. A **class-default** traffic class is predefined and can be added to any policy. It is always placed at the end of a policy map. With an implied **match any** included in the **class-default** class, all packets that have not already matched the other traffic classes will match **class-default**.
Step 6	**set { cos | dscp | ip | precedence | qos-group | wlan user-priority}** **Example:** `Device(config-pmap-c)# set dscp 45`	(Optional) Sets the QoS values. Possible QoS configuration values include: • **cos**—Sets the IEEE 802.1Q/ISL class of service/user priority. • **dscp**—Sets DSCP in IP(v4) and IPv6 packets. • **ip**—Sets IP specific values.

	Command or Action	Purpose
		• **precedence**—Sets precedence in IP(v4) and IPv6 packet. • **qos-group**—Sets QoS group. • **wlan user-priority**—Sets WLAN user priority. In this example, the **set dscp** command classifies the IP traffic by setting a new DSCP value in the packet.
Step 7	**police** { *target_bit_rate* | **cir** | **rate** } **Example:** `Device(config-pmap-c)# police 100000 conform-action transmit exceed-action drop`	(Optional) Configures the policer: • *target_bit_rate*—Specifies the bit rate per second, enter a value between 8000 and 10000000000. • **cir**—Committed Information Rate. • **rate**—Specifies the police rate PCR for hierarchical policies. In this example, the **police** command adds a policer to the class where any traffic beyond the 100000 set target bit rate is dropped.
Step 8	**exit** **Example:** `Router(config-pmap-c)# exit`	Returns to policy map configuration mode.
Step 9	**exit** **Example:** `Router(config-pmap)# exit`	Returns to global configuration mode.
Step 10	**interface** [*interface-id*] **Example:** `Router(config)# interface gigabitethernet 0/1/0`	Specifies the port to attach to the policy map, and enters interface configuration mode. Valid interfaces include physical ports.
Step 11	**service-policy input** [*policy-map-name*] **Example:** `Device(config-if)# service-policy input flowit`	Specifies the policy-map name, and applies it to an ingress port. Only one policy map per ingress port is supported.
Step 12	**end** **Example:** `Router(config-if)# end`	Returns to privileged EXEC mode.

	Command or Action	Purpose
Step 13	**show policy-map** [*policy-map-name* [**class** *class-map-name*]] **Example:** `Router(config)# show policy-map`	(Optional) Verifies your entries.
Step 14	**copy running-config startup-config** **Example:** `Router(config)# copy running-config startup-config`	(Optional) Saves your entries in the configuration file.

What to do next

If applicable to your QoS configuration, configure classification, policing, and marking of traffic on SVIs by using policy maps.



CHAPTER 9

Configuring Switchport Blocking

- About Switchport Blocking, on page 145
- Configuring Switchport Blocking, on page 145

About Switchport Blocking

By default, the router floods packets with unknown destination MAC addresses to all ports. To prevent the forwarding of such traffic, you can configure a port to block unknown multicast or unicast packets.

Occasionally, unknown multicast or unicast traffic is flooded to a switch port because a MAC address has timed out or has not been learned by the switch. Security issues could arise if unknown multicast and unicast traffic is forwarded to a switch port. You can enable switchport blocking to guarantee that no multicast or unicast traffic is flooded to the port. The interface can be a physical interface or an EtherChannel group. When you block multicast or unicast traffic for a port channel, it is blocked on all ports in the port channel group.

Configuring Switchport Blocking

Follow these steps to configure switchport blocking. Blocking of unicast or multicast traffic is not automatically enabled on a switch port.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 2	**interface** {*interface-id* | **port-channel** *number*} **Example:** `Router(config)# interface gigabitethernet 0/1/1`	Enters interface configuration mode.
Step 3	**switchport mode access** **Example:**	Configures the interface as an access port.

	Command or Action	Purpose
	`Router(config-if)# switchport mode access`	
Step 4	**switchport access vlan** *vlan-id* **Example:** `Router(config-if)# switchport access vlan 20`	Specifies the VLAN for which this access port will carry traffic.
Step 5	[**no**] **switchport block** {**multicast** | **unicast**} **Example:** `Router(config-if)# switchport block multicast` `Router(config-if)# switchport block unicast`	Prevents the flooding of unknown multicast or unicast packets on the specified interface. Use the no form of this command to resume normal forwarding on the port.
Step 6	**end** **Example:** `Router(config)# end`	Returns to privileged EXEC mode.
Step 7	(Optional) **show interface** {*interface-id* | **port-channel** *number*} **switchport** **Example:** `Router# show interface gigabitethernet 0/1/1 switchport`	(Optional) Displays the switchport blocking configuration.

Example

The following example shows how to block multicast and unicast flooding on GigabitEthernet interface 0/1/1 and how to verify the configuration:

```
Router# configure terminal
Router(config)# interface GigabitEthernet0/1/1
Router(config-if)# switchport access vlan 20
Router(config-if)# switchport mode access
Router(config-if)# switchport block multicast
Router(config-if)# switchport block unicast
Router(config-if)# exit
Router(config)# end
Router#
```


Following command shows the blocking state of unknown unicast and multicast on the interface:

```
Router#show interfaces gigabitEthernet 0/1/1 switchport
Name: Gi0/1/1
Switchport: Enabled
Administrative Mode: static access
Operational Mode: static access
Administrative Trunking Encapsulation: dot1q
Operational Trunking Encapsulation: native
Negotiation of Trunking: Off
Access Mode VLAN: 20 (VLAN0020)
Trunking Native Mode VLAN: 1 (default)
Administrative Native VLAN tagging: disabled
Voice VLAN: none
```

```
Administrative private-vlan host-association: none
Administrative private-vlan mapping: none
Administrative private-vlan trunk native VLAN: none
Administrative private-vlan trunk Native VLAN tagging: enabled
Administrative private-vlan trunk encapsulation: dot1q
Administrative private-vlan trunk normal VLANs: none
Administrative private-vlan trunk associations: none
Administrative private-vlan trunk mappings: none
Operational private-vlan: none
Trunking VLANs Enabled: ALL
Pruning VLANs Enabled: 2-1001
Capture Mode Disabled
Capture VLANs Allowed: ALL

Protected: false
Unknown unicast blocked: enabled
Unknown multicast blocked: enabled
Appliance trust: none
Router#
```

Configuring Switchport Blocking



CHAPTER 10

Configuring Storm Control

- Information About Storm Control, on page 149
- Configuring Storm Control, on page 150

Information About Storm Control

A traffic storm occurs when packets flood the LAN, creating excessive traffic and degrading network performance. The traffic broadcast and multicast suppression (or storm control) feature prevents LAN ports from being disrupted by a broadcast, multicast and unicast traffic storm on physical interfaces.

A broadcast storm occurs when huge amount of broadcast, multicast, or unknown unicast packets flood the LAN, creating excessive traffic and degrading network performance. Errors in the protocol-stack implementation or in the network configuration can also cause a storm. The mechanism to prevent and control such events is known as storm control or broadcast suppression.

Broadcast and Multicast Suppression monitors incoming traffic levels over a 1-second traffic storm control interval and, during the interval compares the traffic level with the traffic storm control level configured. The traffic storm control threshold level is a percentage of the total available bandwidth of the port. Each port has different storm control levels for broadcast, multicast, and unicast type of traffic.

Storm control uses rising and falling thresholds to block and then restore the forwarding of broadcast, unicast, or multicast packets.

- The rising threshold is the traffic limit after which, that particular traffic is blocked.
- The falling threshold is the traffic limit below which, that particular starts forwarding again, if it was already blocked.



Note If a particular type of ingress traffic (unicast, broadcast and multicast) is more than the rising threshold configured on it, the interface goes to blocked state for that particular traffic.

Storm control prevents traffic on a LAN from being disrupted by a broadcast, multicast, or unicast storm on a port. Storm control is applicable for physical interfaces and is used to restrict the unicast, broadcast and multicast ingress traffic on the Layer2 interfaces.

Storm control for unicast is a combination of known unicast and unknown unicast traffic. When storm control for unicast is configured, and it exceeds the configured value, the storm will hit each type of traffic through

the hardware policer. The following example describes how the unicast traffic is filtered, when the configured storm is 10%:

- Incoming traffic is unknown unicast 8% + known unicast 7%. Total of 15% storm is not filtered in hardware by the hardware policer.
- Incoming traffic is unknown unicast 11% + known unicast 7%. Total of 18% storm will hit unknown unicast traffic type, and the hardware policer will filter unknown traffic that exceeds 11%.
- Incoming traffic is unknown unicast 11% + known unicast 11%. Total of 22% storm will hit unknown unicast traffic and known unicast traffic, and the hardware policer will filter both unknown and unknown unicast traffic.

Configuring Storm Control


You can set the percentage of total available bandwidth that the controlled traffic can use.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**interface** *interface-id* **Example:** `Router(config)# interface gigabitethernet 0/1/1`	Enters interface configuration mode.
Step 4	**storm-control** {**broadcast** | **multicast** | **unicast** | **unknown-unicast**} **level** {*level* [*level-low*] | **bps** *bps* [*bps-low*] | **pps** *pps* [*pps-low*]} **Example:**	Configure broadcast, multicast, unicast or unknown-unicast control. By default, storm control is disabled. • For *level*, specify the rate limit for broadcast, multicast, or unicast traffic as a percentage of the bandwidth. The port suppresses traffic when the rising threshold is reached. For optional *level_low*, specify the low level of the rate limit, as a percentage of the bandwidth. When action SNMP trap is enabled, and the traffic rate exceeds the level then drops below the *level_low*, the port will send out an SNMP trap.

	Command or Action	Purpose
		Note The optional *level-low* will take affect only when storm control SNMP trap is enabled. The minimum acceptable level is 0.01, which means 0.01% of the bandwidth. If level 0 is configured, it will be converted to 0.01 internally. • For bps *bps*, specify the rising threshold level for broadcast, multicast, or unicast traffic in bits per second (up to one decimal place). The port blocks traffic when the rising threshold is reached. The range is 0.0 to 10000000000.0. (Optional) For *bps-low*, specify the falling threshold level in bits per second (up to one decimal place). It can be less than or equal to the rising threshold level. The port forwards traffic when traffic drops below this level. The range is 0.0 to 10000000000.0. • For pps *pps*, specify the rising threshold level for broadcast, multicast, or unicast traffic in packets per second (up to one decimal place). The port blocks traffic when the rising threshold is reached. The range is 0.0 to 10000000000.0. (Optional) For *pps-low* , specifies the falling threshold level in packets per second (up to one decimal place). It can be less than or equal to the rising threshold level. The port forwards traffic when traffic drops below this level. The range is **0.0 to** 10000000000.0. **Note** Do not configure both **storm-control unicast** and **storm-control unknown-unicast** commands on an interface. For BPS and PPS settings, you can use metric suffixes such as k, m, and, g for large number thresholds.
Step 5	**storm-control action** {**shutdown** | **trap**} **Example:**	If none of shutdown or SNMP trap is configured, by default the traffic will be

	Command or Action	Purpose
	`Router(config-if)# storm-control action trap`	suppressed when traffic exceeds the threshold specified by *level*. If *shutdown* is configured, the interface will enter err-disable when traffic exceeds the threshold specified by *level*. If *trap* is configured, the interface will send SNMP trap when traffic exceeds the threshold specified by level. And when traffic drops below the *level_low*, another SNMP trap will be sent out.
Step 6	**end** **Example:** `Router(config-if)# end`	Returns to privileged EXEC mode.
Step 7	**show storm-control** [*interface-id*] [**broadcast** | **multicast** | **unicast** | **unknown-unicast**]	Verify the storm control rate limit set on the interface for the specified traffic type.
Step 8	**exit** **Example:** `Router(config)# exit`	Returns the router to global configuration mode.



CHAPTER 11

Configuring MAC Address Notification

- MAC Address Notification, on page 153
- Configuring MAC Address Notification, on page 153

MAC Address Notification

This feature enables the user or administrator to keep track of the MAC addresses that are learned or removed on the Layer 2 switch while forwarding the Ethernet frames. This feature is required to keep a history of the MAC addresses that are learned and deleted from the router and generate notifications to the NMS periodically.

Whenever a new MAC address is learned or an old MAC address is removed, a SNMP notification is generated and sent to the NMS. A history table is also maintained for every hardware port, so that NMS can collect information by querying the MIB for the history table. This is done to make sure even when the notifications are not delivered to the NMS properly; the data is preserved on the router for the NMS to collect.

Note This feature will generate MAC notifications only for dynamic addresses. No notifications are generated for self, static, or multicast addresses.


Configuring MAC Address Notification

Follow these steps to configure MAC address notification:

Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 2	[**no**] **mac-address-table notification change mac-move** [**interval** *value*] | [**historysize** *value*] | **mac-move**	Enable MAC notification feature. It is disabled by default.

	Command or Action	Purpose
		• **interval** *value*—Sets the notification trap interval in seconds. The switch will dispatch the notification trap only after this value is elapsed. Default is 1 second. **historysize** *value*—Configures the maximum number of entries in the MAC notification history table. The old table will be deleted and a new table will be created when this command is issued. Default size is 1. **mac-move**—Enables MAC move notification.
Step 3	**interface** *interface-id* **Example:** `Router(config)# interface gigabitethernet 0/1/1`	Enters interface configuration mode, and specifies the Layer 2 interface on which to enable the SNMP MAC address notification trap.
Step 4	[**no**] **snmp trap mac-notification** {**added** | **removed**} **Example:** `Router(config-if)# snmp trap mac-notification change added`	After MAC notification is enabled globally, use this command to enable/disable MAC notification traps on a particular port. By default it is disabled. • **added**—Enables MAC notification trap when an address is added on this port. • **removed**—Enables MAC notification trap when an address is removed from this port.
Step 5	**end** **Example:** `Router(config)# end`	Returns to privileged EXEC mode.
Step 6	[**no**] **snmp-server enable traps mac-notification**	The actual notification traps will be sent only after this command is entered even if MAC notification is enabled globally and at the port. It is disabled by default.
Step 7	**show mac-address-table notification** [**interface** *interface-id*]	Verify if the feature is enabled or disabled, and display MAC notification interval and the history table.



CHAPTER 12

Configuring Q-in-Q and Layer 2 Protocol Tunneling

This chapter describes how to configure IEEE 802.1Q-in-Q VLAN tunnels and Layer 2 protocol tunneling on the Cisco IR8340 Routers.

- Information About Q-in-Q Tunnels, on page 155
- Information About Layer 2 Protocol Tunneling, on page 156
- Configuring VLAN Mapping for Selective Q-in-Q on a 802.1Q Tunnel Port, on page 156
- Enabling the Layer 2 Protocol Tunnel, on page 158
- Configuring Thresholds for Layer 2 Protocol Tunnel Ports, on page 159
- Verifying the Q-in-Q Configuration, on page 160
- VLAN Translation One-to-One Mapping, on page 160

Information About Q-in-Q Tunnels

A Q-in-Q VLAN tunnel enables a service provider to segregate the traffic of different customers in their infrastructure, while still giving the customer a full range of VLANs for their internal use by adding a second 802.1Q tag to an already tagged frame.

Business customers of service providers often have specific requirements for VLAN IDs and the number of VLANs to be supported. The VLAN ranges required by different customers in the same service-provider network might overlap, and the traffic of customers through the infrastructure might be mixed. Assigning a unique range of VLAN IDs to each customer would restrict customer configurations and could easily exceed the VLAN limit of 4096 of the 802.1Q specification.

Using the 802.1Q tunneling feature, service providers can use a single VLAN to support customers who have multiple VLANs. Customer VLAN IDs are preserved and the traffic from different customers is segregated within the service-provider infrastructure even when they appear to be on the same VLAN. The 802.1Q tunneling expands the VLAN space by using a VLAN-in-VLAN hierarchy and tagging the tagged packets. A port configured to support 802.1Q tunneling is called a tunnel port. When you configure tunneling, you assign a tunnel port to a VLAN that is dedicated to tunneling. Each customer requires a separate VLAN, but that VLAN supports all of the customer's VLANs.

Customer traffic that is tagged in the normal way with appropriate VLAN IDs come from an 802.1Q trunk port on the customer device and into a tunnel port on the service-provider edge switch. The link between the customer device and the edge switch is an asymmetric link because one end is configured as an 802.1Q trunk

port and the other end is configured as a tunnel port. You assign the tunnel port interface to an access VLAN ID that is unique to each customer.

Packets that enter the tunnel port on the service-provider edge switch, which are already 802.1Q-tagged with the appropriate VLAN IDs, are encapsulated with another layer of an 802.1Q tag that contains a VLAN ID that is unique to the customer. The original 802.1Q tag from the customer is preserved in the encapsulated packet. Therefore, packets that enter the service-provider infrastructure are double-tagged.

The outer tag contains the customer's access VLAN ID (as assigned by the service provider), and the inner VLAN ID is the VLAN of the incoming traffic (as assigned by the customer).

Information About Layer 2 Protocol Tunneling

Customers at different sites connected across a service-provider network need to run various Layer 2 protocols to scale their topology to include all remote sites, as well as the local sites. The Spanning Tree Protocol (STP) must run properly, and every VLAN should build a proper spanning tree that includes the local site and all remote sites across the service-provider infrastructure. The Cisco Discovery Protocol (CDP) must be able to discover neighboring Cisco devices from local and remote sites, and the VLAN Trunking Protocol (VTP) must provide consistent VLAN configuration throughout all sites in the customer network.

When protocol tunneling is enabled, edge switches on the inbound side of the service-provider infrastructure encapsulate Layer 2 protocol packets with a special MAC address and send them across the service-provider network. Core switches in the network do not process these packets, but forward them as normal packets. Bridge protocol data units (BPDUs) for CDP, STP, or VTP cross the service-provider infrastructure and are delivered to customer switches on the outbound side of the service-provider network. Identical packets are received by all customer ports on the same VLANs.

If protocol tunneling is not enabled on 802.1Q tunneling ports, remote switches at the receiving end of the service-provider network do not receive the BPDUs and cannot properly run STP, CDP, 802.1X, and VTP. When protocol tunneling is enabled, Layer 2 protocols within each customer's network are totally separate from those running within the service-provider network. Customer switches on different sites that send traffic through the service- provider network with 802.1Q tunneling achieve complete knowledge of the customer's VLAN.



Note Layer 2 protocol tunneling works by tunneling BPDUs in the software. A large number of BPDUs that come into the supervisor will cause the CPU load to go up. You might need to make use of software rate limiters to reduce the load on the supervisor CPU. See Configuring Thresholds for Layer 2 Protocol Tunnel Ports, on page 159.

Configuring VLAN Mapping for Selective Q-in-Q on a 802.1Q Tunnel Port

To configure VLAN mapping for selective Q-in-Q on a 802.1Q tunnel port, complete the following steps.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	[**no**] **vlan dot1q tag native** **Example:** `Router(config)# vlan dot1q tag native`	Enable or disable native VLAN tagging on trunk port.
Step 4	**interface** *interface-id* **Example:** `Router(config)# interface gigabitethernet 0/1/1`	Enters interface configuration mode for the interface connected to the service provider network.
Step 5	[**no**] **switchport mode dot1q-tunnel** **Example:** `Router(config-if)# switchport mode dot1q-tunnel`	Configure the interface as an IEEE 802.1Q tunnel port.
Step 6	[**no**] **switchport access vlan** *vlan id* **Example:** `Router(config-if)# switchport access vlan 20`	Configure default VLAN used as S-VLAN on dot1q-tunnel ports.
Step 7	[**no**] **switchport vlan mapping default dot1q-tunnel** *outer vlan-id*	Configure VLAN mapping so that all packets entering the port are bundled into the specified S-VLAN: • *outer vlan-id*—Enter the outer VLAN ID (S-VLAN) of the service provider network. The range is from 1 to 4094.
Step 8	[**no**] **switchport vlan mapping** *vlan-id* **dot1q-tunnel** *outer vlan-id*	Enters the VLAN IDs to be mapped: • *vlan-id*—The customer VLAN ID (C-VLAN) entering the switch from the customer network. The range is from 1 to 4094. You can enter a string of VLAN-IDs.

	Command or Action	Purpose
		• *outer vlan-id*—Enter the outer VLAN ID (S-VLAN) of the service provider network. The range is from 1 to 4094.
Step 9	**exit** **Example:** `Router(config-if)# exit`	Exits the configuration mode.

Example

What to do next

Use the **no switchport vlan mapping all** command to remove the VLAN mapping configuration.

Enabling the Layer 2 Protocol Tunnel

You can enable protocol tunneling on the 802.1Q tunnel port.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**interface** *interface-id* **Example:** `Router(config)# interface gigabitethernet 0/1/1`	Enters interface configuration mode.
Step 4	[**no**] **l2protocol-tunnel** [**cdp** | **vtp** | **stp**] **Example:** `Router(config-if)# l2protocol-tunnel stp` `Router(config-if)# no l2protocol-tunnel cdp`	Enable or disable Layer 2 protocol tunneling. Optionally, you can enable CDP, STP, or VTP tunneling.
Step 5	**exit** **Example:**	Exits the configuration mode.

	Command or Action	Purpose
	`Router(config-if)# exit`	

Configuring Thresholds for Layer 2 Protocol Tunnel Ports

You can specify the port drop and shutdown value for a Layer 2 protocol tunneling port.

When a drop threshold is enabled on a tunneling interface, the interface will drop any incoming PDU after the specified threshold for that protocol is reached. Similarly, when a shutdown threshold is enabled, the interface will be error-disabled when the threshold is exceeded. That effectively stops the interface from forwarding any packet. To enable the interface again, a user has to do 'shut' and 'no shut' to the interface. The unit of measure of both the thresholds is the number of packets per second. The valid range for configuration is between 1 to 4096. Both shutdown threshold and drop threshold can be enabled on a same interface for a same protocol. But shutdown threshold must be larger than drop threshold there.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**interface** *interface-id* **Example:** `Router(config)# interface gigabitethernet 0/1/1`	Enters interface configuration mode.
Step 4	[**no**] **l2protocol-tunnel** {**drop-threshold** | **shutdown-threshold**} [**cdp** | **vtp** | **stp**] *packets-per-sec* **Example:** `Router(config-if)# l2protocol-tunnel shutdown-threshold stp 2000` `Router(config-if)# l2protocol-tunnel drop-threshold stp 2500` `Command rejected: protocol tunneling shutdown threshold must be greater than or equal to the drop threshold.` `Router(config-if)# l2protocol-tunnel drop-threshold stp 1500`	**drop-threshold**—Specifies the maximum number of packets that can be processed on an interface before being dropped. **shutdown-threshold**—Specifies the maximum number of packets that can be processed on an interface. When the number of packets is exceeded, the port is put in error-disabled state. Optionally, you can specify CDP, STP, or VTP. Valid values for the packets are from 1 to 4096. Use the **no** form of the command to resets the threshold values to 0 and disable the shutdown threshold.

	Command or Action	Purpose
Step 5	**exit** **Example:** `Router(config-if)# exit`	Exits the configuration mode.

Verifying the Q-in-Q Configuration

Command	Purpose
show dot1q-tunnel	Display all ports in dot1q-tunnel mode.
show vlan mapping [*interface-id*]	Display the VLAN mapping information for all interfaces or for the interface specified.

VLAN Translation One-to-One Mapping

VLAN translation provides the capability of carrying the customers traffic in single tagged packets across the service provider network. Since VLAN translation and selective QinQ are applied to a trunk port, the service provider gets the added benefit of being able to selectively drop or bundle all traffic that does not belong to a given set of C-VLANs and bridge accordingly in the trunk.

VLAN translation on trunk ports supports 1:1 C-VLAN to S-VLAN mapping. C-VLAN received on customer side trunk port is stripped and mapped S-VLAN is added.


The SP provides L2VPN service to two different customers, Customer A and Customer B. The SP needs to keep the data as well as control traffic between the two customers separate from each other and also from the SP`s own control traffic. The SP network also needs to be transparent to the customer edge devices. Several mechanisms are available to keep the customer's VLAN ID space intact across the SP network.

IEEE802.1Q (Port-based QinQ) is one such mechanism wherein all the packets received on a *tunnel* port are tunneled through the SP network with the same outer tag. While such a mechanism is sufficient, it is rather restrictive and inflexible because it allows the SPs only port level granularity in providing the services.

The mechanisms described in the following sections and summarized in the following table give the SPs the ability to provide a more flexible and finer granular level of service. In all the following cases, the mappings of C-VLANs to S-VLANs at the ingress of the SP network and the correct mapping back from S-VLANs to C-VLANS at the egress of SP network relies on the proper configuration of the mappings and reverse mappings.

```
interface GigabitEthernet0/1/2
 switchport mode trunk
 switchport vlan mapping 10 100
 switchport vlan mapping 5 150

interface GigabitEthernet0/1/2
 switchport mode trunk
 switchport vlan mapping 10 dot1q-tunnel 100
 switchport vlan mapping 2-8 dot1q-tunnel 150
 switchport vlan mapping default dot1q-tunnel 300
```



CHAPTER 13

Power over Ethernet

- Power over Ethernet, on page 161
- Device Detection and Power Allocation, on page 162
- Configuring Power Over Ethernet, on page 162
- **Configuring Universal PoE**, on page 163
- PoE Debug Commands, on page 164

Power over Ethernet

Power over Ethernet (PoE) is typically used to power up devices such as Access points, IP Cameras and IP Phones connected to the device's Ethernet ports.

The Cisco IR8340 routers support standard Power over Ethernet (PoE), Power over Ethernet Plus (PoE+), Cisco Enhanced Power over Ethernet (EPoE), and Cisco Universal Power over Ethernet (UPoE) on all copper ports. The total PoE available power is 120 W to be shared by the four LAN ports.

The following features are supported:

- UPoE—Supported on LAN port 1 and 2 with a maximum of 60 watts of power on each port
- PoE+—Supported on all PoE ports (LAN port 1-4) with a maximum of 30 watts of power on each port
- PoE—Supported on all PoE ports (LAN port 1-4) with a maximum of 15 watts of power on each port
- Support both Cisco PD and IEEE802.3af/IEEE802.3 on all ports, with DC power disconnected.
- Per port power consumption measurement.
- Ability to specify max power consumption on every port.
- PoE power policing—Comprises the following two modes, which determines the action to take on the interface after a port shuts down because of an inline-power policing violation:
  - **Logging**—An error message is logged to the console and the interface restarts; the device powers up.
  - **Errdisable** (default)—In addition to logging an error message to the console, the interface is placed in an errdisable state so that the device attached to the port does not receive inline-power until you restart the port or configure an errdisable autorecovery mechanism.
- Static power allocation on ports.

- Load Shedding upon PSU removal or failure.

Device Detection and Power Allocation

The router will detect a Cisco Pre-standard or an IEEE-compliant PD when the PoE is enabled and the connected device is not being powered by an AC adapter.

After device detection, the router will determine the power requirements based on power classification class. Depending on the available power in the power budget, the router determines if a port can be powered. The router initially allocates this power when it detects and powers the device. Power negotiation using CDP/LLDP protocols happens thereafter. Supported protocols for power negotiation are CDP for Cisco PD, and LLDP for non-Cisco PDs. Maximum power budget for 1 WAN port at any time is 15.4 W. On reload the PoE ports are powered down until the unit reboots.

Configuring Power Over Ethernet

Each copper port on the router can auto detect one of following connected devices, and supply power to them properly:

- An IEEE 802.3af and IEEE 802.3at compliant power device
- Cisco EPOE and UPOE power device

To configure power over ethernet, use these commands:

Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 2	**interface** *interface-id* **Example:** `Router(config)# interface gigabitethernet0/1/0`	Specifies the physical port to be configured, and enters interface configuration mode.
Step 3	**power inline** [**auto**| **max** *max-wattage*] **never** **Example:** `Router(config-if)# power inline auto`	Configures the PoE mode on the port. The keywords have these meanings: • Auto—Enables powered-device detection. If enough power is available, automatically allocates power to the PoE port after device detection. This is the default setting. • Max max-wattage—Limits the power allowed on the port. The range for PoE+ ports is 4000 to 30000 mW. The range for

	Command or Action	Purpose
		Cisco UPOE ports is 4000 to 60000 mW. If no value is specified, the maximum is allowed. • Never—Disables device detection, and disable power to the port. **Note** If a port has a Cisco powered device connected to it, do not use the **power inline never** command to configure the port. A false link-up can occur, placing the port into the error-disabled state.
Step 4	**end** **Example:** `router(config-if)# end`	Returns to privileged EXEC mode.

What to do next

Use the following commands to check the PoE port status:

```
Router#show power inline
Available:120.0(w)  Used:70.0(w)  Remaining:50.0(w)
Interface Admin  Oper       Power   Device              Class Max
                            (Watts)
--------- ------ ---------- ------- ------------------- ----- ----
Gi0/1/0   auto   on         30.0    Ieee PD             4     60.0
Gi0/1/1   auto   on         30.0    Ieee PD             4     60.0
Gi0/1/2   auto   on         3.7     IP Phone 7811       1     30.0
Gi0/1/3   auto   on         6.3     IP Phone 7962       2     30.0
--------- ------ ---------- ---------- ---------- ------ -----
Totals:          4    on    70.0

Router#show power inline gigabitEthernet 0/1/0
Interface Admin  Oper       Power   Device              Class Max
                            (Watts)
--------- ------ ---------- ------- ------------------- ----- ----
Gi0/1/0   auto   on         60.0    IR8340-K9           4     60.0
Router#
```

Configuring Universal PoE

Cisco UPOE can provide a maximum of 60Watts power over both signal and spare pairs of RJ45 cable. UPOE capable switch port can enable spare pair and supply power to it through CDP or LLDP negotiations with UPOE power device automatically.

If end-point power device is capable to consume power on both signal and spare pairs but without corresponding CDP/LLDP negotiation mechanism available, following configurations can be used to manually force four-pair on specific port.


Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 2	**interface** *interface-id* **Example:** `Router(config)# interface gigabitethernet0/1/0`	Specifies the physical port to be configured, and enters interface configuration mode.
Step 3	**power inline four-pair forced** **Example:** `Router(config-if)# power inline four-pair forced`	Forces power enabling on both signal and spare pairs from a switch port.
Step 4	**end** **Example:** `router(config-if)# end`	Returns to privileged EXEC mode.

PoE Debug Commands

The following table shows the PoE debug commands:

Command	Description
debug ilpower controller	Display PoE controller debug messages.
debug ilpower event	Display PoE event debug messages.
debug ilpower port	Display PoE port management debug messages.
debug ilpower powerman	Display PoE power management debug messages.
debug ilpower cdp	Display PoE CDP debug messages.
debug ilpower registries	Display PoE registries debug messages.
debug ilpower scp	Display PoE scp debug messages.



CHAPTER 14

Configuring the T1/E1 Network Interface Module

The Cisco T1/E1 Network Interface Modules (NIM) are inserted into the NIM slot on the router to provide T1, fractional T1, E1, and fractional E1 support for data applications.

- Information About T1/E1 Network Interface Module, on page 165
- Configuring T1/E1 Network Interface Module, on page 165

Information About T1/E1 Network Interface Module

The IR8340 router has two Network Interface Module (NIM) slots, 0/2 and 0/3. The T1/E1 Network Interface Module IRM-NIM-2T1E1 can be installed in these two slots. It is a 2-port channelized data module and supports 24/31 channel groups for T1/E1 per port. Each T1/E1 module has two ports, P0 and P1. Each port is linked to a controller in configuration as below:

- If the module is in slot 0/2, it has two controllers 0/2/0 and 0/2/1.
- If the Module is in slot 0/3, it has two controllers 0/3/0 and 0/3/1.

Use RJ-48 cables to connect the T1/E1 modules between two devices.

Configuring T1/E1 Network Interface Module

Configuring the Card Type

The T1/E1 network interface module will not be operational until a card type is configured.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.

	Command or Action	Purpose
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**card type** {**t1**|**e1**} *slot subslot* **Example:** `Router(config)# card type t1 0 2`	Specifies card type as T1 or E1 for the network interface module. In this example, the T1/E1 module is connected on 0/2 slot.

Changing the Card Type

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**no card type** {**t1**|**e1**} *slot subslot* **Example:** `Router(config)# no card type t1 0 2`	(Optional) Removes the previous configuration.
Step 4	**card type** {**t1**|**e1**} *slot subslot* **Example:** `Router(config)# card type e1 0 2`	Specifies T1 or E1 connectivity for the network interface module.
Step 5	**exit** **Example:** `Router(config)# exit`	Exits the card configuration mode and returns to global configuration mode.
Step 6	**write** **Example:** `Router(config)# write`	Rebuilds the router configuration.
Step 7	**reload** **Example:** `Router(config)# reload`	Reloads router so that changes can take effect. After this command executes, the router goes into the ROM monitor (rommon) mode.

	Command or Action	Purpose
Step 8	**boot** **Example:** `Router(rommon)# boot`	Boots the router with the configuration for the newly selected card type.

Configuring the T1/E1 Network Interface Module for Data Support

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**controller** {**t1**|**e1**} *slot/subslot/port* **Example:** `Router(config)# controller t1 0/2/0`	Enters controller configuration mode for the network interface module. • Valid values for slot is 0, subslot is 2 or 3, and port is 0 or 1.
Step 4	Do one of the following: **framing** {**sf**|**esf**} or **framing** {**crc4**|**no-crc4**} **Example:** `Router(config-controller)# framing esf` `Router(config-controller)# framing crc4`	In T1 configurations, specifies super frame (**sf**) or extended super frame (**esf**) as the frame type for data lines. Default is **esf** . In E1 configurations, specifies cyclic redundancy check 4 (**crc4**) or **no-crc4** as the frame type for data lines. Default is **crc4** .
Step 5	Do one of the following: **linecode** {**ami**|**b8zs**} or **linecode** {**ami**|**hdb3**} **Example:** `Router(config-controller)# linecode b8zs`	In T1 configurations, specifies alternate mark inversion (AMI) or bipolar 8-zero substitution (b8zs) as the linecode. Default is **b8zs**. **Note** When using linecode AMI, we recommend that you select 56 kbps as the speed or make sure that the channel groups created do not contain all the timeslots. See step 11. This is to avoid exceeding the “15 zeroes” threshold specified by standards.
Step 6	**fdl** {**att**|**ansi**|**both**} **Example:** `Router(config-controller)# fdl both`	T1 only. Sets the facility data link (fdl) exchange standard for T1 interfaces using esf framing. You can select the ATT standard

	Command or Action	Purpose
		(ATT TR54016), the ANSI standard (ANSI T1.403), or both standards. Default is **ansi** . To disable fdl, enter the **no fdl** command.
Step 7	**clock source** {**internal** | **line** [**primary** | **secondary**] | **network**} **Example:** `Router(config-controller)# clock source network`	Specifies the clock source. The options are as follows: • internal—Sets the controller framer as the clock master. The **clock source i nternal** command is only applicable with the **channel-group** command and the **pri-group** (for data) command. **Note** The **pri-group** command is supported on the NIM-xCE1T1-PRI for data without the keyword **voice-dsp** . • line—Specifies the phase-locked loop (PLL) on a port. When both a primary port and a secondary port are configured and the primary port fails, the PLL switches over to the secondary. When the PLL on the primary port becomes active again, the PLL automatically switches to the primary port. • network—Sets the controller to sync to the TDMSW clock for both TDM voice and data support. This configures the far end of the T1/E1 line as the clock line. Default is line.
Step 8	**line-termination** {**75-ohm**|**120-ohm**} **Example:** `Router(config-controller)# line-termination 75-ohm`	E1 only. Sets the line termination on an E1 controller. • **75-ohm** specifies 75-ohm unbalanced termination. • **120-ohm** specifies 120-ohm balanced termination.
Step 9	**loopback** {**diagnostic** | **local** {**payload** | **line** } | **remote** {**iboc** | **esf** {**payload** | **line** }}} **Example:** `Router(config-controller)# loopback remote esf line`	Sets the loopback method for testing the interface. Options are: • **diagnostic** —Loops the transmit signal back to receive.


	Command or Action	Purpose
		• **local** —Puts the interface into local loopback mode at the **payload** or **line** level. • **remote** —Puts the interface into remote loopback mode through an inband bit oriented code (iboc) or, for T1 only, **remote esf** , which uses fdl codes to set **payload** or **line** levels.
Step 10	Do one of the following: **cablelength long** *db-loss-value* or **cablelength short** *length* **Example:** `Router(config-controller)# cablelength short 110`	T1 only.The **cablelength long** command attenuates the pulse from the transmitter using pulse equalization and line build-out. This command applies to cables longer than 660 feet. Loss values are: • 0db • -7.5db • -15db • -22.5db Default attenuation is 0db. The **cablelength short** command sets transmission attenuation for cable lengths of 660 feet or less. When you use the **cablelength short** command, specify the length as follows: • **110** for cable lengths from 0 to 110 feet • **220** for cable lengths from 111 to 220 feet • **330** for cable lengths from 221 to 330 feet • **440** for cable lengths from 331 to 440 feet • **550** for cable lengths from 441 to 550 feet • **660** for cable lengths from 551 to 660 feet There is no default cable length.
Step 11	**channel group** *channel-group-number* {**timeslots** *range* [**speed** *kbps*] | **unframed**} **Example:** `Router(config-controller)# channel group 1 timeslots 1-4`	Configures the serial WAN on a T1 or E1 interface by specifying channels and their timeslots. For T1, values are as follows: • channel-group-number is from 0 to 23. • **timeslots** range is from 1 to 24.

	Command or Action	Purpose
		• Default value of **speed** for T1 is 64 kbps. Configuration of **speed** is optional. For E1, values are as follows: • channel-group-number is from 0 to 30. • **timeslots** range is from 1 to 31. • Default value of **speed** for E1 is 64 kbps. Configuration of **speed** is optional. • **unframed** (E1 only) specifies that all 31 timeslots are to be used for data and that none are to be used for framing signals.
Step 12	**national reserve** *N sa4 sa5 sa6 sa7 sa8* **Example:** `Router(config-controller)# national reserve 0 1 1 1 1 0`	E1 only. Sets the six required national bits in E1 in the G.751 frame. Default is 1 1 1 1 1 1.
Step 13	**crc-threshold** *value* **Example:** `Router(config-controller)# crc-threshold 500`	T1 only. Defines a severely errored second by specifying the number of CRC errors that must occur in one second to reach the severely errored second state. Default is 320.
Step 14	**yellow** {**generation**|**detection**} **Example:** `Router(config-controller)# no yellow detection`	Enables generation and detection of yellow alarms. Default condition is that **generation** and **detection** of yellow alarms are enabled. Use the **no** form of the command to disable yellow alarm detection.
Step 15	**bert pattern** *pattern* **interval** *time* **Example:** `Router(config-controller)# bert pattern 2^11 interval 1440`	(Optional) Activates the BERT with the chosen test pattern for a specified duration. Configure BERT patterns on the T1/E1 network interface modules as follows: • When the linecode is AMI, use patterns 2^11, 2^15, or 2^20-QRSS. • When the linecode is b8zs or hdb3, use patterns 2^11, 2^15, 2^20-QRSS, or 2^20-O.153. • The **interval** time is from 1 to 14,400 minutes.

Example of T1/E1 Network Interface Module Configuration

The following example shows the configuration of the router with the T1/E1 NIM installed and configured for data.

```
card type t1 0 2
controller T1 0/2/0
framing esf
linecode b8zs
cablelength long 0db
channel-group 0 timeslots 1
channel-group 1 timeslots 2
channel-group 2 timeslots 3
interface Serial0/2/0:0
 ip address 1.1.1.1 255.255.255.0
!
interface Serial0/2/0:1
 ip address 2.2.2.1 255.255.255.0
!
interface Serial0/2/0:2
 ip address 3.3.3.1 255.255.255.0
```



CHAPTER 15

Configuring the Serial Network Interface Module

- About the Asynchronous/Synchronous Serial Network Interface Module, on page 173
- Configuring the Serial Interface to Sync or Async Mode, on page 173
- Configuring Synchronous Serial Ports, on page 174
- Configuring Asynchronous Serial Ports, on page 181

About the Asynchronous/Synchronous Serial Network Interface Module

The 8-port Asynchronous/Synchronous Network Interface Module (NIM) IRM-NIM-RS232 provides asynchronous/synchronous serial connections supporting EIA-RS232 for the Cisco IR8340 Router.

The IR8340 router has two NIM slots, 0/2 and 0/3. The serial NIMs can be installed in these two slots.

Each RS-232 Serial Module has 8 serial interfaces. The interface numers are:

- serial 0/2/0 - serial 0/2/7—If the serial module is in slot 0/2.
- serial 0/3/0 - serial 0/3/7—If the serial module is in slot 0/3.

The following features are supported:

- Supports DCE and DTE.
- Each serial port can be configured as either Asynchronous or Synchronous mode.
- A maximum speed of 256 kbps is supported for RS232 Synchronous port.
- A maximum speed of 230.4 kbps is supported for Asynchronous port.

Configuring the Serial Interface to Sync or Async Mode

By using the Physical Layer mode option, you can configure the serial interface to Synchronous or Asynchronous mode as needed. By default it will be in Synchronous mode. Use the following commands to configure the serial interface:

interface serial *slot/subslot/port*

physical-layer {**async**|**sync**}

```
Router(config)#interface Serial0/3/0
Router(config-if)#physical-layer ?
  async  Configure asynchronous physical layer on serial interface
  sync   Configure synchronous physical layer on serial interface

Router(config-if)#
```

Configuring Synchronous Serial Ports

After the serial port mode is configured as synchronous mode, connect the DCE type serial cable to one side and DTE cable on the other side. The serial link will come up.

Checking DCE and DTE Cable Type

After the serial port mode is configured as Sync, connect the DCE type serial cable to one side and DTE cable on the other side. The serial link will come up. Use the following command to check cable type:

```
Router1#show controllers Serial 0/3/0

Serial0/3/0 - (IRM-NIM-RS232) is administratively down
 Encapsulation : HDLC
 Cable type: RS-232 DCE
 mtu 1500, max_buffer_size 1524, max_pak_size 1656 enc 132
 loopback: Off,  crc: 16, invert_data: Off
 nrzi: Off, idle char: Flag
 dce_terminal_timing_enable: Off ignore_dtr: Off
 tx_clockrate: 64000bps, rx_clockrate: 64000bps, serial_clock_index: 0
 serial_restartdelay:60000,  serial_restartdelay_def:60000

     RTS up, CTS down, DTR up, DCD down, DSR down

Router1#

Router2#show controllers Serial 0/3/1

Serial0/3/1 - (IRM-NIM-RS232) is administratively down
 Encapsulation : HDLC
 Cable type: RS-232 DTE
 mtu 1500, max_buffer_size 1524, max_pak_size 1656 enc 132
 loopback: Off,  crc: 16, invert_data: Off
 nrzi: Off, idle char: Flag
 tx_invert_clk: Off, ignore_dcd: Off
 tx_clockrate: 31998bps, rx_clockrate: 31998bps, rx_clock_threshold: 0
 serial_restartdelay:60000,  serial_restartdelay_def:60000

     RTS down, CTS down, DTR down, DCD down, DSR down

Router2#
```

The **show interfaces serial0/3/0 controller** command can also be used to check the cable type.

Specifying Synchronous Serial Encapsulation

The synchronous serial interfaces support the following serial encapsulation methods:

- Frame-Relay

- PPP (chap and pap)
- HDLC (default)

Use the following command to configure synchronous serial encapsulation. To remove the configuration, use the no form of the command.

[no] encapsulation {frame-relay|ppp|hdlc}

DCE and DTE Configuration for HDLC Encapsulation

The following examples show the basic DCE and DTE configuration for HDLC encapsulation.

```
U1 configuration (DCE Side)
======================
U1#show running-config interface Serial0/3/1
Building configuration...
Current configuration : 99 bytes
!
interface Serial0/3/1
ip address 31.31.31.1 255.255.255.0
no keepalive
clock rate 256000
end

U1#show interfaces Serial0/3/1
Serial0/3/1 is up, line protocol is up
Hardware is IRM-NIM-RS232
Internet address is 31.31.31.1/24
MTU 1500 bytes, BW 256 Kbit/sec, DLY 20000 usec,
reliability 255/255, txload 1/255, rxload 2/255
Encapsulation HDLC, loopback not set
Keepalive not set
Last input 00:00:31, output 00:00:09, output hang never

U1#ping 31.31.31.2
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 31.31.31.2, timeout is 2 seconds:
!!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 8/8/8 ms

U2 configuration (DTE Side)
======================
U2#show running-config interface Serial0/3/1
Building configuration...
Current configuration : 80 bytes
!
interface Serial0/3/1
ip address 31.31.31.2 255.255.255.0
no keepalive
end

U2#show interfaces Serial0/3/1
Serial0/3/1 is up, line protocol is up
Hardware is IRM-NIM-RS232
Internet address is 31.31.31.2/24
MTU 1500 bytes, BW 2000 Kbit/sec, DLY 20000 usec,
reliability 255/255, txload 1/255, rxload 1/255
Encapsulation HDLC, loopback not set
Keepalive not set
Last input 00:00:33, output 00:00:10, output hang never

U2#ping 31.31.31.1
```

```
*Jan 26 15:29:49.206 IST: %LINK-3-UPDOWN: Interface Serial0/3/6, changed state to down
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 31.31.31.1, timeout is 2 seconds:
!!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 7/8/9 ms
```

DCE and DTE Configuration for PPP (CHAP) Encapsulation

The following examples show the basic DCE and DTE configuration for PPP (CHAP) encapsulation.

```
U1 configuration (DCE side)
================================
U1#show running-config interface Serial0/3/2
Building configuration...
Current configuration : 118 bytes
!
interface Serial0/3/2
ip address 32.32.32.1 255.255.255.0
encapsulation ppp
no keepalive
clock rate 256000
end
U1#show interfaces Serial0/3/2
Serial0/3/2 is up, line protocol is up
Hardware is IRM-NIM-RS232
Internet address is 32.32.32.1/24
MTU 1500 bytes, BW 256 Kbit/sec, DLY 20000 usec,
reliability 255/255, txload 1/255, rxload 1/255
Encapsulation PPP, LCP Open
Open: IPCP, CDPCP, loopback not set
Keepalive not set
Last input 00:00:13, output 00:00:13, output hang never

===configuration for ppp-chap authentication=======
U1(config)#username u1 secret userpassword
U1#show running-config interface Serial0/3/1
Building configuration...
Current configuration : 143 bytes
!
interface Serial0/3/1
ip address 31.31.31.2 255.255.255.0
encapsulation ppp
no keepalive
ppp authentication chap
clock rate 256000
end

U1#ping 32.32.32.2
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 32.32.32.2, timeout is 2 seconds:
!!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 8/8/8 ms

U2 configuration (DTE Side)
=====================
U2#show running-config interface Serial0/3/2
Building configuration...
Current configuration : 99 bytes
!
interface Serial0/3/2
ip address 32.32.32.2 255.255.255.0
encapsulation ppp
no keepalive
end
```

```
U2#show interfaces Serial0/3/2
Serial0/3/2 is up, line protocol is up
Hardware is IRM-NIM-RS232
Internet address is 32.32.32.2/24
MTU 1500 bytes, BW 2000 Kbit/sec, DLY 20000 usec,
reliability 255/255, txload 1/255, rxload 1/255
Encapsulation PPP, LCP Open
Open: IPCP, CDPCP, loopback not set
Keepalive not set
Last input 00:00:08, output 00:00:15, output hang never

===configuration for ppp-chap authentication=======
U2(config)#username U1 secret userpassword
U2#show running-config interface Serial0/3/1
Building configuration...
Current configuration : 124 bytes
!
interface Serial0/3/1
ip address 31.31.31.2 255.255.255.0
encapsulation ppp
no keepalive
ppp authentication chap
end

U2#ping 32.32.32.1
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 32.32.32.1, timeout is 2 seconds:
!!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 8/8/9 ms
```

DCE and DTE Configuration for PPP (PAP) Encapsulation

The following examples show the basic DCE and DTE configuration for PPP (PAP) encapsulation.

```
U1 configuration (DCE side)
================================
U1#show running-config interface Serial0/3/2
Building configuration...
Current configuration : 118 bytes
!
interface Serial0/3/2
ip address 32.32.32.1 255.255.255.0
encapsulation ppp
no keepalive
clock rate 256000
end
U1#show interfaces Serial0/3/2
Serial0/3/2 is up, line protocol is up
Hardware is IRM-NIM-RS232
Internet address is 32.32.32.1/24
MTU 1500 bytes, BW 256 Kbit/sec, DLY 20000 usec,
reliability 255/255, txload 1/255, rxload 1/255
Encapsulation PPP, LCP Open
Open: IPCP, CDPCP, loopback not set
Keepalive not set
Last input 00:00:13, output 00:00:13, output hang never

===configuration for ppp-pap authentication=======
U1(config)#username u1 secret userpassword
U1#show running-config interface Serial0/3/1
Building configuration...
Current configuration : 181 bytes
!
```

```
interface Serial0/3/1
ip address 31.31.31.1 255.255.255.0
encapsulation ppp
ppp authentication pap
ppp pap sent-username Sumatra-1 password 0 userpassword
clock rate 256000
end
U1#

U1#ping 32.32.32.2
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 32.32.32.2, timeout is 2 seconds:
!!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 8/8/8 ms

U2 configuration (DTE Side)
======================
U2#show running-config interface Serial0/3/2
Building configuration...
Current configuration : 99 bytes
!
interface Serial0/3/2
ip address 32.32.32.2 255.255.255.0
encapsulation ppp
no keepalive
end

U2#show interfaces Serial0/3/2
Serial0/3/2 is up, line protocol is up
Hardware is IRM-NIM-RS232
Internet address is 32.32.32.2/24
MTU 1500 bytes, BW 2000 Kbit/sec, DLY 20000 usec,
reliability 255/255, txload 1/255, rxload 1/255
Encapsulation PPP, LCP Open
Open: IPCP, CDPCP, loopback not set
Keepalive not set
Last input 00:00:08, output 00:00:15, output hang never

===configuration for ppp-pap authentication=======
U2(config)#username U1 secret userpassword
U2#show running-config interface Serial0/3/1
Building configuration...
Current configuration : 176 bytes
!
interface Serial0/3/1
ip address 31.31.31.2 255.255.255.0
encapsulation ppp
no keepalive
ppp authentication pap
ppp pap sent-username Sumatra-2 password 0 userpassword
end
U2

U2#ping 32.32.32.1
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 32.32.32.1, timeout is 2 seconds:
!!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 8/8/9 ms
```

DCE and DTE Configuration for Frame Relay Encapsulation

The following examples show the basic DCE and DTE configuration for Frame Relay encapsulation.

```
U1 configuration (DCE side)
================================
U1#show running-config interface Serial0/3/3
Building configuration...
Current configuration : 158 bytes
!
interface Serial0/3/3
ip address 33.33.33.1 255.255.255.0
encapsulation frame-relay
no keepalive
clock rate 256000
frame-relay interface-dlci 100
end
U1#show interfaces Serial0/3/3
Serial0/3/3 is up, line protocol is up
Hardware is IRM-NIM-RS232
Internet address is 33.33.33.1/24
MTU 1500 bytes, BW 256 Kbit/sec, DLY 20000 usec,
reliability 255/255, txload 1/255, rxload 1/255
Encapsulation FRAME-RELAY, loopback not set
Keepalive not set
FR SVC disabled, LAPF state down
Broadcast queue 0/64, broadcasts sent/dropped 1/0, interface broadcasts 0
Last input 00:00:16, output 00:00:16, output hang never

U1#ping 33.33.33.2
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 33.33.33.2, timeout is 2 seconds:
!!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 8/8/9 ms

U2 configuration (DTE Side)
======================
U2#show running-config interface Serial0/3/3
Building configuration...
Current configuration : 139 bytes
!
interface Serial0/3/3
ip address 33.33.33.2 255.255.255.0
encapsulation frame-relay
no keepalive
frame-relay interface-dlci 100
end
U2#show interfaces Serial0/3/3
Serial0/3/3 is up, line protocol is up
Hardware is IRM-NIM-RS232
Internet address is 33.33.33.2/24
MTU 1500 bytes, BW 2000 Kbit/sec, DLY 20000 usec,
reliability 255/255, txload 1/255, rxload 1/255
Encapsulation FRAME-RELAY, loopback not set
Keepalive not set
FR SVC disabled, LAPF state down
Broadcast queue 0/64, broadcasts sent/dropped 1/0, interface broadcasts 0
Last input 00:05:05, output 00:05:05, output hang never

U2#ping 33.33.33.1
Type escape sequence to abort.
Sending 5, 100-byte ICMP Echos to 33.33.33.1, timeout is 2 seconds:
!!!!!
Success rate is 100 percent (5/5), round-trip min/avg/max = 8/8/8 ms
```

Serial Synchronous Show and Debug Commands

This section provides show and debug commands of the serial synchronous interfaces.

1. Connect to the NIM console using Telnet or Secure Shell (SSH) and open a session to the device using the **hw-module session** *slot/subslot* command in privileged EXEC mode.

   To exit the session, press **Ctrl-a** and **Ctrl-q** from your keyboard.

2. **show platform hardware subslot** *slot-number* **module device ge-stats**
3. **show platform hardware subslot** *slot-number* **module host-if status**
4. **show platform hardware subslot** *slot-number* **module host-if statistics**
5. **show platform hardware subslot** *slot-number* **module device ?**
   - help: the current information
   - scc-info: module serial information
   - scc-stats: module serial stats
   - scc-stats-p<x>: module serial port stats
   - ge-info: module ge information
   - ge-stats: module ge stats
   - fpga: module fpga information
   - fpga-p<x>: module fpga port information
   - fc-p<x>: module port flow control information
   - mempool: module mempool information
6. **debug hw-module subslot** *slot-number* **?**
   - commands: Control plane configuration and commands
   - errors: Error handling and race conditions
   - events: Control plane event notifications
   - ha: SPA Specific HA
   - interrupts: Interrupt handling
   - obfl: SPA Specific OBFL (on-board failure logging)
   - oir: SPA OIR information
   - periodic: Periodic processing (for example, plugin_one_sec)
7. **show monitor event-trace spa all**
8. Use **show diag subslot** *slot-number* **eeprom detail** to check NIM eeprom contents

Configuring Asynchronous Serial Ports

Configure the serial interface to Asynchronous mode by using these commands:

```
Router(config)#interface Serial0/3/0
Router(config-if)#physical-layer async
```

Specifying Asynchronous Serial Encapsulation

The asynchronous serial interfaces support the following serial encapsulation methods:

- Block Serial tunneling (BSTUN)
- Raw socket TCP (Raw-TCP)
- Raw socket UDP (Raw-UDP)
- SCADA

Use the following command to configure asynchronous serial encapsulation. To remove the configuration, use the no form of the command.

[no] encapsulation {**bstun**|**raw-tcp**|**raw-udp**|**scada**}


Example

```
Router(config)#interface Serial0/3/0
Router(config-if)#physical-layer async
Router(config-if)#encapsulation raw-tcp
Router(config-if)#end
Router#show running-config interface Serial0/3/0
Building configuration...

Current configuration : 89 bytes
!
interface Serial0/3/0
 physical-layer async
 no ip address
 encapsulation raw-tcp
end

Router#
```

Encapsulation methods are set according to the type of protocol or application you configure in the Cisco IOS software.



CHAPTER 16

Cellular Pluggable Interface Modules

The Cisco 4G LTE-Advanced Configuration chapter has been replaced by a new standalone guide called Cellular Pluggable Interface Module Configuration Guide. This guide contains updated information on all aspects of using the Cisco Cellular PIM.

Important The Pluggable Module is not hot swappable. The router must be reloaded after a new module is installed.

• Galileo Support on the LTE Pluggable Modules, on page 183

Galileo Support on the LTE Pluggable Modules

GPS was the only GNSS constellation supported in earlier releases. The Cisco IOS XE 17.11.1a release introduces support for Galileo constellation.

Note You can enable only one constellation at a time.

Configuration Commands

```
config# controller cellular <slot/port>
(config-controller)# <no> lte gps constellation <gps | galileo | gnss >
```

Example:

```
(config-controller)#lte gps constellation ?
  galileo  select Galileo as active constellation
  gps      select GPS as active constellation
  gnss      select multiple GNSS as active constellation
```

Note The default setting is GPS mode.

The galileo and gnss options in this CLI configure Galileo and simultaneous GNSS modes, such as GPS and Galileo.

If you disable the GPS configuration, make sure that no constellation is configured. This maintains consistency with GPS mode configuration. For example:

```
config# controller Cellular 0/4/0
(config-controller)# no lte gps constellation gps
```


Show Commands

This example shows the current GNSS constellation as Galileo:

```
config# show cellular 0/4/0 gps detail
GPS Feature =  enabled
GPS Mode Configured =  standalone
Current Constellation Configured =  galileo
GPS Port Selected =  Dedicated GPS port
GPS Status =  GPS acquiring
```

Any changes made to the configuration will require the router to be rebooted.

More information is available in the Cellular Pluggable Interface Module Configuration Guide.



CHAPTER 17

Information About SCADA

- SCADA Overview, on page 185
- Role of the IR8340, on page 185
- Key Terms, on page 186
- Protocol Translation Application, on page 186
- Prerequisites, on page 187
- Guidelines and Limitations, on page 188
- Default Settings, on page 188
- Configuring Protocol Translation, on page 188
- Configuring the T101 Protocol Stack, on page 190
- Configuring the T104 Protocol Stack, on page 192
- Configuration Example, on page 195
- Configuring the DNP3 Protocol Stacks, on page 197
- Starting and Stopping the Protocol Translation Engine, on page 201
- Verifying Configuration, on page 202
- Debug Commands, on page 203

SCADA Overview

SCADA refers to a control and management system employed in industries such as water management, electric power, and manufacturing. A SCADA system collects data from various types of equipment within the system and forwards that information back to a Control Center for analysis. Generally, individuals located at the Control Center monitor the activity on the SCADA system and intervene when necessary.

The Remote Terminal Unit (RTU) acts as the primary control system within a SCADA system. RTUs are configured to control specific functions within the SCADA system, which can be modified as necessary through a user interface.

Change the serial interface mode as async and then configure the interface.

Role of the IR8340

In the network, the Control Center always serves as the master in the network when communicating with the IR8340. The IR8340 serves as a proxy master station for the Control Center when it communicates with the RTU.

The IR8340 provides protocol translation to serve as a SCADA gateway to do the following:

- Receive data from RTUs and relay configuration commands from the Control Center to RTUs.
- Receive configuration commands from the Control Center and relay RTU data to the Control Center.
- Terminate incoming requests from the Control Center, when an RTU is offline.

The IR8340 performs Protocol Translation for the following protocols:

- IEC 60870 T101 to/from IEC 60870 T104
- DNP3 serial to DNP3 IP

Key Terms

The following terms are relevant when you configure the T101 and T104 protocol stacks on the IR8340:

- Channel—A channel is configured on each IR8340 serial port interface to provide a connection to a single RTU for each IP connection to a remote Control Center. Each connection transports a single T101 (RTU) or T104 (Control Center) protocol stack.
- Link Address—Refers to the device or station address.
- Link Mode (Balanced and Unbalanced)—Refers to the modes of data transfer.
  - An Unbalanced setting refers to a data transfer initiated from the master.
  - A Balanced setting can refer to either a master or slave initiated data transfer.
- Sector—Refers to a single RTU within a remote site.
- Sessions—Represents a single connection to a remote site.

The following terms are relevant when you configure the DNP3 protocol stacks on the on the IR8340:

- Channel—A channel is configured on the IR8340 serial port interface to provide a connection to a single RTU for each IP connection to a remote Control Center. Each connection transports a single DNP3 serial (RTU) or DNP3 IP (Control Center) protocol stack.
- Link Address—Refers to the device or station address.
- Sessions—Represents a single connection to a remote site.


Protocol Translation Application

In the following figure, IR8340 (installed within a secondary substation of the Utility Network) employs Protocol Translation to provide secure, end-to-end connectivity between Control Centers and RTUs within a SCADA System.

The IR8340 connects to the RTU (slave) through a RS232 connection. To protect the traffic when forwarded over public infrastructures (for example, cellular), the IR8340 forwards SCADA data from the RTU to the Control Center in the SCADA system through an IPSec tunnel (FlexVPN site-to-site or hub and spoke). The IPSec tunnel protects all traffic between the IR8340 and the Head-end aggregation router. SCADA traffic can

be inspected through an IPS device positioned in the path of the SCADA traffic before it is forwarded to the proper Control Center.

Figure 2: Routers Within a SCADA System



Prerequisites

RTUs must be configured and operating in the network.

For each RTU that connects to the IR8340, you will need the following information for T101/T104:

- Channel information
  - Channel name
  - Connection type: serial
  - Link transmission procedure setting: unbalanced or balanced
  - Address field of the link (number expressed in octets)
- Session information
  - Session name
  - Size of common address of Application Service Data Unit (ASDU) (number expressed in octets)
  - Cause of transmission (COT) size (number expressed in octets)
  - Information object address (IOA) size (number expressed in octets)
- Sector information
  - Sector name

- ASDU address, (number expressed in octets)

For each RTU that connects to the IR8340, you will need the following information for DNP3:

- Channel information
  - Channel name
  - Connection type: serial
  - Link address
- Session information
  - Session name

Guidelines and Limitations

- Each channel supports only one session.
- Each sessions supports only one sector.
- The object types 8, 17, 18, 19, 20, 38, 39, and 40 are not supported for IEC protocol translation.

Default Settings

DNP3 Parameters	Default
Unsolicited Response (DNP3-serial)	Not Enabled
Send Unsolicited Message (DNP3-IP)	Enabled

Configuring Protocol Translation

Before making any configuration changes to a IR8340 operating with Protocol Translation, please review the section on Starting and Stopping the Protocol Translation Engine, on page 201.

Enabling the IR8340 Serial Port and SCADA Encapsulation

Before you can enable and configure Protocol Translation on the IR8340, you must first enable the serial port on the IR8340 and enable SCADA encapsulation on that port.

Before you begin

Determine availability of serial port on the IR8340.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal**	Enters the global configuration mode.
Step 2	**interface serial** *slot/port/interface*	Enters the interface command mode for the serial slot/port/interface. *slot* –value of 0 *port* –value of 2 or 3 *interface* –value of 0
Step 3	**physical-layer async**	Configure the serial interface to Asynchronous mode.
Step 4	**no shutdown**	Brings up the port, administratively.
Step 5	**encapsulation scada**	Enables encapsulation on the serial port for protocol translation and other SCADA protocols.

EXAMPLE

This example shows how to enable serial port 0/2/0 and how to enable encapsulation on that interface to support SCADA protocols.

```
router# configure terminal
router(config)# interface serial 0/2/0
router(config-if)# physical-layer async
router(config-if)# no shutdown
router(config-if)# encapsulation scada
```

Configuring T101 and T104 Protocol Stacks

You can configure T101 and T104 protocol stacks, which allow end-to-end communication between Control Centers (T104) and RTUs (T101) within a SCADA system.

- Configuring the T101 Protocol Stack, on page 190
- Configuring the T104 Protocol Stack, on page 192
- Starting and Stopping the Protocol Translation Engine, on page 201

Prerequisites

Ensure that you have gathered all the required configuration information.

Enable the serial port and SCADA encapsulation.

Configuring the T101 Protocol Stack

Configure the channel, session, and sector parameters for the T101 protocol stack.

Before you begin

Ensure that you have gathered all the required configuration information. (See Prerequisites, on page 187.)

Enable the serial port and SCADA encapsulation. (See Enabling the IR8340 Serial Port and SCADA Encapsulation, on page 188.)

Procedure

	Command or Action	Purpose
Step 1	**configure terminal**	Enters global configuration mode.
Step 2	**scada-gw protocol t101**	Enters the configuration mode for the T101 protocol.
Step 3	**channel** *channel_name*	Enters the channel configuration mode for the T101 protocol. *channel_name* –Identifies the channel on which the serial port of the IR8340 communicates to the RTU. **Note** When the entered channel name does not already exist, the router creates a new channel. Entering the **no** form of this command deletes an existing channel. However, all sessions must be deleted before you can delete a channel.
Step 4	**link-mode** {**balanced** | **unbalanced**}	Configures the link-mode as either balanced or unbalanced. unbalanced–Refers to a data transfer initiated from the master. balanced–Refers to either a master or slave data transfer.
Step 5	**link-addr-size** {**none** | **one** | **two**}	Defines the link address size in octets.
Step 6	**bind-to-interface serial** *slot/port/interface*	Defines the IR8340 serial interface on which the system sends its T101 protocol traffic. *slot* –Value of 0 *port* –Value of 2 *interface* –Value of 0

	Command or Action	Purpose
Step 7	**exit**	Ends configuration of the channel and exits the channel configuration mode. Saves all settings.
Step 8	**session** *session_name*	Enters the session configuration mode and assigns a name to the session.
Step 9	**attach-to-channel** *channel_name*	Attaches the session to the channel. Enter the same channel name that you entered in Step 3 . *channel_name* –Identifies the channel.
Step 10	**common-addr-size** {**one** | **two** | **three**}	Defines the common address size in octets.
Step 11	**cot size** {**one** | **two** | **three**}	Defines the cause of transmission such as spontaneous or cyclic data schemes in octets.
Step 12	**info-obj-addr-size** {**one** | **two** | **three**}	Defines the information object element address size in octets.
Step 13	**link-addr-size** {**one** | **two** | **three**}	Defines the link address size in octets.
Step 14	**link-addr** *link_address*	Refers to the link address of the RTU. **Note** The link address entered here must match the value set on the RTU to which the serial port connects. *link_address* –Range of 0-65535.
Step 15	**exit**	Exits the session configuration mode.
Step 16	**sector** *sector_name*	Enters the sector configuration mode and assigns a name to the sector for the RTU. *sector_name* –Identifies the sector.
Step 17	**attach-to-session** *session_name*	Attaches the RTU sector to the session. Enter the same session name that you entered in Step 9 . *session_name*- Identifies the session.
Step 18	**asdu-addr** *asdu_address*	Refers to the ASDU structure address of the RTU.
Step 19	**exit**	Exits the sector configuration mode.
Step 20	**exit**	Exits the protocol configuration mode.

EXAMPLE

This example shows how to configure the parameters for the T101 protocol stack.

```
router# configure terminal
router(config)# scada-gw protocol t101
router(config-t101)# channel rtu_channel

router(config-t101-channel)# link-mode unbalanced
router(config-t101-channel)# link-addr-size one
router(config-t101-channel)# bind-to-interface serial 0/2/0
router(config-t101-channel)# exit
router(config-t101)# session rtu_session
router(config-t101-session)# attach-to-channel rtu_channel
router(config-t101-session)# common-addr-size two
router(config-t101-session)# cot-size one
router(config-t101-session)# info-obj-addr-size two
router(config-t101-session)# link-addr 3
router(config-t101-session)# exit
router(config-t101)# sector rtu_sector
router(config-t101-sector)# attach-to-session rtu_session
router(config-t101-sector)# asdu-addr 3
router(config-t101-sector)# exit
router(config-t101)# exit
router(config)#
```

Configuring the T104 Protocol Stack

Follow the steps below for each Control Center that you want to connect to over a T104 protocol.

Before you begin

Ensure that you have gathered all the required configuration information. (See Prerequisites, on page 187.)

Enable the serial port and SCADA encapsulation. (See Enabling the IR8340 Serial Port and SCADA Encapsulation, on page 188.)

Procedure

	Command or Action	Purpose
Step 1	**configure terminal**	Enters configuration mode.
Step 2	**scada-gw protocol t104**	Enters the configuration mode for the T104 protocol.
Step 3	**channel** *channel_name*	Enters the channel configuration mode for the T104 protocol. *channel_name* –Identifies the channel on which the router communicates with the Control Center. **Note** When the entered channel name does not already exist, the router creates a new channel.

	Command or Action	Purpose
		Entering the **no** form of this command deletes an existing channel. However, all sessions must be deleted before you can delete a channel.
Step 4	**k-value** *value*	Sets the maximum number of outstanding Application Protocol Data Units (APDUs) for the channel. **Note** An APDU incorporates the ASDU and a control header. *value* –Range of values from 1 to 32767. Default value is 12 APDUs.
Step 5	**w-value** *value*	Sets the maximum number of APDUs for the channel. *value* –Range of values from 1 to 32767. Default value is 8 APDUs.
Step 6	**t0-timeout** *value*	Defines the t0-timeout value for connection establishment of the T104 channel.
Step 7	**t1-timeout** *value*	Defines the t1-timeout value for send or test APDUs on the T104 channel.
Step 8	**t2-timeout** *value*	Defines the t2-timeout value for acknowledgements when the router receives no data message. **Note** The t2 value must always be set to a lower value than the t1 value on the T104 channel.
Step 9	**t3-timeout** *value*	Defines the t3-timeout value for sending s-frames in case of a long idle state on the T104 channel. **Note** The t3 value must always be set to a higher value than the t1 value on the T104 channel.
Step 10	**tcp-connection {0|1} local-port** {*port_number* | **default} remote-ip** {*A.B.C.D* | *A.B.C.D/LEN* | **any} [vrf** *WORD***]**	In a configuration where there are redundant Control Centers, sets the connection value for the secondary Control Center as defined on the primary Control Center. *port-number* –value between 2000 and 65535. default–value of 2404. *A.B.C.D* –single host. *A.B.C.D/nn* –subnet A.B.C.D/LEN.

	Command or Action	Purpose
		any–any remote hosts 0.0.0.0/0. WORD–VRF name.
Step 11	**exit**	Exits the channel configuration mode.
Step 12	**session** *session_name*	Enters the session configuration mode and assigns a name to the session. *session_name* –Use the same name that you assigned to the channel in Step 3.
Step 13	**attach-to-channel** *channel_name*	Defines the name of the channel that transports the session traffic.
Step 14	**exit**	Exits the session configuration mode.
Step 15	**sector** *sector_name*	Enters the sector configuration mode and assigns a name to the sector for the Control Center.
Step 16	**attach-to-session** *session_name*	Attaches the Control Center sector to the channel. *session_name* –Use the same name that you assigned to the channel in Step 3.
Step 17	**asdu-addr** *asdu_address*	Refers to the ASDU structure address. Value entered here must match the ASDU value on the RTU. *asdu_address* –*asdu_address* –Value of 1 or 2.
Step 18	**map-to-sector** *sector_name*	Maps the Control Center (T104) sector to the RTU (T101) sector.
Step 19	Return to Step 1.	Repeat all steps in this section for each Control Center active in the network.

EXAMPLE

This example shows how to configure the parameters for the T104 protocol stack on *Control Center 1* and *Control Center 2*, both of which are configured as *masters* , and how to map the T104 sector to the T101 sector.

To configure Control Center 1 (*cc_master1*), enter the following commands.

```
router# configure terminal
router(config)# scada-gw protocol t104
router(config-t104)# channel cc_master1
router(config-t104-channel)# k-value 12
router(config-t104-channel)# w-value 8
router(config-t104-channel)# t0-timeout 30
```

```
router(config-t104-channel)# t1-timeout 15
router(config-t104-channel)# t2-timeout 10
router(config-t104-channel)# t3-timeout 30
router(config-t104-channel)# tcp-connection 0 local-port 2050 remote-ip 209.165.200.225
router(config-t104-channel)# tcp-connection 1 local-port 2051 remote-ip 209.165.201.25
router(config-t104-channel)# exit
router(config-t104)# session cc_master1
router(config-t104-session)# attach-to-channel cc_master1

router(config-t104-session)# exit
router(config-t104)# sector cc_master1-sector
router(config-t104-sector)# attach-to-session cc_master1
router(config-t104-sector)# asdu-adr 3
router(config-t104-sector)# map-to-sector rtu_sector
router(config-t104)# exit
router(config)#
```

To configure Control Center 2 (*cc_master2*), enter the following commands.

```
router(config)# scada-gw protocol t104
router(config-t104)# channel cc_master2
router(config-t104-channel)# k-value 12
router(config-t104-channel)# w-value 8
router(config-t104-channel)# t0-timeout 30
router(config-t104-channel)# t1-timeout 15
router(config-t104-channel)# t2-timeout 10
router(config-t104-channel)# t3-timeout 30
router(config-t104-channel)# tcp-connection 0 local-port 2060 remote-ip 209.165.201.237
router(config-t104-channel)# tcp-connection 1 local-port 2061 remote-ip 209.165.200.27
router(config-t104-channel)# exit
router(config-t104)# session
 cc_master2
router(config-t104-session)# attach-to-channel cc_master2

router(config-t104-session)# exit
router(config-t104)# sector cc_master2-sector
router(config-t104-sector)# attach-to-session cc_master2
router(config-t104-sector)# asdu-adr 3
router(config-t104-sector)# map-to-sector rtu_sector
router(config-t104-sector)# exit
router(config-t104)# exit
router(config)#
```

Configuration Example

The following example shows how to configure the serial port interface for T101 connection, configure T101 and T104 protocol stacks, and starts the Protocol Translation Engine on the IR8340.

```
router# configure terminal
router(config)# interface serial 0/2/0
router (config-if)# no shutdown
router (config-if)# encapsulation scada
router (config-if)# exit
router(config)# scada-gw protocol t101
router(config-t101)# channel rtu_channel

router(config-t101-channel)# link-mode unbalanced
router(config-t101-channel)# link-addr-size one
router(config-t101-channel)# bind-to-interface serial 0/2/0
```

```
router(config-t101-channel)# exit
router(config-t101)# session rtu_session
router(config-t101-session)# attach-to-channel rtu_channel
router(config-t101-session)# common-addr-size two
router(config-t101-session)# cot-size one
router(config-t101-session)# info-obj-addr-size two
router(config-t101-session)# link-addr 3
router(config-t101-session)# exit
router(config-t101)# sector rtu_sector
router(config-t101-sector)# attach-to-session rtu_session
router(config-t101-sector)# asdu-addr 3
router(config-t101-sector)# exit
router(config-t101)# exit
router(config)# scada-gw protocol t104
router(config-t104)# channel cc_master1
router(config-t104-channel)# k-value 12
router(config-t104-channel)# w-value 8
router(config-t104-channel)# t0-timeout 30
router(config-t104-channel)# t1-timeout 15
router(config-t104-channel)# t2-timeout 10
router(config-t104-channel)# t3-timeout 30
router(config-t104-channel)# tcp-connection 0 local-port 2050 remote-ip any
router(config-t104-channel)# tcp-connection 1 local-port 2051 remote-ip any
router(config-t104-channel)# exit
router(config-t104)# session cc_master1
router(config-t104-session)# attach-to-channel cc_master1

router(config-t104-session)# exit
router(config-t104)# sector cc_master1-sector
router(config-t104-sector)# attach-to-session cc_master1
router(config-t104-sector)# asdu-adr 3
router(config-t104-sector)# map-to-sector rtu_sector
router(config-t104)# exit

router(config-t104)# session cc_master2
router(config-t104-session)# attach-to-channel cc_master2

router(config-t104-session)# exit
router(config-t104)# sector cc_master2-sector
router(config-t104-sector)# attach-to-session cc_master2
router(config-t104-sector)# asdu-adr 3
router(config-t104-sector)# map-to-sector rtu_sector
router(config-t104-sector)# exit
router(config-t104)# exit
router(config)# scada-gw enable
```

This example configures end-to-end communication between Control Centers and RTUs within a SCADA system using the DNP3 protocol stacks and starts the Protocol Translation Engine on the IR8340:

```
router# configure terminal
router(config)# interface serial 0/2/0
router (config-if)# no shutdown
router (config-if)# encapsulation scada
router (config-if)# exit
router(config)# scada-gw protocol dnp3-serial
router(config-dnp3s)# channel rtu_channel
router(config-dnp3s-channel)# bind-to-interface serial 0/2/0
router(config-dnp3s-channel)# link-addr source 3
router(config-dnp3s-channel)# unsolicited-response enable
router(config-dnp3s-channel)# exit
router(config-dnp3s)# session rtu_session
router(config-dnp3s-session)# attach-to-channel rtu_channel
```

```
router(config-dnp3s-session)# link-addr dest 3
router(config-dnp3s-session)# exit
router(config-dnp3s)# exit
router(config)# scada-gw protocol dnp3-ip
router(config-dnp3n)# channel cc_channel
router(config-dnp3n-channel)# link-addr dest 3
router(config-dnp3n-channel)# tcp-connection local-port default remote-ip any
router(config-dnp3n-channel)# exit
router(config-dnp3n)# session cc_session
router(config-dnp3n-session)# attach-to-channel cc_channel
router(config-dnp3n-session)# link-addr source 3
router(config-dnp3n-session)# map-to-session rtu_session
router(config-dnp3n)# exit
router(config)# exit
router(config)# scada-gw enable
```

Note IOA addresses obtained from T101 side are sent to T104 side without any modification by the SCADA Gateway.

Configuring the DNP3 Protocol Stacks

You can configure the DNP3 serial and DNP3 IP protocol stacks, which allow end-to-end communication between Control Centers and RTUs within a SCADA system.

Configuring DNP3 Serial

Configure the channel and session parameters for the DNP serial communication with an RTU.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal**	Enters global configuration mode.
Step 2	**scada-gw protocol dnp3-serial**	Enters configuration mode for the DNP3 serial protocol.
Step 3	**channel** *channel_name*	Enters channel configuration mode for the DNP3 serial protocol. *channel_name* –Identifies the channel on which the router serial port communicates to the RTU. Note: When the entered channel name does not already exist, the router creates a new channel Entering the **no** form of this command deletes an existing channel. However, all sessions

	Command or Action	Purpose
		must be deleted before you can delete a channel.
Step 4	**bind-to-interface serial 0/2/0**	Defines the router async interface on which the system sends its DNP3 protocol traffic.
Step 5	**link-addr source** *source_address*	Refers to the link address of the master. *source_address* –Range of values from 1 to 65535.
Step 6	**unsolicited-response enable**	(Optional) Allows unsolicited responses. Entering the **no** form of this command disables unsolicited responses. The default is disabled.
Step 7	**exit**	Ends configuration of the channel and exits channel configuration mode. Saves all settings.
Step 8	**session** *session_name*	Enters session configuration mode and assigns a name to the session. Note: When the entered session name does not already exist, the router creates a new session. Entering the **no** form of this command deletes an existing session.
Step 9	**attach-to-channel** *channel_name*	Attaches the session to the channel. Note: Enter the same channel name that you entered in Step 3 above *channel_name* –Identifies the channel.
Step 10	**link-addr dest** *destination_address*	Refers to the link address of the slave. *destination_address* –Range of values from 1 to 65535.
Step 11	**exit**	Exits session configuration mode.
Step 12	**exit**	Exits protocol configuration mode.

EXAMPLE

This example shows how to configure the parameters for the DPN3-serial protocol stack:

```
router# configure terminal
router(config)# scada-gw protocol dnp3-serial
router(config-dnp3s)# channel rtu_channel
router(config-dnp3s-channel)# bind-to-interface serial 0/2/0
router(config-dnp3s-channel)# link-addr source 3
router(config-dnp3s-channel)# unsolicited-response enable
```

```
router(config-dnp3s-channel)# exit
router(config-dnp3s)# session rtu_session
router(config-dnp3s-session)# attach-to-channel rtu_channel
router(config-dnp3s-session)# link-addr dest 3
router(config-dnp3s-session)# exit
router(config-dnp3s)# exit
router(config)#
```

Configuring DNP3 IP

Follow the steps below for the Control Center that you want to connect to over DNP3 IP. For redundancy, you can create multiple connections that share the same session configuration under the same session.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal**	Enters configuration mode.
Step 2	**scada-gw protocol dnp3-ip**	Enters configuration mode for the DNP-IP protocol.
Step 3	**channel** *channel_name*	Enters channel configuration mode for the DNP-IP protocol. *channel_name* –Identifies the channel on which the router communicates with the Control Center. Note: When the entered channel name does not already exist, the router creates a new channel. Entering the **no** form of this command deletes an existing channel. However, all sessions must be deleted before you can delete a channel.
Step 4	**link-addr dest** *destination_address*	Refers to the link address of the master. *destination_address* –Range of values from 1 to 65535.
Step 5	**send-unsolicited-msg enable**	(Optional) Allow unsolicited messages. The default is enabled.
Step 6	**tcp-connection local-port** [**default** | *local_port*] **remote-ip** [**any** | *remote_ip* | *remote_subnet*]	Configures the local port number and remote IP address for the TCP connection: • **default**–20000. • *local_port* –Range of values from 2000 to 65535. • any–Any remote hosts 0.0.0.0/0

	Command or Action	Purpose
		• *remote_ip* –Single host: A.B.C.D • *remote_subnet* –Subnet: A.B.C.D/LEN If remote_subnet is specified, when two channels have the same local ports, the remote subnets cannot overlap each other. Note: Every <local-port, remote-ip> must be unique per channel. If remote_subnet is specified, when two channels have the same local ports, the remote subnets cannot overlap each other.
Step 7	**exit**	Exits channel configuration mode.
Step 8	**session** *session_name*	Enters session configuration mode and assigns a name to the session. Note: When the entered session name does not already exist, the router creates a new session. Entering the **no** form of this command deletes an existing session.
Step 9	**attach-to-channel** *channel_name*	Attaches the session to the channel. Enter the same channel name that you entered in Step 3. *channel_name* –Identifies the channel.
Step 10	**link-addr source** *source_address*	Refers to the link address of the slave. *source_address* –Value of 1-65535.
Step 11	**map-to-session** *session_name*	Maps the dnp3-ip session to an existing dnp3-serial session. Note: One dnp3-ip session can be mapped to only one dnp3-serial session.
Step 12	**exit**	Exits session configuration mode.
Step 13	**exit**	Exits protocol configuration mode.

EXAMPLE

This example shows how to configure the DNP3 IP parameters:

```
router# configure terminal
router(config)# scada-gw protocol dnp3-ip
router(config-dnp3n)# channel cc_channel
router(config-dnp3n-channel)# link-addr dest 3
router(config-dnp3n-channel)# tcp-connection local-port default remote-ip any
```

```
router(config-dnp3n-channel)# exit
router(config-dnp3n)# session cc_session
router(config-dnp3n-session)# attach-to-channel cc_channel
router(config-dnp3n-session)# link-addr source 4
router(config-dnp3n-session)# map-to-session rtu_session
router(config-dnp3n)# exit
router(config)# exit
```

Starting and Stopping the Protocol Translation Engine

You must start the Protocol Translation Engine to use Protocol Translation on the IR8340.

Starting–After enabling SCADA encapsulation on the IR8340 serial port and configuring the T101 and T104 protocols on the IR8340, you can start the Protocol Translation Engine.

Stopping–Before you can make any configuration changes to Protocol Translation on the IR8340 with an active Protocol Translation Engine, you must stop the engine.

Before you begin

Before **starting** the Protocol Translation Engine on the router for the **first time**, make sure you complete the following items:

Enabling the IR8340 Serial Port and SCADA Encapsulation, on page 188

Configuring T101 and T104 Protocol Stacks, on page 189

Procedure

	Command or Action	Purpose
Step 1	**configure terminal**	Enters global configuration mode.
Step 2	**[no] scada-gw enable**	Starts (**scada-gw enable**) or stops (**no scada-gw enable**) the Protocol Translation Engine on the IR8340.

EXAMPLE

To start the protocol translation engine on the router, enter the following commands:

```
router# configure terminal
router(config)# scada-gw enable
```

To stop the protocol translation engine on the router, enter the following commands:

```
router# configure terminal
router(config)# no
 scada-gw enable
```

Verifying Configuration

Command	Purpose
show running-config	Shows the configuration of the router including active features and their settings.
show scada database	Displays details on the SCADA database.
show scada statistics	Shows statistics for the SCADA gateway, including the number of messages sent and received, timeouts, and errors.
show scada tcp	Displays TCP connections associated with the SCADA gateway.

This example shows the output from the show scada tcp and show scada statistics commands:

```
Router#show scada tcp
DNP3 network channel [test]: 4 max simultaneous connections
conn: local-ip: 3.3.3.21 local-port 20000 remote-ip 3.3.3.15 data-socket
1
Total:
1 current client connections
0 total closed connections

Router#show scada statistics
DNP3 network Channel [test]:
5 messages sent, 2 messages received
0 timeouts, 0 aborts, 0 rejections
2 protocol errors, 2 link errors, 0 address errors
DNP3 serial Channel [test]:
152 messages sent, 152 messages received
1 timeouts, 0 aborts, 0 rejections
0 protocol errors, 0 link errors, 0 address errors

Router#show scada database
------------ Scada Gateway Database ----------------------
Configuration Root
   State -- 0x3
   MaxEvents -- 0x258
   Retry -- 0x3
   DegradedFrequency -- 0x2710
   Timeout -- 0x2710
   PointsAvailableToAlloc -- 0x470
   From Master
      IEC 104
         Line(2) status:DOWN
            Link(2) status:DOWN InUse(0)
            Request(-99):NOT running
               function(1)id(1)Triggered(0)MustRun(0)Attempt(4)diff(3604)Freq(100)
               RTU(101) status:DOWN InUse(0) Online(0)
                  Object(Single Input)
                     DI(100)
                        Value -- 0x0
                        Quality -- 0x4
                     DI(101)
                        Value -- 0x0
                        Quality -- 0x4
                     DI(102)
                        Value -- 0x0
                        Quality -- 0x4
```

Debug Commands

This section lists some debug commands that are helpful when troubleshooting.

- SCADA device to trace debug commands:

```
#debug scada device ?
  network   Network device to trace
  none      No device to trace
  serial    Serial device to trace


#debug scada device network ?
  <0-65535>   Address of device to trace

#debug scada device none ?
  <cr>  <cr>

#debug scada device serial ?
  <0-65535>   Address of device to trace
```

- SCADA function level debug commands:

```
#debug scada function ?
  analog          analog ouput trace
  clock           clock trace
  config          config trace
  control         control trace
  datalink        datalink trace
  driver-event    Driver event debug
  driver-packet   Driver Packet debug
  error           error trace
  event           event trace
  file            file trace
  freeze          freeze trace
  general         general debug
  physical        physical trace
  poll            poll trace
  protocol        protocol trace
  request         request trace
  stack           stack trace
  status          status trace
  tcp-event       TCP event debug
  timer           timer trace
  transport       transport trace
  umode           umode trace
```



CHAPTER 18

Raw Socket Transport

Raw Socket Transport transports streams of characters from one serial interface to another over an IP network for utility applications.

This document describes Raw Socket Transport for the IR8340 and provides a reference section describing the Raw Socket Transport commands.

This document includes the following sections:

- Information About Raw Socket Transport, on page 205
- Prerequisites, on page 208
- Guidelines and Limitations, on page 208
- Default Settings, on page 208
- Configuring Raw Socket Transport, on page 208
- Verifying Configuration, on page 214
- Configuration Example, on page 215
- Show Line Details for Configuring Raw-TCP/UDP, on page 218
- Raw-Socket Show and Debug Commands, on page 219

Information About Raw Socket Transport

Raw Socket is a method for transporting serial data through an IP network. The feature can be used to transport Supervisory Control and Data Acquisition (SCADA) data from Remote Terminal Units (RTUs). This method is an alternative to the Block Serial Tunnel (BSTUN) protocol.

Raw Socket Transport supports TCP or UDP as the transport protocol. An interface can be configured to use either protocol but not both at the same time. TCP transport is suitable for applications such as control applications that require acknowledged and sequenced delivery of data. For latency-sensitive applications such as line SEL relays, UDP transport provides faster transport of serial data than TCP.

Raw Socket Transport supports the following for the asynchronous serial interface:

- TCP as the transport protocol, with built-in auto TCP connection retry mechanism.
- Up to 32 TCP sessions and 32 UDP sessions.
- Interface configuration as a server, client, or a combination of both.
- One server interface, but multiple clients.

- VRF-awareness, which enables the router to send Raw Socket Transport traffic to a server host connected through a Virtual Private Network (VPN) Virtual Routing and Forwarding (VRF) interface.


This section includes the following topics:

TCP Transport

TCP Raw Socket transport uses a client-server model. At most one server and multiple clients can be configured on a single asynchronous serial line. In client mode, the IR8340 can initiate up to 32 TCP sessions to Raw Socket servers, which can be other IR8340 routers or third-party devices.

The following figure shows a sample Raw Socket TCP configuration. In this example, serial data is transferred between RTUs and a utility management system across an IP network that includes several IR8340 routers. One IR8340 router (Router 1) acts as a Raw Socket server, listening for TCP connection requests from the other IR8340 routers (Router 2 and Router 3), which are configured as Raw Socket clients.

A Raw Socket client receives streams of serial data from the RTUs and accumulates this data in its buffer, then places the data into packets, based on user-specified packetization criteria. The Raw Socket client initiates a TCP connection with the Raw Socket server and sends the packetized data across the IP network to the Raw Socket server, which retrieves the serial data from the packets and sends it to the serial interface, and on to the utility management system.




Note When you configure the serial link interface on the router as a server, the interface's peer is the serial link interface on the client router and vice versa.

UDP Transport

UDP transport uses a peer-to-peer model. Multiple UDP connections can be configured on an asynchronous serial line. IR8340 can support up to 32 UDP sessions.

The following figure shows a sample Raw Socket UDP configuration. In this example, serial data is transferred between RTUs and a utility management system across an IP network that includes two routers that are configured as Raw Socket UDP peers.

In this example, the Raw Socket UDP peer receives streams of serial data from the RTUs and accumulates this data in its buffer, then places the data into packets, based on user-specified packetization criteria. The Raw Socket UDP peer sends the packetized data across the IP network to the Raw Socket peer at the other end, which retrieves the serial data from the packets and sends it to the serial interface, and on to the utility management system.



Serial Data Processing

When the default serial protocol, Asynchronous Communication Protocol, is used, the streams of serial data received by a Raw Socket peer can be packetized based on the following criteria:

- **Packet length**–You can specify a packet length that triggers the IR8340 to transmit the serial data to the peer. Once the IR8340 collects this much data in its buffer, it packetizes the accumulated data and forwards it to the Raw Socket peer.
- **Packet-timer value**–The packet timer specifies the amount of time the IR8340 waits to receive the next character in a stream. If a character is not received by the time the packet timer expires, the data the IR8340 has accumulated in its buffer is packetized and forwarded to the Raw Socket peer.
- **Special character**–You can specify a character that will trigger the IR8340 to packetize the data accumulated in its buffer and send it to the Raw Socket peer. When the special character (for example, a CR/LF) is received, the IR8340 packetizes the accumulated data and sends it to the Raw Socket peer.

See Configuring Common Raw Socket Line Options, on page 209 for information about configuring the processing options.

VRF-Aware Raw Socket

The VRF-aware Raw Socket Transport feature enables you to isolate Raw Socket traffic using a VRF for efficient management and control of serial data. After configuring a VRF, you can associate the serial interface configured for Raw Socket Transport with the VRF. See Raw Socket VRF, on page 217 for a configuration example.

Prerequisites

Determine how you want Raw Socket traffic transported in your network, including the network devices and interfaces to use, how the router packetizes the serial data, and whether to use VRF.

Guidelines and Limitations

Typically, UDP traffic is blocked by firewalls in the network. If the network has such firewalls, make sure to configure pinholes to allow the raw socket UDP traffic.

Default Settings

Feature	Default Setting
Raw Socket Transport	Disabled.
Packet length	No packet length is configured.
Serial Protocol	Asynchronous Communication Protocol
Packet timeout	15 ms.
Special character	No special character is configured.
Raw Socket mode	Best-effort mode is off, not supported on the IR8340.
TCP idle timeout	5 minutes.

Configuring Raw Socket Transport

This section includes the following topics:

Enabling Raw Socket Transport on the Serial Interface

To enable Raw Socket Transport on the IR8340 router, you must first enable an asynchronous serial port and enable Raw Socket TCP or UDP encapsulation for that port.

Before you begin

Determine availability of the serial port on the IR8340.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal**	Enters global configuration mode.
Step 2	**interface serial** *slot/subslot/port*	Enters the interface command mode for the serial interface.
Step 3	**physical-layer async**	Configure the serial interface to Asynchronous mode.
Step 4	**no ip address**	Disables IP processing on the interface.
Step 5	Do one of the following: • **encapsulation raw-tcp** • **encapsulation raw-udp**	Enables Raw Socket TCP encapsulation or UDP encapsulation for the serial port.

Example

```
router# configure terminal
router(config)# interface serial 0/3/2
router(config)# physical-layer async
router(config-if)# no ip address
router(config-if)# encapsulation raw-tcp
router(config-if)# exit
```

Configuring Common Raw Socket Line Options

You can configure options common to all connections on a line. The common options apply to both TCP and UDP.

Before you begin

Enable Raw Socket Transport as described in Enabling Raw Socket Transport on the Serial Interface, on page 208.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal**	Enters global configuration mode.
Step 2	**line 0**/*slot* /*port*	Enters line command mode for the serial slot/port.
Step 3	**raw-socket packet-length** *length*	Specifies the packet size that triggers the IR8340 to transmit the data to the peer. When the IR8340 accumulates this much data in its

	Command or Action	Purpose
		buffer, it packetizes the data and forwards it to the Raw Socket peer. *length*— 2 to 1400 bytes. By default, the packet-length trigger is disabled.
Step 4	**raw-socket packet-timer** *timeout*	Specifies the maximum time in milliseconds the IR8340 waits to receive the next character in a stream. If a character is not received by the time the packet-timer expires, the accumulated data is packetized and forwarded to the Raw Socket peer. *timeout* —3 to 1000 ms. The default is 15 ms.
Step 5	**raw-socket spec-char** *ascii_char*	Specifies a character that will trigger the IR8340 to packetize the data accumulated in its buffer and send it to the Raw Socket peer. *ascii_char*— 0 to 255. By default, the special character trigger is disabled.

Example

```
router# configure terminal
router(config)# line 0/3/2
router(config-line)# raw-socket packet-length 32
router(config-line)# raw-socket packet-timer 500
router(config-line)# raw-socket special-char 3
router(config-line)# parity even
router(config-line)# stopbits 1
router(config-line)# speed 9600
```

What to do next

Use the **no** form of these commands to return to the default values.

Configuring Raw Socket TCP

After enabling Raw Socket TCP encapsulation, you configure the TCP server and/or clients.

Configuring the Raw Socket TCP Server

Before you begin

Enable a serial port and Raw Socket TCP encapsulation for that port, as described in Enabling Raw Socket Transport on the Serial Interface, on page 208.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal**	Enters configuration mode.
Step 2	**line 0**/*slot* /*port*	Enters line command mode for the serial slot/port.
Step 3	**raw-socket tcp server** *port* [*ip_address*]	Starts the Raw Socket Transport TCP server for an asynchronous line interface. In Raw Socket server mode, the IR8340 listens for incoming connection requests from Raw Socket clients. *port* –Port number the server listens on. *ip_address* –(Optional) Local IP address on which the server listens for connection requests.
Step 4	**raw-socket tcp idle-timeout** *session_timeout*	Sets the Raw Socket Transport TCP session timeout for the asynchronous line interface. If no data is transferred between the client and server over this interval, then the TCP session closes. The client then automatically attempts to reestablish the TCP session with the server. This timeout setting applies to all Raw Socket Transport TCP sessions under this particular line. *session_timeout* –Currently configured session idle timeout in minutes. The default is 5 minutes.

Example

```
router# configure terminal

router(config)# line 0/3/2
router(config-line)# raw-socket tcp server 4000 10.0.0.1
router(config-line)# raw-socket tcp idle-timeout 10
router(config-line)# exit
router(config)#
```

What to do next

To remove a Raw Socket TCP server, use the **no raw-socket tcp server** command.

Configuring the Raw Socket TCP Client

Before you begin

Enable a serial port and Raw Socket TCP encapsulation for that port, as described in Enabling Raw Socket Transport on the Serial Interface, on page 208.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal**	Enters configuration mode.
Step 2	**line 0**/*slot* /*port*	Enters line command mode for the serial slot/port.
Step 3	**raw-socket tcp client** *dest_ip_address dest_port* [*local_ip_address*] [*local_port*]	Specifies settings for Raw Socket Transport TCP client sessions. *dest_ip_address* –Destination IP address of the remote Raw Socket server. *dest_port* –Destination port number to use for the TCP connection to the remote server. *local_ip_address* –(Optional) Local IP address that the client can also bind to. *local_port* –(Optional) Local port number that the client can also bind to.
Step 4	**raw-socket tcp idle-timeout** *session_timeout*	Sets the Raw Socket Transport TCP session timeout for the asynchronous line interface. If no data is transferred between the client and server over this interval, then the TCP session is closed. The client then automatically attempts to reestablish the TCP session with the server. This timeout setting applies to all Raw Socket Transport TCP sessions under this particular line. *session_timeout* –Currently configured session idle timeout in minutes. The default is 5 minutes.
Step 5	**raw-socket tcp keepalive** *interval*	Sets the Raw Socket Transport TCP session keepalive interval for the asynchronous line interface. The router sends keepalive messages based on the configured interval. You may need to configure this interval, for example, when sending raw TCP traffic over a cellular interface.

	Command or Action	Purpose
		interval –Currently configured keepalive interval in seconds. Range is 1-864000 seconds. The default is 1 second.

Example

This example shows how to configure a Raw Socket TCP client for an asynchronous serial line. The IR8340 (router), serving as a Raw Socket client, initiates TCP sessions with a Raw Socket server and forwards packetized serial data to it. The router collects streams of serial data in its buffer; when it accumulates 827 bytes in its buffer, the router packetizes the data and forwards it to the Raw Socket server. If the router and the Raw Socket server do not exchange any data for 10 minutes, then the TCP session with the Raw Socket server closes, and the router attempts to reestablish the session with the Raw Socket server.

```
router# configure terminal

router(config)# line 0/3/2
router(config-line)# raw-socket tcp client 10.0.0.1 4000
router(config-line)# raw-socket packet-length 827
router(config-line)# raw-socket tcp idle-timeout 10
router(config-line)# exit
router(config)#
```

What to do next

To remove a Raw Socket TCP client, use the **no raw-socket tcp client** command.

Configuring a Raw Socket UDP Peer-to-Peer Connection

After enabling Raw Socket UDP encapsulation and the common line options, you configure the Raw Socket UDP peer-to-peer connection. The local port on one end of the connection should be the destination port on the other end.

Before you begin

Enable a serial port and Raw Socket UDP encapsulation for that port, as described in Enabling Raw Socket Transport on the Serial Interface, on page 208.

Procedure

	Command or Action	Purpose
Step 1	**configure terminal**	Enters configuration mode.
Step 2	**line 0**/*slot* /*port*	Enters line command mode for the serial slot/port.
Step 3	**raw-socket udp connection** *dest_ip_address dest_port local_port* [*local_ip_address*]	Specifies settings for Raw Socket Transport UDP connections.

	Command or Action	Purpose
		dest_ip_address –Destination IP address to use for the UDP connection. *dest_port* –Destination port number to use for the UDP connection. *local_port* –Local port number for the UDP connection. *local_ip_address* –(Optional) Local IP address for the UDP connection.

Example

This example shows how to configure a Raw Socket UDP connection between router A (local IP address 192.168.0.8) and router B (local IP address 192.168.0.2).

Router A

```
router# configure terminal
router(config)# line 0/2/0
router(config-line)# raw-socket udp connection 192.168.0.2 5000 7000
router(config-line)# exit
router(config)#
```

Router B

```
router# configure terminal
router(config)# line 0/2/0
router(config-line)# raw-socket udp connection 192.168.0.8 7000 5000
router(config-line)# exit
router(config)#
```

What to do next

To remove a Raw Socket UDP connection, use the **no raw-socket udp connection** command.

Verifying Configuration

Command	Purpose
show running-config	Shows the configuration of the IR8340, including those features that are active and their settings.
show raw-socket tcp detail	Displays information about Raw Socket Transport TCP activity.
show raw-socket tcp sessions	Displays information about Raw Socket Transport TCP sessions.
show raw-socket tcp statistics	Displays Raw Socket Transport TCP statistics for each asynchronous serial line.


Command	Purpose
show raw-socket udp detail	Displays information about Raw Socket Transport UDP activity.
show raw-socket udp sessions	Displays information about Raw Socket Transport UDP sessions.
show raw-socket udp statistics	Displays Raw Socket Transport UDP statistics for each asynchronous serial line.
clear raw-socket statistics	Clears Raw Socket Transport statistics for a specific TTY interface or for all asynchronous serial lines.

Configuration Example

The following sections include Raw Socket Transport configuration examples:

Raw Socket TCP

The following example shows a Raw Socket Transport configuration in which an IR8340 router (Router 1) acts as the server, and another IR8340 (Router 2) acts as the client.



The following table displays the configuration of the server and client IR8340s highlighted in the above figure:

IR8340 Server Configuration	IR8340 Client Configuration
... interface serial 0/3/1 physical-layer async no ip address **encapsulation raw-tcp** ! ... line 0/3/1 **raw-socket tcp server 5000 10.0.0.1** **raw-socket packet-timer 3** **raw-socket tcp idle-timeout 5** ...	... interface serial 0/3/1 physical-layer async no ip address **encapsulation raw-tcp** ! interface serial 0/3/2 physical-layer async no ip address **encapsulation raw-tcp** ! ... line 0/3/1 **raw-socket tcp client 10.0.0.1 5000 10.0.0.2 9000** **raw-socket packet-length 32** **raw-socket tcp idle-timeout 5** line 0/3/2 **raw-socket tcp client 10.0.0.1 5000 10.0.0.2 9001** **raw-socket packet-length 32** **raw-socket tcp idle-timeout 5**

Raw Socket UDP

This example shows the configuration for a Raw Socket UDP connection between two IR8340 routers:

From Router1


```
interface GigabitEthernet 0/1/1
ip address 192.168.0.8 255.255.255.0
duplex auto
speed auto
interface serial 0/3/2
physical-layer async
no ip address
encapsulation raw-udp
line 0/3/2
raw-socket udp connection 192.168.0.2 4000 4000
```

From Router2

```
interface GigabitEthernet0/1/2
ip address 192.168.0.2 255.255.255.0
load-interval 60
duplex auto
speed auto
no keepalive
interface serial 0/3/2
physical-layer async
no ip address
encapsulation raw-udp
line 0/3/2
raw-socket udp connection 192.168.0.8 4000 4000
```

Raw Socket VRF

The following example shows a Raw Socket VRF configuration in which two routers, configured for Raw Socket Transport, connect through a VRF. Router1 is an IR8340, serves as the Raw Socket TCP server, and Router2 is an IR8340 serves as the Raw Socket TCP client.



Following are the configurations of Router1 and Router2 as shown in the above figure:

Router1 Configuration

Defining VRF on the router:

```
vrf definition router1
 rd 100:1
 route-target export 100:3
 route-target import 100:3
 !
 address-family ipv4
 exit-address-family
```

Applying VRF configuration on the interface:

```
interface GigabitEthernet0/0/1
 vrf forwarding router1
 ip address 100.100.100.2 255.255.255.0
 duplex auto
 speed auto
```

Applying raw-tcp on the serial interface:

```
interface serial 0/3/1
 physical-layer async
 vrf forwarding router1
 no ip address
 encapsulation raw-tcp
```

Applying raw-tcp on the line:

```
line 0/3/1
 raw-socket tcp server 5000 4.4.4.4
```

Router2 Configuration

Defining VRF on the router:

```
vrf definition router1
 rd 100:1
 route-target export 100:3
 route-target import 100:3
 !
 address-family ipv4
 exit-address-family
```

Applying VRF configuration on the interface:

```
interface GigabitEthernet0/0/1
 vrf forwarding router1
 ip address 100.100.100.1 255.255.255.0
 duplex auto
 speed auto
```

Applying raw-tcp on the serial interface:

```
interface serial 0/3/1
 physical-layer async
 vrf forwarding router1
 no ip address
 encapsulation raw-tcp
```

Applying raw-tcp on line:

```
line 0/3/1
  raw-socket tcp client 4.4.4.4 5000
```

Show Line Details for Configuring Raw-TCP/UDP

The **show line** command shows all TTY line summary information. The output contains information about mapping between async interface and line number, the line speed, uses, noise, and so on. The line that begins with the asterisk "*" indicates that the line is in use.

By enabling the physical layer Async on the serial port, the corresponding line will be activated and it will be displayed in the **show line** output. In the following example, 0/3/0 and 0/3/4 are configured as async mode and displayed.

```
U1#show line
   Tty Line Typ     Tx/Rx    A Modem  Roty AccO AccI  Uses  Noise Overruns  Int
*     0    0 CTY              -    -      -    -    -     0      0    0/0      -
      1    1 AUX   9600/9600  -    -      -    -    -     0      0    0/0      -
  0/3/0   50 TTY   9600/9600  -    -      -    -    -     0     17    0/0    Se0/3/0
  0/3/4   54 TTY   9600/9600  -    -      -    -    -     0      0    0/0    Se0/3/4
    866  866 VTY              -    -      -    -    -     3      0    0/0      -
    867  867 VTY              -    -      -    -    -     0      0    0/0      -
    868  868 VTY              -    -      -    -    -     0      0    0/0      -
    869  869 VTY              -    -      -    -    -     0      0    0/0      -
    870  870 VTY              -    -      -    -    -     0      0    0/0      -
    871  871 VTY              -    -      -    -    -     0      0    0/0      -
    872  872 VTY              -    -      -    -    -     0      0    0/0      -
    873  873 VTY              -    -      -    -    -     0      0    0/0      -
    874  874 VTY              -    -      -    -    -     0      0    0/0      -
    875  875 VTY              -    -      -    -    -     0      0    0/0      -
    876  876 VTY              -    -      -    -    -     0      0    0/0      -
    877  877 VTY              -    -      -    -    -     0      0    0/0      -
    878  878 VTY              -    -      -    -    -     0      0    0/0      -
    879  879 VTY              -    -      -    -    -     0      0    0/0      -
    880  880 VTY              -    -      -    -    -     0      0    0/0      -
Line(s) not in async mode -or- with no hardware support:
```

```
2-49, 51-53, 55-865
U1#
```

Raw-Socket Show and Debug Commands

Use the following show commands for the verification:

- **show raw-socket {tcp|udp} session**
- **show raw-socket {tcp|udp} statistic**

Use the following commands to debug:

```
debug raw-socket ?
  driver      Driver level debug
  transport   Raw-socket over any transport

debug raw-socket driver ?
  event    Driver event trace
  packet   Driver packet trace

debug raw-socket driver event ?
  <cr>  <cr>

debug raw-socket driver packet ?
  line   Serial/Async line
  <cr>  <cr>


debug raw-socket driver packet line ?
  <0-726>  First Line range
  console  Primary terminal line
  tty      Terminal controller
  vty      Virtual terminal
  x/y/z    Slot/Subslot/Port for Modems

debug raw-socket transport ?
  event    TCP or UDP event trace
  packet   TCP or UDP packet trace

debug raw-socket transport event ?
  <cr>  <cr>

debug raw-socket transport packet ?
  line   Serial/Async line
  <cr>  <cr>

debug raw-socket transport packet line ?
  <0-726>  First Line range
  console  Primary terminal line
  tty      Terminal controller
  vty      Virtual terminal
  x/y/z    Slot/Subslot/Port for Modems
```



CHAPTER 19

Configuring MODBUS TCP

This chapter provides the following sections:

- Understanding MODBUS TCP, on page 221
- Configuring the Router as the MODBUS TCP Server, on page 223
- MODBUS TCP Registers, on page 223

Understanding MODBUS TCP

Use Modicon Communication Bus (MODBUS) TCP over an Ethernet network when connecting the router to devices such as intelligent electronic devices (IEDs), distributed controllers, substation routers, Cisco IP Phones, Cisco Wireless Access Points, and other network devices such as redundant substation routeres.

MODBUS is a serial communications protocol for client-server communication between a router (server) and a device in the network running MODBUS client software (client). You can use MODBUS to connect a computer to a remote terminal unit (RTU) in supervisory control and data acquisition (SCADA) systems.

The client can be an IED or a human machine interface (HMI) application that remotely configure and manage devices running MODBUS TCP. The router functions as the server.

The router encapsulates a request or response message in a MODBUS TCP application data unit (ADU). A client sends a message to a TCP port on the router. The default port number is 502.

Note For information about the registers that a client can query on the router that functions as a MODBUS TCP server, see MODBUS TCP Registers, on page 223.

MODBUS and Security

If a firewall or other security services are enabled, the router TCP port might be blocked, and the router and the client cannot communicate.

If a firewall and other security services are disabled, a denial-of-service attack might occur on the router.

To configure quality of service (QoS) to set the rate-limit for MODBUS TCP traffic, create an access-list that only permits traffic sending to port number 502 that is reserved for MODBUS communication. Then attach the access-list to the input class-map and attach it to the interface and set the rate limit to permit traffic via default port 502 and prioritize SCADA packets.

```
DUT-1:
!
class-map match-any Modbus-out-Traffic
 match qos-group 1
class-map match-any Modbus-In-Traffic
 match access-group 101
!
policy-map Modbus-In
 class Modbus-In-Traffic
  set qos-group 1
policy-map Modbus-Out
 class Modbus-out-Traffic
  police 10000000
  priority
!
!
interface GigabitEthernet0/1/1
 switchport mode access
 service-policy input Modbus-In
!
interface GigabitEthernet0/1/2
 switchport mode access
 service-policy output Modbus-Out
!
!
interface Vlan1
 no ip address
 ip access-group 101 in
 rate-limit input access-group 101 8000 8000 8000 conform-action transmit exceed-action
drop
!
!
!
access-list 101 permit tcp 10.10.10.0 0.0.0.255 any eq 502

DUT-2:

interface Vlan1
 ip address 192.168.1.2 255.255.255.0
```

This example shows that 133 SCADA packets were classified.

```
DUT-1#show policy-map interface GigabitEthernet0/1/2
 GigabitEthernet0/1/2
  Service-policy output: Modbus-Out
    Class-map: Modbus-out-Traffic (match-any)
      133 packets
      Match: qos-group 1
      police cir 10000000 bc 312500
         conform-action transmit
         exceed-action drop
      conform: 133 (packets) exceed: 0 (packets)
        Priority
      Output Queue:
        Max queue-limit default threshold: 272
        Tail Packets Drop: 0
```

Multiple Request Messages

The router can receive multiple request messages from clients and respond to them simultaneously.

You can set the number of client connections from 1 to 5. The default is 1.

Configuring the Router as the MODBUS TCP Server

Defaults

The router is not configured as a MODBUS TCP server.

The TCP port number is 502.

The number of simultaneous connection requests is 1.

Enabling MODBUS TCP on the Switch

Beginning in privileged EXEC mode:

Procedure

	Command or Action	Purpose
Step 1	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 2	**scada modbus tcp server**	Enables MODBUS TCP on the router.
Step 3	**scada modbus tcp server** [**port** *tcp-port-number*]	(Optional) Sets the TCP port to which clients send messages. The range for *tcp-port-number* is 1 to 65535. The default is 502.
Step 4	**scada modbus tcp server** [**connection** *connection-requests*]	(Optional) Sets the number of simultaneous connection requests sent to the router. The range for *connection-requests* is 1 to 5. The default is 1.
Step 5	**end** **Example:** `Router(config)# end`	Returns to privileged EXEC mode.

To disable MODBUS on the router and return to the default settings, enter the **no scada modbus tcp server** global configuration command.

To add security when using MODBUS TCP, configure an ACL to permit traffic from specific clients or configure QoS to rate-limit traffic.

MODBUS TCP Registers

This section lists the read-only MODBUS registers. MODBUS clients use them to communicate with a MODBUS server (i.e., the IR8340 router). There are no writable registers.

System Information Registers

Memory address spaces 0x0800 through 0x0FFF are system information registers. Clients use the 0x03 Read Multiple Registers MODBUS function code. The system-information register mapping is as follows:

Table 15: System Information Registers

Address	# of Registers	Description	R/W	Format
0x0800	64	Product ID	R	Text
0x0840	64	Software image name	R	Text
0x0880	64	Software image version	R	Text
0x08C0	64	Host name	R	Text
0x0900	1	Number of Gigabit Ethernet ports	R	Uint16
CPU Core Temperature Related Registers				
0x0901	1	CPU core-0 temperature (in Celsius)	R	Uint16
0x0902	1	CPU core-1 temperature (in Celsius)	R	Uint16
0x0903	1	CPU core-2 temperature (in Celsius)	R	Uint16
0x0904	1	CPU core-3 temperature (in Celsius)	R	Uint16
0x0905	1	CPU core-4 temperature (in Celsius)	R	Uint16
0x0906	1	CPU core-5 temperature (in Celsius)	R	Uint16
0x0907	1	CPU core-6 temperature (in Celsius)	R	Uint16
0x0908	1	CPU core-7 temperature (in Celsius)	R	Uint16

Port Information Registers

Memory address spaces 0x1000 through 0x3FFF are read-only interface registers. Clients use the 0x03 Read Multiple Registers MODBUS function code to access the registers.

The following table shows the memory map for all interface registers, with 64-bit counters (address space 0x1000 – 0x2FFF, 8K registers):

Table 16: System Information Registers

Address	# of Registers	Description	R/W	Format
0x1000	64	WAN Port 1 name	R	Text
0x1040	64	WAN Port 2 name	R	Text
0x1080	64	LAN Port 1 name	R	Text
0x10C0	64	LAN Port 2 name	R	Text
0x1100	64	LAN Port 3 name	R	Text
0x1140	64	LAN Port 4 name	R	Text
0x1180	64	LAN Port 5 name	R	Text
0x11C0	64	LAN Port 6 name	R	Text
0x1200	64	LAN Port 7 name	R	Text
0x1240	64	LAN Port 8 name	R	Text
0x1280	64	LAN Port 9 name	R	Text
0x12C0	64	LAN Port 10 name	R	Text
0x1300	64	LAN Port 11 name	R	Text
0x1340	64	LAN Port 12 name	R	Text
0x1380	1	WAN Port 1 state	R	Uint16
0x1381	1	WAN Port 2 state	R	Uint16
0x1382	1	LAN Port 1 state	R	Uint16
0x1383	1	LAN Port 2 state	R	Uint16
0x1384	1	LAN Port 3 state	R	Uint16
0x1385	1	LAN Port 4 state	R	Uint16
0x1386	1	LAN Port 5 state	R	Uint16
0x1387	1	LAN Port 6 state	R	Uint16
0x1388	1	LAN Port 7 state	R	Uint16
0x1389	1	LAN Port 8 state	R	Uint16
0x138A	1	LAN Port 9 state	R	Uint16
0x138B	1	LAN Port 10 state	R	Uint16

Address	# of Registers	Description	R/W	Format
0x138C	1	LAN Port 11 state	R	Uint16
0x138D	1	LAN Port 12 state	R	Uint16
Values for 64-Bit Counters				
0x138E	4	WAN Port 1 Statistics – Number of packets received	R	Uint64
0x1392	4	WAN Port 2 Statistics – Number of packets received	R	Uint64
0x1396	4	LAN Port 1 Statistics – Number of packets received	R	Uint64
0x139A	4	LAN Port 2 Statistics – Number of packets received	R	Uint64
0x139E	4	LAN Port 3 Statistics – Number of packets received	R	Uint64
0x13A2	4	LAN Port 4 Statistics – Number of packets received	R	Uint64
0x13A6	4	LAN Port 5 Statistics – Number of packets received	R	Uint64
0x13AA	4	LAN Port 6 Statistics – Number of packets received	R	Uint64
0x13AE	4	LAN Port 7 Statistics – Number of packets received	R	Uint64
0x13B2	4	LAN Port 8 Statistics – Number of packets received	R	Uint64
0x13B6	4	LAN Port 9 Statistics – Number of packets received	R	Uint64
0x13BA	4	LAN Port 10 Statistics – Number of packets received	R	Uint64

Address	# of Registers	Description	R/W	Format
0x13BE	4	LAN Port 11 Statistics – Number of packets received	R	Uint64
0x13C2	4	LAN Port 12 Statistics – Number of packets received	R	Uint64
0x13C6	4	WAN Port 1 Statistics – Number of packets sent	R	Uint64
0x13CA	4	WAN Port 2 Statistics – Number of packets sent	R	Uint64
0x13CE	4	LAN Port 1 Statistics – Number of packets sent	R	Uint64
0x13D2	4	LAN Port 2 Statistics – Number of packets sent	R	Uint64
0x13D6	4	LAN Port 3 Statistics – Number of packets sent	R	Uint64
0x13DA	4	LAN Port 4 Statistics – Number of packets sent	R	Uint64
0x13DE	4	LAN Port 5 Statistics – Number of packets sent	R	Uint64
0x13E2	4	LAN Port 6 Statistics – Number of packets sent	R	Uint64
0x13E6	4	LAN Port 7 Statistics – Number of packets sent	R	Uint64
0x13EA	4	LAN Port 8 Statistics – Number of packets sent	R	Uint64
0x13EE	4	LAN Port 9 Statistics – Number of packets sent	R	Uint64
0x13F2	4	LAN Port 10 Statistics – Number of packets sent	R	Uint64

Address	# of Registers	Description	R/W	Format
0x13F6	4	LAN Port 11 Statistics – Number of packets sent	R	Uint64
0x13FA	4	LAN Port 12 Statistics – Number of packets sent	R	Uint64
0x13FE	4	WAN Port 1 Statistics – Number of bytes received	R	Uint64
0x1402	4	WAN Port 2 Statistics – Number of bytes received	R	Uint64
0x1406	4	LAN Port 1 Statistics – Number of bytes received	R	Uint64
0x140A	4	LAN Port 2 Statistics – Number of bytes received	R	Uint64
0x140E	4	LAN Port 3 Statistics – Number of bytes received	R	Uint64
0x1412	4	LAN Port 4 Statistics – Number of bytes received	R	Uint64
0x1416	4	LAN Port 5 Statistics – Number of bytes received	R	Uint64
0x141A	4	LAN Port 6 Statistics – Number of bytes received	R	Uint64
0x141E	4	LAN Port 7 Statistics – Number of bytes received	R	Uint64
0x1422	4	LAN Port 8 Statistics – Number of bytes received	R	Uint64
0x1426	4	LAN Port 9 Statistics – Number of bytes received	R	Uint64
0x142A	4	LAN Port 10 Statistics – Number of bytes received	R	Uint64

Address	# of Registers	Description	R/W	Format
0x142E	4	LAN Port 11 Statistics – Number of bytes received	R	Uint64
0x1432	4	LAN Port 12 Statistics – Number of bytes received	R	Uint64
0x1436	4	WAN Port 1 Statistics – Number of bytes sent	R	Uint64
0x143A	4	WAN Port 2 Statistics – Number of bytes sent	R	Uint64
0x143E	4	LAN Port 1 Statistics – Number of bytes sent	R	Uint64
0x1442	4	LAN Port 2 Statistics – Number of bytes sent	R	Uint64
0x1446	4	LAN Port 3 Statistics – Number of bytes sent	R	Uint64
0x144A	4	LAN Port 4 Statistics – Number of bytes sent	R	Uint64
0x144E	4	LAN Port 5 Statistics – Number of bytes sent	R	Uint64
0x1452	4	LAN Port 6 Statistics – Number of bytes sent	R	Uint64
0x1456	4	LAN Port 7 Statistics – Number of bytes sent	R	Uint64
0x145A	4	LAN Port 8 Statistics – Number of bytes sent	R	Uint64
0x145E	4	LAN Port 9 Statistics – Number of bytes sent	R	Uint64
0x1462	4	LAN Port 10 Statistics – Number of bytes sent	R	Uint64

Address	# of Registers	Description	R/W	Format
0x1466	4	LAN Port 11 Statistics – Number of bytes sent	R	Uint64
0x146A	4	LAN Port 12 Statistics – Number of bytes sent	R	Uint64
Values for 32-Bit Counters				
0x146E	2	WAN Port 1 Statistics – Number of packets received	R	Uint32
0x1470	2	WAN Port 1 Statistics – Number of packets received	R	Uint32
0x1472	2	LAN Port 1 Statistics – Number of packets received	R	Uint32
0x1474	2	LAN Port 2 Statistics – Number of packets received	R	Uint32
0x1476	2	LAN Port 3 Statistics – Number of packets received	R	Uint32
0x1478	2	LAN Port 4 Statistics – Number of packets received	R	Uint32
0x147A	2	LAN Port 5 Statistics – Number of packets received	R	Uint32
0x147C	2	LAN Port 6 Statistics – Number of packets received	R	Uint32
0x147E	2	LAN Port 7 Statistics – Number of packets received	R	Uint32
0x1480	2	LAN Port 8 Statistics – Number of packets received	R	Uint32
0x1482	2	LAN Port 9 Statistics – Number of packets received	R	Uint32

Address	# of Registers	Description	R/W	Format
0x1484	2	LAN Port 10 Statistics – Number of packets received	R	Uint32
0x1486	2	LAN Port 11 Statistics – Number of packets received	R	Uint32
0x1488	2	LAN Port 12 Statistics – Number of packets received	R	Uint32
0x148A	2	WAN Port 1 Statistics – Number of packets sent	R	Uint32
0x148C	2	WAN Port 2 Statistics – Number of packets sent	R	Uint32
0x148E	2	LAN Port 1 Statistics – Number of packets sent	R	Uint32
0x1490	2	LAN Port 2 Statistics – Number of packets sent	R	Uint32
0x1492	2	LAN Port 3 Statistics – Number of packets sent	R	Uint32
0x1494	2	LAN Port 4 Statistics – Number of packets sent	R	Uint32
0x1496	2	LAN Port 5 Statistics – Number of packets sent	R	Uint32
0x1498	2	LAN Port 6 Statistics – Number of packets sent	R	Uint32
0x149A	2	LAN Port 7 Statistics – Number of packets sent	R	Uint32
0x149C	2	LAN Port 8 Statistics – Number of packets sent	R	Uint32
0x149E	2	LAN Port 9 Statistics – Number of packets sent	R	Uint32

Address	# of Registers	Description	R/W	Format
0x14A0	2	LAN Port 10 Statistics – Number of packets sent	R	Uint32
0x14A2	2	LAN Port 11 Statistics – Number of packets sent	R	Uint32
0x14A4	2	LAN Port 12 Statistics – Number of packets sent	R	Uint32
0x14A6	2	WAN Port 1 Statistics – Number of bytes received	R	Uint32
0x14A8	2	WAN Port 2 Statistics – Number of bytes received	R	Uint32
0x14AA	2	LAN Port 1 Statistics – Number of bytes received	R	Uint32
0x14AC	2	LAN Port 2 Statistics – Number of bytes received	R	Uint32
0x14AE	2	LAN Port 3 Statistics – Number of bytes received	R	Uint32
0x14B0	2	LAN Port 4 Statistics – Number of bytes received	R	Uint32
0x14B2	2	LAN Port 5 Statistics – Number of bytes received	R	Uint32
0x14B4	2	LAN Port 6 Statistics – Number of bytes received	R	Uint32
0x14B6	2	LAN Port 7 Statistics – Number of bytes received	R	Uint32
0x14B8	2	LAN Port 8 Statistics – Number of bytes received	R	Uint32
0x14BA	2	LAN Port 9 Statistics – Number of bytes received	R	Uint32


Address	# of Registers	Description	R/W	Format
0x14BC	2	LAN Port 10 Statistics – Number of bytes received	R	Uint32
0x14BE	2	LAN Port 11 Statistics – Number of bytes received	R	Uint32
0x14C0	2	LAN Port 12 Statistics – Number of bytes received	R	Uint32
0x14C2	2	WAN Port 1 Statistics – Number of bytes sent	R	Uint32
0x14C4	2	WAN Port 2 Statistics – Number of bytes sent	R	Uint32
0x14C6	2	LAN Port 1 Statistics – Number of bytes sent	R	Uint32
0x14C8	2	LAN Port 2 Statistics – Number of bytes sent	R	Uint32
0x14CA	2	LAN Port 3 Statistics – Number of bytes sent	R	Uint32
0x14CC	2	LAN Port 4 Statistics – Number of bytes sent	R	Uint32
0x14CE	2	LAN Port 5 Statistics – Number of bytes sent	R	Uint32
0x14D0	2	LAN Port 6 Statistics – Number of bytes sent	R	Uint32
0x14D2	2	LAN Port 7 Statistics – Number of bytes sent	R	Uint32
0x14D4	2	LAN Port 8 Statistics – Number of bytes sent	R	Uint32
0x14D6	2	LAN Port 9 Statistics – Number of bytes sent	R	Uint32

Address	# of Registers	Description	R/W	Format
0x14D8	2	LAN Port 10 Statistics – Number of bytes sent	R	Uint32
0x14DA	2	LAN Port 11 Statistics – Number of bytes sent	R	Uint32
0x14DC	2	LAN Port 12 Statistics – Number of bytes sent	R	Uint32

Interpreting the Port State

Table 17: Interpreting the Port State

Address	Description	Value
0x1380 to 0x138D	Port state information	The upper byte represents the interface state: • 0x0: Interface is down • 0x1: Interface is going down • 0x2: Interface is in the initializing state • 0x3: Interface is coming up • 0x4: Interface is up and running • 0x5: Interface is reset by the user • 0x6: Interface is shut down by the user • 0x7: Interface is being deleted The lower byte represents the line protocol state: • 0x0: Line protocol state is down • 0x1: Line protocol state is up



CHAPTER 20

VLAN Access Control Lists

This chapter provides information about VLAN Access Control Lists (ACLs) and how to configure them.

- Information About VLAN Access Control Lists, on page 235
- Configuring VACLs, on page 235

Information About VLAN Access Control Lists

VLAN access control lists (VACLs) or VLAN maps are used to control network traffic within a VLAN. VACLs are configured globally, and the rules are applied on VLANs. VACLs are supported in both ingress and egress directions. In ingress direction VACLs are applied after Port ACL and before Routed ACL. In egress direction VACLs are applied after Routed ACL and before Port ACL. VLAN map is applied to both routed and switched traffic. VLAN map can contain both IP and MAC ACLs to be applied to IP and non-IP traffic respectively.

VLAN Maps

VLAN ACLs or VLAN maps are used to control network traffic within a VLAN. You can apply VLAN maps to all packets that are bridged within a VLAN in the switch or switch stack. VACLs are strictly for security packet filtering and for redirecting traffic to specific physical interfaces. VACLs are not defined by direction (ingress or egress).

All non-IP protocols are access-controlled through MAC addresses and Ethertype using MAC VLAN maps. (IP traffic is not access controlled by MAC VLAN maps.) You can enforce VLAN maps only on packets going through the switch; you cannot enforce VLAN maps on traffic between hosts on a hub or on another switch connected to this switch.

With VLAN maps, forwarding of packets is permitted or denied, based on the action specified in the map.

Configuring VACLs

VACL allows you to define VLAN maps and attach them to VLANs. This allows the ability to apply a single access policy across the VLAN and have different policies across different VLANs.

- VLAN map is attached using **vlan filter** <*word*> **vlan-list** <*vlanid*> command
- VLAN map is defined using **vlan access-map** <*word*> command

- In this mode, a match for IP Access-lists is specified using **match ip address** command. This will filter the traffic based on L3/L4 fields specified in the IP ACL. Match for IPv6 access lists can be configured using **match ipv6 address** command. This will filter traffic based on L3/L4 fields specified in IPv6 ACL
- A match for MAC Access-lists is specified using **match mac address** command. This will filter the traffic based on L2 fields specified in the MAC ACL.
- Each VLAN map sequence has an action forward or drop specified which specifies what should happen when the traffic matches a specified match criteria in the VLAN map.

Defining a VLAN Access Map

To define a VLAN access map, perform this task:

Command	Purpose
Router(config)# **vlan access-map** *map_name* [**0-65535**]	Defines the VLAN access map. Optionally, you can specify the VLAN access map sequence number.
Router(config)# **no vlan access-map** *map_name* **0-65535**	Deletes a map sequence from the VLAN access map.
Router(config)# **no vlan access-map** *map_name*	Deletes the VLAN access map.

When defining a VLAN access map, note the following information:

- To insert or modify an entry, specify the map sequence number.
- If you do not specify the map sequence number, a number is automatically assigned.
- You can specify only one match clause and one action clause per map sequence.
- Use the **no** keyword with a sequence number to remove a map sequence.
- Use the **no** keyword without a sequence number to remove the map.

Configuring a Match Clause in a VLAN Access Map Sequence

To configure a match clause in a VLAN access map sequence, perform this task:

Command	Purpose
Router (config-access-map)# **match** {**ip address** {**1-199** | **1300-2699** | *acl_name*}| {**mac address** *acl_name*}}	Configures the match clause in a VLAN access map sequence.
Router (config-access-map)# **no match** {**ip address** {**1-199** | **1300-2699** | *acl_name*}| {**mac address** *acl_name*}}	Deletes the match clause in a VLAN access map sequence.

When configuring a match clause in a VLAN access map sequence, note the following information:

- You can select one or more ACLs.

- Use the **no** keyword to remove a match clause or specified ACLs in the clause.

Configuring an Action Clause in a VLAN Access Map Sequence

To configure an action clause in a VLAN access map sequence, perform this task:

Command	Purpose
Router (config-access-map)# **action** {**drop** [**log**]} | {**forward** [**capture** | **vlan** *vlan_ID*]} | {**redirect** {{**ethernet** | **fastethernet** | **gigabitethernet** | **tengigabitethernet**} *slot/port*} | {*port-channel channel_id*}}	Configures the action clause in a VLAN access map sequence.
Router (config-access-map)# **no action** {**drop** [**log**]} | {**forward** [**capture** | **vlan** *vlan_ID*]} | {**redirect** {{**ethernet** | **fastethernet** | **gigabitethernet** | **tengigabitethernet**} *slot/port*} | {*port-channel channel_id*}}	Deletes the action clause in from the VLAN access map sequence.

Applying a VLAN Access Map

To apply a VLAN access map, perform this task:

Command	Purpose
Router(config)# **vlan filter** *map_name* {**vlan-list** *vlan_list* | interface *type number*}	Applies the VLAN access map to the specified VLANs or WAN interfaces.

Verifying VLAN Access Map Configuration


To verify VLAN access map configuration, perform this task:

Command	Purpose
Router# **show vlan access-map** [*map_name*]	Verifies VLAN access map configuration by displaying the content of a VLAN access map.
Router# **show vlan filter** [**access-map** *map_name* | **vlan** *vlan_id* | **interface** *type number*]	Verifies VLAN access map configuration by displaying the mappings between VACLs and VLANs.
Router# **show platform software fed 0/1 acl info**	Verifies that VACL is installed correctly.
Router# **show platform software fed 0/1 acl cam**	Verifies that VACL is installed correctly on TCAM.

Debugging VACLs

To enable debugs for ACl/VACL, perform this task:

Command	Purpose
Router# **set platform software trace fed 0/1 acl** <*level*>	Enable debug for FED ACL.
Router# **set platform software trace forwarding-manager RP/FP active vlan-acl** <*level*>	Enable debug for Forward-mgr VACL.



CHAPTER 21

Configuring MACsec

This section describes how to configure MACsec on Cisco IR8340 Routers.

- MACsec Encryption Overview, on page 239
- Limitations and Restrictions, on page 239
- Media Access Control Security and MACsec Key Agreement, on page 240
- Configuring MACsec Encryption, on page 241

MACsec Encryption Overview

MACsec is the IEEE 802.1AE standard for authenticating and encrypting packets between two MACsec-capable devices. Cisco IR8340 Router supports 802.1AE encryption with MACsec Key Agreement (MKA) on switch-to-host links for encryption between the switch and host device. IR8340 also supports MACsec encryption for switch-to-switch (inter-network device) security using MKA-based key exchange protocol.

Note HSEC license is required to configure MACsec encryption.

Table 18: MACsec Support on Switch Ports

Connections	MACsec support
Switch-to-host	MACsec MKA encryption
Switch-to-switch	MACsec MKA encryption

MKA is supported on switch-to-host facing links. Host-facing links typically use flexible authentication ordering for handling heterogeneous devices with or without IEEE 802.1x, and can optionally use MKA-based MACsec encryption.

Limitations and Restrictions

- MACsec configuration is not supported on EtherChannel ports. Instead, MACsec configuration can be applied/removed on the individual member ports of an EtherChannel. To add/remove MACsec configuration, you must first unbundle the member ports from the EtherChannel.

- Configure either MACsec or PRP/HSR on the ports.
- Until PCH is available, MACsec and PTP are mutually exclusive.
- Packet number based rekey is not supported.
- Certificate based MKA (switch to switch) is not supported.
- VLAN Tag-in-clear is not supported.
- Legacy Cisco SAP (switch to switch) is not supported.
- Extended Packet Numbering (XPN) is not supported.

Media Access Control Security and MACsec Key Agreement

MACsec, defined in 802.1AE, provides MAC-layer encryption over wired networks by using out-of-band methods for encryption keying. The MACsec Key Agreement (MKA) Protocol provides the required session keys and manages the required encryption keys. MKA and MACsec are implemented after successful authentication using certificate-based MACsec or Pre Shared Key (PSK) framework.

A device using MACsec accepts either MACsec or non-MACsec frames, depending on the policy associated with the MKA peer. MACsec frames are encrypted and protected with an integrity check value (ICV). When the device receives frames from the MKA peer, it decrypts them and calculates the correct ICV by using session keys provided by MKA. The device compares that ICV to the ICV within the frame. If they are not identical, the frame is dropped. The device also encrypts and adds an ICV to any frames sent over the secured port (the access point used to provide the secure MAC service to a MKA peer) using the current session key.

The MKA Protocol manages the encryption keys used by the underlying MACsec protocol. The basic requirements of MKA are defined in 802.1x-REV. The MKA Protocol extends 802.1x to allow peer discovery with confirmation of mutual authentication and sharing of MACsec secret keys to protect data exchanged by the peers.

The EAP framework implements MKA as a newly defined EAP-over-LAN (EAPOL) packet. EAP authentication produces a master session key (MSK) shared by both partners in the data exchange. Entering the EAP session ID generates a secure connectivity association key name (CKN). The device acts as the key server for both uplink and downlink; and acts as the authenticator for downlink. It generates a random secure association key (SAK), which is sent to the client partner. The client is never a key server and can only interact with a single MKA entity, the key server. After key derivation and generation, the device sends periodic transports to the partner at a default interval of 2 seconds.

The packet body in an EAPOL Protocol Data Unit (PDU) is referred to as a MACsec Key Agreement PDU (MKPDU). MKA sessions and participants are deleted when the MKA lifetime (6 seconds) passes with no MKPDU received from a participant. For example, if a MKA peer disconnects, the participant on the device continues to operate MKA until 6 seconds have elapsed after the last MKPDU is received from the MKA peer.



Note Integrity check value (ICV) indicator in MKPDU is optional. ICV is not optional when the traffic is encrypted.

EAPoL Announcements indicate the use of the type of keying material. The announcements can be used to announce the capability of the supplicant as well as the authenticator. Based on the capability of each side, the largest common denominator of the keying material could be used.

Configuring MACsec Encryption

Configuring MKA and MACsec

MACsec is disabled by default. No MKA policies are configured.

Configuring an MKA Policy

Follow these steps to configure an MKA policy.



Note After changing any MKA policy or MACsec configuration for active sessions, execute the **shutdown** command, and then the **no shutdown** command on a port, so that the changes are applied to active sessions.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**mka policy** *policy name* **Example:** `Router(config)# mka policy mka_policy`	Identifies an MKA policy, and enters MKA policy configuration mode. The maximum policy name length is 16 characters. **Note** The default MACsec cipher suite in the MKA policy will always be GCM-AES-128.
Step 4	**macsec-cipher-suite** {**gcm-aes-128** | **gcm-aes-256**} **Example:** `Router(config-mka-policy)# macsec-cipher-suite gcm-aes-128`	Configures a cipher suite for deriving SAK with 128-bit or 256-bit encryption.
Step 5	**end** **Example:** `Router(config-mka-policy)# end`	Exit enters MKA policy configuration mode and returns to privileged EXEC mode.

	Command or Action	Purpose
Step 6	**show mka policy** **Example:** `Router# show mka policy`	Displays MKA policy configuration information.

Configuring MACsec MKA using PSK

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**key chain** *key-chain-name* **macsec** **Example:** `Router(config)# key chain keychain1 macsec`	Configures a key chain and enters the key chain configuration mode.
Step 4	**key** *hex string* **Example:** `Router(config-key-chain)# key 1000`	Configures a unique identifier for each key in the keychain and enters the keychain's key configuration mode. **Note** For 128-bit encryption, use any value between 1 and 32 hex digit key-string. For 256-bit encryption, use 64 hex digit key-string.
Step 5	**cryptographic-algorithm** {**aes-128-cmac** | **aes-256-cmac**} **Example:** `Device(config-key-chain)# cryptographic-algorithm aes-128-cmac`	Set cryptographic authentication algorithm with 128-bit or 256-bit encryption.
Step 6	**key-string** { [**0**|**6**|**7**] *pwd-string* | *pwd-string*} **Example:** `Device(config-key-chain)# key-string 12345678901234567890123456789012`	Sets the password for a key string. Only hex characters must be entered.
Step 7	**end** **Example:** `Router(config-key-chain)# end`	Exits key chain configuration mode and returns to privileged EXEC mode.

Configuring MACsec MKA on an Interface using PSK

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**interface** *interface-id* **Example:** `Router(config)# interface GigabitEthernet 0/1/4`	Enters interface configuration mode.
Step 4	**switchport mode access** **Example:** `Router(config-if)# switchport mode access`	Sets the switchport mode to access.
Step 5	**switchport access vlan** *vlan-id* **Example:** `Router(config-if)# switchport access vlan 203`	Specifies the VLAN for which this access port will carry traffic.
Step 6	**macsec network-link** **Example:** `Router(config-if)# macsec network-link`	Enables MACsec on the interface.
Step 7	**mka policy** *policy name* **Example:** `Router(config-if)# mka policy MKA_128`	Configures an MKA policy.
Step 8	**mka pre-shared-key key-chain** *key-chain-name* **Example:** `Router(config-if)# mka pre-shared-key key-chain KEY128`	Configures an MKA pre-shared-key key-chain name. **Note** The MKA pre-shared key can be configured on either physical interface or sub-interfaces and not on both.
Step 9	**end** **Example:** `Router(config-if)# end`	Exits interface configuration mode and returns to privileged EXEC mode.

Example: Sample Configuration of Switch-to-Switch MACsec

This section shows sample configuration of switch-to-switch MACsec.

Device 1 Configuration

```
configure terminal
mka policy MKA_128
macsec-cipher-suite gcm-aes-128
key chain KEY128 macsec
key 1111
cryptographic-algorithm aes-128-cmac
key-string 11111111111111111111111111111111
end

configure terminal
interface Vlan203
ip address 22.1.1.1 255.255.255.0
end

configure terminal
interface GigabitEthernet0/1/4
switchport mode access
switchport access vlan 203
mka policy MKA_128
mka pre-shared-key key-chain KEY128
macsec network-link
no shutdown
end
```

Device 2 Configuration

```
configure terminal
mka policy MKA_128
macsec-cipher-suite gcm-aes-128
key chain KEY128 macsec
key 1111
cryptographic-algorithm aes-128-cmac
key-string 11111111111111111111111111111111
end

configure terminal
interface Vlan203
ip address 22.1.1.2 255.255.255.0
end

configure terminal
interface GigabitEthernet0/1/4
switchport mode access
switchport access vlan 203
mka policy MKA_128
mka pre-shared-key key-chain KEY128
macsec network-link
no shutdown
end
```

Example: Sample Configuration of Switch-to-Host MACsec

This section shows sample configuration of switch-to-host MACsec.

```
aaa new-model
!
!
```

```
aaa authentication dot1x default group radius
aaa authorization network default group radius
aaa authorization auth-proxy default group radius
aaa accounting network default start-stop group radius
aaa accounting system default start-stop group radius
!
!
aaa server radius dynamic-author
client <radius-server ip> server-key <key>
port 3799
!
aaa session-id common
!
!
ip dhcp-server 17.0.0.1
!
ip dhcp pool VLAN17
network 17.0.0.0 255.255.255.0
default-router 17.0.0.1
!
!
device-tracking policy DEVICE_MACSEC
no protocol udp
tracking enable
!
authentication critical recovery delay 300
!
service-template DEFAULT_LINKSEC_POLICY_MUST_SECURE
linksec policy must-secure
!
dot1x system-auth-control
!
class-map type control subscriber match-all DOT1X
match method dot1x
!
class-map type control subscriber match-all DOT1X_FAILED
match method dot1x
match result-type method dot1x authoritative
!
class-map type control subscriber match-all DOT1X_MEDIUM_PRIO
match authorizing-method-priority gt 20
!
class-map type control subscriber match-all DOT1X_NO_RESP
match method dot1x
match result-type method dot1x agent-not-found
!
class-map type control subscriber match-all DOT1X_TIMEOUT
match method dot1x
match result-type method dot1x method-timeout
!
class-map type control subscriber match-all LINKSEC_FAIL_DOT1X
match authorization-fail linksec-failed
match method dot1x
!
class-map type control subscriber match-all LINKSEC_FAIL_MAB
match authorization-fail linksec-failed
match method mab
!
class-map type control subscriber match-all MAB_FAILED
match method mab
match result-type method mab authoritative
!

policy-map type control subscriber POLICY_MUSTSECURE
```

```
event session-started match-all
10 class always do-until-failure
10 authenticate using dot1x priority 10
event authentication-failure match-first
5 class DOT1X_FAILED do-until-failure
10 terminate dot1x
20 authenticate using mab priority 20
10 class DOT1X_NO_RESP do-until-failure
10 terminate dot1x
20 authenticate using mab priority 20
20 class MAB_FAILED do-until-failure
10 terminate mab
20 authentication-restart 60
40 class always do-until-failure
10 terminate dot1x
20 terminate mab
30 authentication-restart 60
event agent-found match-all
10 class always do-until-failure
10 terminate mab
20 authenticate using dot1x priority 10
event authentication-success match-all
10 class always do-until-failure
10 activate service-template DEFAULT_LINKSEC_POLICY_MUST_SECURE
!
interface GigabitEthernet0/1/1
switchport access vlan 17
switchport mode access
device-tracking attach-policy DEVICE_MACSEC
macsec
access-session host-mode multi-host
access-session closed
access-session port-control auto
dot1x pae authenticator
service-policy type control subscriber POLICY_SHOULDSECURE
!
!
radius-server attribute 8 include-in-access-req
radius-server dead-criteria time 20 tries 2
radius-server timeout 20
radius-server deadtime 5
radius-server key <radius key>

radius server ACS
address ipv4 <radius-server ip> auth-port 1812 acct-port 1813
!
```

Verifying the Configuration

Use the following command to display MKA sessions on the interface:

```
# show mka sessions interface GigabitEthernet0/1/4

Summary of All Currently Active MKA Sessions on Interface GigabitEthernet0/1/4...

===============================================================================================
Interface      Local-TxSCI         Policy-Name      Inherited         Key-Server
Port-ID        Peer-RxSCI          MACsec-Peers     Status            CKN
===============================================================================================
Gi0/1/4        b08b.d071.86ac/000e POLICY           NO                YES
14             b08b.d071.86ac/0000 0                Init              1000
```

Use the following command to display MACsec status on the interface:

```
# show macsec status interface GigabitEthernet0/1/5
 MACsec is enabled
  Replay protect : enabled
  Replay window : 0
  Include SCI : yes
  Use ES Enable : no
  Use SCB Enable : no
  Admin Pt2Pt MAC : forceTrue(1)
  Pt2Pt MAC Operational : no
  Cipher : GCM-AES-128
  Confidentiality Offset : 0

 Capabilities
  ICV length : 16
  Data length change supported: yes
  Max. Rx SA : 16
  Max. Tx SA : 16
  Max. Rx SC : 8
  Max. Tx SC : 8
  Validate Frames : strict
  PN threshold notification support : Yes
  Ciphers supported : GCM-AES-128
                      GCM-AES-256
```

Use the following command to display MACsec statistics on the interface:

```
# show macsec statistics interface GigabitEthernet0/1/5
 Transmit Secure Channels
  SCI : B08BD07186AD000F
  SC state : inUse(1)
   Elapsed time : 00:00:18
   Start time : 7w0d
   Current AN: 0
   Previous AN: -
   Next PN: 14
   SA State: inUse(1)
   Confidentiality : yes
   SAK Unchanged : yes
   SA Create time : 00:11:21
   SA Start time : 7w0d
   SC Statistics
    Auth-only Pkts : 0
    Auth-only Bytes : 0
    Encrypt Pkts : 0
    Encrypt Bytes : 0
   SA Statistics
    Auth-only Pkts : 0
    Encrypt Pkts : 13

  Port Statistics
   Egress untag pkts  0
   Egress long pkts  0

 Receive Secure Channels
  SCI : 0C75BDCC84A40007
  SC state : inUse(1)
   Elapsed time : 00:00:18
   Start time : 7w0d
   Current AN: 0
   Previous AN: -
   Next PN: 23
   RX SA Count: 0
   SA State: inUse(1)
```

```
  SAK Unchanged : yes
  SA Create time : 00:11:19
  SA Start time : 7w0d
  SC Statistics
   Notvalid pkts 0
   Invalid pkts 0
   Valid pkts 0
   Valid bytes 0
   Late pkts 0
   Uncheck pkts 0
   Delay pkts 0
   UnusedSA pkts 0
   NousingSA pkts 0
   Decrypt bytes 0
  SA Statistics
   Notvalid pkts 0
   Invalid pkts 0
   Valid pkts 21
   UnusedSA pkts 0
   NousingSA pkts 0

 Port Statistics
  Ingress untag pkts  0
  Ingress notag pkts  9
  Ingress badtag pkts  0
  Ingress unknownSCI pkts  0
  Ingress noSCI pkts  0
  Ingress overrun pkts  0
```

Use the following command to display detailed status for MKA session:

```
# show mka session interface GigabitEthernet0/1/5 detail

MKA Detailed Status for MKA Session
===================================
Status: SECURED - Secured MKA Session with MACsec

Local Tx-SCI.............. b08b.d071.86ad/000f
Interface MAC Address.... b08b.d071.86ad
MKA Port Identifier...... 15
Interface Name........... GigabitEthernet0/1/5
Audit Session ID.........
CAK Name (CKN)........... 1111
Member Identifier (MI)... CBA23DA1D3D77DF725CD43BB
Message Number (MN)...... 10
EAP Role................. NA
Key Server............... NO
MKA Cipher Suite......... AES-128-CMAC

Latest SAK Status........ Rx & Tx
Latest SAK AN............ 0
Latest SAK KI (KN)....... AD657F4EB0D237F5AFF9186F00000001 (1)
Old SAK Status........... FIRST-SAK
Old SAK AN............... 0
Old SAK KI (KN).......... FIRST-SAK (0)

SAK Transmit Wait Time... 0s (Not waiting for any peers to respond)
SAK Retire Time.......... 0s (No Old SAK to retire)
SAK Rekey Time........... 0s (SAK Rekey interval not applicable)

MKA Policy Name.......... Policy_128
Key Server Priority...... 0
Delay Protection......... NO
Delay Protection Timer.......... 0s (Not enabled)
```


```
Confidentiality Offset... 0
Algorithm Agility........ 80C201
SAK Rekey On Live Peer Loss........ NO
Send Secure Announcement.. DISABLED
SCI Based SSCI Computation.... NO
SAK Cipher Suite......... 0080C20001000001 (GCM-AES-128)
MACsec Capability........ 3 (MACsec Integrity, Confidentiality, & Offset)
MACsec Desired........... YES

# of MACsec Capable Live Peers............ 1
# of MACsec Capable Live Peers Responded.. 0

Live Peers List:
  MI                       MN          Rx-SCI (Peer)        KS        RxSA          SSCI
                                                            Priority  Installed
  ------------------------------------------------------------------------------------
  AD657F4EB0D237F5AFF9186F  8          0c75.bdcc.84a4/0007  0         YES            0

Potential Peers List:
  MI                       MN          Rx-SCI (Peer)        KS        RxSA          SSCI
                                                            Priority  Installed
  ------------------------------------------------------------------------------------

Dormant Peers List:
  MI                       MN          Rx-SCI (Peer)        KS        RxSA          SSCI
                                                            Priority  Installed
  ------------------------------------------------------------------------------------
```



CHAPTER 22

WAN MACSEC and MKA Support Enhancements

The WAN MACsec and MKA feature introduces MACsec support on WAN, and uplink support and Pre-shared key support for the Macsec Key Agreement protocol (MKA).

- MACsec and MKA Overview, on page 251
- Benefits of WAN MACsec and MKA Support Enhancements, on page 252
- Best Practices for Implementing WAN MACsec and MKA Support Enhancements, on page 252
- MKA Policy Inheritance, on page 253
- Key Lifetime and Hitless Key Rollover, on page 253
- Encryption Algorithms for Protocol Packets, on page 253
- Access Control Option for Smoother Migration, on page 254
- Extensible Authentication Protocol over LAN Destination Address, on page 254
- How to Configure WAN MACsec and MKA Support Enhancements, on page 255

MACsec and MKA Overview

MACsec is an IEEE 802.1AE standards based Layer 2 hop-by-hop encryption that provides data confidentiality and integrity for media access independent protocols.

MACsec, provides MAC-layer encryption over wired networks by using out-of-band methods for encryption keying. The MACsec Key Agreement (MKA) Protocol provides the required session keys and manages the required encryption keys. Only host facing links (links between network access devices and endpoint devices such as a PC or IP phone) can be secured using MACsec.

The 802.1AE encryption with MACsec Key Agreement (MKA) is supported on downlink ports for encryption between the routers or switches and host devices.

MACsec encrypts the entire data except for the Source and Destination MAC addresses of an Ethernet packet.

To provide MACsec services over the WAN, service providers offer Layer 2 transparent services such as E-Line or E-LAN using various transport layer protocols such as Ethernet over Multiprotocol Label Switching (EoMPLS) and L2TPv3.

The packet body in an EAP-over-LAN (EAPOL) Protocol Data Unit (PDU) is referred to as a MACsec Key Agreement PDU (MKPDU). When no MKPDU is received from a participants after 3 hearbeats (each hearbeat is of 2 seconds), peers are deleted from the live peer list For example, if a client disconnects, the participant on the switch continues to operate MKA until 3 heartbeats have elapsed after the last MKPDU is received from the client.

The MKA feature support provides tunneling information such as VLAN tag (802.1Q tag) in the clear so that the service provider can provide service multiplexing such that multiple point to point or multipoint services can co-exist on a single physical interface and differentiated based on the now visible VLAN ID.

In addition to service multiplexing, VLAN tag in the clear also enables service providers to provide quality of service (QoS) to the encrypted Ethernet packet across the SP network based on the 802.1P (CoS) field that is now visible as part of the 802.1Q tag.

Benefits of WAN MACsec and MKA Support Enhancements

- Support for Point-to-point (P2P) deployment models.
- Support for Point-to-Multipoint (P2MP) deployment models.
- Support for multiple P2P and P2MP deployments on the same physical interface.
- Support for 128- and 256-bit Advanced Encryption Standard–Galois Counter Mode (AES-GCM) encryption for data packets.
- Support for 128- and 256-bit Advanced Encryption Standard-Cipher-based Message Authentication Code (AEC-CMAC) encryption for control packets.
- Support for VLAN tag in the clear option to enable Carrier Ethernet Service Multiplexing.
- Support for coexisting of MACsec and Non-MACsec subinterfaces.
- Support for configurable Extensible Authentication Protocol over LAN (EAPoL) destination address.
- Support for configurable option to change the EAPoL Ethernet type.
- Support for configurable replay protection window size to accommodate packet reordering in the service provider network.

Best Practices for Implementing WAN MACsec and MKA Support Enhancements

- Ensure basic Layer 2 Ethernet connectivity is established and verified before attempting to enable MACsec. Basic ping between the customer edge devices must work.
- When you are configuring WAN MACsec for the first time, ensure that you have out of band connectivity to the remote site to avoid locking yourself out after enabling MACsec, if the session fails to establish.
- We recommend that you configure the **access-control should-secure** command while enabling MACsec for the first time and subsequently remove the command to change to default **access-control must-secure** , once the session establishment is successful, unless it is needed for migration.
- We recommend that you configure an interface MTU, adjusting it for MACsec overhead, for example, 32 bytes. Although MACsec encryption and decryption occurs at the physical level and MTU is size does not effect the source or destination router, it may effect the intermediate service provider router. Configuring an MTU value at the interface allows for MTU negotiation that includes MACsec overhead.

MKA Policy Inheritance

On WAN routers, MKA policy is inherited and also it has a default value. When a new session is started, the following rules apply:

- If an MKA policy is configured on a subinterface, it will be applied when an MKA session is started.
- If an MKA policy is not configured on a subinterface, a policy that is configured on the physical interface is be applied at session start.
- If a MKA policy is not configured on a subinterface or physical interface, default policy is applied at session start.

Key Lifetime and Hitless Key Rollover

A MACsec key chain can have multiple pre-shared keys (PSK) each configured with a key id and an optional lifetime. A key lifetime specifies at which time the key expires. In the absence of a lifetime configuration, the default lifetime is unlimited. When a lifetime is configured, MKA rolls over to the next configured pre-shared key in the key chain after the lifetime is expired. Time zone of the key can be local or UTC. Default time zone is UTC.

Use the **key chain** *name* **macsec** to configure the MACsec key chain.

You can Key rolls over to the next key within the same key chain by configuring a second key in the key chain and configuring a lifetime for the first key. When the lifetime of the first key expires, it automatically rolls over to the next key in the list. If the same key is configured on both sides of the link at the same time, then the key rollover is hitless, that is, key rolls over without traffic interruption.

Note The lifetime of the keys need to be overlapped in order to achieve hitless key rollover.

Encryption Algorithms for Protocol Packets

Cryptographic Algorithm selection for MKA control protocol packets encryption is as follows:

- Cryptographic Algorithm to encrypt MKA control protocol packets is configured as part of the key chain. There can be only one cryptographic algorithm configured per key chain.
- A key server uses the configured MKA cryptographic algorithm from the key chain that is used.
- All nonkey servers must use the same cryptographic algorithm as the key server.

If an MKA cryptographic algorithm is not configured, a default cryptographic algorithm of AES-CMAC-128 (Cipher-based Message Authentication Code with 128-bit Advanced Encryption Standard) is used.

Encryption algorithm for Data packets:

```
mka policy p1
macsec-cipher-suite [gcm-aes-128 | gcm-aes-256
```

Encryption algorithm for MKA Control packets

```
key chain <name> macsec
key 01
key-string <Hex string>
cryptographic-algorithm [aes-256-cmac  | aes-128-cmac]
```

It is recommended to change data packets cipher suite in the key server for the cipher suite rollover to be seamless, if the nonkey servers have the same cipher-suite configured in the list or is with default configuration.

Access Control Option for Smoother Migration

When MACsec is enabled on an interface, the entire interface traffic is secured, by default. MACsec does not allow any unencrypted packets to be transmitted or received from the same physical interface. However, to enable MACsec on selected subinterfaces, an additional Cisco proprietary extension has been implemented to allow unencrypted packets to be transmitted or received from the same physical interface.

Use the **macsec access-control** {**must-secure** | **should-secure**} command to control the behavior of unencrypted packets.

- The **should-secure** keyword allows unencrypted packets from the physical interface or subinterfaces to be transmitted or received.
- The **must-secure** keyword does not allow unencrypted packets from physical interface or subinterfaces to be transmitted or received. All such packets are dropped except for MKA control protocol packets
- If MACsec is enabled only on selected subinterfaces, configure the **should-secure** keyword option on the corresponding interface.

The default configuration for MACsec on subinterfaces is **macsec access-control must-secure** . This option is enabled by default when the **macsec** command is configured on an interface.

Note The **macsec access-control should-secure** command can be configured only at the interface level and not the subinterface. Configuring this command allows unencrypted traffic on a secured MACsec session.

Note For non-MACsec subinterface, you must configure the **should-secure** option for traffic to pass.

Extensible Authentication Protocol over LAN Destination Address

Before establishing a MACsec secure session, MKA (MACsec Key Agreement) is used as the control protocol. MKA selects the cipher suite to be used for encryption and to exchange the required keys and parameters between peers.

MKA uses Extensible Authentication Protocol over LAN (EAPoL) as the transport protocol to transmit MKA messages. By default, EAPoL uses a destination multicast MAC address of 01:80:c2:00:00:03 to multicast packets to multiple destinations. EAPoL is a standards-based protocol and other authentication mechanisms

such as IEEE 802.1X also use the same protocol. Devices in the service provider cloud might consume this packet (based on the destination multicast MAC address), and try to process the EAPoL packet and eventually drop the packet. This causes MKA session to fail.

Use the **eapol destination-address** command to change the destination MAC address of an EAPoL packet that is transmitted on an interface towards the service provider. This ensures that the service provider tunnels the packet like any other data packet instead of consuming them.

Note The EAPoL destination address can be configured independently on either physical or subinterface level. If it is configured on the physical interface, it is automatically inherited by the subinterfaces. Explicit configuration on the subinterface overrides the inherited value or policy for that subinterface.

Replay Protection Window Size

Replay protection is a feature provided by MACsec to counter replay attacks. Each encrypted packet is assigned a unique sequence number and the sequence is verified at the remote end. Frames transmitted through a Metro Ethernet service provider network are highly susceptible to reordering due to prioritization and load balancing mechanisms used within the network.

A replay window is necessary to support use of MACsec over provider networks that reorder frames. Frames within the window can be received out of order, but are not replay protected. The default window size is set to 64. Use the **macsec replay-protection window-size** command to change the replay window size. The range for window size is 0 to 4294967295.

The replay protection window may be set to zero to enforce strict reception ordering and replay protection.

Note A replay protection window can be configured independently on either physical interface or subinterface. If it is configured on the physical interface, it is automatically inherited by the subinterfaces. Explicit configuration on subinterface overrides the inherited value or policy for that sub-interface.

How to Configure WAN MACsec and MKA Support Enhancements

Configuring MKA

The MACsec Key Agreement (MKA) enables configuration and control of keying parameters. Perform the following task to configure MKA.

Procedure

	Command or Action	Purpose
Step 1	**enable**	Enables privileged EXEC mode.

	Command or Action	Purpose
	Example: `Router> enable`	• Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**mka policy** *policy-name* **Example:** `Router(config)# mka policy MKAPolicy`	Configures an MKA policy.
Step 4	**include-icv-indicator** **Example:** `Device(config-mka-policy)# include-icv-indicator`	(Optional) Includes ICV indicator in MKPDU.
Step 5	**key-server priority** *key-server-priority* **Example:** `Router(config-mka-policy)# key-server priority 200`	(Optional) Configures MKA key server priority.
Step 6	**macsec-cipher-suite {gcm-aes-128 | gcm-aes-256}** **Example:** `Router(config-mka-policy)# macsec-cipher-suite gcm-aes-128 gcm-aes-256`	(Optional) Configures cipher suite(s) for secure association key (SAK) derivation. Each of the cipher suite options can be repeated only once, but they can be used in any order.
Step 7	**sak-rekey interval** *interval* **Example:** `Device(config-mka-policy)# sak-rekey interval 30`	(Optional) Sets the SAK rekey interval (in seconds). The range is from 30 to 65535, and the default value is 0. The SAK rekey timer does not start by default until it is configured. • To stop the SAK rekey timer, use the **no sak-rekey interval** command under the defined MKA policy.
Step 8	**confidentiality-offset** *value* **Example:** `Router(config-mka-policy)# confidentiality-offset 30`	(Optional) Configures confidentiality offset for MACsec operation.
Step 9	**end** **Example:** `Router(config-mka-policy)# end`	Returns to privileged EXEC mode.

Configuring MKA Pre-Shared Key

Perform the following task to configure MACsec Key Agreement (MKA) pre-shared key.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**Key chain** *key-chain-name* [**macsec**] **Example:** `Router(config)# Key chain keychain1 macsec`	Configures a key chain and enters keychain configuration mode.
Step 4	**key** *hex string* **Example:** `Router(config-keychain)# key 9ABCD`	Configures a key and enters keychain key configuration mode.
Step 5	**cryptographic-algorithm** {**gcm-aes-128** | **gcm-aes-256**} **Example:** `Router(config-keychain-key)# cryptographic-algorithm gcm-aes-128`	Set cryptographic authentication algorithm.
Step 6	**key-string** {[**0** | **6**] *pwd-string* | **7** | *pwd-string*} **Example:** `Router(config-keychain-key)# key-string 0 pwd`	Sets the password for a key string.
Step 7	**lifetime local** {{*day month year* **duration** *seconds*} **Example:** `Device(config-keychain-key)# lifetime local 16:00:00 Nov 9 2014 duration 6000`	Sets the lifetime for a key string. The range you can specify for the duration is between 1 and 864000 seconds.
Step 8	**end** **Example:** `Router(config-keychain-key)# end`	Returns to privileged EXEC mode.

Configuring an Option to Change the EAPoL Ethernet Type

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**interface** *type number* **Example:** `Router(config)# interface GigabitEthernet 0/0/1`	Enters interface configuration mode.
Step 4	**eapol** *eth-type* **Example:** `Router(config-if)# eapol eth-type 876F`	Configures an ethernet type (Hexadecimal) for the EAPoL Frame on the interface.
Step 5	**exit** **Example:** `Router(config-if)# exit`	Exits interface configuration mode and returns to global configuration mode.

Sample Configuration for Point-to-Point WAN MACsec

Example: Port Based WAN MACsec

Device1:

```
configure terminal
    key chain test128 macsec
    key 1111
   cryptographic-algorithm aes-128-cmac
   key-string 11111111111111111111111111111111
   exit

   mka policy test
   macsec-cipher-suite gcm-aes-128 gcm-aes-256
   exit

   interface GigabitEthernet0/0/0
   ip address 1.1.1.1 255.255.255.0
   mka policy test
   mka pre-shared-key key-chain test128
   macsec
   exit
```

Device2:

```
configure terminal
    key chain test128 macsec
    key 1111
   cryptographic-algorithm aes-128-cmac
   key-string 11111111111111111111111111111111
   exit

   mka policy test
   macsec-cipher-suite gcm-aes-128 gcm-aes-256
   exit

   interface GigabitEthernet0/0/0
   ip address 1.1.1.2 255.255.255.0
   mka policy test
   mka pre-shared-key key-chain test128
   macsec
   exit
```

Example: VLAN Based WAN MACsec

Device1:

```
configure terminal
    key chain test128 macsec
    key 1111
   cryptographic-algorithm aes-128-cmac
   key-string 11111111111111111111111111111111
   exit

   mka policy test
   macsec-cipher-suite gcm-aes-128 gcm-aes-256
   exit

   interface GigabitEthernet0/0/0
   eapol destination-address broadcast-address
   mka policy test
   macsec dot1q-in-clear 1

   interface GigabitEthernet0/0/0.1
   encapsulation dot1q 10
   ip address 1.1.1.1 255.255.255.0
   mka pre-shared-key key-chain test128
    macsec
    exit
```

Device2:

```
configure terminal
    key chain test128 macsec
    key 1111
   cryptographic-algorithm aes-128-cmac
   key-string 11111111111111111111111111111111
   exit

   mka policy test
   macsec-cipher-suite gcm-aes-128 gcm-aes-256
   exit

   interface GigabitEthernet0/0/0
   eapol destination-address broadcast-address
   mka policy test
```

```
macsec dot1q-in-clear 1

interface GigabitEthernet0/0/0.1
encapsulation dot1q 10
ip address 1.1.1.2 255.255.255.0
mka pre-shared-key key-chain test128
macsec
exit
```

Sample Show Command Output for Port Based WAN MACsec

```
#show mka sessions

Total MKA Sessions....... 1
      Secured Sessions... 1
      Pending Sessions... 0

=============================================================================================
Interface       Local-TxSCI          Policy-Name       Inherited          Key-Server

Port-ID         Peer-RxSCI           MACsec-Peers      Status             CKN

=============================================================================================
Gi0/0/0         b08b.d071.86a0/0007  test              NO                 YES

7               b08b.d079.8a10/0007  1                 Secured            1111



#show mka sessions detail

MKA Detailed Status for MKA Session
===================================
Status: SECURED - Secured MKA Session with MACsec

Local Tx-SCI.............. b08b.d071.86a0/0007
Interface MAC Address.... b08b.d071.86a0
MKA Port Identifier...... 7
Interface Name........... GigabitEthernet0/0/0
Audit Session ID.........
CAK Name (CKN)........... 1111
Member Identifier (MI)... 58D1ED5150ED8811970C4DB9
Message Number (MN)...... 18
EAP Role................. NA
Key Server............... YES
MKA Cipher Suite......... AES-128-CMAC

Latest SAK Status........ Rx & Tx
Latest SAK AN............ 0
Latest SAK KI (KN)....... 58D1ED5150ED8811970C4DB900000001 (1)
Old SAK Status........... FIRST-SAK
Old SAK AN............... 0
Old SAK KI (KN).......... FIRST-SAK (0)

SAK Transmit Wait Time... 0s (Not waiting for any peers to respond)
SAK Retire Time.......... 0s (No Old SAK to retire)
SAK Rekey Time........... 0s (SAK Rekey interval not applicable)

MKA Policy Name.......... test
Key Server Priority...... 0
Delay Protection......... NO
Delay Protection Timer.......... 0s (Not enabled)
```

```
Confidentiality Offset... 0
Algorithm Agility........ 80C201
SAK Rekey On Live Peer Loss........ NO
Send Secure Announcement.. DISABLED
SCI Based SSCI Computation.... NO
SAK Cipher Suite......... 0080C20001000001 (GCM-AES-128)
MACsec Capability........ 3 (MACsec Integrity, Confidentiality, & Offset)
MACsec Desired........... YES

# of MACsec Capable Live Peers............ 1
# of MACsec Capable Live Peers Responded.. 1

Live Peers List:
  MI                        MN          Rx-SCI (Peer)        KS        RxSA          SSCI
                                                             Priority  Installed
  ------------------------------------------------------------------------------------------
  5225C3DE8DD5F35A3B55830C  53          b08b.d079.8a10/0007  0         YES            0

Potential Peers List:
  MI                        MN          Rx-SCI (Peer)        KS        RxSA          SSCI
                                                             Priority  Installed
  ------------------------------------------------------------------------------------------

Dormant Peers List:
  MI                        MN          Rx-SCI (Peer)        KS        RxSA          SSCI
                                                             Priority  Installed
  ------------------------------------------------------------------------------------------
```

```
#show macsec statistics interface gigabitEthernet 0/0/0
MACsec Statistics for GigabitEthernet0/0/0
 SecY Counters
  Ingress Untag Pkts:       0
  Ingress No Tag Pkts:      0
  Ingress Bad Tag Pkts:     0
  Ingress Unknown SCI Pkts: 0
  Ingress No SCI Pkts:      0
  Ingress Overrun Pkts:     0
  Ingress Validated Octets: 0
  Ingress Decrypted Octets: 966
  Egress Untag Pkts:        1
  Egress Too Long Pkts:     0
  Egress Protected Octets:  0
  Egress Encrypted Octets:  1387

 Controlled Port Counters
  IF In Octets:             1086
  IF In Packets:            10
  IF In Discard:            0
  IF In Errors:             0
  IF Out Octets:            1519
  IF Out Packets:           11
  IF Out Errors:            0

 Transmit SC Counters (SCI: B08BD07186A00007)
  Out Pkts Protected:       0
  Out Pkts Encrypted:       11
 Transmit SA Counters (AN 0)
  Out Pkts Protected:       0
  Out Pkts Encrypted:       11
```

```
 Receive SA Counters (SCI: B08BD0798A100007  AN 0)
  In Pkts Unchecked:        0
  In Pkts Delayed:          0
  In Pkts OK:               10
  In Pkts Invalid:          0
  In Pkts Not Valid:        0
  In Pkts Not using SA:     0
  In Pkts Unused SA:        0
  In Pkts Late:             0
```

Sample Show Command Output for VLAN Based WAN MACsec

```
#show mka sessions

Total MKA Sessions....... 1
      Secured Sessions... 1
      Pending Sessions... 0

=============================================================================================================
Interface       Local-TxSCI          Policy-Name       Inherited          Key-Server

Port-ID         Peer-RxSCI           MACsec-Peers      Status             CKN

=============================================================================================================
Gi0/0/0.1       b08b.d071.86a0/0024  test              YES                YES

36              b08b.d079.8a10/001a  1                 Secured            1111



#show mka sessions detail

MKA Detailed Status for MKA Session
===================================
Status: SECURED - Secured MKA Session with MACsec

Local Tx-SCI.............. b08b.d071.86a0/0024
Interface MAC Address.... b08b.d071.86a0
MKA Port Identifier...... 36
Interface Name........... GigabitEthernet0/0/0.1
Audit Session ID.........
CAK Name (CKN)........... 1111
Member Identifier (MI)... 920AF42A7C0F5D2BDC0CBB99
Message Number (MN)...... 35
EAP Role................. NA
Key Server............... YES
MKA Cipher Suite......... AES-128-CMAC

Latest SAK Status........ Rx & Tx
Latest SAK AN............ 1
Latest SAK KI (KN)....... 920AF42A7C0F5D2BDC0CBB9900000002 (2)
Old SAK Status........... No Rx, No Tx
Old SAK AN............... 0
Old SAK KI (KN).......... RETIRED (1)

SAK Transmit Wait Time... 0s (Not waiting for any peers to respond)
SAK Retire Time.......... 0s (No Old SAK to retire)
SAK Rekey Time........... 0s (SAK Rekey interval not applicable)

MKA Policy Name.......... test (inherited)
Key Server Priority...... 0
Delay Protection......... NO
Delay Protection Timer.......... 0s (Not enabled)
```

```
Confidentiality Offset... 0
Algorithm Agility........ 80C201
SAK Rekey On Live Peer Loss........ NO
Send Secure Announcement.. DISABLED
SCI Based SSCI Computation.... NO
SAK Cipher Suite......... 0080C20001000001 (GCM-AES-128)
MACsec Capability........ 3 (MACsec Integrity, Confidentiality, & Offset)
MACsec Desired........... YES

# of MACsec Capable Live Peers............ 1
# of MACsec Capable Live Peers Responded.. 1

Live Peers List:
  MI                        MN          Rx-SCI (Peer)        KS        RxSA          SSCI
                                                             Priority  Installed
  ------------------------------------------------------------------------------------------
  E500D4C281BE01C8777901D4  18          b08b.d079.8a10/001a  0         YES            0

Potential Peers List:
  MI                        MN          Rx-SCI (Peer)        KS        RxSA          SSCI
                                                             Priority  Installed
  ------------------------------------------------------------------------------------------

Dormant Peers List:
  MI                        MN          Rx-SCI (Peer)        KS        RxSA          SSCI
                                                             Priority  Installed
  ------------------------------------------------------------------------------------------
```


```
#show macsec statistics interface gigabitEthernet 0/0/0.1
MACsec Statistics for GigabitEthernet0/0/0.1
 SecY Counters
  Ingress Untag Pkts:       0
  Ingress No Tag Pkts:      0
  Ingress Bad Tag Pkts:     0
  Ingress Unknown SCI Pkts: 0
  Ingress No SCI Pkts:      0
  Ingress Overrun Pkts:     0
  Ingress Validated Octets: 0
  Ingress Decrypted Octets: 4038
  Egress Untag Pkts:        1
  Egress Too Long Pkts:     0
  Egress Protected Octets:  0
  Egress Encrypted Octets:  4476

 Controlled Port Counters
  IF In Octets:             4926
  IF In Packets:            74
  IF In Discard:            0
  IF In Errors:             0
  IF Out Octets:            5460
  IF Out Packets:           82
  IF Out Errors:            0

 Transmit SC Counters (SCI: B08BD07186A00024)
  Out Pkts Protected:       0
  Out Pkts Encrypted:       82
 Transmit SA Counters (AN 1)
  Out Pkts Protected:       0
  Out Pkts Encrypted:       82

 Receive SA Counters (SCI: B08BD0798A10001A  AN 1)
```

```
In Pkts Unchecked:         0
In Pkts Delayed:           0
In Pkts OK:                74
In Pkts Invalid:           0
In Pkts Not Valid:         0
In Pkts Not using SA:      0
In Pkts Unused SA:         0
In Pkts Late:              0
```



CHAPTER 23

Configuring IPv6 First Hop Security

- IPv6 First Hop Security Overview, on page 265
- Configuring an IPv6 DHCP Guard Policy, on page 266
- Configuring an IPv6 Router Advertisement Guard Policy, on page 268

IPv6 First Hop Security Overview

First Hop Security in IPv6 (FHS IPv6) is a set of IPv6 security features, whose policies can be attached to an interface or a VLAN. The following IPv6 policies are supported:

- DHCPv6 Guard
- IPv6 Router Advertisement (RA) Guard

Overview of DHCPv6 Guard

The DHCPv6 Guard feature blocks reply and advertisement messages that come from unauthorized DHCPv6 servers and relay agents. IPv6 DHCP guard can prevent forged messages from being entered in the binding table and block DHCPv6 server messages when they are received on ports that are not explicitly configured as facing a DHCPv6 server or DHCP relay. To use this feature, configure a policy and attach it to an interface or a VLAN.

To debug DHCP guard packets, use the following privileged EXEC command.

debug ipv6 snooping dhcp-guard [**filter** <*name*>] [**interface** <*interface-id*>] [**vlan** <*vlanid*>]

Restrictions of DHCPv6 Guard

The DHCPv6 guard feature is not supported on EtherChannel ports.

Overview of IPv6 RA Guard

The IPv6 Router Advertisement (RA) guard feature enables the network administrator to block or reject unwanted or rogue RA guard messages that arrive at the network device platform. RAs are used by devices to announce themselves on the link. The RA Guard feature analyzes the RAs and filters out bogus RAs sent by unauthorized devices. In host mode, all router advertisement and router redirect messages are disallowed on the port. The RA guard feature compares configuration information on the Layer 2 device with the

information found in the received RA frame. Once the Layer 2 device has validated the content of the RA frame and router redirect frame against the configuration, it forwards the RA to its unicast or multicast destination. If the RA frame content is not validated, the RA is dropped.

To debug RA guard packets, use the following privileged EXEC command.

debug ipv6 snooping raguard [**filter** <*name*>] [**interface** <*interface-id*>] [**vlan** <*vlanid*>]

Limitations and Restrictions of IPv6 RA Guard

- The IPv6 RA Guard feature does not offer protection in environments where IPv6 traffic is tunneled.
- This feature is supported only in hardware when the ternary content addressable memory (TCAM) is programmed.
- This feature can be configured on a switch port interface in the ingress direction.
- This feature supports host mode and router mode.
- This feature is supported only in the ingress direction; it is not supported in the egress direction.
- This feature is not supported on EtherChannel and EtherChannel port members.
- This feature is not supported on trunk ports with merge mode.
- This feature is supported on auxiliary VLANs and private VLANs (PVLANs). In the case of PVLANs, primary VLAN features are inherited and merged with port features.
- Packets dropped by the IPv6 RA Guard feature can be spanned.
- If the **platform ipv6 acl icmp optimize neighbor-discovery** command is configured, the IPv6 RA Guard feature cannot be configured and an error message will be displayed. This command adds default global Internet Control Message Protocol (ICMP) entries that will override the RA guard ICMP entries.

Configuring an IPv6 DHCP Guard Policy

Beginning in privileged EXEC mode, follow these steps to configure an IPv6 DHCP (DHCPv6) Guard policy:

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.

	Command or Action	Purpose
Step 3	**ipv6 dhcp guard policy** *policy-name* **Example:** `Router(config)# ipv6 dhcp guard policy policy1`	Specifies the DHCPv6 Guard policy name and enters DHCPv6 Guard Policy configuration mode.
Step 4	**device-role** {**client** | **monitor** | **server**} **Example:** `Router(config-dhcp-guard)# device-role server`	(Optional) Filters out DHCPv6 replies and DHCPv6 advertisements on the port that are not from a device of the specified role. Default is **client**. • **client**—Default value, specifies that the attached device is a client. Server messages are dropped on this port. • **server**—Specifies that the attached device is a DHCPv6 server. Server messages are allowed on this port.
Step 5	**trusted-port** **Example:** `Router(config-dhcp-guard)# trusted-port`	(Optional) **trusted-port**—Sets the port to a trusted mode. No further policing takes place on the port. **Note** If you configure a trusted port then the device-role option is not available.
Step 6	**end** **Example:** `Router(config-dhcp-guard)# end`	Exits DHCPv6 Guard Policy configuration mode and returns to privileged EXEC mode.
Step 7	**show ipv6 dhcp guard policy** *policy_name* **Example:** `Router# show ipv6 dhcp guard policy policy1`	(Optional) Displays the configuration of the IPv6 DHCP guard policy. Omitting the *policy_name* variable displays all DHCPv6 policies.

Attaching an IPv6 DHCP Guard Policy to an Interface or a VLAN

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.

	Command or Action	Purpose
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**interface** *type number* **Example:** `Router(config)# interface gigabitethernet 0/1/0`	Specifies an interface type and identifier, and enters interface configuration mode.
Step 4	**ipv6 dhcp guard** [**attach-policy** *policy_name*] **Example:** `Router(config-if)# ipv6 dhcp guard attach-policy policy1`	Attaches the DHCP Guard policy to the interface or the specified VLAN.
Step 5	**end** **Example:** `Router(config-if)# end`	Exits interface configuration mode and returns to privileged EXEC mode.
Step 6	**show ipv6 dhcp guard policy** *policy_name* **Example:** `Router# show ipv6 dhcp guard policy1`	(Optional) Displays the policy configuration as well as all the interfaces where the policy is applied.

Configuring an IPv6 Router Advertisement Guard Policy

Beginning in privileged EXEC mode, follow these steps to configure an IPv6 Router Advertisement policy:

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**ipv6 nd raguard policy** *policy-name* **Example:** `Router(config)# ipv6 nd raguard policy example_policy`	Specifies the RA guard policy name and enters RA guard policy configuration mode.

	Command or Action	Purpose
Step 4	**device-role {host | monitor | router | switch}** **Example:** `Router(config-nd-raguard)# device-role switch`	Specifies the role of the device attached to the port. The default is **host**. **Note** For a network with both host-facing ports and router-facing ports, along with a RA guard policy configured with **device-role host** on host-facing ports or vlan, it is mandatory to configure a RA guard policy with **device-role router** on router-facing ports to allow the RA Guard feature to work properly.
Step 5	**hop-limit** {**maximum** | **minimum**} *value* **Example:** `Router(config-nd-raguard)# hop-limit maximum 33`	Enables filtering of Router Advertisement messages by the Hop Limit value. A rogue RA message may have a low Hop Limit value (equivalent to the IPv4 Time to Live) that when accepted by the host, prevents the host from generating traffic to destinations beyond the rogue RA message generator. An RA message with an unspecified Hop Limit value is blocked. (1–255) Range for Maximum and Minimum Hop Limit values. If not configured, this filter is disabled. Configure **minimum** to block RA messages with Hop Limit values lower than the value you specify. Configure **maximum**to block RA messages with Hop Limit values greater than the value you specify.
Step 6	**managed-config-flag** {**off** | **on**} *value* **Example:** `Router(config-nd-raguard)# managed-config-flag on`	Enables filtering of Router Advertisement messages by the managed address configuration, or "M" flag field. A rouge RA message with an M field of 1 can cause a host to use a rogue DHCPv6 server. If not configured, this filter is disabled. **On**—Accepts and forwards RA messages with an M value of 1, blocks those with 0. **Off**—Accepts and forwards RA messages with an M value of 0, blocks those with 1.
Step 7	**other-config-flag** {**on** | **off**} **Example:** `Device(config-ra-guard)# other-config-flag on`	(Optional) Enables verification of the advertised “other” configuration parameter.

	Command or Action	Purpose
Step 8	**router-preference maximum** {**high** | **medium** | **low**} **Example:** `Router(config-nd-raguard)# router-preference maximum high`	Enables filtering of Router Advertisement messages by the router preference flag. If not configured, this filter is disabled. • **high**—Accepts RA messages with the router preference set to high, medium, or low. • **medium**—Blocks RA messages with the router preference set to high. • **low**—Blocks RA messages with the router preference set to medium and high.
Step 9	**match** {**ipv6 access-list** *list* | **ra prefix-list** *list*} **Example:** `Router(config-nd-raguard)# match ipv6 access-list example_list`	Matches a specified prefix list or access list.
Step 10	**trusted-port** **Example:** `Router(config-nd-raguard)# trusted-port`	When configured as a trusted port, all attached devices are trusted, and no further message verification is performed.
Step 11	**end** **Example:** `Router(config-nd-raguard)# end`	Exits RA Guard policy configuration mode and returns to privileged EXEC mode.
Step 12	**show ipv6 nd raguard policy** *policy_name* **Example:** `Router# show ipv6 nd raguard policy example_policy`	(Optional)—Displays the ND guard policy configuration.


Attaching an IPv6 Router Advertisement Guard Policy to an Interface or a VLAN

Beginning in privileged EXEC mode, follow these steps to attach an IPv6 Router Advertisement policy to an interface or to VLANs on the interface :

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.

	Command or Action	Purpose
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enter global configuration mode.
Step 3	**interface** *type number* **Example:** `Router(config)# interface gigabitethernet 0/1/1`	Specifies an interface type and identifier; enters the interface configuration mode.
Step 4	**ipv6 nd raguard** [**attach-policy** *policy_name*] **Example:** `Router(config-if)# ipv6 nd raguard attach-policy example_policy` `Router(config-vlan-config)# ipv6 nd raguard attach-policy example_policy`	Attaches the Neighbor Discovery Inspection policy to the interface or the specified VLANs on that interface. The default policy is attached if the **attach-policy** option is not used.
Step 5	**end** **Example:** `Router(config-if)# end`	Exits interface configuration mode and returns to privileged EXEC mode.



CHAPTER 24

Configuring IP Device Tracking

This chapter provides details about configuring IP Device Tracking (IPDT) on the IR8340 Router.

- Information About IP Device Tracking, on page 273
- Overview of SISF-Based Device Tracking, on page 274
- Options to Enable SISF-Based Device Tracking, on page 274
- How to Configure SISF-Based Device Tracking, on page 275

Information About IP Device Tracking

The main IPDT task is to keep track of connected hosts (association of MAC and IP address). In order to do this, it sends unicast Address Resolution Protocol (ARP) probes with a default interval of 30 seconds; these probes are sent to the MAC address of the host connected on the other side of the link, and use Layer 2 (L2) as the default source the MAC address of the physical interface out of which the ARP goes and a sender IP address of 0.0.0.0, based on the ARP Probe definition listed in RFC 5227.

In this document, the term 'ARP Probe' is used to refer to an ARP Request packet, broadcast on the local link, with an all-zero 'sender IP address'. The 'sender hardware address' MUST contain the hardware address of the interface sending the packet. The 'sender IP address' field MUST be set to all zeroes, to avoid polluting ARP caches in other hosts on the same link in the case where the address turns out to be already in use by another host. The 'target IP address' field MUST be set to the address being probed. An ARP Probe conveys both a question ("Is anyone using this address?") and an implied statement ("This is the address I hope to use.").

The purpose of IPDT is for the switch to obtain and maintain a list of devices that are connected to the switch via an IP address. The probe does not populate the tracking entry; it is simply used in order to maintain the entry in the table after it is learned through an ARP request/reply from the host.

IP ARP Inspection is enabled automatically when IPDT is enabled; it detects the presence of new hosts when it monitors ARP packets. If dynamic ARP inspection is enabled, only the ARP packets that it validates are used in order to detect new hosts for the Device Tracking table.

IP DHCP Snooping, if enabled, detects the presence or removal of new hosts when DHCP assigns or revokes their IP addresses.

IPDT is a feature that has always been available. However, on more recent Cisco IOS releases, its interdependencies are enabled by default (see Cisco bug ID CSCuj04986). It can be extremely useful when its database of IP/MAC hosts associations is used in order to populate the source IP of dynamic Access Control Lists (ACLs), or to maintain a binding of an IP address to a security group tag.

The ARP probe is sent under two circumstances:

- The link associated with a current entry in the IPDT database moves from a DOWN to an UP state, and the ARP entry has been populated.
- A link already in the UP state that is associated with an entry in the IPDT database has an expired probe interval.

Overview of SISF-Based Device Tracking

The Switch Integrated Security Features based (SISF-based) device tracking feature is part of the suite of first-hop security features.

The main role of the feature is to track the presence, location, and movement of end-nodes in the network. SISF snoops traffic received by the switch, extracts device identity (MAC and IP address), and stores them in a binding table. Many features, such as, Cisco TrustSec, IEEE 802.1X, LISP, and web authentication depend on the accuracy of this information to operate properly.

SISF-based device tracking supports both IPv4 and IPv6.

Even with the introduction of SISF-based device tracking, the legacy device tracking CLI (IP Device Tracking (IPDT) and IPv6 Snooping CLI) continues to be available. When you bootup the switch, the set of commands that is available depends on existing configuration, and only one of the following is available:

- SISF-based device tracking CLI, or
- IPDT and IPv6 Snooping CLI

SISF-based device tracking can be enabled manually (by using **device-tracking** commands), or programmatically (which is the case when providing device tracking services to other features).

Options to Enable SISF-Based Device Tracking

SISF-based device tracking is disabled by default.

You can enable it by defining a device tracking policy and attaching the policy to a specific target.

Note The target could be an interface or a VLAN.

Manually Enabling SISF-Based Device Tracking

- Option 1: Apply the **default** device tracking policy to a target.

  Enter the **device-tracking** command in the interface configuration mode or in the VLAN configuration mode. The system then attaches the **default** policy it to the interface or VLAN.

Note The **default** policy is a built-in policy with default settings; you cannot change any of the attributes of the **default** policy. In order to be able to configure device tracking policy attributes you must create a custom policy. See *Option 2: Create a custom policy with custom settings*.

- Option 2: Create a custom policy with custom settings.

  Enter the device-tracking policy command in global configuration mode and enter a custom policy name. The system creates a policy with the name you specify. You can then configure the available settings, in the device tracking configuration mode (config-device-tracking), and attach the policy to a specified target.

Programmatically Enabling SISF-Based Device Tracking

Some features rely on device tracking and utilize the trusted database of binding entries that SISF-based device tracking builds and maintains. These features, also called device tracking clients, enable device tracking programmatically (create and attach the device tracking policy).

Note The exceptions here are IEEE 802.1X, web authentication, Cisco TrustSec, and IP Source Guard (IPSG) - they also rely on device tracking, but they do not enable it. For these device tracking clients, you must enter the **ip dhcp snooping vlan** vlan command, to programmatically enable device tracking on a particular target.

Note the following about programmatically enabling SISF-based device tracking:

- A device tracking client *requires* device tracking to be enabled.

  There are several device tracking clients, therefore, multiple programmatic policies could be created. The settings of each policy differ depending on the device tracking client that creates the policy.

- The policy that is created, and its settings, are system-defined.

  Configurable policy attributes are available in the device tracking configuration mode (config-device-tracking) and vary from one release to another. If you try to modify an attribute that is not configurable, the configuration change is rejected and an error message is displayed.

How to Configure SISF-Based Device Tracking

Manually Enabling SISF-Based Device Tracking

Applying the Default Device Tracking Policy to a Target

Beginning in privileged EXEC mode, follow these steps to apply the default device tracking policy to an interface or VLAN:

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Device> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Device# configure terminal`	Enter global configuration mode.
Step 3	Specify an interface or a VLAN. • **interface** *type number* • **vlan configuration** *vlan_list* **Example:** `Device(config)# interface gigabitethernet 0/1/0` OR `Device(config)# vlan configuration 100`	**interface** *type number*—Specifies the interface and enters interface configuration mode. The device tracking policy will be attached to the specified interface. **vlan configuration** *vlan_list*—Specifies the VLANs and enters VLAN feature configuration mode. The device tracking policy will be attached to the specified VLAN.
Step 4	**device-tracking** **Example:** `Device(config-if)# device-tracking` OR `Device(config-vlan-config)# device-tracking`	Enables SISF-based device tracking and attaches the default policy it to the interface or VLAN. The default policy is a built-in policy with default settings; none of the attributes of the default policy can be changed.
Step 5	**end** **Example:** `Device(config-if)# end` OR `Device(config-vlan-config)# end`	Exits interface configuration mode and returns to privileged EXEC mode. Exits VLAN feature configuration mode and returns to privileged EXEC mode.
Step 6	**show device-tracking policy** *policy-name* **Example:** `Device# show device-tracking policy default`	Displays device-tracking policy configuration, and all the targets it is applied to.

Creating a Custom Device Tracking Policy with Custom Settings

Beginning in privileged EXEC mode, follow these steps to create and configure a device tracking policy:

Procedure

	Command or Action	Purpose
Step 1	**enable**	Enables privileged EXEC mode.

	Command or Action	Purpose
	Example: `Device> enable`	• Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Device# configure terminal`	Enter global configuration mode.
Step 3	[**no**] **device-tracking policy** *policy_name* **Example:** `Device(config)# device-tracking policy example_policy`	Creates the policy and enters device-tracking configuration mode.
Step 4	[**data-glean** | **default** | **destination-glean** | **device-role** | **distribution-switch** | **exit** | **limit** | **no** | **prefix-glean** | **protocol** | **security-level** | **tracking** | **trusted-port** | **vpc**] **Example:** `Device(config-device-tracking)# security-level glean`	Enter the question mark (?) at the system prompt to obtain a list of available options in this mode. You can configure the following for both IPv4 and IPv6: • (Optional) **data-glean** —Enables learning of addresses from a data packet snooped from a source inside the network and populates the binding table with the data traffic source address. Enter one of these options: • log-only —Generates a syslog message upon data packet notification • recovery —Uses a protocol to enable binding table recovery. Enter **NDP** or **DHCP** . • (Optional) **default** —Sets the policy attribute to its default value. You can set these policy attributes to their default values: **data-glean** , **destination-glean** , **device-role** , **limit** , **prefix-glean** , **protocol** , **security-level** , **tracking** , **trusted-port** . • (Optional) **destination-glean** —Populates the binding table by gleaning data traffic destination address. Enter one of these options: • **log-only** —Generates a syslog message upon data packet notification • **recovery** —Uses a protocol to enable binding table recovery. Enter **DHCP** .

	Command or Action	Purpose
		• (Optional) **device-role** —Sets the role of the device attached to the port. It can be a node or a switch. Enter one of these options: • node —Configures the attached device as a node. This is the default option. • switch —Configures the attached device as a switch. • (Optional) **distribution-switch** —Although visible on the CLI, this option is not supported. Any configuration settings you make will not take effect. • **exit** —Exits the device-tracking policy configuration mode. • **limit address-count** —Specifies an address count limit per port. The range is 1 to 32000. • **no** —Negates the command or sets it to defaults. • (Optional) **prefix-glean** —Enables learning of prefixes from either IPv6 Router Advertisements or from DHCP-PD. You have the following option: • (Optional) **only** —Gleans only prefixes and not host addresses. • (Optional) **protocol** —Sets the protocol to glean; by default, all are gleaned. Enter one of these options: • **arp** [**prefix-list** *name*] —Gleans addresses in ARP packets. Optionally, enter the name of prefix-list that is to be matched. • **dhcp4** [**prefix-list** *name*] —Glean addresses in DHCPv4 packets. Optionally, enter the name of prefix-list that is to be matched. • **dhcp6** [**prefix-list** *name*] —Glean addresses in DHCPv6 packets. Optionally, enter the name of prefix-list that is to be matched.

	Command or Action	Purpose
		• **ndp** [**prefix-list** *name*] —Glean addresses in NDP packets. Optionally, enter the name of prefix-list that is to be matched. • **udp** [**prefix-list** *name*] —Although visible on the CLI, this option is not supported. Any configuration settings you make will not take effect. • (Optional) **security-level** —Specifies the level of security enforced by the feature. Enter one of these options: • **glean** —Gleans addresses passively. • **guard** —Inspects and drops un-authorized messages. This is the default. • **inspect** —Gleans and validates messages. • (Optional) **tracking** —Specfies a tracking option. Enter one of these options: • **disable** [**stale-lifetime** [1-86400-seconds| **infinite**]] —Turns of device-tracking. Optionally, you can enter the duration for which the entry is kept inactive before deletion, or keep it permanently inactive. • **enable** [**reachable-lifetime** [1-86400-seconds| **infinite**]] —Turns on device-tracking. Optionally, you can enter the duration for which the entry is kept reachable, or keep it permanently reachable. • (Optional) **trusted-port** —Sets up a trusted port. Disables the guard on applicable targets. Bindings learned through a trusted port have preference over bindings learned through any other port. A trusted port is given preference in case of a collision while making an entry in the table.

	Command or Action	Purpose
		• (Optional) **vpc** —Although visible on the CLI, this option is not supported. Any configuration settings you make will not take effect.
Step 5	**end** **Example:** `Device(config-device-tracking)# end`	Exits device-tracking configuration mode and returns to privileged EXEC mode.
Step 6	**show device-tracking policy** *policy-name* **Example:** `Device# show device-tracking policy default`	Displays the device-tracking policy configuration.

Attaching a Device Tracking Policy to an Interface

Beginning in privileged EXEC mode, follow these steps to attach a device tracking policy to an interface:

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Device> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Device# configure terminal`	Enter global configuration mode.
Step 3	**interface** *interface-id* **Example:** `Device(config)# interface gigabitethernet 0/1/0`	Specifies an interface and enters interface configuration mode.
Step 4	**device-tracking attach-policy** *policy_name* **Example:** `Device(config-if)# device-tracking attach-policy example_policy`	Attaches the device tracking policy to the interface. Device tracking is also supported on EtherChannels. **Note** SISF based device-tracking policies can be disabled only if they are custom policies. Programmatically created policies can be removed only if the corresponding device-tracking client feature configuration is removed.

	Command or Action	Purpose
Step 5	**end** **Example:** `Device(config-if)# end`	Exits device-tracking configuration mode and returns to privileged EXEC mode.
Step 6	**show device-tracking policies** [**interface***interface-id*] **Example:** `Device# show device-tracking policies interface gigabitethernet 0/1/0`	Displays device-tracking policy configuration, and all the targets it is applied to.

Attaching a Device Tracking Policy to a VLAN

Beginning in privileged EXEC mode, follow these steps to attach a device-tracking policy to VLANs across multiple interfaces:

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Device> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Device# configure terminal`	Enter global configuration mode.
Step 3	**vlan configuration** *vlan_list* **Example:** `Device(config)# vlan configuration 100`	Specifies an interface and enters interface configuration mode.
Step 4	**device-tracking attach-policy** *policy_name* **Example:** `Device(config-vlan-config)# device-tracking attach-policy example_policy`	Attaches the device tracking policy to the specified VLANs across all switch interfaces. **Note** SISF based device-tracking policies can be disabled only if they are custom policies. Programmatically created policies can be removed only if the corresponding device-tracking client feature configuration is removed.
Step 5	**end** **Example:** `Device(config-if)# end`	Exits device-tracking configuration mode and returns to privileged EXEC mode.

	Command or Action	Purpose
Step 6	**show device-tracking policies** [**vlan***vlan-id*] **Example:** `Device# show device-tracking policies vlan 100`	Verifies that the policy is attached to the specified VLAN, without exiting the VLAN interface configuration mode.

Configuring a Multi-Switch Network to Stop Creating Binding Entries from a Trunk Port

In a multi-switch network, SISF-based device tracking provides the capability to distribute binding table entries between switches running the feature. Binding entries are only created on the switches where the host appears on an access port. No entry is created for a host that appears over a trunk port. This is achieved by configuring a policy with the **trusted-port** and **device-role switch** options, and attaching it to the trunk port.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Device> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Device# configure terminal`	Enter global configuration mode.
Step 3	**device-tracking policy** *policy_name* **Example:** `Device(config)# device-tracking policy DT_trunk_policy`	Enters device-tracking policy configuration mode, for the specified policy.
Step 4	**device-role switch** **Example:** `Device(config-device-tracking)# device-role switch`	Specifies the role of the device attached to the port. Default is node. Enter the **device-role switch** option to stop the creation of binding entries for the port.
Step 5	**trusted-ports** **Example:** `Device(config-device-tracking)# trusted-port`	Sets up a trusted port. Disables the guard on applicable targets. Bindings learned through a trusted port have preference over bindings learned through any other port. A trusted port is given preference in case of a collision while making an entry in the table.
Step 6	**end** **Example:** `Device(config-device-tracking)# end`	Exits device-tracking policy configuration mode and returns to global configuration mode.

	Command or Action	Purpose
Step 7	**interface** *interface-id* **Example:** `Device(config)# interface gigabitethernet 0/1/0`	Specifies a trunk interface and enters interface configuration mode.
Step 8	**device-tracking attach-policy** *policy_name* **Example:** `Device(config-if)# device-tracking attach-policy DT_trunk_policy`	Attaches a device tracking policy to the interface or the specified VLANs on the interface.
Step 9	**end** **Example:** `Device(config-if)# end`	Exits interface configuration mode and returns to privileged EXEC mode.

Enabling SISF Syslogs

To enable syslogs of binding table events (such as create, delete, or modify entries), the following commands need to be executed:

```
device-tracking binding logging
```

If appropriate syslog level (6 - informational) need to be adjusted, execute:

```
logging console informational
```

To direct it to buffer:

```
logging buffered informational
```

to generate syslogs for MAC and/or IP theft events:

```
device-tracking logging theft
```

To generate syslogs for events when any of the SISF features decides to drop the packet for any reason:

```
device-tracking logging packet drop
```

to generate syslogs for events related to destination guard events:

```
device-tracking logging resolution-veto
```

the following command could be used to enable syslogs for all three event types listed above (but not to binding table events):

```
device-tracking logging
```

Example: DHCP Snooping Auto Enabling DT PROGRAMMATIC Policy

```
configure terminal
device-tracking policy Poo@12345
security-level glean
 device-role node
 limit address-count 10
tracking enable
  end
Switch(confg)#ip dhcp snooping
```

```
Switch(confg)#ip dhcp snooping vlan 100
Switch(confg)#end


configure terminal
interface Gi0/1/0
device-tracking attach-policy Poo@12345
end
```

Use the following show commands to display the status of device tracking:

```
router#show device-tracking policies
Target               Type  Policy               Feature        Target range
Gi0/1/0              PORT  Poo@12345            Device-tracking vlan all
vlan 100             VLAN  DT-PROGRAMMATIC      Device-tracking vlan all
router#
router#show device-tracking policy DT-PROGRAMMATIC
Device-tracking policy DT-PROGRAMMATIC configuration:
security-level glean
device-role node
gleaning from Neighbor Discovery
gleaning from DHCP6
gleaning from ARP
 gleaning from DHCP4
 NOT gleaning from protocol unkn
limit address-count for IPv4 per mac 1
 tracking (downlink only) enable
Policy DT-PROGRAMMATIC is applied on the following targets:
Target               Type  Policy               Feature        Target range
vlan 100             VLAN  DT-PROGRAMMATIC      Device-tracking vlan all
router#
router#show device-tracking policy Poo@12345
Device-tracking policy Poo@12345 configuration:
 security-level glean
 device-role node
 gleaning from Neighbor Discovery
gleaning from DHCP6
  gleaning from ARP
 gleaning from DHCP4
  gleaning from protocol unkn
 limit address-count 10
 tracking enable
Policy Poo@12345 is applied on the following targets:
Target               Type  Policy               Feature        Target range
Gi0/1/0              PORT  Poo@12345            Device-tracking vlan all

Router#show device-tracking database
Binding Table has 11 entries, 11 dynamic (limit 100000)
Codes: L - Local, S - Static, ND - Neighbor Discovery, ARP - Address Resolution Protocol,
DH4 - IPv4 DHCP, DH6 - IPv6 DHCP, PKT - Other Packet, API - API created
Preflevel flags (prlvl):
0001:MAC and LLA match     0002:Orig trunk            0004:Orig access
0008:Orig trusted trunk    0010:Orig trusted access   0020:DHCP assigned
0040:Cga authenticated     0080:Cert authenticated    0100:Statically assigned


 Network Layer Address                  Link Layer Address     Interface  vlan       prlvl
      age        state      Time left
ARP 100.1.1.1                               ac4a.6763.5a51         Gi0/1/10   100
0005       169s       REACHABLE  143 s try 0
DH4 100.0.0.14                              0013.0100.0004         Gi0/1/0    100
0024       53s        REACHABLE  259 s(31535947 s)
DH4 100.0.0.13                              0013.0100.0003         Gi0/1/0    100
0024       53s        REACHABLE  262 s(31535946 s)
DH4 100.0.0.12                              0013.0100.0002         Gi0/1/0    100
0024       52s        REACHABLE  250 s(31535947 s)
```



CHAPTER 25

Configuring Security for VPNs with IPsec

This chapter describes how to configure basic IPsec VPNs. IPsec is a framework of open standards developed by the IETF. It provides security for the transmission of sensitive information over unprotected networks such as the Internet. IPsec acts at the network layer, protecting and authenticating IP packets between participating IPsec devices (“peers”), such as Cisco routers.

Note Security threats, as well as the cryptographic technologies to help protect against them, are constantly changing. For more information about the latest Cisco cryptographic recommendations, see the Next Generation Encryption (NGE) white paper.

- Information About Configuring Security for VPNs with IPsec, on page 285
- How to Configure IPsec VPNs, on page 288

Information About Configuring Security for VPNs with IPsec

Supported Standards

Cisco implements the following standards with this feature:

- IPsec—IPsec is a framework of open standards that provides data confidentiality, data integrity, and data authentication between participating peers. IPsec provides these security services at the IP layer; IPsec uses IKE to handle negotiation of protocols and algorithms based on the local policy, and generate the encryption and authentication keys to be used by IPsec. IPsec can be used to protect one or more data flows between a pair of hosts, between a pair of security gateways, or between a security gateway and a host.

Note The term IPsec is sometimes used to describe the entire protocol of IPsec data services and IKE security protocols, and is also sometimes used to describe only the data services.

- IKE (IKEv1 and IKEv2)—A hybrid protocol that implements Oakley and SKEME key exchanges inside the Internet Security Association and Key Management Protocol (ISAKMP) framework. While IKE is

used with other protocols, its initial implementation is with the IPsec protocol. IKE provides authentication of IPsec peers, negotiates IPsec security associations, and establishes IPsec keys.

The component technologies implemented for IPsec include:

Note Cisco no longer recommends using DES, 3DES, MD5 (including HMAC variant), and Diffie-Hellman (DH) groups 1, 2 and 5; instead, you should use AES, SHA and DH Groups 14 or higher. For more information about the latest Cisco cryptographic recommendations, see the Next Generation Encryption (NGE) white paper.

- AES—Advanced Encryption Standard. A cryptographic algorithm that protects sensitive, unclassified information. AES is a privacy transform for IPsec and IKE and has been developed to replace DES. AES is designed to be more secure than DES. AES offers a larger key size, while ensuring that the only known approach to decrypt a message is for an intruder to try every possible key. AES has a variable key length—the algorithm can specify a 128-bit key (the default), a 192-bit key, or a 256-bit key.
- DES—Data Encryption Standard. An algorithm that is used to encrypt packet data. Cisco software implements the mandatory 56-bit DES-CBC with Explicit IV. Cipher Block Chaining (CBC) requires an initialization vector (IV) to start encryption. The IV is explicitly given in the IPsec packet. For backwards compatibility, Cisco IOS IPsec also implements the RFC 1829 version of ESP DES-CBC.

Cisco IOS also implements Triple DES (168-bit) encryption, depending on the software versions available for a specific platform. Cisco no longer recommends Triple DES (3DES).

Note Cisco IOS images with strong encryption (including, but not limited to 56-bit data encryption feature sets) are subject to United States government export controls, and have a limited distribution. Images to be installed outside the United States require an export license. Customer orders might be denied or subject to delay due to United States government regulations. Contact your sales representative or distributor for more information, or send an e-mail to export@cisco.com.

- SHA-2 and SHA-1 family (HMAC variant)—Secure Hash Algorithm (SHA) 1 and 2. Both SHA-1 and SHA-2 are hash algorithms used to authenticate packet data and verify the integrity verification mechanisms for the IKE protocol. HMAC is a variant that provides an additional level of hashing. SHA-2 family adds the SHA-256 bit hash algorithm and SHA-384 bit hash algorithm. This functionality is part of the Suite-B requirements that comprises four user interface suites of cryptographic algorithms for use with IKE and IPSec that are described in RFC 4869. Each suite consists of an encryption algorithm, a digital signature algorithm, a key agreement algorithm, and a hash or message digest algorithm. See the Configuring Security for VPNs with IPsec feature module for more detailed information about Cisco IOS Suite-B support. SHA-2 for ISAKMP is supported in Cisco IOS XE 15.3(3)S and later.
- Diffie-Hellman—A public-key cryptography protocol that allows two parties to establish a shared secret over an unsecure communications channel. Diffie-Hellman is used within IKE to establish session keys. It supports 768-bit (the default), 1024-bit, 1536-bit, 2048-bit, 3072-bit, and 4096-bit DH groups. It also supports a 2048-bit DH group with a 256-bit subgroup, and 256-bit and 384-bit elliptic curve DH (ECDH). Cisco recommends using 2048-bit or larger DH key exchange, or ECDH key exchange.
- MD5 (Hash-based Message Authentication Code (HMAC) variant)—Message digest algorithm 5 (MD5) is a hash algorithm. HMAC is a keyed hash variant used to authenticate data.

IPsec as implemented in Cisco software supports the following additional standards:

- AH—Authentication Header. A security protocol, which provides data authentication and optional anti-replay services. AH is embedded in the data to be protected (a full IP datagram).
- ESP—Encapsulating Security Payload. A security protocol, which provides data privacy services and optional data authentication, and anti-replay services. ESP encapsulates the data to be protected.

Supported Encapsulation

IPsec works with the following serial encapsulations: Frame Relay, High-Level Data-Links Control (HDLC), and PPP.

IPsec also works with Generic Routing Encapsulation (GRE) and IPinIP Layer 3, Data Link Switching+ (DLSw+), and Source Route Bridging (SRB) tunneling protocols; however, multipoint tunnels are not supported. Other Layer 3 tunneling protocols may not be supported for use with IPsec.

IPsec Functionality Overview

IPsec provides the following network security services. (In general, the local security policy dictates the use of one or more of these services.)

- Data confidentiality—The IPsec sender can encrypt packets before transmitting them across a network.
- Data integrity—The IPsec receiver can authenticate packets sent by the IPsec sender to ensure that the data has not been altered during transmission.
- Data origin authentication—The IPsec receiver can authenticate the source of the sent IPsec packets. This service is dependent upon the data integrity service.
- Anti-replay—The IPsec receiver can detect and reject replayed packets.

IPsec provides secure *tunnels* between two peers, such as two routers. You define which packets are considered sensitive and should be sent through these secure tunnels, and you define the parameters that should be used to protect these sensitive packets by specifying the characteristics of these tunnels. When the IPsec peer recognizes a sensitive packet, the peer sets up the appropriate secure tunnel and sends the packet through the tunnel to the remote peer. (The use of the term *tunnel* in this chapter does not refer to using IPsec in tunnel mode.)

More accurately, these *tunnels* are sets of security associations (SAs) that are established between two IPsec peers. The SAs define the protocols and algorithms to be applied to sensitive packets and specify the keying material to be used by the two peers. SAs are unidirectional and are established per security protocol (AH or ESP).

Once established, the set of SAs (outbound to the peer) is then applied to the triggering packet and to subsequent applicable packets as those packets exit the router. “Applicable” packets are packets that match the same access list criteria that the original packet matched. For example, all applicable packets could be encrypted before being forwarded to the remote peer. The corresponding inbound SAs are used when processing the incoming traffic from that peer.

Multiple IPsec tunnels can exist between two peers to secure different data streams, with each tunnel using a separate set of SAs. For example, some data streams only need to be authenticated, while other data streams must both be encrypted and authenticated.

IKEv1 Transform Sets

An Internet Key Exchange version 1 (IKEv1) transform set represents a certain combination of security protocols and algorithms. During the IPsec SA negotiation, the peers agree to use a particular transform set for protecting a particular data flow.

IKEv2 Transform Sets

An Internet Key Exchange version 2 (IKEv2) proposal is a set of transforms used in the negotiation of IKEv2 SA as part of the IKE_SA_INIT exchange. An IKEv2 proposal is regarded as complete only when it has at least an encryption algorithm, an integrity algorithm, and a Diffie-Hellman (DH) group configured. If no proposal is configured and attached to an IKEv2 policy, then the default proposal is used in the negotiation. The default proposal is a collection of commonly used algorithms which are as follows:

```
encryption aes-cbc-128 3des
integrity sha1 md5
group 5 2
```

Although the **crypto ikev2 proposal** command is similar to the **crypto isakmp policy priority** command, the IKEv2 proposal differs as follows:

- An IKEv2 proposal allows configuration of one or more transforms for each transform type.
- An IKEv2 proposal does not have any associated priority.

Note To use IKEv2 proposals in negotiation, they must be attached to IKEv2 policies. If a proposal is not configured, then the default IKEv2 proposal is used with the default IKEv2 policy.

How to Configure IPsec VPNs

Creating Crypto Access Lists

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enters global configuration mode.
Step 3	Do one of the following: **access-list** *access-list-number* {**deny** | **permit**} *protocol source source-wildcard destination*	Specifies conditions to determine which IP packets are protected.

	Command or Action	Purpose
	destination-wildcard [**log**] or **ip access-list extended** *name* **Example:** `Router(config)# access-list 100 permit ip 10.0.68.0 0.0.0.255 10.1.1.0 0.0.0.255` `Router(config)# ip access-list extended vpn-tunnel`	• You specify conditions using an IP access list designated by either a number or a name. The **access-list** command designates a numbered extended access list; the **ip access-list extended** command designates a named access list. • Enable or disable crypto for traffic that matches these conditions. **Tip** Cisco recommends that you configure "mirror image" crypto access lists for use by IPsec and that you avoid using the **any** keyword.
Step 4	Repeat Step 3 for each crypto access list you want to create.	

What to do next

After at least one crypto access list is created, a transform set needs to be defined as described in Configuring Transform Sets for IKEv1 and IKEv2 Proposals, on page 289.

Next the crypto access lists need to be associated to particular interfaces when you configure and apply crypto map sets to the interfaces. (Follow the instructions in Creating Crypto Map Sets, on page 293 and Applying Crypto Map Sets to Interfaces, on page 301).

Configuring Transform Sets for IKEv1 and IKEv2 Proposals

Perform this task to define a transform set that is to be used by the IPsec peers during IPsec security association negotiations with IKEv1 and IKEv2 proposals.

Restrictions

If you are specifying SEAL encryption, note the following restrictions:

- Your router and the other peer must not have a hardware IPsec encryption.
- Your router and the other peer must support IPsec.
- Your router and the other peer must support the k9 subsystem.
- SEAL encryption is available only on Cisco equipment. Therefore, interoperability is not possible.
- Unlike IKEv1, the authentication method and SA lifetime are not negotiable in IKEv2, and because of this, these parameters cannot be configured under the IKEv2 proposal.

Configuring Transform Sets for IKEv1

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enters global configuration mode.
Step 3	**crypto ipsec transform-set** *transform-set-name transform1* [*transform2* [*transform3*]] **Example:** `Router(config)# crypto ipsec transform-set aesset esp-aes 256 esp-sha-hmac`	Defines a transform set and enters crypto transform configuration mode. • There are complex rules defining the entries that you can use for transform arguments. These rules are explained in the command description for the **crypto ipsec transform-set** command, and the table in "About Transform Sets" section provides a list of allowed transform combinations.
Step 4	**mode** [**tunnel** | **transport**] **Example:** `Router(cfg-crypto-tran)# mode transport`	(Optional) Changes the mode associated with the transform set. • The mode setting is applicable only to traffic whose source and destination addresses are the IPsec peer addresses; it is ignored for all other traffic. (All other traffic is in tunnel mode only.)
Step 5	**end** **Example:** `Router(cfg-crypto-tran)# end`	Exits crypto transform configuration mode and enters privileged EXEC mode.
Step 6	**clear crypto sa** [**peer** {*ip-address* | *peer-name*} | **sa map** *map-name* | **sa entry** *destination-address protocol spi*] **Example:** `Router# clear crypto sa`	(Optional) Clears existing IPsec security associations so that any changes to a transform set takes effect on subsequently established security associations. Manually established SAs are reestablished immediately. • Using the **clear crypto sa** command without parameters clears out the full SA database, which clears out active security sessions.

	Command or Action	Purpose
		• You may also specify the **peer**, **map**, or **entry** keywords to clear out only a subset of the SA database.
Step 7	**show crypto ipsec transform-set** [**tag** *transform-set-name*] **Example:** `Router# show crypto ipsec transform-set`	(Optional) Displays the configured transform sets.

What to do next

After you have defined a transform set, you should create a crypto map as specified in Creating Crypto Map Sets, on page 293.

Configuring Transform Sets for IKEv2

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enters global configuration mode.
Step 3	**crypto ikev2 proposal** *proposal-name* **Example:** `Router(config)# crypto ikev2 proposal proposal-1`	Specifies the name of the proposal and enters crypto IKEv2 proposal configuration mode. • The proposals are referred in IKEv2 policies through the proposal name.
Step 4	**encryption** *transform1* [*transform2*] ... **Example:** `Router(config-ikev2-proposal)# encryption aes-cbc-128`	(Optional) Specifies one or more transforms of the following encryption type: • AES-CBC 128—128-bit AES-CBC • AES-CBC 192—192-bit AES-CBC • AES-CBC 256—256-bit AES-CBC • 3DES—168-bit DES (No longer recommended. AES is the recommended encryption algorithm).

	Command or Action	Purpose
Step 5	**integrity** *transform1* [*transform2*] ... **Example:** `Router(config-ikev2-proposal)# integrity sha1`	(Optional) Specifies one or more transforms of the following integrity type: • The **sha256** keyword specifies SHA-2 family 256-bit (HMAC variant) as the hash algorithm. • The **sha384** keyword specifies SHA-2 family 384-bit (HMAC variant) as the hash algorithm. • The **sha512** keyword specifies SHA-2 family 512-bit (HMAC variant) as the hash algorithm • The **sha1** keyword specifies the SHA-1 (HMAC variant) as the hash algorithm. • The **md5** keyword specifies MD5 (HMAC variant) as the hash algorithm. (No longer recommended. SHA-1 is the recommended replacement.)
Step 6	**group** *transform1* [*transform2*] ... **Example:** `Router(config-ikev2-proposal)# group 14`	(Optional) Specifies one or more transforms of the possible DH group type: • **1**—768-bit DH (No longer recommended.) • **2**—1024-bit DH (No longer recommended) • **5**—1536-bit DH (No longer recommended) • **14**—Specifies the 2048-bit DH group. • **15**—Specifies the 3072-bit DH group. • **16**—Specifies the 4096-bit DH group. • **19**—Specifies the 256-bit elliptic curve DH (ECDH) group. • **20**—Specifies the 384-bit ECDH group. • **24**—Specifies the 2048-bit DH/DSA group.
Step 7	**end** **Example:** `Router(config-ikev2-proposal)# end`	Exits crypto IKEv2 proposal configuration mode and returns to privileged EXEC mode.

	Command or Action	Purpose
Step 8	**show crypto ikev2 proposal** **Example:** `Router# show crypto ikev2 proposal`	(Optional) Displays the parameters for each IKEv2 proposal.

Creating Crypto Map Sets

Creating Static Crypto Maps

When IKE is used to establish SAs, the IPsec peers can negotiate the settings they use for the new security associations. This means that you can specify lists (such as lists of acceptable transforms) within the crypto map entry.

Perform this task to create crypto map entries that use IKE to establish SAs. To create IPv6 crypto map entries, you must use the **ipv6** keyword with the **crypto map** command. For IPv4 crypto maps, use the **crypto map** command without the **ipv6** keyword.

Note Security threats, as well as the cryptographic technologies to help protect against them, are constantly changing. For more information about the latest Cisco cryptographic recommendations, see the Next Generation Encryption (NGE) white paper.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enters global configuration mode.
Step 3	**crypto map** [**ipv6**] *map-name seq-num* [**ipsec-isakmp**] **Example:** `Router(config)# crypto map static-map 1 ipsec-isakmp`	Creates or modifies a crypto map entry, and enters crypto map configuration mode. • For IPv4 crypto maps, use the command without the **ipv6** keyword.
Step 4	**match address** *access-list-id* **Example:** `Router(config-crypto-m)# match address vpn-tunnel`	Names an extended access list. • This access list determines the traffic that should be protected by IPsec and the traffic that should not be protected by IPsec security in the context of this crypto map entry.

	Command or Action	Purpose
Step 5	**set-peer** {*hostname* | *ip-address*} **Example:** `Router(config-crypto-m)# set-peer 192.168.101.1`	Specifies a remote IPsec peer—the peer to which IPsec protected traffic can be forwarded. • Repeat for multiple remote peers.
Step 6	**crypto ipsec security-association dummy** {**pps** *rate* | **seconds** *seconds*} **Example:** `Router(config-crypto-m)# set security-association dummy seconds 5`	Enables generating dummy packets. These dummy packets are generated for all flows created in the crypto map.
Step 7	**set transform-set** *transform-set-name1* [*transform-set-name2...transform-set-name6*] **Example:** `Router(config-crypto-m)# set transform-set aesset`	Specifies the transform sets that are allowed for this crypto map entry. • List multiple transform sets in the order of priority (highest priority first).
Step 8	**set security-association lifetime** {**seconds** *seconds* | **kilobytes** *kilobytes* | **kilobytes disable**} **Example:** `Router(config-crypto-m)# set security-association lifetime seconds 2700`	(Optional) Specifies a SA lifetime for the crypto map entry. • By default, the SAs of the crypto map are negotiated according to the global lifetimes, which can be disabled.
Step 9	**set security-association level per-host** **Example:** `Router(config-crypto-m)# set security-association level per-host`	(Optional) Specifies that separate SAs should be established for each source and destination host pair. • By default, a single IPsec "tunnel" can carry traffic for multiple source hosts and multiple destination hosts. **Caution** Use this command with care because multiple streams between given subnets can rapidly consume resources.
Step 10	**set pfs [group1 | group14 | group15 | group16 | group19 | group2 | group20 | group24 | group5]** **Example:** `Router(config-crypto-m)# set pfs group14`	(Optional) Specifies that IPsec either should ask for password forward secrecy (PFS) when requesting new SAs for this crypto map entry or should demand PFS in requests received from the IPsec peer. • Group 1 specifies the 768-bit Diffie-Hellman (DH) identifier (default). (No longer recommended). • Group 2 specifies the 1024-bit DH identifier. (No longer recommended).

	Command or Action	Purpose
		• Group 5 specifies the 1536-bit DH identifier. (No longer recommended) • Group 14 specifies the 2048-bit DH identifier. • Group 15 specifies the 3072-bit DH identifier. • Group 16 specifies the 4096-bit DH identifier. • Group 19 specifies the 256-bit elliptic curve DH (ECDH) identifier. • Group 20 specifies the 384-bit ECDH identifier. • Group 24 specifies the 2048-bit DH/DSA identifier • By default, PFS is not requested. If no group is specified with this command, group 1 is used as the default.
Step 11	**end** **Example:** `Router(config-crypto-m)# end`	Exits crypto map configuration mode and returns to privileged EXEC mode.
Step 12	**show crypto map** [**interface** *interface*| **tag** *map-name*] **Example:** `Router# show crypto map`	Displays your crypto map configuration.

Certain configuration changes take effect only when negotiating subsequent SAs. If you want the new settings to take immediate effect, you must clear the existing SAs so that they are reestablished with the changed configuration. If the router is actively processing IPsec traffic, clear only the portion of the SA database that would be affected by the configuration changes (that is, clear only the SAs established by a given crypto map set). Clearing the full SA database should be reserved for large-scale changes, or when the router is processing very little other IPsec traffic.

To clear IPsec SAs, use the **clear crypto sa** command with appropriate parameters. (Omitting all parameters clears out the full SA database, which clears active security sessions.)

What to do next

After you have successfully created a static crypto map, you must apply the crypto map set to each interface through which IPsec traffic flows. To complete this task, see Applying Crypto Map Sets to Interfaces, on page 301.

Creating Dynamic Crypto Maps

Dynamic crypto map entries specify crypto access lists that limit traffic for which IPsec SAs can be established. A dynamic crypto map entry that does not specify an access list is ignored during traffic filtering. A dynamic crypto map entry with an empty access list causes traffic to be dropped. If there is only one dynamic crypto map entry in the crypto map set, it must specify the acceptable transform sets.

Perform this task to create dynamic crypto map entries that use IKE to establish the SAs.

Note IPv6 addresses are not supported on dynamic crypto maps.

Note Security threats, as well as the cryptographic technologies to help protect against them, are constantly changing. For more information about the latest Cisco cryptographic recommendations, see the Next Generation Encryption (NGE) white paper.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enters global configuration mode.
Step 3	**crypto dynamic-map** *dynamic-map-name dynamic-seq-num* **Example:** `Router(config)# crypto dynamic-map test-map 1`	Creates a dynamic crypto map entry and enters crypto map configuration mode.
Step 4	**set transform-set** *transform-set-name1* [*transform-set-name2...transform-set-name6*] **Example:** `Router(config-crypto-m)# set transform-set aesset`	Specifies the transform sets allowed for the crypto map entry. • List multiple transform sets in the order of priority (highest priority first). This is the only configuration statement required in dynamic crypto map entries.
Step 5	**match address** *access-list-id* **Example:** `Router(config-crypto-m)# match address 101`	(Optional) Specifies the list number or name of an extended access list. • This access list determines which traffic should be protected by IPsec and which traffic should not be protected by IPsec

	Command or Action	Purpose
		security in the context of this crypto map entry. **Note** Although access lists are optional for dynamic crypto maps, they are highly recommended. • If an access list is configured, the data flow identity proposed by the IPsec peer must fall within a **permit** statement for this crypto access list. • If an access list is not configured, the device accepts any data flow identity proposed by the IPsec peer. However, if an access list is configured but the specified access list does not exist or is empty, the device drops all packets. This is similar to static crypto maps, which require access lists to be specified. • Care must be taken if the **any** keyword is used in the access list, because the access list is used for packet filtering as well as for negotiation. • You must configure a match address; otherwise, the behavior is not secure, and you cannot enable TED because packets are sent in the clear (unencrypted.)
Step 6	**set-peer** {*hostname* | *ip-address*} **Example:** `Router(config-crypto-m)# set-peer 192.168.101.1`	(Optional) Specifies a remote IPsec peer. Repeat this step for multiple remote peers. **Note** This is rarely configured in dynamic crypto map entries. Dynamic crypto map entries are often used for unknown remote peers.
Step 7	**set security-association lifetime** {**seconds** *seconds* | **kilobytes** *kilobytes* | **kilobytes disable**} **Example:** `Router(config-crypto-m)# set security-association lifetime seconds 720`	(Optional) Overrides (for a particular crypto map entry) the global lifetime value, which is used when negotiating IP Security SAs. **Note** To minimize the possibility of packet loss when rekeying in high bandwidth environments, you can disable the rekey request triggered by a volume lifetime expiry.

	Command or Action	Purpose
Step 8	**set pfs [group1 | group14 | group15 | group16 | group19 | group2 | group20 | group24 | group5]** **Example:** `Router(config-crypto-m)# set pfs group14`	(Optional) Specifies that IPsec should ask for PFS when requesting new security associations for this crypto map entry or should demand PFS in requests received from the IPsec peer. • Group 1 specifies the 768-bit Diffie-Hellman (DH) identifier (default). (No longer recommended). • Group 2 specifies the 1024-bit DH identifier. (No longer recommended). • Group 5 specifies the 1536-bit DH identifier. (No longer recommended) • Group 14 specifies the 2048-bit DH identifier. • Group 15 specifies the 3072-bit DH identifier. • Group 16 specifies the 4096-bit DH identifier. • Group 19 specifies the 256-bit elliptic curve DH (ECDH) identifier. • Group 20 specifies the 384-bit ECDH identifier. • Group 24 specifies the 2048-bit DH/DSA identifier • By default, PFS is not requested. If no group is specified with this command, **group1** is used as the default.
Step 9	**exit** **Example:** `Router(config-crypto-m)# exit`	Exits crypto map configuration mode and returns to global configuration mode.
Step 10	**exit** **Example:** `Router(config)# exit`	Exits global configuration mode.
Step 11	**show crypto dynamic-map** [**tag** *map-name*] **Example:** `Router# show crypto dynamic-map`	(Optional) Displays information about dynamic crypto maps.
Step 12	**configure terminal** **Example:**	Enters global configuration mode.

	Command or Action	Purpose
	`Router# configure terminal`	
Step 13	**crypto map** *map-name seq-num* **ipsec-isakmp dynamic** *dynamic-map-name* [**discover**] **Example:** `Router(config)# crypto map static-map 1 ipsec-isakmp dynamic test-map discover`	(Optional) Adds a dynamic crypto map to a crypto map set. • You should set the crypto map entries referencing dynamic maps to the lowest priority entries in a crypto map set. **Note** You must enter the **discover** keyword to enable TED.
Step 14	**exit** **Example:** `Router(config)# exit`	Exits global configuration mode.

Certain configuration changes take effect only when negotiating subsequent SAs. If you want the new settings to take immediate effect, you must clear the existing SAs so that they are reestablished with the changed configuration. If the router is actively processing IPsec traffic, clear only the portion of the SA database that would be affected by the configuration changes (that is, clear only the SAs established by a given crypto map set). Clearing the entire SA database must be reserved for large-scale changes, or when the router is processing minimal IPsec traffic.

To clear IPsec SAs, use the **clear crypto sa** command with appropriate parameters. (Omitting all parameters clears the full SA database, which clears active security sessions.)

What to do next

After you have successfully created a crypto map set, you must apply the crypto map set to each interface through which IPsec traffic flows. To complete this task, see Applying Crypto Map Sets to Interfaces, on page 301.

Creating Crypto Map Entries to Establish Manual SAs

Perform this task to create crypto map entries to establish manual SAs (that is, when IKE is not used to establish the SAs). To create IPv6 crypto maps entries, you must use the **ipv6** keyword with the **crypto map** command. For IPv4 crypto maps, use the **crypto map** command without the **ipv6** keyword.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. • Enter your password if prompted.
Step 2	**configure terminal** **Example:**	Enters global configuration mode.

	Command or Action	Purpose
	`Router# configure terminal`	
Step 3	**crypto map** [**ipv6**] *map-name seq-num* [**ipsec-manual**] **Example:** `Router(config)# crypto map mymap 10 ipsec-manual`	Specifies the crypto map entry to be created or modified and enters crypto map configuration mode. • For IPv4 crypto maps, use the **crypto map** command without the **ipv6** keyword.
Step 4	**match address** *access-list-id* **Example:** `Router(config-crypto-m)# match address 102`	Names an IPsec access list that determines which traffic should be protected by IPsec and which traffic should not be protected by IPsec in the context of this crypto map entry. • The access list can specify only one **permit** entry when IKE is not used.
Step 5	**set peer** {*hostname* | *ip-address*} **Example:** `Router(config-crypto-m)# set peer 10.0.0.5`	Specifies the remote IPsec peer. This is the peer to which IPsec protected traffic should be forwarded. • Only one peer can be specified when IKE is not used.
Step 6	**set transform-set** *transform-set-name* **Example:** `Router(config-crypto-m)# set transform-set someset`	Specifies which transform set should be used. • This must be the same transform set that is specified in the remote peer's corresponding crypto map entry. **Note** Only one transform set can be specified when IKE is not used.
Step 7	Do one of the following: **set session-key inbound ah** *spi hex-key-string* or **set session-key outbound ah** *spi hex-key-string* **Example:** `Router(config-crypto-m)# set session-key inbound ah 256 9876543210987654987654321098765 4` `Router(config-crypto-m)# set session-key outbound ah 256 fedcbafedcbafedcfedcbafedcbafedc`	Sets the AH security parameter indexes (SPIs) and keys to apply to inbound and outbound protected traffic if the specified transform set includes the AH protocol. • This manually specifies the AH security association to be used with protected traffic.
Step 8	Do one of the following: **set session-key inbound ah esp** *spi* **cipher** *hex-key-string* [**authenticator** *hex-key-string*] or **set session-key outbound ah esp** *spi* **cipher** *hex-key-string* [**authenticator** *hex-key-string*] **Example:**	Sets the Encapsulating Security Payload (ESP) Security Parameter Indexes (SPI) and keys to apply to inbound and outbound protected traffic if the specified transform set includes the ESP protocol. Or

	Command or Action	Purpose
	`Router(config-crypto-m)# set session-key inbound esp 256 cipher 0123456789012345` `Router(config-crypto-m)# set session-key outbound esp 256 cipher abcdefabcdefabcd`	Specifies the cipher keys if the transform set includes an ESP cipher algorithm. Specifies the authenticator keys if the transform set includes an ESP authenticator algorithm. • This manually specifies the ESP security association to be used with protected traffic.
Step 9	**exit** **Example:** `Router(config-crypto-m)# exit`	Exits crypto map configuration mode and returns to global configuration mode.
Step 10	**exit** **Example:** `Router(config)# exit`	Exits global configuration mode.
Step 11	**show crypto map** [**interface** *interface*| **tag** *map-name*] **Example:** `Router# show crypto map`	Displays your crypto map configuration.

For manually established SAs, you must clear and reinitialize the SAs for the changes to take effect. To clear IPsec SAs, use the **clear crypto sa** command with appropriate parameters. (Omitting all parameters clears the entire SA database, which clears active security sessions.)

What to do next

After you have successfully created a crypto map set, you must apply the crypto map set to each interface through which IPsec traffic flows. To complete this task, see Applying Crypto Map Sets to Interfaces, on page 301.

Applying Crypto Map Sets to Interfaces


You must apply a crypto map set to each interface through which IPsec traffic flows. Applying the crypto map set to an interface instructs the device to evaluate the interface's traffic against the crypto map set and to use the specified policy during connection or security association negotiation on behalf of traffic to be protected by the crypto map.

Perform this task to apply a crypto map to an interface.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:**	Enables privileged EXEC mode. • Enter your password if prompted.

	Command or Action	Purpose
	`Router> enable`	
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enters global configuration mode.
Step 3	**interface** *type/number* **Example:** `Router# (config)# interface Gi 0/0/1`	Configures an interface and enters interface configuration mode.
Step 4	**crypto map** *map-name* **Example:** `Router(config-if)# crypto map mymap`	Applies a crypto map set to an interface.
Step 5	**exit** **Example:** `Router(config-if)# exit`	Exits interface configuration mode and returns to global configuration mode.
Step 6	**crypto map** *map-name* **local-address** *interface-id* **Example:** `Router(config)# crypto map mymap local-address loopback0`	(Optional) Permits redundant interfaces to share the same crypto map using the same local identity.
Step 7	**exit** **Example:** `Router(config)# exit`	(Optional) Exits global configuration mode.
Step 8	**show crypto map** [**interface** *interface*] **Example:** `Router# show crypto map`	Displays your crypto map configuration.



CHAPTER 26

Configuring High-availability Seamless Redundancy (HSR)

This chapter provides details about configuring High-availability Seamless Redundancy (HSR) on the Cisco IR8340 Router.

- Information About HSR, on page 303
- Configuring an HSR Ring, on page 306
- Clearing All Node Table and VDAN Table Dynamic Entries , on page 307
- Verifying Configuration, on page 307

Information About HSR


High-availability Seamless Redundancy (HSR) is defined in International Standard IEC 62439-3-2016 clause 5. HSR is similar to Parallel Redundancy Protocol (PRP) but is designed to work in a ring topology. Instead of two parallel independent networks of any topology (LAN-A and LAN-B), HSR defines a ring with traffic in opposite directions. Port-A sends traffic counter clockwise in the ring, and Port-B sends traffic clockwise in the ring.

The HSR packet format is also different from PRP. To allow the router to determine and discard duplicate packets, additional protocol specific information is sent with the data frame. For PRP, this is sent as part of a trailer called the redundancy control trailer (RCT), whereas for HSR this is sent as part of the header called the HSR header. Both the RCT and HSR header contain a sequence number, which is the primary data used to determine if the received frame is the first instance or a duplicate instance.

The non-switching nodes with two interfaces attached to the HSR ring are referred to as Doubly Attached Nodes implementing HSR (DANHs). Similar to PRP, Singly Attached Nodes (SANs) are attached to the HSR ring through a device called a RedBox (Redundancy Box). The RedBox acts as a DANH for all traffic for which it is the source or the destination. The router implements RedBox functionality using Gigabit Ethernet port connections to the HSR ring.

The following figure shows an example of an HSR ring as described in IEC 62439-3. In this example, the RedBox is an IR8340.

Figure 3: Example of HSR Ring Carrying Unicast Traffic



Devices that do not support HSR out of the box (for example, laptops and printers) cannot be attached to the HSR ring directly because all HSR capable devices must be able to process the HSR header on packets received from the ring and add the HSR header to all packets sent into the ring. These nodes are attached to the HSR ring through a RedBox. As shown in the figure above, the RedBox has two ports on the DANH side. Non-HSR SAN devices are attached to the upstream switch ports. The RedBox generates the supervision frames on behalf of these devices so that they are seen as DANH devices on the ring. Because the RedBox emulates these as DANH, they are called Virtual Doubly Attached Nodes (VDAN).

Loop Avoidance

To avoid loops and use network bandwidth effectively, the RedBox does not transmit frames that are already transmitted in same direction. When a node injects a packet into the ring, the packet is handled as follows to avoid loops:

- Unicast packet with destination inside the ring: When the unicast packet reaches the destination node, the packet is consumed by the respective node and is not forwarded.
- Unicast packet with destination not inside the ring: Because this packet does not have a destination node in the ring, it is forwarded by every node in the ring until it reaches the originating node. Because every node has a record of the packet it sent, along with the direction in which it was sent, the originating node detects that packet has completed the loop and drops the packet.
- Multicast packet: A multicast packet is forwarded by each node because there can be more than one consumer of this packet. For this reason a multicast packet always reaches the originating node. However, every node will check whether it has already forwarded the received packet through its outgoing interface.

Once the packet reaches the originating node, the originating node determines that it already forwarded this packet and drops the packet instead of forwarding it again.

HSR RedBox Modes of Operation

An HSR RedBox can operate in one of the following modes that define how HSR handles packets in different scenarios:

- HSR-SAN—This is the most basic mode. In this mode, the RedBox connects SAN devices to an HSR Ring. No other PRP or HSR network is involved in this configuration. In this mode, the traffic on the upstream switch port does not have HSR/PRP tags, and the RedBox represents the SAN device as a VDAN in the ring.
- HSR-PRP—This configuration is used to bridge HSR and PRP networks. The RedBox extracts the data from the PRP frame and generates the HSR frame using this data, and it performs the reverse operation for packets in the opposite direction.

  More than one PRP network can be bridged to one HSR ring and vice versa.
- HSR-HSR—In this mode, two HSR rings are connected through a four-port device called a QuadBox. In this mode, two of the ports on the switch are associated with one HSR ring, and the other two ports are associated with the second HSR ring. The remaining ports on the switch are shut down.



Note Only HSR-SAN mode is supported on IR8340 in Cisco IOS XE Release 17.8.x.

HSR-SAN Mode

In HSR-SAN mode, the RedBox inserts the HSR tag on behalf of the host and forwards the ring traffic, except for frames sent by the node itself, duplicate frames, and frames for which the node is the unique destination. In this mode, packets are handled as follows:

- A source DANH sends a frame passed from its upper layers ("C" frame), prefixes it with an HSR tag to identify frame duplicates, and sends the frame over each port ("A" frame and "B" frame).
- A destination DANH receives two identical frames from each port within a certain interval. The destination DANH removes the HSR tag of the first frame before passing it to its upper layers and discards any duplicate.
- Each node in the HSR ring forwards frames received from one port to the other port of the HSR pair. A node will not forward frames received on one port to the other under the following conditions:
  - The received frame returns to the originating node in the ring.
  - The frame is a unicast frame with a destination MAC address of a node upstream of the receiving node.
  - The node had already sent the same frame in the same direction. This rule prevents a frame from spinning in the ring in an infinite loop.

Note Maximum of 512 entries of node table and 512 entries of VDAN table is supported.

HSR-SAN Interfaces

One HSR ring can be configured on the following specific port pairs:

- Gi0/1/4, Gi0/1/5
- Gi0/1/6, Gi0/1/7

Configuring an HSR Ring

Use the **hsr-ring** command to configure an HSR ring.

```
Router(config)#hsr-ring 1 ?
  entryForgetTime                    Time to clear an entry from duplicate discard table
  fpgamode-DualUplinkEnhancement     Set FPGA register for source mac filtering
  nodeForgetTime                     Time to clear node entry from node table
  nodeRebootInterval                 Time to remain silent after reboot
  pauseFrameTime                     HSR pause frame time
  proxyNodeTableForgetTime           Time to clear node entry from vdan table
  supervisionFrameLifeCheckInterval  HSR supervision frame life check interval
  supervisionFrameOption             HSR supervision frame option
  supervisionFrameRedboxMacaddress   HSR Supervision Frame Redbox mac address
  supervisionFrameTime               HSR Inter supervision frame time

Router(config)#hsr-ring 1 nodeforgetTime ?
  <0-65535>  Node Forget time value

Router(config)#hsr-ring 1 proxyNodeTableForgetTime ?
  <0-65535>  Proxy Node table Forget time value

Router(config)#hsr-ring 1 supervisionFrameOption ?
  mac-da       MAC DA last two bit
  vlan-cfi     Enable CFI for the VLAN tagged frame
  vlan-cos     COS value for the VLAN tag
  vlan-tagged  Enable VLAN tagging

Router(config)#hsr-ring 1 supervisionFrameLifeCheckInterval ?
  <0-65535>  life check interval value for supervision frames

Router(config)#hsr-ring 1 supervisionFrameTime ?
  <0-65535>  time value between supervision frames

Router(config)#hsr-ring 1 supervisionFrameRedboxMacaddress ?
  H.H.H  48 bit redbox mac address
```

Configuring Interface Sub-Mode

Use the following commands to configure the physical ports, which are part of the HSR ring. Once you configure a physical port to be part of an HSR ring, a new interface “HSR-ring” will be created.

```
Router(config)#interface GigabitEthernet 1/1
Router(config-if)#hsr-ring 1
```

Clearing All Node Table and VDAN Table Dynamic Entries

To clear all dynamic entries in the node table, enter


clear hsr node-table

To clear all dynamic entries in the VDAN table, enter

clear hsr vdan-table

Verifying Configuration

Command	Purpose
show hsr ring	Displays HSR ring information.
show hsr statistics	Displays statistics for HSR components. **Note** To clear HSR statistics information, enter the command **clear hsr statistics**.
show hsr node-table	Displays HSR node table.
show hsr vdan-table	Displays HSR Virtual Doubly Attached Node (VDAN) table.
show hsr supervisionFrameLifeCheckInterval	Displays supervision frame life check interval.
show hsr supervisionFrameOption	Displays supervision frame option.
show hsr supervisionFrameRedboxMacaddress	Displays supervision Redbox MAC Address.
show hsr supervisionFrameTime	Displays supervision frame time.



CHAPTER 27

Configuring Parallel Redundancy Protocol (PRP)

This chapter provides details about configuring Parallel Redundancy Protocol (PRP) on the Cisco IR8340 Router.

- Information About PRP, on page 309
- Creating a PRP Channel and Group, on page 310
- Clearing All Node Table and VDAN Table Dynamic Entries, on page 312
- Disabling the PRP Channel and Group, on page 312
- PRP Mode LED, on page 312
- Verifying Configuration, on page 313

Information About PRP

Parallel Redundancy Protocol (PRP) is defined in the International Standard IEC 62439-3. PRP is designed to provide hitless redundancy (zero recovery time after failures) in Ethernet networks.

To recover from network failures, redundancy can be provided by network elements connected in mesh or ring topologies using protocols like RSTP, REP, or MRP, where a network failure causes some reconfiguration in the network to allow traffic to flow again (typically by opening a blocked port). These schemes for redundancy can take between a few milliseconds to a few seconds for the network to recover and traffic to flow again.

PRP uses a different scheme, where the end nodes implement redundancy (instead of network elements) by connecting two network interfaces to two independent, disjointed, parallel networks (LAN-A and LAN-B). Each of these Dually Attached Nodes (DANs) then have redundant paths to all other DANs in the network.


The DAN sends two packets simultaneously through its two network interfaces to the destination node. A redundancy control trailer (RCT), which includes a sequence number, is added to each frame to help the destination node distinguish between duplicate packets. When the destination DAN receives the first packet successfully, it removes the RCT and consumes the packet. If the second packet arrives successfully, it is discarded. If a failure occurs in one of the paths, traffic continues to flow over the other path uninterrupted, and zero recovery time is required.

Non-redundant endpoints in the network that attach only to either LAN-A or LAN-B are known as Singly Attached Nodes (SANs).

A Redundancy Box (RedBox) is used when an end node that does not have two network ports and does not implement PRP needs to implement redundancy. Such an end node can connect to a RedBox, which provides connectivity to the two different networks on behalf of the device. Because a node behind a RedBox appears

for other nodes like a DAN, it is called a Virtual DAN (VDAN). The RedBox itself is a DAN and acts as a proxy on behalf of its VDANs.

Figure 4: PRP Redundant Network



PRP Channels

PRP channel or channel group is a logical interface that aggregates two Gigabit Ethernet interfaces (access, trunk, or routed) into a single link. In the channel group, the lower numbered Gigabit Ethernet member port is the primary port and connects to LAN_A. The higher numbered port is the secondary port and connects to LAN_B. The PRP channel remains up as long as at least one of these member ports remains up and sends traffic. When both member ports are down, the channel is down. The total number of supported PRP channel groups is 2 per router, and the interfaces that can be utilized for each group are fixed.

- PRP channel group 1 always uses Gi0/1/4 for LAN_A and Gi0/1/5 for LAN_B
- PRP channel group 2 always uses Gi0/1/6 for LAN_A and Gi0/1/7 for LAN_B

Creating a PRP Channel and Group

To create and enable a PRP channel and group, follow these steps:

Procedure

Step 1 Enter global configuration mode:

configure terminal

Step 2 Assign two Gigabit Ethernet interfaces to the PRP channel group:

interface {**GigabitEthernet 0/1/4** | **GigabitEthernet 0/1/5**}

Use the **no interface prp-channel 1|2** command to disable PRP on the defined interfaces and shut down the interfaces.

Note
You must apply the Gi 0/1/4 interface before the Gi 0/1/5 interface. So, we recommend using the **interface range** command. Similarly, you must apply the Gi 0/1/6 interface before the Gi 0/1/7 interface.

Step 3 (Optional) For Layer 2 traffic, enter **switchport**. (Default):

switchport

Step 4 (Optional) Set a non-trunking, non-tagged single VLAN Layer 2 (access) interface:

switchport mode access

Step 5 (Optional) Create a VLAN for the Gi 0/1/4 and Gi 0/1/5 interfaces:

switchport access vlan <*value*>

Note
Only required for Layer 2 traffic.

Step 6 (Optional) Disable Precision Time Protocol (PTP) on the switch:

no ptp enable

PTP is enabled by default. You can disable it if you do not need to run PTP.

Step 7 Disable loop detection for the redundancy channel:

no keepalive

Step 8 Disable UDLD for the redundancy channel:

udld port disable

Step 9 Enter sub-interface mode and create a PRP channel group:

prp-channel-group *prp-channel group*

prp-channel group—Value of 1 or 2

The two interfaces that you assigned in step 2 are assigned to this channel group.

The **no** form of this command is not supported.

Step 10 Bring up the PRP channel:

no shutdown

Step 11 Specify the PRP interface and enter interface mode:

interface prp-channel *prp-channel-number*

prp-channel-number—Value of 1 or 2

Step 12 Configure bpdufilter on the prp-channel interface:

spanning-tree bpdufilter enable

Spanning-tree BPDU filter drops all ingress/egress BPDU traffic. This command is required to create independent spanning-tree domains (zones) in the network.

Step 13 (Optional) Configure LAN-A/B ports to quickly get to FORWARD mode:

spanning-tree portfast edge trunk

This command is optional but highly recommended. It improves the spanning-tree convergence time on PRP RedBoxes and LAN-A and LAN-B switch edge ports. It is also highly recommended to configure this command on the LAN_A/LAN_B ports directly connected to a RedBox PRP interface.

Clearing All Node Table and VDAN Table Dynamic Entries

To clear all dynamic entries in the node table, enter

clear prp node-table [**channel-group** *group*]

To clear all dynamic entries in the VDAN table, enter

clear prp vdan-table [**channel-group** *group*]

If you do not specify a channel group, the dynamic entries are cleared for all PRP channel groups.

Note The **clear prp node-table** and **clear prp vdan-table** commands clear only dynamic entries. To clear static entries, use the **no** form of the **nodeTableMacaddress** or **vdanTableMacaddress** commands.

Disabling the PRP Channel and Group

Procedure

Step 1 Enter global configuration mode:

configure terminal

Step 2 Disable the PRP channel:

no interface prp-channel *prp-channel-number*

prp-channel number— Value of 1 or 2

Step 3 Exit interface mode:

exit


PRP Mode LED

The REDUN (Redundancy status) LED is on the faceplate. The router supports the following states.

Label Description	Color and State	Description
REDUN (Redundancy status)	Green (solid)	Redundancy protocols are configured and active.
	Amber (solid)	Redundancy fault detected.

Verifying Configuration

Command	Purpose
show prp control {**ptpLanOption** | **ptpProfile** | **supervisionFrameLifeCheckInterval** | **supervisionFrameOption** | **supervisionFrameRedboxMacaddress** | **supervisionFrameTime** | **nodeForgetTime** | **entryForgetTime** | **nodeRebootIntervalTime** | **pauseFrameTime**}	Displays PRP control information and supervision frame information.
show prp statistics {**egressPacketStatistics** | **ingressPacketStatistics** | **nodeTableStatistics** | **pauseFrameStatistics** | **ptpPacketStatistics**}	Displays statistics for PRP components.



CHAPTER 28


Configuring Resilient Ethernet Protocol (REP)

Resilient Ethernet Protocol (REP) is a Cisco proprietary protocol that provides an alternative to Spanning Tree Protocol (STP) to control network loops, handle link failures, and improve convergence time.

For detailed information on configuring REP, see the Configuring Resilient Ethernet Protocol chapter in *Redundancy Protocol Configuration Guide, Cisco Catalyst IE3x00 Rugged, IE3400 Heavy Duty, and ESS3300 Series Switches*.

Note The following features are not supported on IR8340:

- REP Fast
- REP Day Zero
- REP Segment Id Auto Discovery
- REP Negotiated



CHAPTER 29

System Messages

This chapter contains the following sections:

- Information About Process Management, on page 317
- How to Find Error Message Details, on page 317

Information About Process Management

You can access system messages by logging in to the console through Telnet protocol and monitoring your system components remotely from any workstation that supports the Telnet protocol.

Starting and monitoring software is referred to as process management. The process management infrastructure for a router is platform independent, and error messages are consistent across platforms running on Cisco IOS XE. You do not have to be directly involved in process management, but we recommend that you read the system messages that refer to process failures and other issues.

How to Find Error Message Details

To show further details about a process management or a syslog error message, enter the error message into the Error Message Decoder tool at: https://www.cisco.com/cgi-bin/Support/Errordecoder/index.cgi.

For example, enter the message `%PMAN-0-PROCESS_NOTIFICATION` into the tool to view an explanation of the error message and the recommended action to be taken.

The following are examples of the description and the recommended action displayed by the Error Message Decoder tool for some of the error messages.

Error Message: `%PMAN-0-PROCESS_NOTIFICATION : The process lifecycle notification component failed because [chars]`

Explanation	Recommended Action

The process lifecycle notification component failed, preventing proper detection of a process start and stop. This problem is likely the result of a software defect in the software subpackage.	Note the time of the message and investigate the kernel error message logs to learn more about the problem and see if it is correctable. If the problem cannot be corrected or the logs are not helpful, copy the error message exactly as it appears on the console along with the output of the **show tech-support** command and provide the gathered information to a Cisco technical support representative.

Error Message: `%PMAN-0-PROCFAILCRIT A critical process [chars] has failed (rc [dec])`

Explanation	Recommended Action
A process important to the functioning of the router has failed.	Note the time of the message and investigate the error message logs to learn more about the problem. If the problem persists, copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at: http://www.cisco.com/tac. With some messages, these tools and utilities will supply clarifying information. Search for resolved software issues using the Bug Search Tool at: https://bst.cloudapps.cisco.com/bugsearch. If you still require assistance, open a case with the Technical Assistance Center at: http://tools.cisco.com/ServiceRequestTool/create/, or contact your Cisco technical support representative and provide the representative with the information you have gathered. Attach the following information to your case in nonzipped, plain-text (.txt) format: the output of the **show logging** and **show tech-support** commands and your pertinent troubleshooting logs.

Error Message: `%PMAN-3-PROCFAILOPT An optional process [chars] has failed (rc [dec])`

Explanation	Recommended Action

A process that does not affect the forwarding of traffic has failed.	Note the time of the message and investigate the kernel error message logs to learn more about the problem. Although traffic will still be forwarded after receiving this message, certain functions on the router may be disabled because of this message and the error should be investigated. If the logs are not helpful or indicate a problem you cannot correct, copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at http://www.cisco.com/tac. With some messages, these tools and utilities will supply clarifying information. Search for resolved software issues using the Bug Search Tool at: https://bst.cloudapps.cisco.com/bugsearch. If you still require assistance, open a case with the Technical Assistance Center at: http://tools.cisco.com/ServiceRequestTool/create/, or contact your Cisco technical support representative and provide the representative with the information you have gathered. Attach the following information to your case in nonzipped, plain-text (.txt) format: the output of the **show logging** and **show tech-support** commands and your pertinent troubleshooting logs.

Error Message: `%PMAN-3-PROCFAIL The process [chars] has failed (rc [dec])`

Explanation	Recommended Action
The process has failed as the result of an error.	This message will appear with other messages related to the process. Check the other messages to determine the reason for the failures and see if corrective action can be taken. If the problem persists, copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at: http://www.cisco.com/tac. With some messages, these tools and utilities will supply clarifying information. Search for resolved software issues using the Bug Search Tool at: https://bst.cloudapps.cisco.com/bugsearch. If you still require assistance, open a case with the Technical Assistance Center at: http://tools.cisco.com/ServiceRequestTool/create/, or contact your Cisco technical support representative and provide the representative with the information you have gathered. Attach the following information to your case in nonzipped, plain-text (.txt) format: the output of the **show logging** and **show tech-support** commands and your pertinent troubleshooting logs.

Error Message: `%PMAN-3-PROCFAIL_IGNORE [chars] process exits and failures are being ignored due to debug settings. Normal router functionality will be affected. Critical router functions like RP switchover, router reload, FRU resets, etc. may not function properly.`

Explanation	Recommended Action
A process failure is being ignored due to the user-configured debug settings.	If this behavior is desired and the debug settings are set according to a user's preference, no action is needed. If the appearance of this message is viewed as a problem, change the debug settings. The router is not expected to behave normally with this debug setting. Functionalities such as SSO switchover, router reloads, FRU resets, and so on will be affected. This setting should only be used in a debug scenario. It is not normal to run the router with this setting.

Error Message: `%PMAN-3-PROCHOLDDOWN The process [chars] has been helddown (rc [dec])`

Explanation	Recommended Action
The process was restarted too many times with repeated failures and has been placed in the hold-down state.	This message will appear with other messages related to the process. Check the other messages to determine the reason for the failures and see if corrective action can be taken. If the problem persists, copy the message exactly as it appears on the console or in the system log. Research and attempt to resolve the issue using the tools and utilities provided at: http://www.cisco.com/tac. With some messages, these tools and utilities will supply clarifying information. Search for resolved software issues using the Bug Search Tool at: https://bst.cloudapps.cisco.com/bugsearch. If you still require assistance, open a case with the Technical Assistance Center at: http://tools.cisco.com/ServiceRequestTool/create/, or contact your Cisco technical support representative and provide the representative with the information you have gathered. Attach the following information to your case in nonzipped, plain-text (.txt) format: the output of the **show logging** and **show tech-support** commands and your pertinent troubleshooting logs.

Error Message: `%PMAN-3-RELOAD_RP_SB_NOT_READY : Reloading: [chars]`

Explanation	Recommended Action
The route processor is being reloaded because there is no ready standby instance.	Ensure that the reload is not due to an error condition.

Error Message: `%PMAN-3-RELOAD_RP : Reloading: [chars]`

Explanation	Recommended Action

The RP is being reloaded.	Ensure that the reload is not due to an error condition. If it is due to an error condition, collect information requested by the other log messages.

Error Message: `%PMAN-3-RELOAD_SYSTEM : Reloading: [chars]`

Explanation	Recommended Action
The system is being reloaded.	Ensure that the reload is not due to an error condition. If it is due to an error condition, collect information requested by the other log messages.

Error Message: `%PMAN-3-PROC_BAD_EXECUTABLE : Bad executable or permission problem with process [chars]`

Explanation	Recommended Action
The executable file used for the process is bad or has permission problem.	Ensure that the named executable is replaced with the correct executable.

Error Message: `%PMAN-3-PROC_BAD_COMMAND:Non-existent executable or bad library used for process <process name>`

Explanation	Recommended Action
The executable file used for the process is missing, or a dependent library is bad.	Ensure that the named executable is present and the dependent libraries are good.

Error Message: `%PMAN-3-PROC_EMPTY_EXEC_FILE : Empty executable used for process [chars]`

Explanation	Recommended Action
The executable file used for the process is empty.	Ensure that the named executable is non-zero in size.

Error Message: `%PMAN-5-EXITACTION : Process manager is exiting: [chars]`

Explanation	Recommended Action
The process manager is exiting.	Ensure that the process manager is not exiting due to an error condition. If it is due to an error condition, collect information requested by the other log messages.

Error Message: `%PMAN-6-PROCSHUT : The process [chars] has shutdown`

Explanation	Recommended Action
The process has gracefully shut down.	No user action is necessary. This message is provided for informational purposes only.


Error Message: `%PMAN-6-PROCSTART : The process [chars] has started`

Explanation	Recommended Action

The process has launched and is operating properly.	No user action is necessary. This message is provided for informational purposes only.

Error Message: `%PMAN-6-PROCSTATELESS : The process [chars] is restarting stateless`

Explanation	Recommended Action
The process has requested a stateless restart.	No user action is necessary. This message is provided for informational purposes only.



CHAPTER 30

Environmental Monitoring

This chapter contains the following sections:

- Environmental Monitoring, on page 323
- Environmental Monitoring and Reporting Functions, on page 323
- Environmental Monitoring Functions, on page 324
- Environmental Reporting Functions, on page 325
- Additional References, on page 325

Environmental Monitoring

The router provides a robust environment-monitoring system with several sensors that monitor the system temperatures. The following are some of the key functions of the environmental monitoring system:

- Monitoring temperature of CPUs and Motherboard
- Recording abnormal events and generating notifications
- Monitoring Simple Network Management Protocol (SNMP) traps
- Generating and collecting Onboard Failure Logging (OBFL) data
- Sending call home event notifications
- Logging system error messages
- Displaying present settings and status

Environmental Monitoring and Reporting Functions

Monitoring and reporting functions allow you to maintain normal system operation by identifying and resolving adverse conditions prior to loss of operation.

- Environmental Monitoring Functions, on page 324
- Environmental Reporting Functions, on page 325

Environmental Monitoring Functions

Environmental monitoring functions use sensors to monitor the temperature of the cooling air as it moves through the chassis.

The router is expected to meet the following environmental operating conditions

- Operating Temperature: -40°F to 140°F (-40°C to 60°C)
- Operating Humidity: 5% to 95% relative humidity (non-condensing)
- Operating Altitude: Up to 10,000 ft (3048 m)



Note Refer to the *Cisco Catalyst IR8340 Rugged Series Router Harware Installation Guide* for restricted ranges of the environmental operating conditions for exceptions which is specially applicable for harsh industrial deployments.

The following table displays the levels of status conditions used by the environmental monitoring system.

Table 19: Levels of Status Conditions Used by the Environmental Monitoring System

Status Level	Description
Normal	All monitored parameters are within normal tolerance.
Warning	The system has exceeded a specified threshold. The system continues to operate, but operator action is recommended to bring the system back to a normal state.
Critical	An out-of-tolerance temperature or voltage condition exists. Although the system continues to operate, it is approaching shutdown. Immediate operator action is required.

The environmental monitoring system sends system messages to the console, for example, when the conditions described here are met:

Temperature and Voltage Exceed Max/Min Thresholds

The following example shows the warning messages indicating the maximum and minimum thresholds of the temperature or voltage:

```
Warnings :
--------
For all the temperature sensors (name starting with “Temp:”) above,
the critical warning threshold is 100C (100C and higher)
the warning threshold is 80C (range from 80C to 99C)
the low warning threshold is 1C (range from -inf to 1C).

For all voltage sensors (names starting with "V:"),
the high warning threshold starts at that voltage +10%. (voltage + 10% is warning)
the low warning threshold starts at the voltage -10%. (voltage - 10% is warning)
```

Environmental Reporting Functions

You can retrieve and display environmental status reports using the following commands:

- **show diag all eeprom**
- **show environment**
- **show environment all**
- **show inventory**
- **show platform**
- **show platform diag**
- **show platform software status control-processor**
- **show diag slot R0 eeprom detail**
- **show version**
- **show power**

These commands show the current values of parameters such as temperature and voltage.

The environmental monitoring system updates the values of these parameters every 60 seconds.

Additional References


The following sections provide references related to the power efficiency management feature.

MIBs

MIBs	MIBs Link
CISCO-ENTITY-FRU-CONTROL-MIB	To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use the Cisco MIB Locator at: http://www.cisco.com/go/mibs.

Technical Assistance

Description	Link
The Cisco Support website provides extensive online resources, including documentation and tools for troubleshooting and resolving technical issues with Cisco products and technologies. To receive security and technical information about your products, you can subscribe to various services, such as the Product Alert Tool (accessed from Field Notices), the Cisco Technical Services Newsletter, and Really Simple Syndication (RSS) Feeds. Access to most tools on the Cisco Support website requires a Cisco.com user ID and password.	http://www.cisco.com/cisco/web/support/index.html



CHAPTER 31

IOx Application Hosting

This section contains the following topics:

- Application Hosting, on page 327
- Information About Application Hosting, on page 327
- Application Hosting on the IR8340 Router, on page 329
- How to Configure Application Hosting, on page 331
- Installing and Uninstalling Apps, on page 336
- Overriding the App Resource Configuration, on page 337
- Verifying the Application Hosting Configuration, on page 338
- IOx Configuration with ERSPAN, on page 340
- Configuration Examples for Application Hosting, on page 341
- Signed Application Support, on page 342
- Cisco Cyber Vision, on page 342

Application Hosting

A hosted application is a software as a service solution, and it can be run remotely using commands. Application hosting gives administrators a platform for leveraging their own tools and utilities.

This chapter describes the Application Hosting feature and how to enable it.

Information About Application Hosting

This section provides information about Application Hosting.

Need for Application Hosting

The move to virtual environments has given rise to the need to build applications that are reusable, portable, and scalable. Application hosting gives administrators a platform for leveraging their own tools and utilities. An application, hosted on a network device, can serve a variety of purposes. This ranges from automation, configuration management monitoring, and integration with existing tool chains.

Cisco devices support third-party off-the-shelf applications built using Linux tool chains. Users can run custom applications cross-compiled with the software development kit that Cisco provides.

IOx Overview

IOx is a Cisco-developed end-to-end application framework that provides application hosting capabilities for different application types on Cisco network platforms.

From Cisco IOS-XE Release 17.8.1, IOx installation on IR8340 requires Cisco supported mSATA to be the storage device. There are two partitions on the mSATA. One for IOS, and the other for IOx. The IOS partition will be mounted on **/mnt/msata** and IOx partition will be mounted on **/vol/harddisk**. OIR is not supported for mSATA device. When mSATA is inserted to the router, the router needs to be reloaded to have two partitions. If mSATA is not present, bootflash is used for application hosting.

In Cisco IOS XE Release 17.7.x, SD card is used as storage device for IOx. Any upgrade from 17.7.x to 17.8.x requires all applications to be reinstalled.

Cisco Application Hosting Overview

The IR8340 allows you to deploy applications using the application hosting CLI commands. You can also deploy applications using the Local Manager.

Application hosting provides the following services:

- Launches designated applications in containers.
- Checks available resources (memory, CPU, and storage), and allocates and manages them.
- Provides support for console logging.
- Provides a CLI endpoint.
- Provides an application hosting infrastructure referred to as Cisco Application Framework (CAF).
- Helps in the setup of platform-specific networking (packet-path) via VirtualPortGroup and management interfaces.

The container is referred to as the virtualization environment provided to run the guest application on the host operating system. The Cisco IOS-XE virtualization services provide manageability and networking models for running guest applications. The virtualization infrastructure allows the administrator to define a logical interface that specifies the connectivity between the host and the guest. IOx maps the logical interface into the Virtual Network Interface Card (vNIC) that the guest application uses.

Applications to be deployed in the containers are packaged as TAR files. The configuration that is specific to these applications is also packaged as part of the TAR file.

The management interface on the device connects the application hosting network to the IOS management interface. The Layer 3 interface of the application receives the Layer 2 bridged traffic from the IOS management interface. The management interface connects through the management bridge to the container/application interface. The IP address of the application must be on the same subnet as the management interface IP address.

IOXMAN


IOXMAN is a process that establishes a tracing infrastructure to provide logging or tracing services for guest applications, except Libvirt, that emulates serial devices. IOXMAN is based on the lifecycle of the guest application to enable and disable the tracing service, to send logging data to IOS syslog, to save tracing data to IOx tracelog, and to maintain IOx tracelog for each guest application.

Application Hosting on the IR8340 Router

This section describes the application hosting characteristics specific to the IR8340 router.

Application hosting can be achieved using the application hosting CLI commands as well as using Local Manager. Application hosting using Local Manager is done through WebUI. To deploy the applications using Local Manager, enable WebUI and then log in to Local Manager.

Figure 5: Local Manager



1. From WebUI, click on **Configuration > Services > IOx**
2. Log in using the username and password configured.
3. Follow the steps for the application lifecycle in the Cisco IOx Local Manager Reference Guide.

The next section explains the deployment of an application using the application hosting CLI commands.

Application Hosting on Layer 2 and Layer 3 Interfaces

The application configurations have two interfaces to support L2 and L3 traffic from the LAN and WAN ports respectively.

For application hosting, you can configure the L2 and L3 interfaces as following:

- L2 interfaces are configured with AppGigabitEthernet and VLAN with IP address in the same VLAN network, which are used or forwarding the L2 app traffic. Dedicated VLAN range 2340 - 2349 must be used for configuring L2 interfaces of application and to communicate the application for L2 traffic.

  You should configure the AppGigEthernet interface as a trunk interface.

- L3 interfaces or gateway interfaces are configured with Virtual port group, and IP address in the same network as VPG, which are used for forwarding the L3 traffic to applications.

VirtualPortGroup


The VirtualPortGroup is a software construct on Cisco IOS that maps to a Linux bridge IP address. As such, the VirtualPortGroup represents the switch virtual interface (SVI) of the Linux container. Each bridge can contain multiple interfaces; each mapping to a different container. Each container can also have multiple interfaces.

VirtualPortGroup interfaces are configured by using the interface virtualportgroup command. Once these interfaces are created, IP address and other resources are allocated.

The VirtualPortGroup interface connects the application hosting network to the IOS routing domain. The Layer 3 interface of the application receives routed traffic from IOS. The VirtualPortGroup interface connects through the SVC Bridge to the container/application interface.

The following graphic helps to understand the relationship between the VirtualPortGroup and other interfaces.

Figure 6: Virtual Port Group Mapping



vNIC

For the container life cycle management, the Layer 3 routing model that supports one container per internal logical interface is used. This means that a virtual Ethernet pair is created for each application; and one interface of this pair, called vNIC is part of the application container. The other interface, called vpgX is part of the host system.

NIC is the standard Ethernet interface inside the container that connects to the platform dataplane for the sending and receiving of packets. IOx is responsible for the gateway (VirtualPortGroup interface), IP address, and unique MAC address assignment for each vNIC in the container.

The vNIC inside the container/application are considered as standard Ethernet interfaces.

How to Configure Application Hosting

The following sections provide information about the various tasks that comprise the configuration of application hosting.

Enabling IOx

Perform this task to enable access to the IOx Local Manager. The IOx Local Manager provides a web-based user interface that you can use to manage, administer, monitor, and troubleshoot apps on the host system, and to perform a variety of related activities.



Note In the steps that follow, IP HTTP commands do not enable IOx, but allow the user to access the WebUI to connect the IOx Local Manager.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router>enable`	Enables privileged EXEC mode. Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enters global configuration mode.
Step 3	**iox** **Example:** `Router(config)#iox`	Enables IOx.
Step 4	**ip http server** **Example:** `Router(config)#ip http server`	Enables the HTTP server on your IP or IPv6 system.
Step 5	**ip http secure-server** **Example:** `Router(config)#ip http secure-server`	Enables a secure HTTP (HTTPS) server.
Step 6	**username** *name* **privilege** *level* **secret** {**0** | **7** | *user-password*} *encrypted-password* **Example:** `Router(config)#username cisco privilege 15 secret 0 cisco`	Establishes a username-based authentication system and privilege level for the user. The username privilege level must be configured as 15.

	Command or Action	Purpose
Step 7	**end** **Example:** `Router(config)#end`	Exits interface configuration mode and returns to privileged EXEC mode.

Configuring Application Hosting to Layer 2 Interfaces

Follow these steps to configure application hosting to Layer 2 interfaces.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Device>enable`	Enables privileged EXEC mode. Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Device#configure terminal`	Enters global configuration mode.
Step 3	**interface AppGigEthernet** *number* **Example:** `Device(config)#interface AppGigabitEthernet 0/1/1`	Configures the AppGigabitEthernet and enters interface configuration mode.
Step 4	**switchport mode trunk** **Example:** `Device(config-if)#switchport mode trunk`	Sets the interface into permanent trunking mode and negotiates to convert the neighboring link into a trunk link.
Step 5	**exit** **Example:** `Device(config-if)#exit`	Exits interface configuration mode and returns to global configuration mode.
Step 6	**app-hosting appid** *name* **Example:** `Device(config)# app-hosting appid iperf_3`	Configures the application and enters the application hosting configuration mode.
Step 7	**app-vnic AppGigabitEthernet trunk** **Example:** `Device(config-app-hosting)# app-vnic AppGigabitEthernet trunk`	Configures a trunk port for an application, and enters application-hosting trunk-configuration mode.

	Command or Action	Purpose
Step 8	**vlan** *vlan-ID* **guest-interface** *guest-interface-number* **Example:** `Device(config-app-hosting-trunk)# vlan 2340 guest-interface 1`	Configures a VLAN guest interface and enters application-hosting VLAN-access IP configuration mode.
Step 9	**guest-ipaddress** *ip-address* **netmask** *netmask* **Example:** `Device(config-app-hosting-vlan-access-ip)# guest-ipaddress 20.1.1.2 netmask 255.255.255.0`	Configures a static IP address.
Step 10	**end** **Example:** `Device(config-config-app-hosting-vlan-access-ip)# end`	Exits application-hosting VLAN-access IP configuration mode and returns to privileged EXEC mode.

Configuring a VirtualPortGroup to a Layer 3 Data Port

Multiple Layer 3 data ports can be routed to one or more VirtualPortGroups or containers. VirutalPortGroups and Layer 3 data ports must be on different subnets.

Enable the **ip routing** command to allow external routing on the Layer 3 data-port.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Device>enable`	Enables privileged EXEC mode. Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Device#configure terminal`	Enters global configuration mode.
Step 3	**ip routing** **Example:** `Device(config)#ip routing`	Enables IP routing. The **ip routing** command must be enabled to allow external routing on Layer 3 data ports.
Step 4	**interface type number** **Example:** `Device(config)#interface gigabitethernet 0/0/0`	Configures an interface and enters interface configuration mode

	Command or Action	Purpose
Step 5	**no switchport** **Example:** `Device(config-if)#no switchport`	Places the interface in Layer 3 mode, and makes it operate more like a router interface rather than a switch port.
Step 6	**ip address ip-address mask** **Example:** `Device(config-if)#ip address 10.1.1.1 255.255.255.0`	Configures an IP address for the interface.
Step 7	**exit** **Example:** `Device(config-if)#exit`	Exits interface configuration mode and returns to global configuration mode.
Step 8	**interface type number** **Example:** `Device(config)#interface virtualportgroup 0`	Configures an interface and enters interface configuration mode.
Step 9	**ip address** *ip-address mask* **Example:** `Device(config-if)#ip address 20.1.2.1 255.255.255.0`	Configures an IP address for the interface.
Step 10	**end** **Example:** `Device(config-if)#end`	Exits interface configuration mode and returns to privileged EXEC mode.
Step 11	**configure terminal** **Example:** `Device#configure terminal`	Enters global configuration mode.
Step 12	**interface vlan** *vlan-id* **Example:** `Device(config-if)#interface vlan 2340`	Configure the SVI interface for supporting L2 traffic. VLAN range: 2340 - 2349.
Step 13	**ip address** *ip-address mask* **Example:** `Device(config-if)#ip address 20.1.1.1 255.255.255.0`	Configures an IP address and IP subnet mask.
Step 14	**end** **Example:** `Device(config-if)#end`	Exits interface configuration mode and returns to privileged EXEC mode.

	Command or Action	Purpose
Step 15	**configure terminal** **Example:** `Device#configure terminal`	Enters global configuration mode.
Step 16	**app-hosting appid** *name* **Example:** `Device(config)#app-hosting appid iperf_3`	Configures the application and enters the application hosting configuration mode.
Step 17	**app-vnic gateway2 virtualportgroup 0 guest-interface 2** **Example:** `Device(config-app-hosting)#app-vnic gateway2 virtualportgroup 0 guest-interface 2`	Configures the application interface and the gateway of the application. You can create multiple interfaces with different virtualportgroups.
Step 18	**guest-ipaddress** *ip-address* **netmask** *netmask* **Example:** `Device(config-app-hosting-gateway0)#guest-ipaddress 20.1.2.2 netmask 255.255.255.0`	Configures the application Ethernet interface ip address.
Step 19	**app-default-gateway** *ip-address* **guest-interface 2** **Example:** `Device(config-app-hosting-gateway0)#app-default-gateway 20.1.2.1 guest-interface 2`	Configures the default gateway for the application. Only one gateway is supported.
Step 20	**end** **Example:** `Device#end`	Exits global configuration mode and returns to privileged EXEC configuration mode.

Configuring Docker Run Time Options

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Device >enable`	Enables privileged EXEC mode. Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Device#configure terminal`	Enters global configuration mode.

	Command or Action	Purpose
Step 3	**app-hosting appid** *name* **Example:** `Router(config)#app-hosting appid app1`	Enables application hosting and enters application hosting configuration mode.
Step 4	**app-hosting docker** **Example:** `Device(config-app-hosting)# app-resource docker`	Enters application-hosting docker-configuration mode to specify application resource updates. Application start-up scripts are activated.
Step 5	**run-opts** *options* **Example:** `Device(config-app-hosting-docker)# run-opts 1 "-v $(APP_DATA):/data"`	Specifies the Docker run time options.
Step 6	**end** **Example:** `Device(config-app-hosting-docker)# end`	Exits application-hosting docker-configuration mode and returns to privileged EXEC mode.

Example

```
app-hosting appid app1
app-resource docker
run-opts 1 "--tmpfs /tmp:rw,size=128m"
```

Installing and Uninstalling Apps

Follow these steps to install or uninstall apps:

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Device >enable`	Enables privileged EXEC mode. Enter your password if prompted.
Step 2	**app-hosting install appid** *application-name* **package** *package-path* **Example:** `Device# app-hosting install appid lxc_app package flash:my_iox_app.tar`	Installs an app from the specified location. The app can be installed from any local storage location such as, flash, bootflash, and usbflash0.
Step 3	**app-hosting activate appid** *application-name* **Example:**	Activates the application.

	Command or Action	Purpose
	`Device# app-hosting activate appid app1`	This command validates all application resource requests, and if all resources are available the application is activated; if not, the activation fails.
Step 4	**app-hosting start appid** *application-name* **Example:** `Device# app-hosting start appid app1`	Starts the application. Application start-up scripts are activated.
Step 5	**app-hosting stop appid** *application-name* **Example:** `Device#app-hosting stop appid app1`	Stops the application.
Step 6	**app-hosting deactivate appid** *application-name* **Example:** `Device# app-hosting deactivate appid app1`	Deactivates all resources allocated for the application.
Step 7	**app-hosting uninstall appid** *application-name* **Example:** `Device# app-hosting uninstall appid app1`	Uninstalls the application. Uninstalls all packaging and images stored. All changes and updates to the application are also removed.

What to do next



Note The app traffic to VirtualPortGroup interfaces will be blocked after you uninstall the app and reinstall it again with the same IP addresses, because the ARP entry for VirtualPortGroup interface is not updated after the app is reinstalled. You must clear the ARP cache for those IP addresses to be manually refreshed for the ARP.

Overriding the App Resource Configuration

Resource changes will take effect only after the app-hosting activate command is configured.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router>enable`	Enables privileged EXEC mode. Enter your password if prompted.

	Command or Action	Purpose
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enters global configuration mode.
Step 3	**app-hosting appid** *name* **Example:** `Router(config)#app-hosting appid app1`	Enables application hosting and enters application hosting configuration mode.
Step 4	**app-resource profile** *name* **Example:** `Router(config-app-hosting)#app-resource profile custom`	Configures the custom application resource profile, and enters custom application resource profile configuration mode. Only the custom profile name is supported.
Step 5	**cpu** *unit* **Example:** `Router(config-app-resource-profile-custom)# cpu 800`	Changes the default CPU allocation for the application. Resource values are application-specific, and any adjustment to these values must ensure that the application can run reliably with the changes.
Step 6	**memory** *memory* **Example:** `Router(config-app-resource-profile-custom)# memory 512`	Changes the default memory allocation.
Step 7	**vcpu** *number* **Example:** `Router(config-app-resource-profile-custom)# vcpu 2`	Changes the virtual CPU (vCPU) allocation for the application.
Step 8	**end** **Example:** `Router(config-app-resource-profile-custom)# end`	Exits custom application resource profile configuration mode and returns to privileged EXEC mode.

Verifying the Application Hosting Configuration

1. **enable**

Enables privileged EXEC mode. Enter your password if prompted.

Example:

```
Device>enable
```

2. show iox-service

Displays the status of all IOx services

Example:

```
Device# show iox-service
IOx Infrastructure Summary:
---------------------------
IOx service (CAF) : Running
IOx service (HA) : Not Supported
IOx service (IOxman) : Running
IOx service (Sec storage) : Running
Libvirtd 5.5.0 : Running
Dockerd 18.03.0 : Running
Device#
```

3. show app-hosting detail

Displays detailed information about the application.

Example:

```
Device#show app-hosting detail appid iperf_3
App id : iperf_3
Owner : iox
State : RUNNING
Application
Type : docker
Name : networkstatic/iperf3
Version : latest
Description :
Author : Brent
Path : bootflash:iperf3x86.tar
URL Path :
Activated profile name : custom

Resource reservation
Memory : 500 MB
Disk : 500 MB
CPU : 173 units
CPU-percent : 5 %
VCPU : 1

Platform resource profiles
Profile Name CPU(unit) Memory(MB) Disk(MB)
------------------------------------------------------------

Attached devices
Type Name Alias
---------------------------------------------
serial/shell iox_console_shell serial0
serial/aux iox_console_aux serial1
serial/syslog iox_syslog serial2
serial/trace iox_trace serial3
Network interfaces
---------------------------------------
eth0:
MAC address : 52:54:dd:67:81:6f
IPv6 address : ::
Network name : mgmt-bridge300
eth3:
MAC address : 52:54:dd:b2:4d:86
IPv4 address : 20.1.2.2
IPv6 address : ::
Network name : VPG0
eth1:
MAC address : 52:54:dd:f2:29:67
IPv4 address : 20.1.1.2
```

```
IPv6 address : 2001:1::5054:ddff:fef2:2967
Network name : mgmt-bridge-v2340


Docker
------
Run-time information
Command :
Entry-point : /bin/sleep 10000
Run options in use : --entrypoint '/bin/sleep 10000'
Package run options :
Application health information
Status : 0
Last probe error :
Last probe output :

Device#
```

4. show app-hosting list

Displays the list of applications and their status.

Example:

```
Device#show app-hosting list
App id                           State
---------------------------------------------------------
app1                             RUNNING
```

IOx Configuration with ERSPAN

The traffic can be spanned to IOX applications with the ERSPAN configurations on LAN or WAN ports. ACL can be applied on traffic like ERSPAN with FSPAN.

Procedure

Step 1 Create ACL like any extended access-list.

Example:

```
ip access-list extended ACL120
10 permit ip host 120.1.1.1 host 120.120.120.120
```

Step 2 Configure ERSPAN session for LAN or WAN ports to span data to the application.

- Configure ERSPAN session for LAN ports to span data to the application.

  Note
  ERSPAN Session ID 1 - 4 are only supported on LAN ports.

  ```
  monitor session 1 type erspan-source
  source interface Gi0/1/10 rx
  filter access-group ACL120
  destination
  erspan-id 1
  ip address 20.1.2.2 <== Ip address of L2/VLAN interface on APP
  origin ip address 68.68.68.68
  ```

- configuring ERSPAN session for WAN ports to span data to the application.

```
monitor session 1 type erspan-source
source interface Gi0/0/0 rx
filter access-group ACL120
destination
erspan-id 1
ip address 20.1.1.2 <== Ip address of L3 interface on APP
origin ip address 68.68.68.68
```

Configuration Examples for Application Hosting

See the following examples:

Example: Enabling IOx

```
Device> enable
Device# configure terminal
Device(config)# iox
Device(config)# ip http server
Device(config)# ip http secure-server
Device(config)# username cisco privilege 15 secret 0 cisco
Device(config)# end
```

Example: Configuring a VirtualPortGroup to a Layer 3 Data Port

```
Device> enable
Device# configure terminal
Device(config)# ip routing
Device(config)# interface gigabitethernet 0/0/0
Device(config-if)# no switchport
Device(config-if)# ip address 10.1.1.1 255.255.255.0
Device(config-if)# exit
Device(config)# interface virtualportgroup 0
Device(config-if)# ip address 192.168.0.1 255.255.255.0
Device(config-if)# end
```

Example: Installing and Uninstalling Apps

```
Device> enable
Device# app-hosting install appid app1 package flash:my_iox_app.tar
Device# app-hosting activate appid app1
Device# app-hosting start appid app1
Device# app-hosting stop appid app1
Device# app-hosting deactivate appid app1
Device# app-hosting uninstall appid app1
```

Example: Overriding the App Resource Configuration

```
Device# configure terminal
```

```
Device(config)# app-hosting appid app1
Device(config-app-hosting)# app-resource profile custom
Device(config-app-resource-profile-custom)# cpu 800
Device(config-app-resource-profile-custom)# memory 512
Device(config-app-resource-profile-custom)# vcpu 2
Device(config-app-resource-profile-custom)# end
```

Signed Application Support

To install a signed application, signed verification has to be enabled on the device. Signed verification can be enabled or disabled by the following command:

app-hosting verification {**enable**|**disable**}

The signed verification enabled or disabled status can be verified by the **show app-hosting infra** command:

```
# show app-hosting infra
IOX version: 2.7.0.0
App signature verification: disabled
Internal working directory: /vol/harddisk/iox

Application Interface Mapping
AppGigabitEthernet Port # Interface Name Port Type Bandwidth
1 AppGigabitEthernet0/1/1 KR Port - Internal 10G


CPU:
Quota: 99(Percentage)
Available: 99(Percentage)
Quota: 3465(Units)
Available: 0(Units)
```

When signed verification is enabled, any unsigned app can not be activated, and signed app can move to different states irrespective of the app sign verification enabled or disabled.


After enabling the signed verification, follow the instructions in Installing and Uninstalling Apps, on page 336 to install the application.

Cisco Cyber Vision

Cisco Cyber Vision Center (CVC) gives more visibility into Industrial IoT networks across Industrial Control Systems (ICS) with real-time monitoring of control and data networks. On IoT IOS-XE platforms beginning with release 17.4, integration of CVC is supported by deploying IOX Cyber Vision sensor. With this sensor deployed on IoT Routers, the platform can forward the traffic from IOX applications to Cyber Vision Center for real-time monitoring and we can forward any captured PCAP files to Vision center from IOX application. The minimum Cyber Vision release is 4.1.1 to work with the IR8340. For more information about CVC, see the release notes:

https://www.cisco.com/c/en/us/support/security/cyber-vision/products-release-notes-list.html

For more information about CVC installation and ERSPAN with CVC, see the Cisco Cyber Vision Network Sensor Installation Guide for Cisco IR8340.



CHAPTER 32

ROM Monitor Overview

- ROM Monitor Overview, on page 343
- Access ROM Monitor Mode, on page 344
- Displaying the Configuration Register Setting, on page 346
- Environment Variable Settings, on page 347
- Exiting ROM Monitor Mode, on page 348

ROM Monitor Overview

The *ROM Monitor* is a bootstrap program that initializes the hardware and boots the Cisco IOS XE software when you power on or reload a router. When you connect a terminal to the router that is in ROM Monitor mode, the ROM Monitor (rommon 1>) prompt is displayed.

During normal operation, users do not use ROM Monitor mode. ROM Monitor mode is used only in special circumstances, such as reinstalling the entire software set, resetting the router password, or specifying a configuration file to use at startup.

The *ROM Monitor software* is known by many names. It is sometimes called *ROMMON* because of the CLI prompt in ROM Monitor mode. The ROM Monitor software is also called the *boot software* , *boot image* , or *boot helper*. Although it is distributed with routers that use the Cisco IOS XE software, ROM Monitor is a separate program from the Cisco IOS XE software. During normal startup, the ROM Monitor initializes the router, and then control passes to the Cisco IOS XE software. After the Cisco IOS XE software takes over, the ROM Monitor is no longer in use.

Environmental Variables and the Configuration Register

Two primary connections exist between ROM Monitor and the Cisco IOS XE software: the ROM Monitor environment variables and the configuration register.

The ROM Monitor environment variables define the location of the Cisco IOS XE software and describe how to load it. After the ROM Monitor has initialized the router, it uses the environment variables to locate and load the Cisco IOS XE software.

⚠

Caution Be caucious to change ROMMON variables, because it may cause unexpected consequences.

The *configuration register* is a software setting that controls how a router starts up. One of the primary uses of the configuration register is to control whether the router starts in ROM Monitor mode or Administration

EXEC mode. The configuration register is set in either ROM Monitor mode or Administration EXEC mode as needed. Typically, you set the configuration register using the Cisco IOS XE software prompt when you need to use ROM Monitor mode. When the maintenance in ROM Monitor mode is complete, you change the configuration register so the router reboots with the Cisco IOS XE software.

Accessing ROM Monitor Mode with a Terminal Connection

When the router is in ROM Monitor mode, you can access the ROM Monitor software only from a terminal connected directly to the console port of the card. Because the Cisco IOS XE software (EXEC mode) is not operating, nonmanagement interfaces are not accessible. Basically, all Cisco IOS XE software resources are unavailable. The hardware is available, but no configuration exists to make use of the hardware.

Network Management Access and ROM Monitor Mode

It is important to remember that ROM Monitor mode is a router mode, not a mode within the Cisco IOS XE software. It is best to remember that ROM Monitor software and the Cisco IOS XE software are two separate programs that run on the same router. At any given time, the router runs only one of these programs.

One area that can be confusing when using ROM Monitor and the Cisco IOS XE software is the area that defines the IP configuration for the Management Ethernet interface. Most users are comfortable with configuring the Management Ethernet interface in the Cisco IOS XE software. When the router is in ROM Monitor mode, however, the router does not run the Cisco IOS XE software, so that Management Ethernet interface configuration is not available.

When you want to access other devices, such as a TFTP server, while in ROM Monitor mode on the router, you must configure the ROM Monitor variables with IP access information.



Note TFTP access variables are currently not supported on the IR8340 platform.

Access ROM Monitor Mode

The following sections describe how to enter the ROMMON mode, and contains the following sections:

Checking the Current ROMMON Version

To display the version of ROMmon running on a router, use the **show rom-monitor** command . To show all variables that are set in ROMmon, use show romvar.

```
Router#show rom-monitor r0
============================================================

System Bootstrap, Version v0.33, DEVELOPMENT SOFTWARE
Copyright (c) 1994-2021 by cisco Systems, Inc.
Compiled Mon Jul 12 18:53:57 2021 by gilchen

Router# show romvar
ROMMON variables:
PS1 = rommon ! >
DEVICE_MANAGED_MODE = autonomous
CRYPTO_BI_THPUT = 50000
TEMPLATE = advanced
DISABLE_USB_FLASH = no
```

```
DISABLE_CC_AUTH = 1
DISABLE_SD_FLASH = no
PASSWD_RECOVERY = no
ENABLE_BREAK = no
ENABLE_FLASH_PRIMARY_BOOT = no
BAUD = 9600
LICENSE_BOOT_LEVEL =
SKIP_CHIPGUARD = 1
RET_2_RTS =
BOOT =
flash:ir8340-universalk9.BLD_POLARIS_DEV_LATEST_20210322_153228.SSA.bin,12;flash:ir8340-universalk9.BLD_POLARIS_DEV_LATEST_20210323_184154.SSA.bin,12;
BSI = 0
RET_2_RCALTS =
RANDOM_NUM = 404654831
```

If your configuration register was set to hex value 0x0 or 0x1820, reload operation will bring you to the ROMmon mode command prompt (rommon 1>). Invoking the set command at the prompt (rommon 1> set) will display the same information as "show romvar" above in IOS/XE exec mode.

```
rommon 2 >set
BOOT=flash:ir8340-universalk9.BLD_POLARIS_DEV_LATEST_20210710_191629_V17_7_0_60.SSA.bin,12;
BSI=0
CRYPTO_BI_THPUT=50000
DEVICE_MANAGED_MODE=autonomous
LICENSE_BOOT_LEVEL=
PS1=rommon ! >
RANDOM_NUM=1822515242
RET_2_RCALTS=1630484680
RET_2_RTS=
SKIP_CHIPGUARD=1
TEMPLATE=advanced
rommon 3 >
```

Commonly Used ROM Monitor Commands

The following table summarizes the commands commonly used in ROM Monitor. For specific instructions on using these commands, refer to the relevant procedure in this document.

Table 20: Commonly Used ROM Monitor Commands

ROMMON Command	Description
boot image	Manually boots a Cisco IOS XE software image.
boot image –o config-file-path	Manually boots the Cisco IOS XE software with a temporary alternative administration configuration file.
confreg	Changes the config-register setting.
dev	Displays the available local storage devices.
dir	Displays the files on a storage device.
reset	Resets the node.
set	Displays the currently set ROM Monitor environmental settings.
sync	Saves the new ROM Monitor environmental settings.

ROMMON Command	Description
unset	Removes an environmental variable setting.

Examples

The following example shows what appears when you enter the **?** command on a router:

```
rommon 3 >?
- - - - - - - - - - - - - - - - - - - - - - - - - - - - - - - -
alias set and/or display command aliases
boot boot up an external process
cpuinfo display processor information
confreg configuration register utility
ctchallenge Generate a challenge for dev key install
ctinstkey Parse the response and install dev key
ctiskeyinstalled checks if devkey installed and display it
ctremkey Remove the devkey from Aikido
ctrespsave Store parts of incoming response
dev display the device table
dir list files in a file system
efi_shell launch the UEFI SHELL enviroment
flwr burn new BIOS onto the bootrom
help monitor built-in command(s) help
history display monitor command history
meminfo display main memory information
repeat repeat a monitor command
reset system reset
set display the monitor environment
showmon display currently selected ROM monitor
sync write monitor environment to NVRAM
token display board's unique token identifier
unalias unset an alias
unset unset a variable from the monitor environment
rommon 4 >
```

Changing the ROM Monitor Prompt

You can change the prompt in ROM Monitor mode by using the **PS1=** command as shown in the following example:

```
rommon 4 >PS1="IR8340 rommon ! >"
IR8340 rommon 5 >
```

Changing the prompt is useful if you are working with multiple routers in ROM Monitor at the same time. This example specifies that the prompt should be “IR8340 rommon ”, followed by the line number, and then followed by “ > “ by the line number.

Displaying the Configuration Register Setting

To display the current configuration register setting, enter the **showmon** command without parameters as follows:

```
IR8340 rommon 8 >showmon


System Bootstrap, Version v0.33, DEVELOPMENT SOFTWARE
```

```
Copyright (c) 1994-2021 by cisco Systems, Inc.
Compiled Mon Jul 12 18:53:57 2021 by root


!!! DEBUG SECURE-BOOT CPLD Version Installed. For INTERNAL USE ONLY !!!

Current image running : Boot ROM0

Last reset cause (0x00000002): LocalSoft
IR8340-K9 platform with 8388608 Kbytes of main memory

IR8340 rommon 9 >
```

The configuration register setting is labeled *Virtual Configuration Register* . Enter the **no** command to avoid changing the configuration register setting.

Environment Variable Settings

The ROM Monitor environment variables define the attributes of the ROM Monitor. Environmental variables are entered like commands and are always followed by the equal sign (=). Environment variable settings are entered in capital letters, followed by a definition. For example:

```
IP_ADDRESS=10.0.0.2
```

Under normal operating conditions, you do not need to modify these variables. They are cleared or set only when you need to make changes to the way ROM Monitor operates.

This section includes the following topics:

Frequently Used Environmental Variables

The following table shows the main ROM Monitor environmental variables. For instructions on how to use these variables, see the relevant instructions in this document. The IR8340 boot loader does not support netboot, so any setting like environment variables IP_ADDRESS, IP_SUBNET_MASK, DEFAULT_GATEWAY, TFTP_SERVER, TFTP_FILE are not used.

Table 21: Frequently Used ROM Monitor Environmental Variables

Environmental variable	Description
BOOT=path/file	Identifies the boot software for a node. This variable is usually set automatically when the router boots.

Displaying Environment Variable Settings

To display the current environment variable settings, enter the **set** command :

```
IR8340 rommon 8 >showmon


System Bootstrap, Version v0.33, DEVELOPMENT SOFTWARE
Copyright (c) 1994-2021 by cisco Systems, Inc.
Compiled Mon Jul 12 18:53:57 2021 by root
```

```
!!! DEBUG SECURE-BOOT CPLD Version Installed. For INTERNAL USE ONLY !!!

Current image running : Boot ROM0

Last reset cause (0x00000002): LocalSoft
IR8340-K9 platform with 8388608 Kbytes of main memory

IR8340 rommon 9 >
```

Entering Environment Variable Settings

Environment variable settings are entered in capital letters, followed by a definition. The following example shows the environmental variables that can be configured in ROMmon mode.:

```
rommon 1 > confreg 0x0
rommon 1> BOOT_WDOG = DISABLE
rommon 1> BOOT = IR8340-K9_image_name
```

Saving Environment Variable Settings

To save the current environment variable settings, enter the **sync** command:

```
rommon > sync
```



Note Environmental values that are not saved with the **sync** command are discarded whenever the system is reset or booted.

Exiting ROM Monitor Mode

To exit ROM Monitor mode, you must change the configuration register and reset the router.

Procedure

	Command or Action	Purpose
Step 1	**confreg** **Example:** `rommon 1> confreg`	Initiates the configuration register configuration prompts.
Step 2	Respond to each prompt as instructed.	See the example that follows this procedure for more information.
Step 3	**reset** **Example:** `rommon 2> reset`	Resets and initializes the router.

Configuration Example

```
rommon 3 > confreg
           Configuration Summary
   (Virtual Configuration Register: 0x0)
enabled are:
 [ 0 ] break/abort has effect
 [ 1 ] console baud: 9600
 boot: ...... the ROM Monitor
do you wish to change the configuration? y/n  [n]:  y
 enable  "diagnostic mode"? y/n  [n]:
 enable  "use net in IP bcast address"? y/n  [n]:
 enable  "load rom after netboot fails"? y/n  [n]:
 enable  "use all zero broadcast"? y/n  [n]:
 disable "break/abort has effect"? y/n  [n]:
 enable  "ignore system config info"? y/n  [n]:
 change console baud rate? y/n  [n]:
change the boot characteristics? y/n  [n]:
           Configuration Summary
   (Virtual Configuration Register: 0x0)
enabled are:
 [ 0 ] break/abort has effect
 [ 1 ] console baud: 9600
 boot: ...... the ROM Monitor
do you wish to change the configuration? y/n  [n]:
```

Upgrading the ROMmon for a Router

ROMmon upgrade on the IR8340-K9 router is automatically done when the image is booted. The latest version of the ROMmon is bundled with the IOSXE image. An algorithm detects if the current running version is older than the bundled version, if so, it is automatically upgraded. If the current running version is equal to the bundled version no upgrade is executed. For every successful upgrade, the router is automatically rebooted in order for the new version to get loaded and executed.:


Procedure

Step 1 (Optional) Run the **show rom-monitor** *slot* command on the router to see the current release numbers of ROMmon on the hardware. See the Checking the Current ROMMON Version, on page 344 for information about interpreting the output of the command that you run.

Step 2 If autoboot has not been enabled by using the **config-register 0x2102** command, run the **boot** *filesystem:/file-location* command at the ROMmon prompt to boot the Cisco IOS XE image, where *filesystem:/file-location* is the path to the consolidated package file. The ROMmon upgrade is not permanent for any piece of hardware until the Cisco IOS XE image is booted.

Step 3 Run the **enable** command at the user prompt to enter the privileged EXEC mode after the boot is complete.

Step 4 Run the **show rom-monitor** *slot* command to verify whether the ROMmon has been upgraded.



CHAPTER 33

Process Health Monitoring

This chapter describes how to manage and monitor the health of various components of your router. It contains the following sections:

- Monitoring Control Plane Resources, on page 351
- Monitoring Hardware Using Alarms, on page 363

Monitoring Control Plane Resources

The following sections explain the details of memory and CPU monitoring from the perspective of the Cisco IOS process and the overall control plane:

- Avoiding Problems Through Regular Monitoring, on page 351
- Cisco IOS Process Resources, on page 351
- Overall Control Plane Resources, on page 361

Avoiding Problems Through Regular Monitoring

Processes should provide monitoring and notification of their status/health to ensure correct operation. When a process fails, a syslog error message is displayed and either the process is restarted or the router is rebooted. A syslog error message is displayed when a monitor detects that a process is stuck or has crashed. If the process can be restarted, it is restarted; else, the router is restarted.

Monitoring system resources enables you to detect potential problems before they occur, thus avoiding outages. It also establishes a baseline for a normal system load. You can use this information as a basis for comparison, when you upgrade hardware or software to see if the upgrade has affected resource usage.

Cisco IOS Process Resources

You can view CPU utilization statistics on active processes and see the amount of memory being used in these processes using the **show memory** command and the **show process cpu** command. These commands provide a representation of memory and CPU utilization from the perspective of only the Cisco IOS process; they do not include information for resources on the entire platform. When the **show memory** command is used in a system with 4 GB RAM running a single Cisco IOS process, the following memory usage is displayed:

```
Router# show memory
Tracekey : 1#ac03ca5b9748c51baa2971d7a417e55e

Head Total(b) Used(b) Free(b) Lowest(b) Largest(b)
Processor 7F74107C4048 3807080396 239658308 3567422088 661095820 3145727908
reserve P 7F74107C40A0 102404 92 102312 102312 102312
lsmpi_io 7F740259B1A8 6295128 6294304 824 824 412
Dynamic heap limit(MB) 3000 Use(MB) 0



Processor memory

Address Bytes Prev Next Ref PrevF NextF what Alloc PC
7F74107C4048 0000102408 00000000 7F74107DD0A8 001 -------- -------- *Init*
:559FB88BD000+5E73061
7F74107DD0A8 0000000056 7F74107C4048 7F74107DD138 001 -------- -------- *Init*
:559FB88BD000+5E7307F
7F74107DD138 0000008224 7F74107DD0A8 7F74107DF1B0 001 -------- -------- *Init*
:559FB88BD000+5E7309A
7F74107DF1B0 0000000296 7F74107DD138 7F74107DF330 001 -------- -------- *Init*
:559FB88BD000+9093511
7F74107DF330 0000000568 7F74107DF1B0 7F74107DF5C0 001 -------- -------- *Init*
:559FB88BD000+9099C4A
7F74107DF5C0 0000032776 7F74107DF330 7F74107E7620 001 -------- -------- Managed Chunk Q
:559FB88BD000+90832BF
7F74107E7620 0000000056 7F74107DF5C0 7F74107E76B0 001 -------- -------- *Init*
:559FB88BD000+5EC98DD
7F74107E76B0 0000032776 7F74107E7620 7F74107EF710 001 -------- -------- Queue Pair - Q
:559FB88BD000+90B02EF
7F74107EF710 0000012808 7F74107E76B0 7F74107F2970 001 -------- -------- *Init*
:559FB88BD000+13BF988B
7F74107F2970 0000032776 7F74107EF710 7F74107FA9D0 001 -------- -------- List Elements
:559FB88BD000+904DB29
7F74107FA9D0 0000032776 7F74107F2970 7F7410802A30 001 -------- -------- List Headers
:559FB88BD000+904DB77
7F7410802A30 0000032776 7F74107FA9D0 7F741080AA90 001 -------- -------- IOSXE Process S
:559FB88BD000+A664348
7F741080AA90 0000032776 7F7410802A30 7F7410812AF0 001 -------- -------- IOSXE Queue Pro
:559FB88BD000+A66438A
7F7410812AF0 0000065544 7F741080AA90 7F7410822B50 001 -------- -------- IOSXE Queue Bal
:559FB88BD000+A6643C5
7F7410822B50 0000000328 7F7410812AF0 7F7410822CF0 001 -------- -------- *Init*
:559FB88BD000+13BF1567
7F7410822CF0 0000000328 7F7410822B50 7F7410822E90 001 -------- -------- *Init*
:559FB88BD000+13BF1567
7F7410822E90 0000000192 7F7410822CF0 7F7410822FA8 001 -------- -------- *Init*
:559FB88BD000+90C3F74
7F7410822FA8 0000036872 7F7410822E90 7F741082C008 001 -------- -------- *Init*
:559FB88BD000+A65A3A8
7F741082C008 0000010008 7F7410822FA8 7F741082E778 001 -------- -------- Platform VM Pag
:559FB88BD000+A68A8A3
7F741082E778 0000002008 7F741082C008 7F741082EFA8 001 -------- -------- *Init*
iosd_crb_crankshaft_unix:7F7460E22000+7D8CB
7F741082EFA8 0000200712 7F741082E778 7F7410860008 001 -------- -------- Interrupt Stack
:559FB88BD000+A65A3A8
7F7410860008 0000000328 7F741082EFA8 7F74108601A8 001 -------- -------- *Init*
:559FB88BD000+13BF1567
7F74108601A8 0000003008 7F7410860008 7F7410860DC0 001 -------- -------- Watched Semapho
:559FB88BD000+90BBCE8
7F7410860DC0 0000000400 7F74108601A8 7F7410860FA8 001 -------- -------- *Init*
:559FB88BD000+13BF1567
7F7410860FA8 0000036872 7F7410860DC0 7F741086A008 001 -------- -------- *Init*
```

```
:559FB88BD000+A65A3A8
7F741086A008 0000000328 7F7410860FA8 7F741086A1A8 001 -------- -------- *Init*
:559FB88BD000+13BF1567
7F741086A1A8 0000000184 7F741086A008 7F741086A2B8 001 -------- -------- *Init*
:559FB88BD000+90A4B10
7F741086A2B8 0000000184 7F741086A1A8 7F741086A3C8 001 -------- -------- *Init*
:559FB88BD000+90A4B10
7F741086A3C8 0000000184 7F741086A2B8 7F741086A4D8 001 -------- -------- *Init*
:559FB88BD000+90A4B10
7F741086A4D8 0000000184 7F741086A3C8 7F741086A5E8 001 -------- -------- *Init*
:559FB88BD000+90A4B10
7F741086A5E8 0000000184 7F741086A4D8 7F741086A6F8 001 -------- -------- *Init*
:559FB88BD000+90A4B10
7F741086A6F8 0000000096 7F741086A5E8 7F741086A7B0 001 -------- -------- *Init*
:559FB88BD000+90A4AA4
7F741086A7B0 0000000152 7F741086A6F8 7F741086A8A0 001 -------- -------- Crypto CA
:559FB88BD000+98E58BF
7F741086A8A0 0000000152 7F741086A7B0 7F741086A990 001 -------- -------- Crypto CA
:559FB88BD000+98E58BF
7F741086A990 0000000152 7F741086A8A0 7F741086AA80 001 -------- -------- Crypto CA
:559FB88BD000+98E58BF
7F741086AA80 0000000152 7F741086A990 7F741086AB70 001 -------- -------- Crypto CA
:559FB88BD000+98E58BF
7F741086AB70 0000000176 7F741086AA80 7F741086AC78 001 -------- -------- Crypto CA
:559FB88BD000+98E58BF
7F741086AC78 0000000272 7F741086AB70 7F741086ADE0 001 -------- -------- Crypto CA
:559FB88BD000+98E5875
7F741086ADE0 0000000096 7F741086AC78 7F741086AE98 000 7F741C306070 7F7415EC2CE8 (fragment)
 :559FB88BD000+98E5875
7F741086AE98 0000000184 7F741086ADE0 7F741086AFA8 001 -------- -------- Init
:559FB88BD000+52443C9
7F741086AFA8 0000036872 7F741086AE98 7F7410874008 001 -------- -------- *Init*
:559FB88BD000+A65A3A8
7F7410874008 0000000328 7F741086AFA8 7F74108741A8 001 -------- -------- *Init*
:559FB88BD000+13BF1567
7F74108741A8 0000000184 7F7410874008 7F74108742B8 001 -------- -------- *Init*
:559FB88BD000+90A4B10
7F74108742B8 0000000064 7F74108741A8 7F7410874350 001 -------- -------- Parser Linkage
:559FB88BD000+5D90EDA
7F7410874350 0000000216 7F74108742B8 7F7410874480 001 -------- -------- IPv4 FIB subblo
:559FB88BD000+5A2947A
7F7410874480 0000000224 7F7410874350 7F74108745B8 001 -------- -------- *Init*
:559FB88BD000+9060A7C
7F74108745B8 0000000224 7F7410874480 7F74108746F0 001 -------- -------- *Init*
:559FB88BD000+9060A7C
7F74108746F0 0000000328 7F74108745B8 7F7410874890 001 -------- -------- *Init*
:559FB88BD000+9060A7C
7F7410874890 0000000328 7F74108746F0 7F7410874A30 001 -------- -------- *Init*
:559FB88BD000+9060A7C
7F7410874A30 0000000328 7F7410874890 7F7410874BD0 001 -------- -------- *Init*
:559FB88BD000+9060A7C
7F7410874BD0 0000000896 7F7410874A30 7F7410874FA8 001 -------- -------- *Init*
:559FB88BD000+9060A7C
7F7410874FA8 0000200712 7F7410874BD0 7F74108A6008 001 -------- -------- Interrupt Stack
:559FB88BD000+A65A3A8
7F74108A6008 0000000968 7F7410874FA8 7F74108A6428 001 -------- -------- *Init*
iosd_crb_crankshaft_unix:7F7460E22000+3AC76
7F74108A6428 0000002008 7F74108A6008 7F74108A6C58 001 -------- -------- Watcher Message
:559FB88BD000+90BBD7B
7F74108A6C58 0000000360 7F74108A6428 7F74108A6E18 001 -------- -------- Process Events
:559FB88BD000+90B6840
7F74108A6E18 0000000096 7F74108A6C58 7F74108A6ED0 001 -------- -------- SWIDB_SB_PTP
:559FB88BD000+5324CAA
7F74108A6ED0 0000000128 7F74108A6E18 7F74108A6FA8 001 -------- -------- *Init*
```

```
:559FB88BD000+9060A7C
7F74108A6FA8 0000036872 7F74108A6ED0 7F74108B0008 001 -------- -------- *Init*
:559FB88BD000+A65A3A8
7F74108B0008 0000002840 7F74108A6FA8 7F74108B0B78 001 -------- -------- *Init*
:559FB88BD000+B529B9D
7F74108B0B78 0000000984 7F74108B0008 7F74108B0FA8 001 -------- -------- Watched Message
:559FB88BD000+90BBD4A
7F74108B0FA8 0000200712 7F74108B0B78 7F74108E2008 001 -------- -------- Interrupt Stack
:559FB88BD000+A65A3A8
7F74108E2008 0000002336 7F74108B0FA8 7F74108E2980 001 -------- -------- Process Array
:559FB88BD000+90C3DC0
7F74108E2980 0000000360 7F74108E2008 7F74108E2B40 001 -------- -------- Process Events
:559FB88BD000+90B6840
7F74108E2B40 0000000328 7F74108E2980 7F74108E2CE0 001 -------- -------- *Init*
:559FB88BD000+13BF1567
7F74108E2CE0 0000000120 7F74108E2B40 7F74108E2DB0 001 -------- -------- *Init*
:559FB88BD000+90A4347
7F74108E2DB0 0000000184 7F74108E2CE0 7F74108E2EC0 001 -------- -------- *Init*
:559FB88BD000+90A4B10
7F74108E2EC0 0000000144 7F74108E2DB0 7F74108E2FA8 001 -------- -------- *Init*
:559FB88BD000+4FFE35D
7F74108E2FA8 0000036872 7F74108E2EC0 7F74108EC008 001 -------- -------- *Init*
:559FB88BD000+A65A3A8
7F74108EC008 0000001232 7F74108E2FA8 7F74108EC530 001 -------- -------- Process
:559FB88BD000+90C3F05
7F74108EC530 0000001232 7F74108EC008 7F74108ECA58 001 -------- -------- Process
:559FB88BD000+90C3F05
7F74108ECA58 0000000096 7F74108EC530 7F74108ECB10 001 -------- -------- Init
:559FB88BD000+8FF0694
7F74108ECB10 0000000184 7F74108ECA58 7F74108ECC20 001 -------- -------- *Init*
:559FB88BD000+90A4B10
7F74108ECC20 0000000184 7F74108ECB10 7F74108ECD30 001 -------- -------- *Init*
:559FB88BD000+90A4B10
7F74108ECD30 0000000184 7F74108ECC20 7F74108ECE40 001 -------- -------- *Init*
:559FB88BD000+90A4B10
7F74108ECE40 0000000272 7F74108ECD30 7F74108ECFA8 001 -------- -------- *Init*
:559FB88BD000+90A4B10
7F74108ECFA8 0000200712 7F74108ECE40 7F741091E008 001 -------- -------- Interrupt Stack
:559FB88BD000+A65A3A8
7F741091E008 0000000184 7F74108ECFA8 7F741091E118 001 -------- -------- *Init*
:559FB88BD000+90A4B10
7F741091E118 0000003008 7F741091E008 7F741091ED30 001 -------- -------- Reg Function Li
:559FB88BD000+905FC68
7F741091ED30 0000000064 7F741091E118 7F741091EDC8 001 -------- -------- Parser Linkage
:559FB88BD000+5D90C9A
7F741091EDC8 0000000064 7F741091ED30 7F741091EE60 001 -------- -------- Parser Linkage
:559FB88BD000+5D90EDA
7F741091EE60 0000000064 7F741091EDC8 7F741091EEF8 001 -------- -------- Parser Linkage
:559FB88BD000+5D90C9A
7F741091EEF8 0000000088 7F741091EE60 7F741091EFA8 001 -------- -------- *Init*
:559FB88BD000+5EC98DD
7F741091EFA8 0000036872 7F741091EEF8 7F7410928008 001 -------- -------- *Init*
:559FB88BD000+A65A3A8
7F7410928008 0000000184 7F741091EFA8 7F7410928118 001 -------- -------- *Init*
:559FB88BD000+90A4B10
7F7410928118 0000001504 7F7410928008 7F7410928750 001 -------- -------- Reg Function Se
:559FB88BD000+905FCC2
7F7410928750 0000001504 7F7410928118 7F7410928D88 001 -------- -------- Reg Function Ca
:559FB88BD000+905FCEF
7F7410928D88 0000000064 7F7410928750 7F7410928E20 001 -------- -------- Parser Linkage
:559FB88BD000+5D90C9A
7F7410928E20 0000000064 7F7410928D88 7F7410928EB8 001 -------- -------- Parser Linkage
:559FB88BD000+5D90EDA
7F7410928EB8 0000000152 7F7410928E20 7F7410928FA8 001 -------- -------- Init
```

```
:559FB88BD000+500508B
7F7410928FA8 0000200712 7F7410928EB8 7F741095A008 001 -------- -------- Interrupt Stack
:559FB88BD000+A65A3A8
7F741095A008 0000006888 7F7410928FA8 7F741095BB48 001 -------- -------- TTY data
:559FB88BD000+8F75806
7F741095BB48 0000004104 7F741095A008 7F741095CBA8 001 -------- -------- TTY Input Buf
:559FB88BD000+8F77B6F
7F741095CBA8 0000004104 7F741095BB48 7F741095DC08 001 -------- -------- TTY Output Buf
:559FB88BD000+8F77BC7
7F741095DC08 0000024584 7F741095CBA8 7F7410963C68 001 -------- -------- proc_hist_lmt_v
:559FB88BD000+D06DC00
7F7410963C68 0000008200 7F741095DC08 7F7410965CC8 001 -------- -------- proc_hist_lmt_v
:559FB88BD000+D06DC48
7F7410965CC8 0000008200 7F7410963C68 7F7410967D28 001 -------- -------- proc_hist_lmt_v
:559FB88BD000+D06DC82
7F7410967D28 0000005008 7F7410965CC8 7F7410969110 001 -------- -------- messages
:559FB88BD000+90BBBB5
7F7410969110 0000005008 7F7410967D28 7F741096A4F8 001 -------- -------- Watched message
:559FB88BD000+90BBBED
7F741096A4F8 0000020008 7F7410969110 7F741096F378 001 -------- -------- Watched Queue
:559FB88BD000+90BBC1E
7F741096F378 0000065544 7F741096A4F8 7F741097F3D8 001 -------- -------- Watched Queue I
:559FB88BD000+90BBC55
7F741097F3D8 0000020008 7F741096F378 7F7410984258 001 -------- -------- Watched Boolean
:559FB88BD000+90BBC86
7F7410984258 0000020008 7F741097F3D8 7F74109890D8 001 -------- -------- Watched Bitfiel
:559FB88BD000+90BBCB7
7F74109890D8 0000010008 7F7410984258 7F741098B848 001 -------- -------- Watcher Info
:559FB88BD000+90BBD19
7F741098B848 0000010008 7F74109890D8 7F741098DFB8 001 -------- -------- Read/Write Lock
:559FB88BD000+90BBDAC
7F741098DFB8 0000000184 7F741098B848 7F741098E0C8 001 -------- -------- *Init*
:559FB88BD000+90A4B10
7F741098E0C8 0000000064 7F741098DFB8 7F741098E160 001 -------- -------- Init
:559FB88BD000+98AD5C3
7F741098E160 0000000576 7F741098E0C8 7F741098E3F8 001 -------- -------- *Init*
:559FB88BD000+9060A7C
7F741098E3F8 0000000400 7F741098E160 7F741098E5E0 001 -------- -------- *Init*
:559FB88BD000+9060A7C
7F741098E5E0 0000001240 7F741098E3F8 7F741098EB10 001 -------- -------- *Init*
:559FB88BD000+9060A7C
7F741098EB10 0000000488 7F741098E5E0 7F741098ED50 001 -------- -------- *Init*
:559FB88BD000+9060A7C
7F741098ED50 0000000072 7F741098EB10 7F741098EDF0 001 -------- -------- Init
:559FB88BD000+98DB044
7F741098EDF0 0000000056 7F741098ED50 7F741098EE80 001 -------- -------- Init
:559FB88BD000+5D94FF6
7F741098EE80 0000000208 7F741098EDF0 7F741098EFA8 001 -------- -------- *Init*
:559FB88BD000+C1E0292
7F741098EFA8 0000028104 7F741098EE80 7F7410995DC8 001 -------- -------- Process Stack
:559FB88BD000+A65A3A8
7F7410995DC8 0000000152 7F741098EFA8 7F7410995EB8 001 -------- -------- *Init*
:559FB88BD000+90C3F74
7F7410995EB8 0000000152 7F7410995DC8 7F7410995FA8 001 -------- -------- *Init*
:559FB88BD000+9060A7C
7F7410995FA8 0000016104 7F7410995EB8 7F7410999EE8 001 -------- -------- Process Stack
:559FB88BD000+A65A3A8
7F7410999EE8 0000032776 7F7410995FA8 7F74109A1F48 001 -------- -------- List Elements
:559FB88BD000+904DF98
7F74109A1F48 0000032776 7F7410999EE8 7F74109A9FA8 001 -------- -------- List Elements
:559FB88BD000+904DF98
7F74109A9FA8 0000032776 7F74109A1F48 7F74109B2008 001 -------- -------- List Elements
:559FB88BD000+904DF98
7F74109B2008 0000032776 7F74109A9FA8 7F74109BA068 001 -------- -------- List Elements
```

```
:559FB88BD000+904DF98
7F74109BA068 0000032776 7F74109B2008 7F74109C20C8 001 -------- -------- List Elements
:559FB88BD000+904DF98
7F74109C20C8 0000032776 7F74109BA068 7F74109CA128 001 -------- -------- List Elements
:559FB88BD000+904DF98
7F74109CA128 0000032776 7F74109C20C8 7F74109D2188 001 -------- -------- List Element
```

The **show process cpu** command displays Cisco IOS CPU utilization average:

```
Router# show process cpu
CPU utilization for five seconds: 1%/0%; one minute: 1%; five minutes: 1%
PID Runtime(ms) Invoked uSecs 5Sec 1Min 5Min TTY Process
PID Runtime(ms) Invoked uSecs 5Sec 1Min 5Min TTY Process
1 3 21 142 0.00% 0.00% 0.00% 0 Chunk Manager
2 166 399 416 0.00% 0.00% 0.00% 0 Load Meter
3 0 1 0 0.00% 0.00% 0.00% 0 PKI Trustpool
4 0 1 0 0.00% 0.00% 0.00% 0 Retransmission o
5 0 1 0 0.00% 0.00% 0.00% 0 IPC ISSU Dispatc
6 17 14 1214 0.00% 0.00% 0.00% 0 RF Slave Main Th
7 0 1 0 0.00% 0.00% 0.00% 0 EDDRI_MAIN
8 0 1 0 0.00% 0.00% 0.00% 0 RO Notify Timers
9 1017 304 3345 0.47% 0.06% 0.03% 0 Check heaps
10 5 34 147 0.00% 0.00% 0.00% 0 Pool Manager
11 0 1 0 0.00% 0.00% 0.00% 0 DiscardQ Backgro
12 1 2 500 0.00% 0.00% 0.00% 0 Timers
13 0 53 0 0.00% 0.00% 0.00% 0 WATCH_AFS
14 0 1 0 0.00% 0.00% 0.00% 0 MEMLEAK PROCESS
15 4 18 222 0.00% 0.00% 0.00% 0 ARP Input
16 37 2132 17 0.00% 0.00% 0.00% 0 ARP Background
17 0 2 0 0.00% 0.00% 0.00% 0 ATM Idle Timer
18 0 1 0 0.00% 0.00% 0.00% 0 ATM ASYNC PROC
19 0 1 0 0.00% 0.00% 0.00% 0 CEF MIB API
20 0 1 0 0.00% 0.00% 0.00% 0 AAA_SERVER_DEADT
21 0 1 0 0.00% 0.00% 0.00% 0 Policy Manager
22 0 2 0 0.00% 0.00% 0.00% 0 DDR Timers
23 130 50 2600 0.00% 0.00% 0.00% 0 Entity MIB API
24 179 83 2156 0.00% 0.00% 0.00% 0 PrstVbl
25 2 247 8 0.00% 0.00% 0.00% 0 Serial Backgroun
26 0 1 0 0.00% 0.00% 0.00% 0 RMI RM Notify Wa
27 0 2 0 0.00% 0.00% 0.00% 0 ATM AutoVC Perio
28 0 2 0 0.00% 0.00% 0.00% 0 ATM VC Auto Crea
29 10 1000 10 0.00% 0.00% 0.00% 0 IOSXE heartbeat
30 31 1023 30 0.00% 0.00% 0.00% 0 DB Lock Manager
31 33 1989 16 0.00% 0.00% 0.00% 0 GraphIt
32 0 1 0 0.00% 0.00% 0.00% 0 DB Notification
33 0 1 0 0.00% 0.00% 0.00% 0 IPC Apps Task
34 0 1 0 0.00% 0.00% 0.00% 0 ifIndex Receive
35 5 401 12 0.00% 0.00% 0.00% 0 IPC Event Notifi
36 32 1952 16 0.00% 0.00% 0.00% 0 IPC Mcast Pendin
37 0 1 0 0.00% 0.00% 0.00% 0 Platform appsess
38 0 34 0 0.00% 0.00% 0.00% 0 IPC Dynamic Cach
39 1 401 2 0.00% 0.00% 0.00% 0 IPC Service NonC
40 0 1 0 0.00% 0.00% 0.00% 0 IPC Zone Manager
41 16 1952 8 0.00% 0.00% 0.00% 0 IPC Periodic Tim
42 19 1952 9 0.00% 0.00% 0.00% 0 IPC Deferred Por
43 0 1 0 0.00% 0.00% 0.00% 0 IPC Process leve
44 0 1 0 0.00% 0.00% 0.00% 0 IPC Seat Manager
45 0 115 0 0.00% 0.00% 0.00% 0 IPC Check Queue
46 0 1 0 0.00% 0.00% 0.00% 0 IPC Seat RX Cont
47 0 1 0 0.00% 0.00% 0.00% 0 IPC Seat TX Cont
48 10 201 49 0.00% 0.00% 0.00% 0 IPC Keep Alive M
49 33 401 82 0.00% 0.00% 0.00% 0 IPC Loadometer
50 0 1 0 0.00% 0.00% 0.00% 0 IPC Session Deta
51 0 1 0 0.00% 0.00% 0.00% 0 SENSOR-MGR event
52 2 201 9 0.00% 0.00% 0.00% 0 Compute SRP rate
```

```
53 0 1 0 0.00% 0.00% 0.00% 0 IFS Agent Manage
54 0 1 0 0.00% 0.00% 0.00% 0 License IPC stat
55 0 1 0 0.00% 0.00% 0.00% 0 License IPC serv
56 0 7 0 0.00% 0.00% 0.00% 0 Net Input
57 0 2 0 0.00% 0.00% 0.00% 0 Dialer event
58 0 1 0 0.00% 0.00% 0.00% 0 SERIAL A'detect
59 0 1 0 0.00% 0.00% 0.00% 0 IOSXE signals IO
60 0 1 0 0.00% 0.00% 0.00% 0 client_entity_se
61 1 1 1000 0.00% 0.00% 0.00% 0 RF SCTPthread
62 0 1 0 0.00% 0.00% 0.00% 0 CHKPT RG SCTPthr
63 0 2 0 0.00% 0.00% 0.00% 0 XML Proxy Client
64 0 1 0 0.00% 0.00% 0.00% 0 ARP Snoop
65 28 1999 14 0.00% 0.00% 0.00% 0 Dynamic ARP Insp
66 1216 110 11054 0.00% 0.00% 0.00% 0 crypto sw pk pro
67 0 2 0 0.00% 0.00% 0.00% 0 License Client N
68 0 1 0 0.00% 0.00% 0.00% 0 Image License br
69 24 133 180 0.00% 0.00% 0.00% 0 SAEventLog
70 11 2 5500 0.00% 0.00% 0.00% 0 SAStorage
71 1 4 250 0.00% 0.00% 0.00% 0 SASConnect
72 41 1165 35 0.00% 0.00% 0.00% 0 SASRcvWQ
73 2 5 400 0.00% 0.00% 0.00% 0 SACConnect
74 30 1183 25 0.00% 0.00% 0.00% 0 SACRcvWQ
75 8 68 117 0.00% 0.00% 0.00% 0 Licensing Auto U
76 0 1 0 0.00% 0.00% 0.00% 0 License HA Consi
77 0 1 0 0.00% 0.00% 0.00% 0 Token Daemon
78 0 1 0 0.00% 0.00% 0.00% 0 Critical Bkgnd
79 221 1374 160 0.00% 0.00% 0.00% 0 Net Background
80 0 3 0 0.00% 0.00% 0.00% 0 IDB Work
81 8 101 79 0.00% 0.00% 0.00% 0 Logger
82 71 1985 35 0.00% 0.00% 0.00% 0 TTY Background
83 53 24 2208 0.00% 0.00% 0.00% 0 CTS CORE
84 1 3 333 0.00% 0.00% 0.00% 0 SXP CORE
85 56 1164 48 0.00% 0.00% 0.00% 0 SASRcvWQWrk1
86 3 14 214 0.00% 0.00% 0.00% 0 IF-MGR control p
87 0 28 0 0.00% 0.00% 0.00% 0 IF-MGR event pro
88 0 2 0 0.00% 0.00% 0.00% 0 CTS HA
89 0 2 0 0.00% 0.00% 0.00% 0 CTS HA IPC flow
90 0 1 0 0.00% 0.00% 0.00% 0 CTS HA operation
91 5357 18052 296 0.15% 0.20% 0.20% 0 IOSD ipc task
92 213 5786 36 0.00% 0.00% 0.00% 0 IOSD chasfs task
93 0 2 0 0.00% 0.00% 0.00% 0 Crimson interfac
94 274 19 14421 0.00% 0.00% 0.00% 0 Crimson Database
95 681 2548 267 0.00% 0.02% 0.00% 0 Crimson flush tr
96 4 287 13 0.00% 0.00% 0.00% 0 REDUNDANCY FSM
97 0 1 0 0.00% 0.00% 0.00% 0 Punt FP Stats Du
98 171 953 179 0.00% 0.00% 0.00% 0 PuntInject Keepa
99 0 16 0 0.00% 0.00% 0.00% 0 ESG MATM Learnin
100 141 401 351 0.00% 0.00% 0.00% 0 CMAN RP Msg Proc
101 118 1998 59 0.00% 0.00% 0.00% 0 Environmental Mo
102 42 1998 21 0.00% 0.00% 0.00% 0 RP HA Periodic
103 0 2 0 0.00% 0.00% 0.00% 0 cpf_msg_holdq_pr
104 0 1 0 0.00% 0.00% 0.00% 0 cpf_msg_rcvq_pro
105 0 1 0 0.00% 0.00% 0.00% 0 cpf_process_tpQ
106 0 1 0 0.00% 0.00% 0.00% 0 CEF RRP RF waite
107 0 1 0 0.00% 0.00% 0.00% 0 CONSOLE helper p
108 175 50 3500 0.00% 0.00% 0.00% 0 DBAL EVENTS
109 0 1 0 0.00% 0.00% 0.00% 0 XDR RRP RF waite
110 50 1999 25 0.00% 0.00% 0.00% 0 REDUNDANCY peer
111 337 19959 16 0.00% 0.00% 0.00% 0 100ms check
112 0 1 0 0.00% 0.00% 0.00% 0 CWAN APS HA Proc
113 1 34 29 0.00% 0.00% 0.00% 0 RF CWAN HA Proce
114 0 1 0 0.00% 0.00% 0.00% 0 CWAN IF EVENT HA
115 0 4 0 0.00% 0.00% 0.00% 0 ANCP HA
116 0 2 0 0.00% 0.00% 0.00% 0 ANCP HA IPC flow
```

```
117 0 1 0 0.00% 0.00% 0.00% 0 QoS HA ID RETAIN
118 0 1 0 0.00% 0.00% 0.00% 0 CHKPT Test clien
119 0 1 0 0.00% 0.00% 0.00% 0 CHKPT Test clien
120 0 1 0 0.00% 0.00% 0.00% 0 CHKPT Test clien
121 0 1 0 0.00% 0.00% 0.00% 0 CHKPT Test clien
122 0 1 0 0.00% 0.00% 0.00% 0 CHKPT Test clien
123 0 1 0 0.00% 0.00% 0.00% 0 CHKPT Test clien
124 0 1 0 0.00% 0.00% 0.00% 0 CHKPT Test clien
125 0 1 0 0.00% 0.00% 0.00% 0 CHKPT Test clien
126 0 1 0 0.00% 0.00% 0.00% 0 CHKPT Test clien
127 0 1 0 0.00% 0.00% 0.00% 0 CHKPT Test clien
128 0 1 0 0.00% 0.00% 0.00% 0 CHKPT Test clien
129 0 1 0 0.00% 0.00% 0.00% 0 DHCPC HA
130 0 1 0 0.00% 0.00% 0.00% 0 DHCPD HA
131 0 1 0 0.00% 0.00% 0.00% 0 DHCPv6 Relay HA
132 0 1 0 0.00% 0.00% 0.00% 0 DHCPv6 Server HA
133 0 2 0 0.00% 0.00% 0.00% 0 SISF HA Process
134 0 5 0 0.00% 0.00% 0.00% 0 ARP HA
135 0 1 0 0.00% 0.00% 0.00% 0 IOSXE-RP Punt Se
136 0 1 0 0.00% 0.00% 0.00% 0 IOSXE-RP Punt IP
137 0 1 0 0.00% 0.00% 0.00% 0 ACL Log Punt Ser
138 0 1 0 0.00% 0.00% 0.00% 0 ACL deny punt se
139 1576 124342 12 0.07% 0.06% 0.07% 0 L2 LISP Punt Pro
140 0 1 0 0.00% 0.00% 0.00% 0 OFSDN Punject Pr
141 1653 124341 13 0.15% 0.08% 0.07% 0 SIS Punt Process
142 0 1 0 0.00% 0.00% 0.00% 0 IOSXE-RP SPA TSM
143 0 1 0 0.00% 0.00% 0.00% 0 IOSXE-RP QFP HA
144 0 1 0 0.00% 0.00% 0.00% 0 Network-rf Notif
145 0 1 0 0.00% 0.00% 0.00% 0 DHCP Snooping cl
146 1 18 55 0.00% 0.00% 0.00% 0 DHCP Snooping
147 0 1 0 0.00% 0.00% 0.00% 0 DHCP Snooping db
148 0 1 0 0.00% 0.00% 0.00% 0 IKE HA Mgr
149 0 1 0 0.00% 0.00% 0.00% 0 IPSEC HA Mgr
150 0 1 0 0.00% 0.00% 0.00% 0 Crypto PKI-HA
151 3 12 250 0.00% 0.00% 0.00% 0 RF Master Main T
152 0 7 0 0.00% 0.00% 0.00% 0 RF Master Status
153 39 1009 38 0.00% 0.00% 0.00% 0 SACRcvWQWrk1
154 28 1009 27 0.00% 0.00% 0.00% 0 SACRcvWQWrk2
155 103 1185 86 0.00% 0.00% 0.00% 0 SACRcvWQWrk3
156 0 1 0 0.00% 0.00% 0.00% 0 BACK CHECK
157 323 210 1538 0.00% 0.00% 0.00% 0 SAMsgThread
158 25 202 123 0.00% 0.00% 0.00% 0 Compute load avg
159 515 107 4813 0.00% 0.02% 0.00% 0 Per-minute Jobs
160 167 2009 83 0.00% 0.00% 0.00% 0 Per-Second Jobs
161 0 1 0 0.00% 0.00% 0.00% 0 Transport Port A
162 167 9 18555 0.00% 0.00% 0.00% 0 ACT2 Crypto Engi
163 0 1 0 0.00% 0.00% 0.00% 0 AggMgr Process
164 0 4 0 0.00% 0.00% 0.00% 0 EEM ED MAT
165 4 73 54 0.00% 0.00% 0.00% 0 EEM ED ND
166 0 1 0 0.00% 0.00% 0.00% 0 MACSEC POST rest
167 0 1 0 0.00% 0.00% 0.00% 0 MACSEC POST hand
168 0 1 0 0.00% 0.00% 0.00% 0 MACSEC POST hand
169 0 1 0 0.00% 0.00% 0.00% 0 IOSXE-RP FastPat
170 0 6 0 0.00% 0.00% 0.00% 0 NGIO_BRI_POLL_DE
171 0 1 0 0.00% 0.00% 0.00% 0 ASYNC Input
172 21 2001 10 0.00% 0.00% 0.00% 0 IR8340 Alarm Con
173 0 2 0 0.00% 0.00% 0.00% 0 dialer isdn sess
174 0 1 0 0.00% 0.00% 0.00% 0 DSX3MIB ll handl
175 29 1961 14 0.00% 0.00% 0.00% 0 fanrp_l2fib
176 0 1 0 0.00% 0.00% 0.00% 0 POS APS Event Pr
177 0 2 0 0.00% 0.00% 0.00% 0 netclk_process
178 0 1 0 0.00% 0.00% 0.00% 0 netclk_ha_proces

Router#show process cpu platform sorted
```

```
CPU utilization for five seconds: 21%, one minute: 22%, five minutes: 22%
Core 0: CPU utilization for five seconds: 4%, one minute: 5%, five minutes: 5%
Core 1: CPU utilization for five seconds: 2%, one minute: 5%, five minutes: 5%
Core 2: CPU utilization for five seconds: 4%, one minute: 6%, five minutes: 6%
Core 3: CPU utilization for five seconds: 4%, one minute: 6%, five minutes: 6%
Core 4: CPU utilization for five seconds: 5%, one minute: 5%, five minutes: 5%
Core 5: CPU utilization for five seconds: 2%, one minute: 2%, five minutes: 2%
Core 6: CPU utilization for five seconds: 41%, one minute: 42%, five minutes: 43%
Core 7: CPU utilization for five seconds: 100%, one minute: 100%, five minutes: 100%
Pid PPid 5Sec 1Min 5Min Status Size Name
------------------------------------------------------------------------------
15435 15419 158% 158% 157% S 226748 ucode_pkt_PPE0
16998 16972 7% 6% 7% S 14252 btman
56 2 3% 5% 5% S 0 ksmd
15179 15139 2% 2% 2% S 171524 fman_fp_image
3821 3807 2% 3% 3% S 584524 linux_iosd-imag
26565 26536 1% 1% 1% S 52764 fman_cc
29044 2 0% 0% 0% I 0 kworker/u32:0-events
26536 16605 0% 0% 0% S 3788 pman
25912 25906 0% 0% 0% S 116208 fed main event
25906 16605 0% 0% 0% S 3796 pman
25689 25684 0% 0% 0% S 5036 nginx
25688 25684 0% 0% 0% S 5868 nginx
25684 25678 0% 0% 0% S 9980 nginx
25678 2784 0% 0% 0% S 3792 pman
25359 25349 0% 0% 0% S 8448 ngiolite
25349 16605 0% 0% 0% S 3792 pman
25048 25043 0% 0% 0% S 9876 ngiolite
25043 16605 0% 0% 0% S 3792 pman
24784 24779 0% 0% 0% S 12352 ngiolite
24779 16605 0% 0% 0% S 3824 pman
24713 2 0% 0% 0% I 0 kworker/1:2H
24688 24446 0% 0% 0% S 432 sleep
24446 1 0% 0% 0% S 2100 memory_monitor.
24341 24333 0% 0% 0% S 12300 ngiolite
24333 16605 0% 0% 0% S 3824 pman
24164 2 0% 0% 0% S 0 SarIosdMond
22339 2 0% 0% 0% I 0 gobisetpower-2-
22338 2 0% 0% 0% I 0 gobireadcb-2-2-
22337 2 0% 0% 0% I 0 gobiprobe-2-2-3
22139 22129 0% 0% 0% S 62172 iomd
22129 16605 0% 0% 0% S 3768 pman
21734 21723 0% 0% 0% S 62064 iomd
21723 16605 0% 0% 0% S 3768 pman
21566 2 0% 0% 0% I 0 kworker/1:3-gobiread
21466 21458 0% 0% 0% S 61992 iomd
21458 16605 0% 0% 0% S 3768 pman
21135 2 0% 0% 0% I 0 gobisetpower-1-
21131 2 0% 0% 0% I 0 gobireadcb-1-2-
21129 2 0% 0% 0% I 0 gobiprobe-1-2-2
21128 2 0% 0% 0% I 0 gobisetpower-0-
21127 2 0% 0% 0% I 0 gobireadcb-0-2-
21126 2 0% 0% 0% I 0 gobiprobe-0-2-2
21120 21113 0% 0% 0% S 74960 iomd
21113 16605 0% 0% 0% S 3820 pman
20788 20780 0% 0% 0% S 63312 iomd
20780 16605 0% 0% 0% S 3768 pman
19604 19582 0% 0% 0% S 18360 btman
19582 16605 0% 0% 0% S 3772 pman
19136 2 0% 0% 0% I 0 kworker/7:2H
18966 18953 0% 0% 0% S 23472 cmcc
18953 16605 0% 0% 0% S 3768 pman
18687 18674 0% 0% 0% S 12420 hman
18674 16605 0% 0% 0% S 3768 pman
```

```
18341 18320 0% 0% 0% S 7020 pttcd
18320 2784 0% 0% 0% S 3776 pman
18046 18031 0% 0% 0% S 78104 pubd
18031 2784 0% 0% 0% S 3776 pman
17396 2 0% 0% 0% I 0 kworker/5:0H
17301 16605 0% 0% 0% S 712 inotifywait
17057 1 0% 0% 0% S 3356 rotee
16972 14118 0% 0% 0% S 3768 pman
16605 1 0% 0% 0% S 8020 pvp.sh
16567 16545 0% 0% 0% S 19688 cman_fp
16545 14118 0% 0% 0% S 3768 pman
16331 16317 0% 0% 0% S 170672 cpp_cp_svr
16317 14118 0% 0% 0% S 3768 pman
16108 16095 0% 0% 0% S 66440 cpp_driver
16095 14118 0% 0% 0% S 3768 pman
15888 15873 0% 0% 0% S 70160 cpp_ha_top_leve
15873 14118 0% 0% 0% S 3772 pman
15660 15646 0% 0% 0% S 80592 cpp_sp_svr
15646 14118 0% 0% 0% S 3768 pman
15419 14118 0% 0% 0% S 3772 pman
15139 14118 0% 0% 0% S 3768 pman
14861 14844 0% 0% 0% S 12420 hman
14844 14118 0% 0% 0% S 3768 pman
14745 14731 0% 0% 0% S 1676 sort_files_by_i
14731 2784 0% 0% 0% S 3756 pman
14405 14118 0% 0% 0% S 712 inotifywait
14282 1 0% 0% 0% S 3356 rotee
14118 1 0% 0% 0% S 7988 pvp.sh
13169 13160 0% 0% 0% S 4224 flash_check.sh
13160 2784 0% 0% 0% S 3764 pman
12444 12435 0% 0% 0% S 14176 lman
12435 2784 0% 0% 0% S 3772 pman
12306 5095 0% 0% 0% S 3108 journalctl
10703 2784 0% 0% 0% S 712 inotifywait
10439 10345 0% 0% 0% S 712 inotifywait
10431 1 0% 0% 0% S 3360 rotee
10347 1 0% 0% 0% S 1180 xinetd
10346 1 0% 0% 0% S 1188 xinetd
10345 1 0% 0% 0% S 12168 rollback_timer.
10343 1 0% 0% 0% S 2068 auxinit.sh
9415 1 0% 0% 0% S 1012 xinetd
9412 1 0% 0% 0% S 1176 xinetd
9150 2 0% 0% 0% I 0 kworker/2:2H-kblockd
8448 1 0% 0% 0% S 6240 dhcpd
8198 8176 0% 0% 0% S 6784 tam_svcs_esg_cf
8176 2784 0% 0% 0% S 3776 pman
7929 7914 0% 0% 0% S 8432 tamd_proc
7914 2784 0% 0% 0% S 3776 pman
7673 7658 0% 0% 0% S 7904 tams_proc
7658 2784 0% 0% 0% S 3776 pman
7422 7405 0% 0% 0% S 32684 btman
7405 2784 0% 0% 0% S 3772 pman
7127 7106 0% 0% 0% S 26272 cli_agent
7106 2784 0% 0% 0% S 3780 pman
6878 6862 0% 1% 1% S 27788 cmand
6862 2784 0% 0% 0% S 3776 pman
6600 6583 0% 0% 0% S 92300 dbm
6583 2784 0% 0% 0% S 3772 pman
6059 6025 0% 0% 0% S 84992 fman_rp
6025 2784 0% 0% 0% S 3772 pman
5779 2 0% 0% 0% S 0 lfts_sar_aux
5778 5763 0% 0% 0% R 15868 hman
5763 2784 0% 0% 0% S 3772 pman
5568 5103 0% 0% 0% S 712 inotifywait
```

```
5560 1 0% 0% 0% S 3356 rotee
5412 5388 0% 0% 0% S 11452 keyman
5388 2784 0% 0% 0% S 3772 pman
5287 1 0% 0% 0% S 3360 rotee
5103 1 0% 0% 0% S 5640 iptbl.sh
5095 5086 0% 0% 0% S 10900 plogd
5086 2784 0% 0% 0% S 3780 pman
5054 13169 0% 0% 0% S 440 sleep
5043 4729 0% 0% 0% S 716 inotifywait
5030 14745 0% 0% 0% S 432 sleep
4940 1 0% 0% 0% S 3424 rotee

Router#
```

Overall Control Plane Resources

Control plane memory and CPU utilization on each control processor allows you to keep a tab on the overall control plane resources. You can use the **show platform software status control-processor brief** command (summary view) or the **show platform software status control-processor command** (detailed view) to view control plane memory and CPU utilization information.

All control processors should show status, Healthy. Other possible status values are Warning and Critical. Warning indicates that the router is operational, but that the operating level should be reviewed. Critical implies that the router is nearing failure.

If you see a Warning or Critical status, take the following actions:

- Reduce the static and dynamic loads on the system by reducing the number of elements in the configuration or by limiting the capacity for dynamic services.
- Reduce the number of routes and adjacencies, limit the number of ACLs and other rules, and so on.

The following sections describe the fields in the **show platform software status control-processor** command output.

Load Average

Load average represents the process queue or process contention for CPU resources. For example, on a single-core processor, an instantaneous load of 7 would mean that seven processes are ready to run, one of which is currently running. On a dual-core processor, a load of 7 would mean that seven processes are ready to run, two of which are currently running.

Memory Utilization

Memory utilization is represented by the following fields:

- Total—Total system memory
- Used—Consumed memory
- Free—Available memory
- Committed—Virtual memory committed to processes

CPU Utilization

CPU utilization is an indication of the percentage of time the CPU is busy, and is represented by the following fields:

- CPU—Allocated processor
- User—Non-Linux kernel processes
- System—Linux kernel process
- Nice—Low-priority processes
- Idle—Percentage of time the CPU was inactive
- IRQ—Interrupts
- SIRQ—System Interrupts
- IOwait—Percentage of time CPU was waiting for I/O

Example: show platform software status control-processor Command

The following are some examples of using the **show platform software status control-processor** command:

```
Router# show platform software status control-processor
RP0: online, statistics updated 2 seconds ago
Load Average: healthy
1-Min: 2.07, status: healthy, under 9.30
5-Min: 2.03, status: healthy, under 9.30
15-Min: 1.92, status: healthy, under 9.30
Memory (kb): healthy
Total: 8000724
Used: 2565652 (32%), status: healthy
Free: 5435072 (68%)
Committed: 3263176 (41%), under 90%
Per-core Statistics
CPU0: CPU Utilization (percentage of time spent)
User: 0.80, System: 4.00, Nice: 0.00, Idle: 95.19
IRQ: 0.00, SIRQ: 0.00, IOwait: 0.00
CPU1: CPU Utilization (percentage of time spent)
User: 2.50, System: 1.60, Nice: 0.00, Idle: 95.90
IRQ: 0.00, SIRQ: 0.00, IOwait: 0.00
CPU2: CPU Utilization (percentage of time spent)
User: 2.90, System: 1.80, Nice: 0.00, Idle: 95.30
IRQ: 0.00, SIRQ: 0.00, IOwait: 0.00
CPU3: CPU Utilization (percentage of time spent)
User: 1.49, System: 7.79, Nice: 0.00, Idle: 90.70
IRQ: 0.00, SIRQ: 0.00, IOwait: 0.00
CPU4: CPU Utilization (percentage of time spent)
User: 4.60, System: 1.80, Nice: 0.00, Idle: 93.59
IRQ: 0.00, SIRQ: 0.00, IOwait: 0.00
CPU5: CPU Utilization (percentage of time spent)
User: 0.99, System: 1.89, Nice: 0.00, Idle: 97.10
IRQ: 0.00, SIRQ: 0.00, IOwait: 0.00
CPU6: CPU Utilization (percentage of time spent)
User: 24.10, System: 18.30, Nice: 0.00, Idle: 57.60
IRQ: 0.00, SIRQ: 0.00, IOwait: 0.00
CPU7: CPU Utilization (percentage of time spent)
User: 92.50, System: 7.50, Nice: 0.00, Idle: 0.00
IRQ: 0.00, SIRQ: 0.00, IOwait: 0.00
```

```
Router#

Router# show platform software status control-processor brief
Load Average
Slot Status 1-Min 5-Min 15-Min
RP0 Healthy 2.01 2.01 1.91

Memory (kB)
Slot Status Total Used (Pct) Free (Pct) Committed (Pct)
RP0 Healthy 8000724 2565240 (32%) 5435484 (68%) 3263124 (41%)

CPU Utilization
Slot CPU User System Nice Idle IRQ SIRQ IOwait
RP0 0 0.70 3.30 0.00 96.00 0.00 0.00 0.00
1 4.39 7.39 0.00 88.11 0.00 0.09 0.00
2 4.80 9.30 0.00 85.80 0.00 0.10 0.00
3 3.39 8.69 0.00 87.91 0.00 0.00 0.00
4 4.40 1.80 0.00 93.80 0.00 0.00 0.00
5 1.00 1.90 0.00 97.10 0.00 0.00 0.00
6 24.64 23.54 0.00 51.80 0.00 0.00 0.00
7 92.60 7.40 0.00 0.00 0.00 0.00 0.00

Router#
```

Monitoring Hardware Using Alarms

Router Design and Monitoring Hardware

The router sends alarm notifications when problems are detected, allowing you to monitor the network remotely. You do not need to use **show** commands to poll devices on a routine basis; however, you can perform onsite monitoring if you choose.

BootFlash Disk Monitoring

The bootflash disk must have enough free space to store two core dumps. This condition is monitored, and if the bootflash disk is too small to store two core dumps, a syslog alarm is generated, as shown in the following example:

```
Oct  6 14:10:56.292: %FLASH_CHECK-3-DISK_QUOTA: R0/0: flash_check: Flash disk quota exceeded

[free space is 1429020 kB] - Please clean up files on bootflash.
```

Approaches for Monitoring Hardware Alarms

Viewing the Console or Syslog for Alarm Messages

The network administrator can monitor alarm messages by reviewing alarm messages sent to the system console or to a system message log (syslog).

Enabling the logging alarm Command

The **logging alarm** command must be enabled for the system to send alarm messages to a logging device, such as the console or a syslog. This command is not enabled by default.

You can specify the severity level of the alarms to be logged. All the alarms at and above the specified threshold generate alarm messages. For example, the following command sends only critical alarm messages to logging devices:

```
Router(config)# logging alarm critical
```

If alarm severity is not specified, alarm messages for all severity levels are sent to logging devices.


Network Management System Alerts a Network Administrator when an Alarm is Reported Through SNMP

The SNMP is an application-layer protocol that provides a standardized framework and a common language used for monitoring and managing devices in a network.

SNMP provides notification of faults, alarms, and conditions that might affect services. It allows a network administrator to access router information through a network management system (NMS) instead of reviewing logs, polling devices, or reviewing log reports.

To use SNMP to get alarm notification, use the following MIBs:

- ENTITY-MIB, RFC4133 (required for the CISCO-ENTITY-ALARM-MIB, ENTITY-STATE-MIB and CISCO-ENTITY-SENSOR-MIB to work)
- CISCO-ENTITY-ALARM-MIB
- ENTITY-STATE-MIB
- CISCO-ENTITY-SENSOR-MIB (for transceiver environmental alarm information, which is not provided through the CISCO-ENTITY-ALARM-MIB)



CHAPTER 34

Troubleshooting

- Troubleshooting, on page 365
- Understanding Diagnostic Mode, on page 365
- Before Contacting Cisco or Your Reseller, on page 366
- show interfaces Troubleshooting Command, on page 366
- Software Upgrade Methods, on page 366
- Change the Configuration Register, on page 367
- Recovering a Lost Password, on page 370

Troubleshooting

This section describes the troubleshooting scenarios.

Before troubleshooting a software problem, you must connect a PC to the router via the console port. With a connected PC, you can view status messages from the router and enter commands to troubleshoot a problem.

You can also remotely access the interface by using Telnet. The Telnet option assumes that the interface is up and running.

Understanding Diagnostic Mode

The router boots up or accesses diagnostic mode in the following scenarios:

- The IOS process or processes fail, in some scenarios. In other scenarios, the system resets when the IOS process or processes fail.
- A user-configured access policy was configured using the **transport-map** command that directs the user into the diagnostic mode.
- A send break signal (**Ctrl-C** or **Ctrl-Shift-6**) was entered while accessing the router, and the router was configured to enter diagnostic mode when a break signal was sent.

In the diagnostic mode, a subset of the commands that are available in user EXEC mode are made available to the users. Among other things, these commands can be used to:

- Inspect various states on the router, including the IOS state.
- Replace or roll back the configuration.

- Provide methods of restarting the IOS or other processes.
- Reboot hardware, such as the entire router, a module, or possibly other hardware components.
- Transfer files into or off of the router using remote access methods such as FTP, TFTP, and SCP.

The diagnostic mode provides a more comprehensive user interface for troubleshooting than previous routers, which relied on limited access methods during failures, such as ROMMON, to diagnose and troubleshoot Cisco IOS problems. The diagnostic mode commands can work when the Cisco IOS process is not working properly. These commands are also available in privileged EXEC mode on the router when the router is working normally.

Before Contacting Cisco or Your Reseller

If you cannot locate the source of a problem, contact your local reseller for advice. Before you call, you should have the following information ready:

- Chassis type and serial number
- Maintenance agreement or warranty information
- Type of software and version number
- Date you received the hardware
- Brief description of the problem
- Brief description of the steps you have taken to isolate the problem

show interfaces Troubleshooting Command

Use the **show interfaces** command to display the status of all physical ports and logical interfaces on the router. describes messages in the command output.

The IR8340 supports the following interfaces:

- GigabitEthernet 0/0/0 and 0/0/1
- Cellular 0/4/0, Cellular 0/4/1, Cellular 0/5/0, and Cellular 0/5/1
- msata

Software Upgrade Methods

Several methods are available for upgrading software on the Cisco IR1840H Routers, including:

- Copy the new software image to flash memory over the WAN interface when the existing Cisco IOS software image is in use.
- Copy the new software image over the console port while in ROM monitor mode.

- From ROM monitor mode, boot the router from a software image that is loaded on a TFTP server. To boot the image from the TFTP server, the TFTP server must be on the same network as the router.

Change the Configuration Register

To change a configuration register, follow these steps:

Procedure

Step 1 Connect a PC to the CONSOLE port on the router.

Step 2 At the privileged EXEC prompt (*router_name* #), enter the **show version** command to display the existing configuration register value (shown in bold at the bottom of this output example):

Example:

```
Router# show version
Cisco IOS XE Software, Version BLD_V177_THROTTLE_LATEST_20210827_030512_V17_7_0_91
Cisco IOS Software [Bengaluru], ir8340 Software (X86_64_LINUX_IOSD-UNIVERSALK9_IOT-M),
Experimental Version 17.7.20210827:033430
[S2C-build-v177_throttle-289-/nobackup/mcpre/BLD-BLD_V177_THROTTLE_LATEST_20210827_030512
154]
Copyright (c) 1986-2021 by Cisco Systems, Inc.
Compiled Fri 27-Aug-21 15:58 by mcpre


Cisco IOS-XE software, Copyright (c) 2005-2021 by cisco Systems, Inc.
All rights reserved. Certain components of Cisco IOS-XE software are
licensed under the GNU General Public License ("GPL") Version 2.0. The
software code licensed under GPL Version 2.0 is free software that comes
with ABSOLUTELY NO WARRANTY. You can redistribute and/or modify such
GPL code under the terms of GPL Version 2.0. For more details, see the
documentation or "License Notice" file accompanying the IOS-XE software,
or the applicable URL provided on the flyer accompanying the IOS-XE
software.


ROM: v0.33

Router uptime is 1 week, 1 day, 23 hours, 9 minutes
Uptime for this control processor is 1 week, 1 day, 23 hours, 10 minutes
System returned to ROM by Reload Command
System image file is
"flash:ir8340-universalk9.BLD_V177_THROTTLE_LATEST_20210827_030512_V17_7_0_91.SSA.bin"
Last reload reason: Reload Command



This product contains cryptographic features and is subject to United
States and local country laws governing import, export, transfer and
use. Delivery of Cisco cryptographic products does not imply
third-party authority to import, export, distribute or use encryption.
Importers, exporters, distributors and users are responsible for
compliance with U.S. and local country laws. By using this product you
agree to comply with applicable laws and regulations. If you are unable
to comply with U.S. and local laws, return this product immediately.

A summary of U.S. laws governing Cisco cryptographic products may be found at:
```

```
http://www.cisco.com/wwl/export/crypto/tool/stqrg.html

If you require further assistance please contact us by sending email to
export@cisco.com.


Technology Package License Information:

------------------------------------------------------------------
Technology Type Technology-package Technology-package
Current Next Reboot
------------------------------------------------------------------
Smart License Perpetual network-advantage network-advantage
Smart License Subscription None None

The current crypto throughput level is 250000 kbps


Smart Licensing Status: Registration Not Applicable/Not Applicable

cisco IR8340-K9 (2RU) processor with 3717851K/6147K bytes of memory.
Processor board ID FDO2502JF0L
Router operating mode: Autonomous
1 Virtual Ethernet interface
14 Gigabit Ethernet interfaces
8 Serial interfaces
8 terminal lines
2 Cellular interfaces
32768K bytes of non-volatile configuration memory.
8388608K bytes of physical memory.
7574982K bytes of flash memory at bootflash:.
33554432K bytes of mSATA at msata:.
929715K bytes of sdcard flash at sdcard:.
30031856K bytes of USB flash at usb0:.

Configuration register is 0x0

Router#
```

Step 3 Record the setting of the configuration register.

Step 4 To enable the break setting (indicated by the value of bit 8 in the configuration register), enter the **config-register** <*value*>command from privileged EXEC mode.

- Break enabled—Bit 8 is set to 0.
- Break disabled (default setting)—Bit 8 is set to 1.

Configuring the Configuration Register for Autoboot



Note Altering the configuration register is only for advanced troubleshooting and should only be done with guidance from Cisco support.

The configuration register can be used to change router behavior. This includes controlling how the router boots. Set the configuration register to 0x0 to boot into ROM, by using one of the following commands:

- In Cisco IOS configuration mode, use the **config-reg** 0x0 command.
- From the ROMMON prompt, use the **confreg** 0x0 command.



Note Setting the configuration register to 0x2102 will set the router to autoboot the Cisco IOS XE software.

Reset the Router

To reset the router, follow these steps:

Procedure

Step 1 If the break is disabled, turn off the router, wait for 5 seconds and turn the router back on. Within 60 seconds push the Reset button.

The terminal displays the Rommon prompt.

Example:

```
rommon 1>
```

Step 2 Enter **confreg 0x2142** to ignore the running config.

Example:

```
rommon 2> confreg 0x142
```

Step 3 Sync the configuration changes with the **sync** command.

Example:

```
rommon 3>sync
```

Step 4 Reset the router to apply confreg. The router will reload with the reset.

Example:

```
rommon 4>reset

resetting...
```

Step 5 Verify that the correct confreg 0x2142 was applied, and enter **n** when asked if you want to change the configuration.

Example:

```
rommon 1> confreg
Configuration Summary
(Virtual Configuration Register: 0x2142)
enabled are:
[ 0 ] console baud: 9600
boot:...... image specified by the boot system commands
do you wish to change the configuration? y/n [n]: n
```

Step 6 Boot the image with the confreg 0x2142.

Example:

```
rommon 2> boot
flash:ir8340-universalk9.BLD_V177_THROTTLE_LATEST_20210827_030512_V17_7_0_91.SSA.bin
```

Recovering a Lost Password

To recover a lost password, follow these steps. Refer to Reset the Router, on page 369 for details.

1. Reset the router.
2. Change the confreg to 0x2142.
3. Boot the router with confreg 0x2142 from Rommon.
4. If you used the reset button, add the license:

```
Router#config term
Router#license smart reservation
```

Note Recovering a lost password is only possible when you are connected to the router through the console port. These procedures cannot be performed through a Telnet session.

Reset the Configuration Register Value

To reset the configuration register value after you have recovered or reconfigured a password, follow these steps:

Procedure

Step 1 Enter the **configure terminal** command to enter global configuration mode:

Example:

```
Router# configure terminal
```

Step 2 Enter the **configure register** command and the original configuration register value that you recorded.

Example:

```
Router(config)# config-reg
value
```

Step 3 Enter **exit** to exit configuration mode:

Example:

```
Router(config)# exit
```

Note
To return to the configuration being used before you recovered the lost enable password, do not save the configuration changes before rebooting the router.

Step 4 Reboot the router, and enter the recovered password.

Configuring a Console Port Transport Map

This task describes how to configure a transport map for a console port interface on the router.

Procedure

	Command or Action	Purpose
Step 1	**enable** **Example:** `Router> enable`	Enables privileged EXEC mode. Enter your password if prompted.
Step 2	**configure terminal** **Example:** `Router# configure terminal`	Enters global configuration mode.
Step 3	**transport-map type console** *transport-map-name* **Example:** `Router(config)# transport-map type console consolehandler`	Creates and names a transport map for handling console connections, and enters transport map configuration mode.
Step 4	**connection wait** [**allow** [**interruptible**] | **none** [**disconnect**]] **Example:** `Router(config-tmap)# connection wait none`	Specifies how a console connection will be handled using this transport map. • **allow interruptible**—The console connection waits for a Cisco IOS VTY line to become available, and also allows users to enter diagnostic mode by interrupting a console connection that is waiting for a Cisco IOS VTY line to become available. This is the default setting. **Note** Users can interrupt a waiting connection by entering **Ctrl-C** or **Ctrl-Shift-6**. • **none**—The console connection immediately enters diagnostic mode.

	Command or Action	Purpose
Step 5	(Optional) **banner** [**diagnostic** | **wait**] *banner-message* **Example:** `Router(config-tmap)# banner diagnostic X` `Enter TEXT message. End with the character 'X'.` `--Welcome to Diagnostic Mode--` `X` `Router(config-tmap)#`	(Optional) Creates a banner message that will be seen by users entering diagnostic mode or waiting for the Cisco IOS VTY line because of the console transport map configuration. • **diagnostic**—Creates a banner message seen by users directed to diagnostic mode because of the console transport map configuration. **Note** Users can interrupt a waiting connection by entering **Ctrl-C** or **Ctrl-Shift-6**. • **wait**—Creates a banner message seen by users waiting for Cisco IOS VTY to become available. • *banner-message*—Banner message, which begins and ends with the same delimiting character.
Step 6	**exit** **Example:** `Router(config-tmap)# exit`	Exits transport map configuration mode to re-enter global configuration mode.
Step 7	**transport type console** *console-line-number* **input** *transport-map-name* **Example:** `Router(config)# transport type console 0 input consolehandler`	Applies the settings defined in the transport map to the console interface. The *transport-map-name* for this command must match the *transport-map-name* defined in the **transport-map type console** command.

Examples

The following example shows how to create a transport map to set console port access policies and attach to console port 0:

```
Router(config)# transport-map type console consolehandler
Router(config-tmap)# connection wait allow interruptible
Router(config-tmap)# banner diagnostic X
Enter TEXT message. End with the character 'X'.
--Welcome to diagnostic mode--
X
Router(config-tmap)# banner wait X
Enter TEXT message. End with the character 'X'.
Waiting for IOS vty line
X
Router(config-tmap)# exit
Router(config)# transport type console 0 input consolehandler
```

Viewing Console Port, SSH, and Telnet Handling Configurations

Use the following commands to view console port, SSH, and Telnet handling configurations:

- **show transport-map**
- **show platform software configuration access policy**

Use the **show transport-map** command to view transport map configurations.

show transport-map [**all** | **name** *transport-map-name* | **type** [**console**]]

This command can be used either in user EXEC mode or privileged EXEC mode.

Example

The following example shows transport maps that are configured on the router: console port (`consolehandler`):

```
Router# show transport-map all
Transport Map:
Name: consolehandler Type: Console Transport

Connection:
Wait option: Wait Allow Interruptable Wait banner:

Waiting for the IOS CLI bshell banner:
Welcome to Diagnostic Mode



Router# show transport-map type console
Transport Map:
Name: consolehandler


REVIEW DRAFT - CISCO CONFIDENTIAL

Type: Console Transport

Connection:
Wait option: Wait Allow Interruptable Wait banner:

Waiting for the IOS CLI Bshell banner:
Welcome to Diagnostic Mode



Router# show transport-map type persistent ssh
Transport Map:
Name: consolehandler Type: Console Transport

Connection:
Wait option: Wait Allow Interruptable Wait banner:

Waiting for the IOS CLI Bshell banner:
Welcome to Diagnostic Mode
```

Use the **show platform software configuration access policy** command to view the current configurations for handling the incoming console port, SSH, and Telnet connections. The output of this command provides

the current wait policy for each type of connection (Telnet, SSH, and console), as well as information on the currently configured banners.

Unlike the **show transport-map** command, the **show platform software configuration access policy** command is available in diagnostic mode so that it can be entered in scenarios where you need transport map configuration information, but cannot access the Cisco IOS CLI.

Example

The following example shows the **show platform software configuration access policy** command.

```
Router# show platform software configuration access policy
The current access-policies

Method : telnet
Rule : wait with interrupt Shell banner:
Welcome to Diagnostic Mode

Wait banner :
Waiting for IOS Process

Method : ssh Rule : wait Shell banner: Wait banner :

Method : console
Rule : wait with interrupt Shell banner:
Wait banner :
```

Using the factory reset Commands

The **factory reset** commands are used to remove all the customer specific data on a router/switch that has been added. The data can be configuration, log files, boot variables, core files, and so on.

The **factory-reset all** command erases the bootflash, nvram, rommon variables, licenses, and logs.

Caution Use of the factory reset command should not be done lightly. All customer configurations will be ddeleted and the platform will boot up as if new from the factory.

Note factory-reset all does not work if IOS-XE is running in controller mode. Please refer to SDWAN configuration information.

```
Router#factory-reset all
The factory reset operation is irreversible for all operations. Are you sure? [confirm]
*Enter*

*May 12 09:55:45.831: %SYS-5-RELOAD: Reload requested by Exec. Reload Reason: Factory Reset.

***Return to ROMMON Prompt
```

Boot Sequence after Factory Reset

Booting the image:

- The bootloader attempts to boot “golden.bin” from the bootflash: partition
- If no “golden.bin” is present, then boot the first image.

Loading the configuration:

- IOS looks for “golden.cfg” file on nvram: partition and applies it upon booting.
- If no “golden.cfg” is present on nvram: then IOS looks for “golden.cfg” file on bootflash: partition and applies it upon booting.
- If no “golden.cfg” is present on bootflash: then configurations are erased and Software Configuration dialog is used.