

Configure LC Priority Shutdown

This chapter describes the procedure to configure the shutdown priority on line cards using IOS.

- Configure LC Priority Shutdown, on page 1

Configure LC Priority Shutdown

This task enables the LC priority shutdown feature on a NCS 4000 chassis and assigns a shutdown priority on the line cards. For more information, see LC Priority Shutdown.

Procedure

Step 1 **configure**

Enters the configuration mode terminal.

Example:

```
RP/0/# configure
```

Step 2 **power-mgmt progressive location** *rack-id*

Enables the LC priority shutdown feature on the chassis specified and assigns a default priority of 20 to all the line cards.

To disable this feature, use the **no** form of this command.

Example:

```
RP/0/ (config)#power-mgmt progressive location L0
```

Step 3 **priority location** *line-card-location card-priority*

Configures the shutdown priority to the line card specified.

To remove the priority, use the **no** form of this command.

Example:

```
RP/0/ (config-location-L0)#priority location 0/9 6
```

Step 4 **commit**