

# FXOS Troubleshooting Commands

This section includes common troubleshooting commands.


- Chassis Mode Troubleshooting Commands, on page 1
- Eth-Uplink Mode Troubleshooting Commands, on page 6
- Fabric Interconnect Mode Troubleshooting Commands, on page 9
- Connect Local-Mgmt Troubleshooting Commands for the Firepower 2100 in Platform Mode, on page 12
- Connect Local-Mgmt Troubleshooting Commands for the Secure Firewall 3100, on page 17
- Connect Local-Mgmt Troubleshooting Commands for the Secure Firewall 4200 in Appliance Mode, on page 29
- Security Services Mode Troubleshooting Commands, on page 38
- Packet Capture for Secure Firewall 3100/4200, on page 39


# Chassis Mode Troubleshooting Commands

Use the following chassis mode FXOS CLI commands to troubleshoot issues with your system.

**show environment**

Displays environment information for the chassis.

For example:

```
FPR2100 /chassis # show environment expand detail
Chassis 1:
Overall Status: Power Problem
        Operability: Operable
        Power State: Ok
        Thermal Status: Ok
PSU 1:
            Overall Status: Powered Off
            Operability: Unknown
            Power State: Off
            Voltage Status: Unknown
        PSU 2:
            Overall Status: Operable
            Operability: Operable
            Power State: On
            Voltage Status: Ok
        Tray 1 Module 1:
            Overall Status: Operable
            Operability: Operable
            Power State: On
```

```
Fan 1:
            Overall Status: Operable
            Operability: Operable
            Power State: On
        Fan 2:
            Overall Status: Operable
            Operability: Operable
            Power State: On
        Fan 3:
            Overall Status: Operable
            Operability: Operable
            Power State: On
        Fan 4:
            Overall Status: Operable
            Operability: Operable
            Power State: On
        Server 1:
            Overall Status: Ok
                Memory Array 1:
                    Current Capacity (MB): 32768
                    Populated: 2
                    DIMMs:
                    ID  Overall Status           Capacity (MB)
                    --- ------------------------ -------------
                      1 Operable                 16384
                      2 Operable                 16384
                CPU 1:
                    Presence: Equipped
                    Cores: 8
                    Product Name: Intel(R) Xeon(R) CPU D-1548 @ 2.00GHz
                    Vendor: GenuineIntel
                    Thermal Status: OK
                    Overall Status: Operable
                    Operability: Operable
```

**scope fan**

Enters the fan mode on Firepower 2110, 2120, and Secure Firewall 3100 series devices.

**scope fan-module**

Enters the fan mode on Firepower 2130, 2140, and Secure Firewall 3100 devices. From this mode, you can display detailed information about the chassis fan.

For example:

```
FPR2100 /chassis # show fan-module expand detail
Fan Module:
    Tray: 1
    Module: 1
    Overall Status: Operable
    Operability: Operable
    Power State: On
    Presence: Equipped
    Product Name: Cisco Firepower 2000 Series Fan Tray
    PID: FPR2K-FAN
    Vendor: Cisco Systems, Inc
    Fan:
        ID: 1
        Overall Status: Operable
        Operability: Operable
        Power State: On
        Presence: Equipped
        ID: 2
        Overall Status: Operable
        Operability: Operable
        Power State: On
        Presence: Equipped
```

**show inventory**

Displays inventory information such as the chassis number, vendor, and serial number.
Note: This command only applies to Firepower 2130 and Secure Firewall 3100 devices.
For example:

```
    FPR2100 /chassis # show inventory
Chassis    PID             Vendor            Serial (SN) HW Revision
---------- --------------- ----------------- ----------- -----------
         1 FPR-2140        Cisco Systems, In JAD201005FC 0.1
```

**show inventory expand**

Displays detailed inventory information about FRUable components such as the chassis, PSU, and network modules.
For example:

```
    FPR2100 /chassis #   show inventory expand detail
    Chassis 1:
        Product Name: Cisco Firepower 2000 Appliance
        PID: FPR-2130
        VID: V01
        Vendor: Cisco Systems, Inc
        Model: FPR-2130
        Serial (SN): JAD2012091X
        HW Revision: 0.1
        PSU 1:
            Presence: Equipped
            Product Name: Cisco Firepower 2000 Series AC 400W Power Supply
            PID: FPR2K-PWR-AC-400
            VID: V01
            Vendor: Cisco Systems, Inc
            Serial (SN): LIT2010CAFE
            HW Revision: 0
        PSU 2:
            Presence: Equipped
            Product Name: Cisco Firepower 2000 Series AC 400W Power Supply
            PID: FPR2K-PWR-AC-400
            VID: V01
            Vendor: Cisco Systems, Inc
            Serial (SN): LIT2010CAFE
            HW Revision: 0
        Fan Modules:
            Tray 1 Module 1:
                Presence: Equipped
                Product Name: Cisco Firepower 2000 Series Fan Tray
                PID: FPR2K-FAN
                Vendor: Cisco Systems, Inc
        Fans:
            ID Presence
            -- --------
             1 Equipped
             2 Equipped
             3 Equipped
             4 Equipped
    Fabric Card 1:
        Description: Cisco SSP FPR 2130 Base Module
        Number of Ports: 16
        State: Online
        Vendor: Cisco Systems, Inc.
        Model: FPR-2130
        HW Revision: 0
        Serial (SN): JAD2012091X
        Perf: N/A
        Operability: Operable
```

```
    Overall Status: Operable
    Power State: Online
    Presence: Equipped
    Thermal Status: N/A
    Voltage Status: N/A
Fabric Card 2:
    Description: 8-port 10 Gigabit Ethernet Expansion Module
    Number of Ports: 8
    State: Online
    Vendor: Cisco Systems, Inc.
    Model: FPR-NM-8X10G
    HW Revision: 0
    Serial (SN): JAD19510AKD
    Perf: N/A
    Operability: Operable
    Overall Status: Operable
    Power State: Online
    Presence: Equipped
    Thermal Status: N/A
    Voltage Status: N/A
```

**scope psu**

Enters the power supply unit mode. From this mode, you can view detailed information about the power supply unit.

For example:

```
FPR2100 /chassis #  show psu expand detail
PSU:
    PSU: 1
    Overall Status: Powered Off
    Operability: Unknown
    Power State: Off
    Presence: Equipped
    Voltage Status: Unknown
    Product Name: Cisco Firepower 2000 Series AC 400W Power Supply
    PID: FPR2K-PWR-AC-400
    VID: V01
    Vendor: Cisco Systems, Inc
    Serial (SN): LIT2010CAFE
    Type: AC
    Fan Status: Ok
    PSU: 2
    Overall Status: Operable
    Operability: Operable
    Power State: On
    Presence: Equipped
    Voltage Status: Ok
    Product Name: Cisco Firepower 2000 Series AC 400W Power Supply
    PID: FPR2K-PWR-AC-400
    VID: V01
    Vendor: Cisco Systems, Inc
    Serial (SN): LIT2010CAFE
    Type: AC
    Fan Status: Ok
```

**scope stats**

Enters the stats mode. From this mode, you can view detailed information about the chassis statatistics.

For example:

```
FPR2100 /chassis # show stats
Chassis Stats:
    Time Collected: 2016-11-14T21:19:46.317
    Monitored Object: sys/chassis-1/stats
    Suspect: No
```

```
    Outlet Temp1 (C): 43.000000
    Outlet Temp2 (C): 41.000000
    Inlet Temp (C): 30.000000
    Internal Temp (C): 34.000000
    Thresholded: 0
Fan Stats:
    Time Collected: 2016-11-14T21:19:46.317
    Monitored Object: sys/chassis-1/fan-module-1-1/fan-1/stats
    Suspect: No
    Speed (RPM): 17280
    Thresholded: 0
    Time Collected: 2016-11-14T21:19:46.317
    Monitored Object: sys/chassis-1/fan-module-1-1/fan-2/stats
    Suspect: No
    Speed (RPM): 17340
    Thresholded: 0
    Time Collected: 2016-11-14T21:19:46.317
    Monitored Object: sys/chassis-1/fan-module-1-1/fan-3/stats
    Suspect: No
    Speed (RPM): 17280
    Thresholded: 0
    Time Collected: 2016-11-14T21:19:46.317
    Monitored Object: sys/chassis-1/fan-module-1-1/fan-4/stats
    Suspect: No
    Speed (RPM): 17280
    Thresholded: 0
Psu Stats:
    Time Collected: 2016-11-14T21:19:46.318
    Monitored Object: sys/chassis-1/psu-1/stats
    Suspect: No
    Input Current (A): 0.000000
    Input Power (W): 8.000000
    Input Voltage (V): 0.000000
    Psu Temp1 (C): 32.000000
    Psu Temp2 (C): 36.000000
    Psu Temp3 (C): 32.000000
    Fan Speed (RPM): 0
    Thresholded: 0
    Time Collected: 2016-11-14T21:19:46.318
    Monitored Object: sys/chassis-1/psu-2/stats
    Suspect: No
    Input Current (A): 0.374000
    Input Power (W): 112.000000
    Input Voltage (V): 238.503006
    Psu Temp1 (C): 36.000000
    Psu Temp2 (C): 47.000000
    Psu Temp3 (C): 47.000000
    Fan Speed (RPM): 2240
    Thresholded: 0
CPU Env Stats:
    Time Collected: 2016-11-14T21:19:46.317
    Monitored Object: sys/chassis-1/blade-1/board/cpu-1/env-stats
    Suspect: No
    Temperature (C): 46.000000
    Thresholded: 0
    Time Collected: 2016-11-14T21:19:46.317
    Monitored Object: sys/chassis-1/blade-1/npu/cpu-1/env-stats
    Suspect: No
    Temperature (C): 38.000000
    Thresholded: 0
```

**show dimm detail**

Enter **scope server** and then enter **scope server scope memory-array**.

Note: This command only applies to Secure Firewall 6100 devices.
The following example shows detailed information about field-replaceable dual-inline memory module that is installed in the Secure Firewall 6100 devices:
Note: This command only applies to Secure Firewall 6100 devices.

```
 firepower-6120# scope server
firepower-6120 /chassis/server # scope memory-array 1
firepower-6120 /chassis/server/memory-array # show dimm detail
   DIMM:
    ID: 1
    Presence: Yes
    Bank Location: P0 CHANNEL A
    Overall Status: Operable
    PID: MEM-CSF6100-96GB
    Vendor: Samsung
    Vendor Part Number: M321R4GA3PB0-CWMKH
    Vendor Serial (SN): 80CE0124240653AE44
    Capacity (MB): 32768
    Speed: 5600
    Correctable Errors: 0
    Uncorrectable Errors: 0

    ID: 2
    Presence: Yes
    Bank Location: P0 CHANNEL B
    Overall Status: Operable
    PID: MEM-CSF6100-96GB
    Vendor: Samsung
    Vendor Part Number: M321R4GA3PB0-CWMKH
    Vendor Serial (SN): 80CE0124240653AF14
    Capacity (MB): 32768
    Speed: 5600
    Correctable Errors: 0
    Uncorrectable Errors: 0

    ID: 3
    Presence: Yes
    Bank Location: P0 CHANNEL C
    Overall Status: Operable
    PID: MEM-CSF6100-96GB
    Vendor: Samsung
    Vendor Part Number: M321R4GA3PB0-CWMKH
    Vendor Serial (SN): 80CE0124240653AD82
    Capacity (MB): 32768
    Speed: 5600
    Correctable Errors: 0
    Uncorrectable Errors: 0
```

# Eth-Uplink Mode Troubleshooting Commands

Use the following eth-uplink mode FXOS CLI commands to troubleshoot issues with your system.

**show detail**

Displays detailed information about your device's Ethernet uplink.
For example:

```
FPR2100 /eth-uplink # show detail
    Ethernet Uplink:
        Mode: Security Node
```

```
        MAC Table Aging Time (dd:hh:mm:ss): 00:04:01:40
        VLAN Port Count Optimization: Disabled
        Current Task:
```

**scope fabric a**

Enters the eth-uplink interface mode. From this mode, you can view port channel, statistics, and interface information.

For example:

```
FPR2100 /eth-uplink/fabric # show interface
Interface:
    Port Name      Port Type          Admin State Oper State       State Reason
    -------------- ------------------ ----------- ---------------- ------------
    Ethernet1/1    Data               Enabled     Up               Up
    Ethernet1/2    Data               Enabled     Link Down        Down
    Ethernet1/3    Data               Disabled    Link Down        Down
    Ethernet1/4    Data               Disabled    Link Down        Down
    Ethernet1/5    Data               Disabled    Link Down        Down
    Ethernet1/6    Data               Disabled    Link Down        Down
    Ethernet1/7    Data               Disabled    Link Down        Down
    Ethernet1/8    Data               Disabled    Link Down        Down
    Ethernet1/9    Data               Disabled    Link Down        Down
    Ethernet1/10   Data               Disabled    Link Down        Down
    Ethernet1/11   Data               Disabled    Link Down        Down
    Ethernet1/12   Data               Disabled    Link Down        Down
    Ethernet1/13   Data               Disabled    Link Down        Down
    Ethernet1/14   Data               Disabled    Link Down        Down
    Ethernet1/15   Data               Disabled    Link Down        Down
    Ethernet1/16   Data               Disabled    Link Down        Down
    Ethernet2/1    Data               Disabled    Link Down        Down
    Ethernet2/2    Data               Disabled    Link Down        Down
    Ethernet2/3    Data               Disabled    Link Down        Down
    Ethernet2/4    Data               Disabled    Link Down        Down
    Ethernet2/5    Data               Disabled    Link Down        Down
    Ethernet2/6    Data               Disabled    Link Down        Down
    Ethernet2/7    Data               Disabled    Link Down        Down
    Ethernet2/8    Data               Disabled    Link Down        Down


FPR2100 /eth-uplink/fabric # show port-channel
    Port Channel:
        Port Channel Id Name             Port Type          Admin State            Oper
 State            State Reason
        --------------- ---------------- ------------------           -----------
          ----------------           ------------
        1               Port-channel1    Data               Disabled
     Link Down                       Down


FPR2100 /eth-uplink/fabric/port-channel # show stats
    Ether Error Stats:
        Time Collected: 2016-11-14T21:27:16.386
        Monitored Object: fabric/lan/A/pc-1/err-stats
        Suspect: No
        Rcv (errors): 0
        Align (errors): 0
        Fcs (errors): 0
        Xmit (errors): 0
        Under Size (errors): 0
        Out Discard (errors): 0
        Deferred Tx (errors): 0
        Int Mac Tx (errors): 0
        Int Mac Rx (errors): 0
        Thresholded: Xmit Delta Min
```

```
Ether Loss Stats:
    Time Collected: 2016-11-14T21:27:16.386
    Monitored Object: fabric/lan/A/pc-1/loss-stats
    Suspect: No
    Single Collision (errors): 0
    Multi Collision (errors): 0
    Late Collision (errors): 0
    Excess Collision (errors): 0
    Carrier Sense (errors): 0
    Giants (errors): 0
    Symbol (errors): 0
    SQE Test (errors): 0
    Thresholded: 0
Ether Pause Stats:
    Time Collected: 2016-11-14T21:27:16.386
    Monitored Object: fabric/lan/A/pc-1/pause-stats
    Suspect: No
    Recv Pause (pause): 0
    Xmit Pause (pause): 0
    Resets (resets): 0
    Thresholded: 0
Ether Rx Stats:
    Time Collected: 2016-11-14T21:27:16.386
    Monitored Object: fabric/lan/A/pc-1/rx-stats
    Suspect: No
    Total Packets (packets): 0
    Unicast Packets (packets): 0
    Multicast Packets (packets): 0
    Broadcast Packets (packets): 0
    Total Bytes (bytes): 0
    Jumbo Packets (packets): 0
    Thresholded: 0
Ether Tx Stats:
   Time Collected: 2016-11-14T21:27:16.386
    Monitored Object: fabric/lan/A/pc-1/tx-stats
    Suspect: No
    Total Packets (packets): 0
    Unicast Packets (packets): 0
    Multicast Packets (packets): 0
    Broadcast Packets (packets): 0
    Total Bytes (bytes): 0
    Jumbo Packets (packets): 0
FPR2100 /eth-uplink/fabric/interface # show stats
Ether Error Stats:
    Time Collected: 2016-11-14T21:27:46.395
    Monitored Object: sys/switch-A/slot-1/switch-ether/port-1/err-stats
    Suspect: No
    Rcv (errors): 0
    Align (errors): 0
    Fcs (errors): 0
    Xmit (errors): 0
    Under Size (errors): 0
    Out Discard (errors): 0
    Deferred Tx (errors): 0
    Int Mac Tx (errors): 0
    Int Mac Rx (errors): 0
    Thresholded: Xmit Delta Min
Ether Loss Stats:
    Time Collected: 2016-11-14T21:27:46.395
    Monitored Object: sys/switch-A/slot-1/switch-ether/port-1/loss-stats
    Suspect: No
    Single Collision (errors): 0
    Multi Collision (errors): 0
    Late Collision (errors): 0
```

```
    Excess Collision (errors): 0
    Carrier Sense (errors): 0
    Giants (errors): 7180
    Symbol (errors): 0
    SQE Test (errors): 0
    Thresholded: 0
Ether Pause Stats:
    Time Collected: 2016-11-14T21:27:46.395
    Monitored Object: sys/switch-A/slot-1/switch-ether/port-1/pause-stats
    Suspect: No
    Recv Pause (pause): 0
    Xmit Pause (pause): 0
    Resets (resets): 0
    Thresholded: 0
Ether Rx Stats:
    Time Collected: 2016-11-14T21:27:46.395
    Monitored Object: sys/switch-A/slot-1/switch-ether/port-1/rx-stats
    Suspect: No
    Total Packets (packets): 604527
    Unicast Packets (packets): 142906
    Multicast Packets (packets): 339031
    Broadcast Packets (packets): 122590
    Total Bytes (bytes): 59805045
    Jumbo Packets (packets): 0
    Thresholded: 0
Ether Tx Stats:
    Time Collected: 2016-11-14T21:27:46.395
    Monitored Object: sys/switch-A/slot-1/switch-ether/port-1/tx-stats
    Suspect: No
    Total Packets (packets): 145018
    Unicast Packets (packets): 145005
    Multicast Packets (packets): 0
    Broadcast Packets (packets): 13
    Total Bytes (bytes): 13442404
    Jumbo Packets (packets): 0
    Thresholded: 0
```

# Fabric Interconnect Mode Troubleshooting Commands

Use the following fabric-interconnect mode FXOS CLI commands to troubleshoot issues with your system.

**show card**

Displays information on a fabric card.

For example:

```
FPR2100 /fabric-interconnect # show card detail expand
Fabric Card:
    Id: 1
    Description: Cisco SSP FPR 2130 Base Module
    Number of Ports: 16
    State: Online
    Vendor: Cisco Systems, Inc.
    Model: FPR-2130
    HW Revision: 0
    Serial (SN): JAD2012091X
    Perf: N/A
    Operability: Operable
    Overall Status: Operable
    Power State: Online
    Presence: Equipped
```

```
        Thermal Status: N/A
        Voltage Status: N/A
```

**show image**

Displays all available images.

```
firepower /firmware # show image
Name                                        Type                Version
------------------------------------------- ------------------- -------
cisco-asa-9.10.1.csp                        Firepower Cspapp    9.10.1
cisco-asa-9.9.2.csp                         Firepower Cspapp    9.9.2
fxos-k8-fp2k-firmware.0.4.04.SPA            Firepower Firmware  0.4.04
fxos-k8-fp2k-lfbff.82.1.1.303i.SSA          Firepower System    82.1(1.303i)
fxos-k8-fp2k-npu.82.1.1.303i.SSA            Firepower Npu       82.1(1.303i)
fxos-k8-fp2k-npu.82.1.1.307i.SSA            Firepower Npu       82.1(1.307i)
fxos-k9-fp2k-manager.82.1.1.303i.SSA        Firepower Manager   82.1(1.303i)
```

**show package**

Displays all available packages.

```
firepower /firmware # show package
    Name                                        Package-Vers
    ------------------------------------------- ------------
    cisco-ftd-fp2k.9.10.1.SSA                   9.10.1
    cisco-ftd-fp2k.9.9.2.SSA                    9.9.2
```

**show package *package_name* expand**

Displays the package details.

```
    firepower /firmware # show package cisco-ftd-fp2k.9.10.1.SSA expand
    Package cisco-ftd-fp2k.9.10.1.SSA:
        Images:
            cisco-asa.9.10.1.csp
            fxos-k8-fp2k-firmware.0.4.04.SPA
            fxos-k8-fp2k-lfbff.82.1.1.303i.SSA
            fxos-k8-fp2k-npu.82.1.1.303i.SSA
            fxos-k9-fp2k-manager.82.1.1.303i.SSA
```

**scope auto-install**

Enters the auto-install mode. From this mode, you can view the current FXOS upgrade state.

```
firepower /firmware/auto-install # show
    Firmware Auto-Install:
        Package-Vers Oper State                  Upgrade State
        ------------ ----------------------------- -------------
        9.10.1            Scheduled                     Installing Application
```

**scope firmware**

Enters the firmware mode. From this mode, you can view download task information.
For example:

```
FPR2100 /firmware # show download-task
    Download task:
        File Name                                     Protocol Server          Port
     Userid          State
        ---------                                  -------- --------------- ----------
 ---------------- -----
        cisco-ftd-fp2k.9.10.1.SSA                     Scp      172.29.191.78
   0 danp            Downloaded
        cisco-ftd-fp2k.9.9.1.SSA                      Scp      172.29.191.78
```

```
   0 danp            Downloaded
```

**scope download-task**

Enters the download-task mode. From this mode, you can view additional details about each download task and restart the download task.

For example:

```
Download task:
    File Name: test.SSA
    Protocol: Scp
    Server: 172.29.191.78
    Port: 0
    Userid: user
    Path: /tmp
    Downloaded Image Size (KB): 0
    Time stamp: 2016-11-15T19:42:29.854
    State: Failed
    Transfer Rate (KB/s): 0.000000
    Current Task: deleting downloadable test.SSA on
local(FSM-STAGE:sam:dme:FirmwareDownloaderDownload:DeleteLocal)
firepower /firmware/download-task # show fsm status
File Name: test.SSA
    FSM 1:
        Remote Result: End Point Failed
        Remote Error Code: ERR MO Illegal Iterator State
        Remote Error Description: End point timed out. Check for IP, port, password,
disk space or network access related issues.#
        Status: Download Fail
        Previous Status: Download Fail
        Timestamp: 2016-11-15T19:42:29.854
        Try: 2
        Progress (%): 0
        Current Task: deleting downloadable test.SSA on
local(FSM-STAGE:sam:dme:FirmwareDownloaderDownload:DeleteLocal)

    firepower /firmware/download-task # restart
    Password:
```

**scope psu**

Enters the power supply unit mode. From this mode, you can view detailed information about the power supply unit.

For example:

```
    FPR2100 /chassis #  show psu expand detail
    PSU:
        PSU: 1
        Overall Status: Powered Off
        Operability: Unknown
        Power State: Off
        Presence: Equipped
        Voltage Status: Unknown
        Product Name: Cisco Firepower 2000 Series AC 400W Power Supply
        PID: FPR2K-PWR-AC-400
        VID: V01
        Vendor: Cisco Systems, Inc
        Serial (SN): LIT2010CAFE
        Type: AC
        Fan Status: Ok
        PSU: 2
        Overall Status: Operable
        Operability: Operable
        Power State: On
        Presence: Equipped
```

```
Voltage Status: Ok
Product Name: Cisco Firepower 2000 Series AC 400W Power Supply
PID: FPR2K-PWR-AC-400
VID: V01
Vendor: Cisco Systems, Inc
Serial (SN): LIT2010CAFE
Type: AC
Fan Status: Ok
```

# Connect Local-Mgmt Troubleshooting Commands for the Firepower 2100 in Platform Mode

Use the following connect local-mgmt mode FXOS CLI commands to troubleshoot issues with your Firepower 2100 in Platform mode. To access connect local-mgmt mode, enter:

FPR2100# **connect local-mgmt**

**show lacp**

Displays detailed information about EtherChannel LACP.
For example:

```
FPR2100(local-mgmt)# show lacp neighborFlags:  S - Device is requesting Slow LACPDUs
        F - Device is requesting Fast LACPDUs
        A - Device is in Active mode       P - Device is in Passive mode

Channel group: 11

Partner (internal) information:

          Partner                Partner                       Partner
Port      System ID             Port Number     Age         Flags
Eth1/1    32768,286f.7fec.5980  0x10e           13 s        FA


          LACP Partner           Partner           Partner
          Port Priority        Oper Key        Port State
          32768                0x16            0x3f

          Port State Flags Decode:
          Activity:   Timeout:   Aggregation:   Synchronization:
          Active      Long       Yes            Yes

          Collecting:   Distributing:   Defaulted:   Expired:
          Yes           Yes             No           No

          Partner                Partner                       Partner
Port      System ID             Port Number     Age         Flags
Eth1/2    32768,286f.7fec.5980  0x10f           5  s        FA

          LACP Partner           Partner           Partner
          Port Priority        Oper Key        Port State
          32768                0x16            0x3f

          Port State Flags Decode:
          Activity:   Timeout:   Aggregation:   Synchronization:
          Active      Long       Yes            Yes

          Collecting:   Distributing:   Defaulted:   Expired:
```

```
          Yes           Yes             No           No


FP2100(local-mgmt)# show lacp counters

              LACPDUs         Marker      Marker Response    LACPDUs
Port       Sent   Recv     Sent   Recv    Sent    Recv      Pkts Err
--------------------------------------------------------------------------
Channel group: 11
Eth1/1     4435   3532     0      0        0      0         0
Eth1/2     4566   3532     0      0        0      0         0
```

**show portchannel**

Displays detailed information about EtherChannels.
For example:

```
FPR2100(local-mgmt)# show portchannel summary
Flags:  D - Down        P - Up in port-channel (members)
I - Individual  H - Hot-standby (LACP only)
s - Suspended   r - Module-removed
S - Switched    R - Routed
U - Up (port-channel)
M - Not in use. Min-links not met
--------------------------------------------------------------------------------
Group Port-       Type     Protocol  Member Ports
      Channel
--------------------------------------------------------------------------------
11    Po11(U)     Eth      LACP      Eth1/1(P)    Eth1/2(P)
```

**show portmanager**

Displays detailed information about physical interfaces.
For example:

```
FPR2100(local-mgmt)# show portmanager counters ethernet 1 1
Good Octets Received                             : 105503260
Bad Octets Received                              : 0
MAC Transmit Error                               : 0
Good Packets Received                            : 1376050
Bad Packets Received                             : 0
BRDC Packets Received                            : 210
MC Packets Received                              : 1153664
Size 64                                          : 1334830
Size 65 to 127                                   : 0
Size 128 to 255                                  : 0
Size 256 to 511                                  : 41220
Size 512 to 1023                                 : 0
Size 1024 to Max                                 : 0
Good Octets Sent                                 : 0
Good Packets Sent                                : 0
Excessive Collision                              : 0
MC Packets Sent                                  : 0
BRDC Packets Sent                                : 0
Unrecognized MAC Received                        : 0
FC Sent                                          : 0
Good FC Received                                 : 0
Drop Events                                      : 0
Undersize Packets                                : 0
Fragments Packets                                : 0
Oversize Packets                                 : 0
Jabber Packets                                   : 0
```

```
MAC RX Error Packets Received                     : 0
Bad CRC                                           : 0
Collisions                                        : 0
Late Collision                                    : 0
bad FC Received                                   : 0
Good UC Packets Received                          : 222176
Good UC Packets Sent                              : 0
Multiple Packets Sent                             : 0
Deferred Packets Sent                             : 0
Size 1024 to 15180                                : 0
Size 1519 to Max                                  : 0
txqFilterDisc                                     : 0
linkChange                                        : 1
```

```
FPR2100(local-mgmt)# show portmanager port-info ethernet 1 1
port_info:
        if_index:    0x1081000
        type:        PORTMGR_IPC_MSG_PORT_TYPE_PHYSICAL
        mac_address: 2c:f8:9b:1e:8f:d6
        flowctl:     PORTMGR_IPC_MSG_FLOWCTL_NONE
        role:        PORTMGR_IPC_MSG_PORT_ROLE_NPU
        admin_state: PORTMGR_IPC_MSG_PORT_STATE_ENABLED
        oper_state:  PORTMGR_IPC_MSG_PORT_STATE_UP
        admin_speed: PORTMGR_IPC_MSG_SPEED_AUTO
        oper_speed:  PORTMGR_IPC_MSG_SPEED_1GB
        admin_mtu:   9216
        admin_duplex: PORTMGR_IPC_MSG_PORT_DUPLEX_AUTO
        oper_duplex: PORTMGR_IPC_MSG_PORT_DUPLEX_FULL
        pc_if_index: 0x0
        pc_membership_status: PORTMGR_IPC_MSG_MMBR_NOT_MEMBER
        pc_protocol: PORTMGR_IPC_MSG_PORT_CHANNEL_PRTCL_NONE
        native_vlan: 101
        num_allowed_vlan: 1
                allowed_vlan[0]: 101
        PHY Data:
        PAGE IFC OFFSET VALUE  | PAGE IFC OFFSET VALUE
        ---- --- ------ -----  | ---- --- ------ -----
         0    0  0x0000 0x1140 |  0    0  0x0001 0x796d
         0    0  0x0002 0x0141 |  0    0  0x0003 0x0ee1
         0    0  0x0004 0x03e3 |  0    0  0x0005 0xc1e1
         0    0  0x0006 0x000f |  0    0  0x0007 0x2001
         0    0  0x0008 0x4f08 |  0    0  0x0009 0x0f00
         0    0  0x000a 0x3800 |  0    0  0x000f 0x3000
         0    0  0x0010 0x3070 |  0    0  0x0011 0xac08
         0    0  0x0012 0x0000 |  0    0  0x0013 0x1c40
         0    0  0x0014 0x8020 |  0    0  0x0015 0x0000
        18    0  0x001b 0x0000 |
```

| Item | Description |
|---|---|
| Good Octets Received | Number of ethernet frames received that are not bad ethernet frames |
| Bad Octets Received | Sum of lengths (in bytes) of all bad ethernet frames received. |
| MAC Transmit Error | Number of frames not transmitted correctly or dropped due to internal MAC Tx error |

| Item | Description |
|---|---|
| Good Packets Received | The number of frames received that are not bad ethernet frames. |
| Bad Packets Received | The number of bad frames received |
| BRDC Packets Received | The number of good frames received that have a Broadcast destination MAC address |
| MC Packets Received | The number of good frames received that have a Multicast destination MAC address |
| Good Octets Sent | The sum of lengths of all Ethernet frames sent |
| Good Packets Sent | The number of good frames sent |
| Excessive Collision | The number of collision events seen by the MAC not including those counted in Single, Multiple, Excessive, or Late. This counter is applicable in half-duplex only |
| MC Packets Sent | The number of good frames send that have a Multicast destination MAC address |
| BRDC Packets Sent | The number of good frames send that have a Broadcast destination MAC address |
| Unrecognized MAC Received | Number of received MAC Control frames that are not Flow control frames. |
| FC sent | Number of Flow Control frames sent. |
| Good FC Received | Number of good IEEE 802.3x Flow Control packets received. |
| Drop Events | Number of packets dropped |
| Undersize Packets | Number of undersize packets received |
| Fragments Packets | Number of fragments received. |
| Oversize Packets | Number of oversize packets received |
| Jabber Packets | Number of jabber packets received |
| MAC RX Error Packets Received | Number of Rx Error events seen by the receive side of the MAC |
| Bad CRC | Number of packets received with bad CRC |
| Collisions | Number of late collisions seen by the MAC |
| Late collison | Total number of late collisions seen by the MAC |

| Item | Description |
|---|---|
| Bad FC Received | Number of bad IEEE 802.3x Flow Control packets received |
| Good UC Packets Received | Number of Ethernet Unicast frames received |
| Good UC Packets Sent | Number of Ethernet Unicast frames sent |
| Multiple Packets Sent | Valid Frame transmitted on half-duplex link that encountered more then one collision. Byte count and cast are valid. |
| Deferred Packets Sent | Valid frame transmitted on half-duplex link with no collisions, but where the frame transmission was delayed due to media being busy. Byte count and cast are valid. |
| Size 1024 to 15180 | The number of received and transmitted, good and bad frames that are 1024 to 1518 bytes in size |
| Size 1519 to Max | The number of received and transmitted, good and bad frames that are more than 1519 bytes in size |
| txqFilterDisc | Number of IN packets that were filtered due to TxQ |
| linkChange | number of link up or link down changes for the port |

```
FPR2100(local-mgmt)# show portmanager switch mac-filters
port ix          MAC               mask        action      packets       bytes

00   0ba  2C:F8:9B:1E:8F:D7  FF:FF:FF:FF:FF:FF  FORWARD
     0c9  01:80:C2:00:00:02  FF:FF:FF:FF:FF:FF  FORWARD
     0cc  2C:F8:9B:1E:8F:F7  FF:FF:FF:FF:FF:FF  FORWARD
     0cf  FF:FF:FF:FF:FF:FF  FF:FF:FF:FF:FF:FF  FORWARD
     b70  00:00:00:00:00:00  01:00:00:00:00:00  DROP         222201    14220864
     bb8  01:00:00:00:00:00  01:00:00:00:00:00  DROP        1153821    91334968

01   0bd  2C:F8:9B:1E:8F:D6  FF:FF:FF:FF:FF:FF  FORWARD
     0c0  01:80:C2:00:00:02  FF:FF:FF:FF:FF:FF  FORWARD
     0c3  2C:F8:9B:1E:8F:F6  FF:FF:FF:FF:FF:FF  FORWARD
     0c6  FF:FF:FF:FF:FF:FF  FF:FF:FF:FF:FF:FF  FORWARD         210       13440
     b73  00:00:00:00:00:00  01:00:00:00:00:00  DROP         222201    14220864
     bbb  01:00:00:00:00:00  01:00:00:00:00:00  DROP        1153795    91281055
<...>


FPR2100(local-mgmt)# show portmanager switch status
Dev/Port         Mode        Link   Speed  Duplex  Loopback Mode
---------  ----------------  -----  -----  ------  -------------

0/0             QSGMII         Up     1G     Full    None
0/1             QSGMII         Up     1G     Full    None
0/2             QSGMII       Down     1G     Half    None
0/3             QSGMII       Down     1G     Half    None
0/4             QSGMII       Down     1G     Half    None
0/5             QSGMII       Down     1G     Half    None
```

```
0/6             QSGMII        Up     1G     Full    None
0/7             QSGMII       Down    1G     Half    None
0/48            QSGMII       Down    1G     Half    None
0/49            QSGMII       Down    1G     Half    None
0/50            QSGMII       Down    1G     Half    None
0/51            QSGMII       Down    1G     Half    None
0/52              KR          Up     40G    Full    None
0/56            SR_LR        Down    10G    Full    None
0/57            SR_LR        Down    10G    Full    None
0/58            SR_LR        Down    10G    Full    None
0/59            SR_LR        Down    10G    Full    None
0/64            SR_LR        Down    10G    Full    None
0/65            SR_LR        Down    10G    Full    None
0/66            SR_LR        Down    10G    Full    None
0/67            SR_LR        Down    10G    Full    None
0/68            SR_LR        Down    10G    Full    None
0/69            SR_LR        Down    10G    Full    None
0/70            SR_LR        Down    10G    Full    None
0/71            SR_LR        Down    10G    Full    None
0/80              KR          Up     10G    Full    None
0/81              KR         Down    10G    Full    None
0/83              KR          Up     10G    Full    None
```

# Connect Local-Mgmt Troubleshooting Commands for the Secure Firewall 3100

In addition to the existing debugging commands, CLIs specific to Secure Firewall 3100 are explained in this section below.

Use the following connect local-mgmt mode FXOS CLI commands to troubleshoot issues with your Secure Firewall 3100. To access connect local-mgmt mode, enter:

FPR3100# **connect local-mgmt**

**show portmanager**

Displays detailed information about switched, packets, SFP-FEC counters, digital optical monitoring, QOS functionality, CPSS AP, and Cyclic log dumps.

For example:

The following CLI displays the FXOS port manager switch hardware TCAM rules dump in vtcam-tti:

```
firepower-3140(local-mgmt)# show portmanager switch forward-rules hardware vtcam-tti
detail
 VTCAM_RULE_ID   VLAN   SRC_PORT  PORTCHANNEL_ID  FLAGS  MODE  REF_COUNT
1               21      0          2               0      2     5          3
2             3078      0          0               0      0     0          1
3             3077      0          0               0      0     0          1
4             3076      0          0               0      0     0          1
5             3075      0          0               0      0     0          1
6             3074      0          0               0      0     0          1
7             3073      0          0               0      0     0          1
8                1      0          0               0      0     0          1
9               18    102          0               0     24     8          1
10               5    157          0               0     24     8          1
11              31      0         12               0      2     5          3
12              15    105          0               0     24     8          1
13               9    111          0               0     24     8          1
14              13    107          0               0     24     8          1
```

```
15              26      0          7               0      2     5          3
16              29      0         10               0      2     5          3
17              23      0          4               0      2     5          3
18              19    101          0               0     24     8          1
19              30      0         11               0      2     5          3
20              28      0          9               0      2     5          3
21               4    156          0               0     24     8          1
22              34      0         15               0      2     5          3
23               6    158          0               0     24     8          1
24               8    112          0               0     24     8          1
25              24      0          5               0      2     5          3
26              14    106          0               0     24     8          1
27              32      0         13               0      2     5          3
28              25      0          6               0      2     5          3
29              12      0          0               9      6     5          2
30              20      0          1               0      2     5          3
31              11    109          0               0     24     8          1
32              27      0          8               0      2     5          3
33              17    103          0               0     24     8          1
34              22      0          3               0      2     5          3
35              16    104          0               0     24     8          1
36               3      0         19               0     26     8          1
37              35      0         16               0      2     5          3
38              33      0         14               0      2     5          3
39               7    159          0               0     24     8          1
40               2      0         17               0     26     8          1
41              10    110          0               0     24     8          1
```

The following CLI displays the FXOS port manager switch VLANs output:

```
firepower-3140(local-mgmt)# show portmanager switch vlans
VLAN                          Ports                              Tag      MAC-Learning
  FDB-mode
-----  ------------------------------------------------------  --------  --------------
 ---------
1                            0/17,19                          pop_outer_tag    Control
      FID
2                            0/1-16,18               outer_tag0_inner_tag1   Control
      FID
                               0/20                      pop_outer_tag

3                            0/1-16,18               outer_tag0_inner_tag1   Control
      FID
4                            0/1-16,18               outer_tag0_inner_tag1   Control
      FID
5                            0/1-16,18               outer_tag0_inner_tag1   Control
      FID
6                            0/1-16,18               outer_tag0_inner_tag1   Control
      FID
7                            0/1-16,18               outer_tag0_inner_tag1   Control
      FID
8                            0/1-16,18               outer_tag0_inner_tag1   Control
      FID
```

The following CLI helps you to to check port-channel interface summary:

```
firepower-3140(local-mgmt)# show por
portchannel  portmanager

firepower-3140(local-mgmt)# show portchannel summary
Flags:  D - Down        P - Up in port-channel (members)
I - Individual  H - Hot-standby (LACP only)
```

```
s - Suspended   r - Module-removed
S - Switched    R - Routed
U - Up (port-channel)
M - Not in use. Min-links not met
--------------------------------------------------------------------------------
Group Port-       Type     Protocol  Member Ports
      Channel
--------------------------------------------------------------------------------
3     Po3(U)      Eth      LACP      Eth1/3(P)
2     Po2(U)      Eth      LACP      Eth1/2(P)

LACP KeepAlive Timer:
--------------------------------------------------------------------------------
      Channel  PeerKeepAliveTimerFast
--------------------------------------------------------------------------------
3     Po3(U)      False
2     Po2(U)      False

Cluster LACP Status:
--------------------------------------------------------------------------------
      Channel  ClusterSpanned  ClusterDetach  ClusterUnitID  ClusterSysID
--------------------------------------------------------------------------------
3     Po3(U)      False          False          0
2     Po2(U)      False          False          0
</pre>
```

The following CLI displays the port-channel load-balancing method:

```
firepower-3140(local-mgmt)# show portchannel load-balance
PortChannel Load-Balancing Configuration:
   src-dst ip-l4port
PortChannel Load-Balancing Configuration Used Per-Protocol:
Non-IP: src-dst mac
   IP: src-dst ip-l4port
</pre>
```

The following CLI displays the status of FXOS system processes:

```
firepower-3140(local-mgmt)# show pmon state

SERVICE NAME             STATE     RETRY(MAX)    EXITCODE    SIGNAL    CORE
------------             -----     ----------    --------    ------    ----
svc_sam_dme            running           0(4)           0         0      no
svc_sam_dcosAG         running           0(4)           0         0      no
svc_sam_portAG         running           0(4)           0         0      no
svc_sam_statsAG        running           0(4)           0         0      no
httpd.sh               running           0(4)           0         0      no
svc_sam_sessionmgrAG   running           0(4)           0         0      no
sam_core_mon           running           0(4)           0         0      no
svc_sam_svcmonAG       running           0(4)           0         0      no
svc_sam_serviceOrchAG   running           0(4)           0         0      no
svc_sam_appAG          running           0(4)           0         0      no
svc_sam_envAG          running           0(4)           0         0      no
svc_sam_npuAG          running           0(4)           0         0      no
svc_sam_eventAG        running           0(4)           0         0      no
```

The following CLI displays switch hardware TCAM rules dump in vtcam-tti stage matching ethernet 1/1 port:

```
firepower-3140(local-mgmt)# show portmanager switch forward-rules hardware vtcam-tti
ethernet 1 1
RULE_ID   VLAN   SRC_PORT   PC_ID   SRC_ID   MODE   PAK_CNT
 1          20     0   1       0     101      0       151
```

The following CLI displays switch hardware TCAM rules dump in vtcam-tti stage matching vlan 0:

```
firepower-3140(local-mgmt)# show portmanager switch forward-rules hardware vtcam-tti
vlan 0
          RULE_ID   VLAN   SRC_PORT   PC_ID   SRC_ID   MODE   PAK_CNT
1           2       0        17       0       17       0       1709
2           3       0        19       0       19       0       1626
3           4       0        16       0        0       0          0
4           5       0        15       0        0       0          0
5           6       0        14       0        0       0          0
6           7       0        13       0        0       0          0
7           8       0        12       0        0       0          0
8           9       0        11       0        0       0          0
9          10       0        10       0        0       0          0
10         11       0         9       0        0       0          0
11         12       0         8       0        0       0          0
12         13       0         7       0        0       0          0
13         14       0         6       0        0       0          0
14         15       0         5       0        0       0          0
15         16       0         4       0        0       0          0
16         17       0         3       0        0       0          0
17         18       0         2       0        0       0          0
18         19       0         1       0        0       0          0
19         20       0         1       0      101       0        166
20         21       0         2       0      102       0       1597
21         22       0         3       0      103       0          0
22         23       0         4       0      104       0          0
23         24       0         5       0      105       0          0
24         25       0         6       0      106       0          0
25         26       0         7       0      107       0          0
26         27       0         8       0      108       0          0
27         28       0         9       0      109       0          0
28         29       0        10       0      110       0          0
29         30       0        11       0      111       0          0
30         31       0        12       0      112       0          0
31         32       0        13       0      159       0          0
32         33       0        14       0      158       0          0
33         34       0        15       0      157       0          0
34         35       0        16       0      156       0          0
35          1       0        17       0        0       0          0
```

The following CLI displays detailed information about hardware MAC-filter / EM stage rules:

```
firepower-3140(local-mgmt)# show portmanager switch forward-rules hardware mac-filter
detail
EM Entry-No  :     1


      VLAN            :    0
      SRC_PORT        :   17
      PC_ID           :    0
      SRC_ID          :   17
      DST_PORT        :   19
      HW_ID           :   3072
      ACT_CMD         :    0
      PCL_ID          :    1
      REDIRECT_CMD    :    1
      BYPASS_BRG      :    1
      CND_INDEX       : 3074
      PACKET_COUNT    :       1977
      DMAC            : 00:00:00:00:00:00


EM Entry-No  :     2
```

```
VLAN            :    0
SRC_PORT        :   19
PC_ID           :    0
SRC_ID          :   19
DST_PORT        :   17
HW_ID           :   3074
ACT_CMD         :    0
PCL_ID          :    1
REDIRECT_CMD    :    1
BYPASS_BRG      :    1
CND_INDEX       : 3075
PACKET_COUNT    :       1858
DMAC            : 00:00:00:00:00:00
```

The following CLI displays switch hardware TCAM rules dump in mac-filter stage matching ethernet 1/9 port:

```
firepower-3140(local-mgmt)# show portmanager switch forward-rules hardware mac-filter
ethernet 1 9
VLAN   SRC_PORT   PC_ID   SRC_ID   DST_PORT     PKT_CNT      DMAC
1        0          9       0      109      1536            0  1:80:c2:0:0:2
```

The following CLI displays detailed information about software MAC-filter:

```
firepower-3140(local-mgmt)# show portmanager switch forward-rules software mac-filter
detail
 VLAN   SRC_PORT   PORTCHANNEL_ID   DST_PORT   FLAGS   MODE      DMAC
1         0         17                0         19      26      8   0:0:0:0:0:0
2         0          9                0       1536       2      5   1:80:c2:0:0:2
3       104          0                0          4      24      8   0:0:0:0:0:0
4         0          7                0       1536       2      5   1:80:c2:0:0:2
5       101          0                0          1      24      8   0:0:0:0:0:0
6         0          1                0       1536       2      5   1:80:c2:0:0:2
7         0          3                0       1536       2      5   1:80:c2:0:0:2
8       106          0                0          6      24      8   0:0:0:0:0:0
9       158          0                0         14      24      8   0:0:0:0:0:0
10        0         13                0       1536       2      5   1:80:c2:0:0:2
11        0         14                0       1536       2      5   1:80:c2:0:0:2
12        0          6                0       1536       2      5   1:80:c2:0:0:2
13        0          8                0       1536       2      5   1:80:c2:0:0:2
14      112          0                0         12      24      8   0:0:0:0:0:0
15      107          0                0          7      24      8   0:0:0:0:0:0
16        0         19                0         17      26      8   0:0:0:0:0:0
17        0         12                0       1536       2      5   1:80:c2:0:0:2
18        0          5                0       1536       2      5   1:80:c2:0:0:2
19      102          0                0          2      24      8   0:0:0:0:0:0
20      156          0                0         16      24      8   0:0:0:0:0:0
21      103          0                0          3      24      8   0:0:0:0:0:0
22        0         11                0       1536       2      5   1:80:c2:0:0:2
23      157          0                0         15      24      8   0:0:0:0:0:0
24      111          0                0         11      24      8   0:0:0:0:0:0
25        0         10                0       1536       2      5   1:80:c2:0:0:2
26      108          0                0          8      24      8   0:0:0:0:0:0
27      159          0                0         13      24      8   0:0:0:0:0:0
28      110          0                0         10      24      8   0:0:0:0:0:0
29      105          0                0          5      24      8   0:0:0:0:0:0
30        0          2                0       1536       2      5   1:80:c2:0:0:2
31        0          4                0       1536       2      5   1:80:c2:0:0:2
32        0         16                0       1536       2      5   1:80:c2:0:0:2
33      109          0                0          9      24      8   0:0:0:0:0:0
34        0         15                0       1536       2      5   1:80:c2:0:0:2
```

The following CLI displays switch software DB rules in mac-filter stage matching ethernet1/9 port:

```
firepower-3140(local-mgmt)# show portmanager switch forward-rules software mac-filter
ethernet 1 9
VLAN   SRC_PORT   PORTCHANNEL_ID   DST_PORT   FLAGS   MODE      DMAC
1         0          9                0       1536       2      5   1:80:c2:0:0:2
```

The following CLI displays detailed information about switch bridge engine packet drops:

```
firepower-3140(local-mgmt)# show portmanager switch counters bridge
Bridge Ingress Drop Counter: 2148
No Bridge Ingress Drop
```

The following CLI displays details on hardware switch packet counters:

```
firepower-3140(local-mgmt)# show portmanager switch counters packet-trace

       Counter                              Description
---------------------- ------------------------------------------------------------
goodOctetsRcv          Number of ethernet frames received that are not bad
                       ethernet frames or MAC Control pkts
badOctetsRcv           Sum of lengths of all bad ethernet frames received
gtBrgInFrames          Number of packets received
gtBrgVlanIngFilterDisc Number of packets discarded due to VLAN Ingress Filtering
gtBrgSecFilterDisc     Number of packets discarded due to
                       Security Filtering measures
gtBrgLocalPropDisc     Number of packets discarded due to reasons other than
                       VLAN ingress and Security filtering
dropCounter            Ingress Drop Counter
outUcFrames            Number of unicast packets transmitted
outMcFrames            Number of multicast packets transmitted. This includes
                       registered multicasts, unregistered multicasts
                       and unknown unicast packets
outBcFrames            Number of broadcast packets transmitted
brgEgrFilterDisc       Number of IN packets that were Bridge Egress filtered
txqFilterDisc          Number of IN packets that were filtered
                       due to TxQ congestion
outCtrlFrames          Number of out control packets
                       (to cpu, from cpu and to  analyzer)
egrFrwDropFrames       Number of packets dropped due to egress
                       forwarding restrictions
goodOctetsSent         Sum of lengths of all good ethernet
                       frames sent from this MAC
        Counter            Source port- 0/0    Destination port- 0/0
----------------------  ---------------------  ---------------------
goodOctetsRcv                    ---                    ---
badOctetsRcv                      ---                    ---
                                       Ingress counters
gtBrgInFrames                   6650                   6650
gtBrgVlanIngFilterDisc            0                      0
gtBrgSecFilterDisc                0                      0
gtBrgLocalPropDisc                0                      0
dropCounter                    2163           Only for source-port
                                       Egress counters
outUcFrames                       0                      0
outMcFrames                    2524                   2524
outBcFrames                    1949                   1949
brgEgrFilterDisc                 14                     14
txqFilterDisc                     0                      0
outCtrlFrames                     0                      0
egrFrwDropFrames                  0                      0
goodOctetsSent                    ---                    ---          #
```

The following CLI displays detailed informatin about the switch traffic for CPU:

```
firepower-3140(local-mgmt)# show portmanager switch traffic cpu

Dev/RX queue  packets    bytes
------------  ---------- ----------

0/0           0          0
0/1           0          0
0/2           0          0
0/3           0          0
0/4           0          0
0/5           0          0
0/6           0          0
0/7           0          0          #
```

The following CLI displays details on hardware switch port traffic:

```
firepower-3140(local-mgmt)# show portmanager switch traffic port


max-rate - pps that the port allow with packet size=64
actual-tx-rate - pps that egress the port (+ % from 'max')
actual-rx-rate - pps that ingress the port(+ % from 'max')

Dev/Port   max-rate  actual-tx-rate    actual-rx-rate
---------  --------  ----------------  ----------------
0/1         1488095    (0%)---           (0%)---
0/2         1488095    (0%)---           (0%)---
0/3         14880      (0%)---           (0%)---
0/4         14880      (0%)---           (0%)---
0/5         14880      (0%)---           (0%)---
0/6         14880      (0%)---           (0%)---
0/7         14880      (0%)---           (0%)---
0/8         14880      (0%)---           (0%)---
0/9         14880952   (0%)---           (0%)---
0/10        14880952   (0%)---           (0%)---
0/11        14880952   (0%)---           (0%)---
0/12        14880952   (0%)---           (0%)---
0/13        14880952   (0%)---           (0%)---
0/14        14880952   (0%)---           (0%)---
0/15        1488095    (0%)---           (0%)---
0/16        1488095    (0%)---           (0%)---
0/17        14880952   (0%)---           (0%)---
0/18        74404761   (0%)---           (0%)---
0/19        37202380   (0%)---           (0%)---
0/20        37202380   (0%)---           (0%)---
```

The following CLI displays detailed information about SFP-FEC Counters matching ethernet 1/13 port:

```
firepower-3140(local-mgmt)# show portmanager counters ethernet 1 13
   Good Octets Received                              : 2153
   Bad Octets Received                               : 0
   MAC Transmit Error                                : 0
   Good Packets Received                             : 13
   Bad packets Received                              : 0
   BRDC Packets Received                             : 0
   MC Packets Received                               : 13
   .........
   .........
   txqFilterDisc                                     : 0
```

```
   linkchange                                        : 1
   FcFecRxBlocks                                     : 217038081
   FcFecRxBlocksNoError                              : 217038114
   FcFecRxBlocksCorrectedError                       : 0
   FcFecRxBlocksUnCorrectedError                     : 0
   FcFecRxBlocksCorrectedErrorBits                   : 0
   FcFecRxBlocksCorrectedError0                      : 0
   FcFecRxBlocksCorrectedError1                      : 0
   FcFecRxBlocksCorrectedError2                      : 0
   FcFecRxBlocksCorrectedError3                      : 0
   FcFecRxBlocksUnCorrectedError0                    : 0
   FcFecRxBlocksUnCorrectedError1                    : 0
   FcFecRxBlocksUnCorrectedError2                    : 0
   FcFecRxBlocksUnCorrectedError3                    : 0
```

The following CLI displays detailed information about SFP-FEC Counters matching ethernet 1/14 port:

```
firepower-3140(local-mgmt)# show portmanager counters ethernet 1 14
   Good Octets Received                              : 2153
   Bad Octets Received                               : 0
   MAC Transmit Error                                : 0
   Good Packets Received                             : 13
   Bad packets Received                              : 0
   BRDC Packets Received                             : 0
   MC Packets Received                               : 13
   .....
   .....
   txqFilterDisc                                     : 0
   linkchange                                        : 1
   RsFeccorrectedFecCodeword                         : 0
   RsFecuncorrectedFecCodeword                       : 10
   RsFecsymbolError0                                 : 5
   RsFecsymbolError1                                 : 0
   RsFecsymbolError2                                 : 0
   RsFecsymbolError3                                 : 0
```

The following CLI displays detailed information on the Digital Optical Monitoring information matching ethernet 1/5 port:

```
firepower-4245(local-mgmt)# show portmanager port-info ethernet 1 5
        ....
        ....
                DOM info:
                ========:

                Status/Control Register: 0800
                      RX_LOS State: 0
                      TX_FAULT State: 0
                Alarm Status: 0000
                No active alarms
                Warning Status: 0000
                No active warnings

      THRESHOLDS
                                high alarm    high warning    low warning     low alarm

        Temperature     C     +075.000        +070.000        +000.000         -05.000

        Voltage         V     003.6300        003.4650        003.1350        002.9700

        Bias Current    mA    012.0000        011.5000        002.0000        001.0000
```

```
Transmit power mW    034.6740        017.3780        002.5120        001.0000

Receive power  mW    034.6740        017.3780        001.3490        000.5370


       Environmental Information - raw values
       Temperature: 38.84 C
       Supply voltage: 33703 in units of 100uVolt
       Tx bias: 3499 in units of 2uAmp
       Tx power:  0.1 dBm (10251 in units of 0.1 uW)
       Rx power: -0.9 dBm (8153 in units of 0.1 uW)
       DOM (256 bytes of raw data in hex)
          =====================================
          0x0000 : 4b 00 fb 00 46 00 00 00 8d cc 74 04 87 5a 7a 76
          0x0010 : 17 70 01 f4 16 76 03 e8 87 72 03 e8 43 e2 09 d0
          0x0020 : 87 72 02 19 43 e2 05 45 00 00 00 00 00 00 00 00
          0x0030 : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
          0x0040 : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
          0x0050 : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 86
          0x0060 : 26 54 83 a7 0d ab 28 0b 1f d9 00 00 00 00 08 00
          0x0070 : 00 00 03 00 00 00 00 00 08 f3 00 00 00 00 00 01
          0x0080 : 49 4e 55 49 41 43 53 45 41 41 31 30 2d 33 33 38
          0x0090 : 38 2d 30 31 56 30 31 20 01 00 46 00 00 00 00 e3
          0x00a0 : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
          0x00b0 : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
          0x00c0 : 53 46 50 2d 31 30 2f 32 35 47 2d 43 53 52 2d 53
          0x00d0 : 20 20 20 20 30 38 00 00 00 00 00 00 00 00 00 d1
          0x00e0 : 1e 20 2a 2a 31 34 29 36 00 00 00 00 00 00 00 00
          0x00f0 : 00 00 00 00 00 56 00 00 ff ff ff ff 00 00 00 cf
          =====================================
        PHY Data:
        PAGE IFC OFFSET VALUE  | PAGE IFC OFFSET VALUE
        ---- --- ------ -----  | ---- --- ------ -----
```

The following CLI displays detailed information about the parameters set for the packet capture:

```
firepower-3140(local-mgmt)# show portmanager switch pktcap-rules software
Software DB rule:1
 Slot= 1
 Interface= 12
 Breakout-port= 0
 Protocol= 6
 Ethertype= 0x0000
 Filter_key= 0x00000040
 Session= 1
 Vlan= 0
 SrcPort= 0
 DstPort= 0
 SrcIp= 0.0.0.0
 DstIp= 0.0.0.0
 SrcIpv6= ::
 DestIpv6= ::
 SrcMacAddr= 00:00:00:00:00:00
 DestMacAddr= 00:00:00:00:00:00
```

The following CLI displays detailed information on the FXOS port manager switch hardware TCAM rules:

```
firepower-3140(local-mgmt)# show portmanager switch pktcap-rules hardware
Hardware DB rule:1
 Hw_index= 15372
 Rule_id= 10241
```

```
Cnc_index= 1
Packet_count= 0
Slot= 1
Interface= 12
Protocol= 6
Ethertype= 0x0000
Vlan= 0
SrcPort= 0
DstPort= 0
SrcIp= 0.0.0.0
DstIp= 0.0.0.0
SrcIpv6= ::
DestIpv6= ::
SrcMacAddr= 00:00:00:00:00:00
DestMacAddr= 00:00:00:00:00:00
```

The following displays detailed information about the QOS functionality:

```
firepower(local-mgmt)# show portmanager switch qos-rule policer counters
Policer_type   green(pass_count)    yellow(pass_count)     red(drop_count)
------------------------------------------------------------------------
OSPF                 102025351                17832                590
780
Policer_type   green(pass_count)    yellow(pass_count)     red(drop_count)
------------------------------------------------------------------------
CCL_CLU                   0                0                  0
Policer_type   green(pass_count)    yellow(pass_count)     red(drop_count)
------------------------------------------------------------------------
BFD                  61343307                0                 0
Policer_type   green(pass_count)    yellow(pass_count)     red(drop_count)
------------------------------------------------------------------------
HA                  0                 0                  0
Policer_type   green(pass_count)    yellow(pass_count)     red(drop_count)
------------------------------------------------------------------------
CCL_CONTROL                   0                0                 0
```

The following CLI verifies if the high priority traffic is hitting the TCAM:

```
firepower(local-mgmt)# show portmanager switch qos-rule counters
Rule_no   Rule_id    Rule_type     pass_count
---------------------------------------------
  1        9218     SW_QOS_BFD           0
Rule_no   Rule_id    Rule_type     pass_count
---------------------------------------------
  2        9216     SW_QOS_OSPF      102633941
Rule_no   Rule_id    Rule_type     pass_count
---------------------------------------------
  3        9217     SW_QOS_BFD      61343307
```

The following CLI displays the CPU statistics as per queue per device matching ethernet 1/10 port:

```
firepower(local-mgmt)# show queuing interface ethernet 1 10
Queue     Traffic-type    Scheduler-type  oper-bandwidth    Destination
------------------------------------------------------------------------
  3            Data           WRR             100           Application
  4         CCL-CLU            SP               0           Application
  5             BFD            SP               0           Application
  6            OSPF            SP               0           Application
  7  CCL-CONTROL/HA/LACP_Tx    SP               0           Application
  0  packet-capture           N/A              0                   CPU
  7            LACP_Rx        N/A              0                   CPU
```

```
Port 1/10 Queue Statistics:
Queue 0:
  Number of packets passed :                    0
  Number of packets dropped:                    0
Queue 1:
 Number of packets passed :                     0
 Number of packets dropped:                     0
Queue 2:
  Number of packets passed :                    0
  Number of packets dropped:                    0
Queue 3:
  Number of packets passed :            466420167
  Number of packets dropped:                    0
Queue 4:
  Number of packets passed :                    0
  Number of packets dropped:                    0
Queue 5:
  Number of packets passed :                    0
  Number of packets dropped:                    0
Queue 6:
  Number of packets passed :             41536261
  Number of packets dropped:                    0
Queue 7:
  Number of packets passed :                  912
  Number of packets dropped:                    0
CPU Statistics:
Queue 2:
  Number of packets passed :                180223
  Number of packets dropped:                     0
Queue 7:
  Number of packets passed :                 1572
  Number of packets dropped:                     0
```

The following CLI displays the CPU statistics as per queue per device matching internal 1/1 port:

```
firepower(local-mgmt)# show queuing interface internal 1 1
Queue     Traffic-type    Scheduler-type  oper-bandwidth    Destination
------------------------------------------------------------------------
  3            Data           WRR             100           Application
  4         CCL-CLU            SP               0           Application
  5             BFD            SP               0           Application
  6            OSPF            SP               0           Application
  7  CCL-CONTROL/HA/LACP_Tx    SP               0           Application
  0  packet-capture           N/A              0                   CPU
  7           LACP_Rx         N/A              0                   CPU
Port 1/18 Queue Statistics:
Queue 0:
  Number of packets passed :                    0
  Number of packets dropped:                    0
Queue 1:
 Number of packets passed :                     0
 Number of packets dropped:                     0
Queue 2:
  Number of packets passed :                    0
  Number of packets dropped:                    0
Queue 3:
  Number of packets passed :                   17
  Number of packets dropped:                    0
Queue 4:
  Number of packets passed :                    0
  Number of packets dropped:                    0
Queue 5:
```

```
  Number of packets passed :                    0
  Number of packets dropped:                    0
Queue 6:
  Number of packets passed :                 5151
  Number of packets dropped:                    0
Queue 7:
  Number of packets passed :                17345
  Number of packets dropped:                    0
CPU Statistics:
Queue 2:
  Number of packets passed :               180223
  Number of packets dropped:                    0
Queue 7:
  Number of packets passed :                 1572
  Number of packets dropped:                    0
Note:The CPU statistics are per Queue per Device
```

The following CLI displays detailed information about dump AP log option :

```
firepower-3110(local-mgmt)# dump portmanager switch ap-log
requested log has been dumped to /opt/cisco/platform/logs/portmgr.out*

firepower-3110(local-mgmt)# dump portmanager switch cyclic-log
requested log has been dumped to /opt/cisco/platform/logs/portmgr.out*
```

The following CLI displays detailed information on enabling or disabling verbose logging for port manager:

```
firepower-3110(local-mgmt)# debug portmanager switch
all  Enable or Disable verbose logging for switch

firepower-3110(local-mgmt)# debug portmanager switch all
firepower-3110(local-mgmt)#

firepower-3110(local-mgmt)# no debug portmanager switch all
firepower-3110(local-mgmt)#
```

The following CLI displays detailed information on port-based packet drops for eight traffic classes/queues:

```
firepower-3110(local-mgmt)# show portmanager switch tail-drop-allocated buffers all
-----------------------------------------------------------------------------------------------

     |          |                          Per Port and Traffic Class
          |
Port | Per port | TC0     | TC1     | TC2     | TC3     | TC4     | TC5     | TC6
| TC7     |
-----|----------|---------|---------|---------|---------|---------|---------|---------|---------|
0/1  |10        |10       |0        |0        |0        |0        |0        |0
|0        |
0/2  |15        |5        |5        |5        |0        |0        |0        |0
|0        |
0/3  |0         |0        |0        |0        |0        |0        |0        |0
|0        |
0/4  |80        |0        |0        |0        |0        |0        |0        |0
|80       |
0/5  |0         |0        |0        |0        |0        |0        |0        |0
|0        |
0/6  |0         |0        |0        |0        |0        |0        |0        |0
|0        |
```

```
0/7  |200        |25        |25        |50        |0         |0         |25        |50
|25        |
0/8  |0          |0         |0         |0         |0         |0         |0         |0
|0         |
-------------------------------------------------------------------------------------------
```

The following CLI displays dropped packet counts due to tti-lookup0:

```
firepower-3110(local-mgmt)# show portmanager switch default-rule-drop-counter tti-lookup0

Rule_id    cnc_index     packet_count
-------------------------------------
  1           1                4
```

The following CLI displays dropped packet counts due to ipcl-lookup0:

```
firepower-3110(local-mgmt)# show portmanager switch default-rule-drop-counter ipcl-lookup0

Rule_id    cnc_index     packet_count
-------------------------------------
4096          0              114
```

# Connect Local-Mgmt Troubleshooting Commands for the Secure Firewall 4200 in Appliance Mode

In addition to the existing debugging commands, CLIs specific to Secure Firewall 3100 are explained in this section below.

Use the following connect local-mgmt mode FXOS CLI commands to troubleshoot issues with your Secure Firewall 3100 in Appliance mode. To access connect local-mgmt mode, enter:

FPR 4200# **connect local-mgmt**

**show portmanager**

Displays detailed information about switched, packets, SFP-FEC counters, digital optical monitoring, QOS functionality, CPSS AP, and Cyclic log dumps.
For example:
The following CLI displays the FXOS port manager switch hardware TCAM rules dump in vtcam-tti:

```
firepower(local-mgmt)# show portmanager switch forward-rules hardware vtcam-tti
      RULE_ID   VLAN   NUM_MPLS_LABELS  SRC_PORT   PC_ID   SRC_ID   MODE   PAK_CNT
1           2      0       0               10       0       10       0         1951
2           3      0       0               14       0       14       0           19
3           4      0       0                9       0        9       0       227505
4           5      0       0               13       0       13       0       103587
5           6      0       0                8       0        0       0            0
6           7      0       0                7       0        0       0            0
7           8      0       0                6       0        0       0            0
8           9      0       0                5       0        0       0            0
9          10      0       0                4       0        0       0            0
10         11      0       0                3       0        0       0            0
11         12      0       0                2       0        0       0            0
12         13      0       0                1       0        0       0          607
13         14      0       0               44       0        0       0            0
14         15      0       0               40       0        0       0            0
```

```
15          16       0        0                36        0         0       0             0
16          17       0        0                32        0         0       0             0
17          30       0        0                 1        0       101       1          2120
18          18       0        0                 1        0       101       0           306
19          19       0        0                 2        0       102       0          2429
20          20       0        0                 3        0       103       0             0
21          21       0        0                 4        0       104       0             0
22          22       0        0                 5        0       105       0             0
23          23       0        0                 6        0       106       0             0
24          24       0        0                 7        0       107       0             0
25          25       0        0                 8        0       108       0             0
26          26       0        0                32        0       117       0             0
27          27       0        0                36        0       121       0             0
28          28       0        0                40        0       125       0             0
29          29       0        0                44        0       129       0             0
30           1       0        0                 9        0         0       0          1875
31        8193       0        1                 0        0         0       0             0
32        8194       0        2                 0        0         0       0             0
33        8195       0        3                 0        0         0       0             0
34        8196       0        4                 0        0         0       0             0
35        8197       0        5                 0        0         0       0             0
36        8198       0        6                 0        0         0       0             0
```

The following CLI displays switch hardware TCAM rules dump in vtcam-tti stage matching vlan 0:

```
firepower(local-mgmt)# show portmanager switch forward-rules hardware vtcam-tti
      RULE_ID   VLAN   NUM_MPLS_LABELS  SRC_PORT   PC_ID   SRC_ID   MODE  PAK_CNT
1           2      0        0               10       0       10       0     1961
2           3      0        0               14       0       14       0     19
3           4      0        0                9       0        9       0     227517
4           5      0        0               13       0       13       0     103683
5           6      0        0                8       0        0       0          0
6           7      0        0                7       0        0       0          0
7           8      0        0                6       0        0       0          0
8           9      0        0                5       0        0       0          0
9          10      0        0                4       0        0       0          0
10         11      0        0                3       0        0       0          0
11         12      0        0                2       0        0       0          0
12         13      0        0                1       0        0       0        617
13         14      0        0               44       0        0       0          0
14         15      0        0               40       0        0       0          0
15         16      0        0               36       0        0       0          0
16         17      0        0               32       0        0       0          0
17         30      0        0                1       0      101       1       2156
18         18      0        0                1       0      101       0        306
19         19      0        0                2       0      102       0       2466
20         20      0        0                3       0      103       0          0
21         21      0        0                4       0      104       0          0
22         22      0        0                5       0      105       0          0
23         23      0        0                6       0      106       0          0
24         24      0        0                7       0      107       0          0
25         25      0        0                8       0      108       0          0
26         26      0        0               32       0      117       0          0
27         27      0        0               36       0      121       0          0
28         28      0        0               40       0      125       0          0
29         29      0        0               44       0      129       0          0
30          1      0        0                9       0        0       0       1875
31       8193      0        1                0       0        0       0          0
32       8194      0        2                0       0        0       0          0
33       8195      0        3                0       0        0       0          0
34       8196      0        4                0       0        0       0          0
35       8197      0        5                0       0        0       0          0
36       8198      0        6                0       0        0       0          0
```

The following CLI displays switch hardware TCAM rules dump in mac-filter stage matching ethernet 1/9 port:

```
firepower(local-mgmt)# show portmanager switch forward-rules hardware mac-filter
      VLAN    SRC_PORT    PC_ID    SRC_ID    DST_PORT      PKT_CNT      DMAC
1        0          44        0       129        1536            0  1:80:c2:0:0:2
2        0          44        0       129        1536            0  ff:ff:ff:ff:ff:ff
3        0           2        0       102        1536            0  ba:db:ad:f0:2:8f
4        0           4        0       104        1536            0  ff:ff:ff:ff:ff:ff
5        0           4        0       104        1536            0  1:80:c2:0:0:2
6        0           5        0       105        1536            0  1:80:c2:0:0:2
7        0           5        0       105        1536            0  ff:ff:ff:ff:ff:ff
8        0          13        0        13           9       103735  0:0:0:0:0:0
9        0          32        0       117        1536            0  ba:db:ad:f0:2:9e
10       0           7        0       107        1536            0  ff:ff:ff:ff:ff:ff
11       0           7        0       107        1536            0  1:80:c2:0:0:2
12       0           6        0       106        1536            0  1:80:c2:0:0:2
13       0           6        0       106        1536            0  ff:ff:ff:ff:ff:ff
14       0          14        0        14          10           19  0:0:0:0:0:0
15       0          10        0        10          14         1979  0:0:0:0:0:0
16       0          44        0       129        1536            0  ba:db:ad:f0:2:a1
17       0           9        0         9          13      1227537  0:0:0:0:0:0
18       0           8        0       108        1536            0  1:80:c2:0:0:2
19       0           8        0       108        1536            0  ff:ff:ff:ff:ff:ff
20       0           1        0       101        1536            0  ff:ff:ff:ff:ff:ff
21       0           1        0       101        1536            0  1:80:c2:0:0:2
22       0           3        0       103        1536            0  1:80:c2:0:0:2
23       0           1        0       101        1536         2183  1:0:0:0:0:0
24       0           3        0       103        1536            0  ff:ff:ff:ff:ff:ff
25       0           2        0       102        1536           23  ff:ff:ff:ff:ff:ff
26       0           2        0       102        1536            0  1:80:c2:0:0:2
27       0          32        0       117        1536            0  ff:ff:ff:ff:ff:ff
28       0          32        0       117        1536            0  1:80:c2:0:0:2
29       0          40        0       125        1536            0  ff:ff:ff:ff:ff:ff
30       0          40        0       125        1536            0  1:80:c2:0:0:2
31       0           7        0       107        1536            0  ba:db:ad:f0:2:94
32       0           5        0       105        1536            0  ba:db:ad:f0:2:92
33       0          36        0       121        1536            0  1:80:c2:0:0:2
34       0           4        0       104        1536            0  ba:db:ad:f0:2:91
35       0          36        0       121        1536            0  ff:ff:ff:ff:ff:ff
36       0           8        0       108        1536            0  ba:db:ad:f0:2:95
37       0           6        0       106        1536            0  ba:db:ad:f0:2:93
38       0           3        0       103        1536            0  ba:db:ad:f0:2:90
39       0          36        0       121        1536            0  ba:db:ad:f0:2:9f
40       0           1        0       101        1536           32  ba:db:ad:f0:2:8e
41       0          40        0       125        1536            0  ba:db:ad:f0:2:a0
```

The following CLI displays detailed information about software MAC-filter:

```
firepower-4225(local-mgmt)# show portmanager switch forward-rules software mac-filter

      NATIVE_VLAN    VLAN   SRC_PORT   PORTCHANNEL_ID   DST_PORT   FLAGS   MODE DMAC
1               0     106          6                0       1536       2      5
1:80:c2:0:0:2
2               0     105          5                0       1536       2      5
ff:ff:ff:ff:ff:ff
3               0     105          5                0       1536       2      5
1:80:c2:0:0:2
4               0     121          0                0         36      24      8
0:0:0:0:0:0
5               0     106          6                0       1536       2      5
ff:ff:ff:ff:ff:ff
6               0     121         36                0       1536       2      5
```

```
1:80:c2:0:0:2
7               0       117          32                0       1536        2       5
1:80:c2:0:0:2
8               0       125          40                0       1536        2       5
ff:ff:ff:ff:ff:ff
9               0       129           0                0         44       24       8
0:0:0:0:0:0
10              0       117          32                0       1536        2       5
ff:ff:ff:ff:ff:ff
11              0       103           3                0       1536        2       5
1:80:c2:0:0:2
12              0       102           2                0       1536        2       5
ff:ff:ff:ff:ff:ff
13              0       117           0                0         32       24       8
0:0:0:0:0:0
14              0       107           0                0          7       24       8
0:0:0:0:0:0
15              0       101           1                0       1536        2       5
ba:db:ad:f0:2:8e
16              0       107           7                0       1536        2       5
ff:ff:ff:ff:ff:ff
17              0       106           6                0       1536        2       5
ba:db:ad:f0:2:93
18              0       105           0                0          5       24       8
0:0:0:0:0:0
19              0       102           0                0          2       24       8
0:0:0:0:0:0
20              0       104           4                0       1536        2       5
ba:db:ad:f0:2:91
21              0       107           7                0       1536        2       5
ba:db:ad:f0:2:94
22              0       129          44                0       1536        2       5
1:80:c2:0:0:2
23              0       102           2                0       1536        2       5
1:80:c2:0:0:2
24              0       121          36                0       1536        2       5
ff:ff:ff:ff:ff:ff
25              0         1          13                0          9       26       8
0:0:0:0:0:0
26              0       108           8                0       1536        2       5
1:80:c2:0:0:2
27              0       101           1                0       1536        2       5
ff:ff:ff:ff:ff:ff
28              0         2          10                0         14       26       8
0:0:0:0:0:0
29              0       101           1                0       1536        2       5
1:80:c2:0:0:2
30              0         1           9                0         13       26       8
0:0:0:0:0:0
31              0       129          44                0       1536        2       5
ff:ff:ff:ff:ff:ff
32              0       125           0                0         40       24       8
0:0:0:0:0:0
33              0       108           8                0       1536        2       5
ba:db:ad:f0:2:95
34              0         2          14                0         10       26       8
0:0:0:0:0:0
35              0       129          44                0       1536        2       5
ba:db:ad:f0:2:a1
36              0       103           0                0          3       24       8
0:0:0:0:0:0
37              0       104           0                0          4       24       8
0:0:0:0:0:0
38              0       104           4                0       1536        2       5
```

```
ff:ff:ff:ff:ff:ff
39              0      107          7                0       1536        2       5
1:80:c2:0:0:2
40              0      104          4                0       1536        2       5
1:80:c2:0:0:2
41              0      101          1                0       1536       18       8
0:0:0:0:0:0
42              0      101          0                0          1       24       8
0:0:0:0:0:0
43              0      108          8                0       1536        2       5
ff:ff:ff:ff:ff:ff
44              0      121         36                0       1536        2       5
ba:db:ad:f0:2:9f
45              0      117         32                0       1536        2       5
ba:db:ad:f0:2:9e
46              0      105          5                0       1536        2       5
ba:db:ad:f0:2:92
47              0      125         40                0       1536        2       5
ba:db:ad:f0:2:a0
48              0      125         40                0       1536        2       5
1:80:c2:0:0:2
49              0      108          0                0          8       24       8
0:0:0:0:0:0
50              0      106          0                0          6       24       8
0:0:0:0:0:0
51              0      103          3                0       1536        2       5
ba:db:ad:f0:2:90
52              0      102          2                0       1536        2       5
ba:db:ad:f0:2:8f
53              0      103          3                0       1536        2       5
ff:ff:ff:ff:ff:ff
```

The following CLI displays detailed information about switch bridge engine packet drops:

```
firepower-4225(local-mgmt)# show portmanager switch counters bridge
Bridge Ingress Drop Counter: 4688
No Bridge Ingress Drop
```

The following CLI displays details on hardware switch packet counters:

```
how portmanager switch counters packet-trace

firepower-4225(local-mgmt)# show portmanager switch counters packet-trace

       Counter                              Description
---------------------- ------------------------------------------------------
goodOctetsRcv          Number of ethernet frames received that are not bad
                       ethernet frames or MAC Control pkts
badOctetsRcv           Sum of lengths of all bad ethernet frames received
gtBrgInFrames          Number of packets received
gtBrgVlanIngFilterDisc Number of packets discarded due to VLAN Ingress Filtering
gtBrgSecFilterDisc     Number of packets discarded due to
                       Security Filtering measures
gtBrgLocalPropDisc     Number of packets discarded due to reasons other than
                       VLAN ingress and Security filtering
dropCounter            Ingress Drop Counter
outUcFrames            Number of unicast packets transmitted
outMcFrames            Number of multicast packets transmitted. This includes
                       registered multicasts, unregistered multicasts
                       and unknown unicast packets
outBcFrames            Number of broadcast packets transmitted
brgEgrFilterDisc       Number of IN packets that were Bridge Egress filtered
txqFilterDisc          Number of IN packets that were filtered
```

```
                      due to TxQ congestion
outCtrlFrames         Number of out control packets
                      (to cpu, from cpu and to  analyzer)
egrFrwDropFrames      Number of packets dropped due to egress
                      forwarding restrictions
goodOctetsSent        Sum of lengths of all good ethernet
                      frames sent from this MAC


        Counter            Source port- 0/0    Destination port- 0/0
-----------------------  --------------------  ---------------------
goodOctetsRcv                    ---                    ---
badOctetsRcv                     ---                    ---

                                       Ingress counters
gtBrgInFrames                   1341132                1341132
gtBrgVlanIngFilterDisc             0                      0
gtBrgSecFilterDisc                 0                      0
gtBrgLocalPropDisc                 0                      0
dropCounter                     4699           Only for source-port

                                       Egress counters
outUcFrames                     1329593                1329593
outMcFrames                      4594                   4594
outBcFrames                      2237                   2237
brgEgrFilterDisc                   9                      9
txqFilterDisc                      0                      0
outCtrlFrames                      0                      0
egrFrwDropFrames                   0                      0
mcFifoDropPkts                     0                      0
mcFilterDropPkts                   0                      0

goodOctetsSent                   ---                    ---
```

The following CLI displays detailed informatin about the switch traffic for CPU:

```
firepower-4225(local-mgmt)# show portmanager switch traffic cpu

Dev/RX queue  packets    bytes
------------  ---------- ----------

Dev/RX queue  packets    bytes
------------  ---------- ----------

0/0           0          0
0/1           0          0
0/2           0          0
0/3           0          0
0/4           0          0
0/5           0          0
0/6           0          0
0/7           0          0
```

The following CLI displays details on hardware switch port traffic:

```
firepower-4225(local-mgmt)# show portmanager switch traffic port


max-rate - pps that the port allow with packet size=64
actual-tx-rate - pps that egress the port (+ % from 'max')
actual-rx-rate - pps that ingress the port(+ % from 'max')

Dev/Port   max-rate  actual-tx-rate    actual-rx-rate
```

```
---------  --------  ---------------   ---------------
0/1         1488095    (0%)---           (0%)---
0/2         1488095    (0%)---           (0%)---
0/3         14880      (0%)---           (0%)---
0/4         14880      (0%)---           (0%)---
0/5         14880      (0%)---           (0%)---
0/6         14880      (0%)---           (0%)---
0/7         14880      (0%)---           (0%)---
0/8         14880      (0%)---           (0%)---
0/9         14880952   (0%)---           (0%)---
0/10        14880952   (0%)---           (0%)---
0/11        14880952   (0%)---           (0%)---
0/12        14880952   (0%)---           (0%)---
0/13        14880952   (0%)---           (0%)---
0/14        14880952   (0%)---           (0%)---
0/15        1488095    (0%)---           (0%)---
0/16        1488095    (0%)---           (0%)---
0/17        14880952   (0%)---           (0%)---
0/18        74404761   (0%)---           (0%)---
0/19        37202380   (0%)---           (0%)---
0/20        37202380   (0%)---           (0%)---
```

The following CLI displays detailed information about SFP-FEC Counters matching ethernet 1/13 port:

```
firepower-4225(local-mgmt)# show portmanager counters ethernet 1 13
   Good Octets Received                              : 2153
   Bad Octets Received                               : 0
   MAC Transmit Error                                : 0
   Good Packets Received                             : 13
   Bad packets Received                              : 0
   BRDC Packets Received                             : 0
   MC Packets Received                               : 13
   .........
   .........
   txqFilterDisc                                     : 0
   linkchange                                        : 1
   FcFecRxBlocks                                     : 217038081
   FcFecRxBlocksNoError                              : 217038114
   FcFecRxBlocksCorrectedError                       : 0
   FcFecRxBlocksUnCorrectedError                     : 0
   FcFecRxBlocksCorrectedErrorBits                   : 0
   FcFecRxBlocksCorrectedError0                      : 0
   FcFecRxBlocksCorrectedError1                      : 0
   FcFecRxBlocksCorrectedError2                      : 0
   FcFecRxBlocksCorrectedError3                      : 0
   FcFecRxBlocksUnCorrectedError0                    : 0
   FcFecRxBlocksUnCorrectedError1                    : 0
   FcFecRxBlocksUnCorrectedError2                    : 0
   FcFecRxBlocksUnCorrectedError3                    : 0
```

The following CLI displays detailed information about SFP-FEC Counters matching ethernet 1/14 port:

```
firepower-4225(local-mgmt)# show portmanager counters ethernet 1 14
   Good Octets Received                              : 2153
   Bad Octets Received                               : 0
   MAC Transmit Error                                : 0
   Good Packets Received                             : 13
   Bad packets Received                              : 0
   BRDC Packets Received                             : 0
   MC Packets Received                               : 13
   .....
```

```
.....
txqFilterDisc                                  : 0
linkchange                                     : 1
RsFeccorrectedFecCodeword                      : 0
RsFecuncorrectedFecCodeword                    : 10
RsFecsymbolError0                              : 5
RsFecsymbolError1                              : 0
RsFecsymbolError2                              : 0
RsFecsymbolError3                              : 0
```

The following CLI displays detailed information on the Digital Optical Monitoring information matching ethernet 1/5 port:

```
firepower-4245(local-mgmt)# show portmanager port-info ethernet 1 5
        ....
        ....
                DOM info:
                ========:

                Status/Control Register: 0800
                      RX_LOS State: 0
                      TX_FAULT State: 0
                Alarm Status: 0000
                No active alarms
                Warning Status: 0000
                No active warnings

       THRESHOLDS
                                 high alarm    high warning    low warning     low alarm

          Temperature     C     +075.000        +070.000        +000.000         -05.000

          Voltage         V     003.6300        003.4650        003.1350        002.9700

          Bias Current    mA    012.0000        011.5000        002.0000        001.0000

          Transmit power mW     034.6740        017.3780        002.5120        001.0000

          Receive power  mW     034.6740        017.3780        001.3490        000.5370


                Environmental Information - raw values
                Temperature: 38.84 C
                Supply voltage: 33703 in units of 100uVolt
                Tx bias: 3499 in units of 2uAmp
                Tx power:  0.1 dBm (10251 in units of 0.1 uW)
                Rx power: -0.9 dBm (8153 in units of 0.1 uW)
                DOM (256 bytes of raw data in hex)
                   ====================================
                   0x0000 : 4b 00 fb 00 46 00 00 00 8d cc 74 04 87 5a 7a 76
                   0x0010 : 17 70 01 f4 16 76 03 e8 87 72 03 e8 43 e2 09 d0
                   0x0020 : 87 72 02 19 43 e2 05 45 00 00 00 00 00 00 00 00
                   0x0030 : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
                   0x0040 : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
                   0x0050 : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 86
                   0x0060 : 26 54 83 a7 0d ab 28 0b 1f d9 00 00 00 00 08 00
                   0x0070 : 00 00 03 00 00 00 00 00 08 f3 00 00 00 00 00 01
                   0x0080 : 49 4e 55 49 41 43 53 45 41 41 31 30 2d 33 33 38
                   0x0090 : 38 2d 30 31 56 30 31 20 01 00 46 00 00 00 00 e3
                   0x00a0 : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
                   0x00b0 : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
                   0x00c0 : 53 46 50 2d 31 30 2f 32 35 47 2d 43 53 52 2d 53
                   0x00d0 : 20 20 20 20 30 38 00 00 00 00 00 00 00 00 00 d1
                   0x00e0 : 1e 20 2a 2a 31 34 29 36 00 00 00 00 00 00 00 00
```

```
  0x00f0 : 00 00 00 00 00 56 00 00 ff ff ff ff 00 00 00 cf
  ======================================
PHY Data:
PAGE IFC OFFSET VALUE  | PAGE IFC OFFSET VALUE
---- --- ------ -----  | ---- --- ------ -----
```

The following CLI displays detailed information about the parameters set for the packet capture:

```
firepower-4225(local-mgmt)# show portmanager switch pktcap-rules software
Software DB rule:1
 Slot= 1
 Interface= 12
 Breakout-port= 0
 Protocol= 6
 Ethertype= 0x0000
 Filter_key= 0x00000040
 Session= 1
 Vlan= 0
 SrcPort= 0
 DstPort= 0
 SrcIp= 0.0.0.0
 DstIp= 0.0.0.0
 SrcIpv6= ::
 DestIpv6= ::
 SrcMacAddr= 00:00:00:00:00:00
 DestMacAddr= 00:00:00:00:00:00
```

The following CLI displays detailed information on the FXOS port manager switch hardware TCAM rules:

```
firepower-4225(local-mgmt)# show portmanager switch pktcap-rules hardware
Hardware DB rule:1
 Hw_index= 15372
 Rule_id= 10241
 Cnc_index= 1
 Packet_count= 0
 Slot= 1
 Interface= 12
 Protocol= 6
 Ethertype= 0x0000
 Vlan= 0
 SrcPort= 0
 DstPort= 0
 SrcIp= 0.0.0.0
 DstIp= 0.0.0.0
 SrcIpv6= ::
 DestIpv6= ::
 SrcMacAddr= 00:00:00:00:00:00
 DestMacAddr= 00:00:00:00:00:00
```

The following CLI displays detailed information on port-based packet drops for eight traffic classes/queues:

```
firepower-4225(local-mgmt)# show portmanager switch tail-drop-allocated buffers all
-----------------------------------------------------------------------------------------------

     |          |                          Per Port and Traffic Class
          |
Port | Per port | TC0     | TC1     | TC2     | TC3     | TC4     | TC5     | TC6
| TC7     |
-----|----------|---------|---------|---------|---------|---------|---------|---------|
0/1  |10        |10       |0        |0        |0        |0        |0        |0
|0        |
0/2  |15        |5        |5        |5        |0        |0        |0        |0
```

```
|0        |
0/3  |0          |0         |0         |0         |0         |0         |0         |0
|0        |
0/4  |80         |0         |0         |0         |0         |0         |0         |0
|80       |
0/5  |0          |0         |0         |0         |0         |0         |0         |0
|0        |
0/6  |0          |0         |0         |0         |0         |0         |0         |0
|0        |
0/7  |200        |25        |25        |50        |0         |0         |25        |50
|25       |
0/8  |0          |0         |0         |0         |0         |0         |0         |0
|0        |
-------------------------------------------------------------------------------------------
```

The following CLI displays dropped packet counts due to tti-lookup0:

```
firepower-4225(local-mgmt)# show portmanager switch default-rule-drop-counter tti-lookup0

Rule_id    cnc_index     packet_count
-------------------------------------
  1           1               4
```

# Security Services Mode Troubleshooting Commands

Use the following security services (ssa) mode FXOS CLI commands to troubleshoot issues with your system.

**show app**

Displays information about the applications attached to you Firpower device.
For example:

```
firepower /ssa # show app
    Application:
        Name       Version    Description Author     Deploy Type CSP Type    Is Default
 App
        ---------- ---------- ----------- ---------- ----------- -----------
--------------
        asa        9.10.1     N/A         cisco      Native      Application Yes
        asa        9.9.2      N/A         cisco      Native      Application No
```

**showapp-instance**

Displays information about the verified app-instance status

```
    firepower-2120 /ssa # show app-instance
Application Name     Slot ID    Admin State     Operational State    Running Version Startup
 Version Cluster Oper State
-------------------- ---------- --------------- -------------------- ---------------
--------------- ------------------
asa                  1          Enabled         Online               9.14.2          9.14.2
          Not Applicable
```

**showfault**

Displays information about the fault message

```
firepower-2120 /ssa # show fault
Severity  Code     Last Transition Time     ID       Description
```

```
--------- -------- ----------------------- -------- -----------
Cleared   F16589   2021-10-11T21:58:53.200    25140 [FSM:STAGE:RETRY:]: Waiting for chassis
 object ready(FSM-STAGE:sam:dme:SmSecSvcAutoDeployCSP:WaitForChassisM
oReady)
```

**show failsafe-params**

The fail-safe mode for an Firewall Threat Defense application on Firepower 1000/2100 or Secure Firewall 3100 is activated due to continuous boot loop, traceback, etc. The following parameters control the activation of the fail-safe mode:

- Max Restart—maximum number of times that an application should restart in order to activate the fail-safe mode.
- Current Reboot Count—number of times the application continuously restarted.
- Restart Time Interval (secs)—the amount of time in seconds, during which the Max Restart counter should be reached in order to trigger the fail-safe mode. If the application restarts 'Max Restart' or more times within this interval, the fail-safe mode is enabled.

For example:

```
firepower-2120-failed(local-mgmt)# show failsafe-params
Max Restart: 8
Current Reboot Count: 0
Restart Time Interval(secs): 3600
```

When the system is in the fail-safe mode:

- The system name is appended with the "-failed" string:

  ```
  firepower-2120-failed /ssa #
  ```

- The output of the "show failsafe-params" command in the local-mgmt command shell contains a warning message:

  ```
  firepower-2120-failed(local-mgmt)# show failsafe-params
  Max Restart: 1
  Current Reboot Count: 1
  Restart Time Interval(secs): 3600
  WARNING: System in Failsafe mode. Applications are not running!
  ```

- Operation State of the application is Offline:

  ```
  firepower-2120-failed /ssa # show app-instance
  Application Name     Slot ID    Admin State     Operational State    Running Version
  Startup Version Cluster Oper State   Cluster Role
  -------------------- ---------- --------------- -------------------- ---------------
  --------------- -------------------- ------------
  asa                  1          Enabled         Offline <=====       9.16.2.3
  9.16.2.3        Not Applicable       None
  ```

# Packet Capture for Secure Firewall 3100/4200

The Packet Capture tool is a valuable asset for use in debugging connectivity and configuration issues and for understanding traffic flows through your devices. You can now use the Packet Capture CLIs to log traffic that is going through specific interfaces on your Secure Firewall 3100/4200 devices.

You can create multiple packet capture sessions, and each session can capture traffic on multiple interfaces. For each interface included in a packet capture session, a separate packet capture (PCAP) file will be created.

# Guidelines and Limitations for Packet Capture

The Packet Capture tool has the following limitations:

- Packet Capture on Secure Firewall 3100/4200 series devices can capture up to 300 Mbps.
- Packet capture sessions can be created even when there is not enough storage space available to run the packet capture session. You should verify that you have enough storage space available before you start a packet capture session.
- For packet capture sessions on a single-wide 4x100Gbps or 2x100Gbps network module (part numbers FPR-NM-4X100G and FPR-NM-2X100G respectively), if the module `adminstate` is set to `off`, the capture session is automatically disabled with an "Oper State Reason: Unknown Error." You will have to restart the capture session after the module `adminstate` is set to `on` again.

  With all other network modules, packet capture sessions continue across module `adminstate` changes.
- Does not support multiple active packet capturing sessions.
- There is no option to filter based on source or destination IPv6 address.
- Filters are not effective on packets that cannot be understood by the internal switch (for example Security Group Tag and Network Service Header packets).
- You cannot capture packets for an EtherChannel as a whole. However, for an EtherChannel allocated to a logical device, you can capture packets on each member interface of the EtherChannel.
- You cannot copy or export a PCAP file while the capture session is still active.
- When you delete a packet capture session, all packet capture files associated with that session are also deleted.

# Creating or Editing a Packet Capture Session

### Procedure

**Step 1** Enter packet capture mode:

firepower-4215 # **scope packet-capture**

**Step 2** Create a filter.

firepower-4215 /packet-capture/filter* # **set** <*filterprop filterprop_value*

***Table 1: Supported Filter Properties***

| | |
|---|---|
| ivlan | Inner VLAN ID (vlan of packet while ingressing port) |
| ovlan | Outer VLAN ID |
| srcip | Source IP Address (IPv4) |
| destip | Destination IP Address (IPv4) |

| | |
|---|---|
| srcport | Source Port Number |
| destport | Destination Port Number |
| protocol | IP Protocol [IANA defined Protocol values in decimal format] |
| ethertype | Ethernet Protocol type [IANA defined Ethernet Protocol type value in decimal format. For eg: IPv4 = 2048, IPv6 = 34525, ARP = 2054, SGT = 35081] |
| srcmac | Source Mac Address |
| destmac | Destination Mac Address |

You can apply filters to any of the interfaces included in a packet capture session.

**Step 3** To create or edit a packet capture session:

firepower-4215 /packet-capture # **enter session** *session_name*

**Step 4** Specify the length of the packet that you want to capture for this packet capture session:

firepower-4215 /packet-capture/session* # **set session-pcap-snaplength** *session_snap_length_in_bytes*

The specified snap length must be between 64 and 9006 bytes. If you do not configure the session snap length, the default capture length is 1518 bytes.

**Step 5** Specify the physical source ports that should be included in this packet capture session.

You can capture from multiple ports and can capture from both physical ports and application ports during the same packet capture session. A separate packet capture file is created for each port included in the session. You cannot capture packets for an EtherChannel as a whole. However, for an EtherChannel allocated to a logical device, you can capture packets on each member interface of the EtherChannel.

**Note**
To remove a port from the packet capture session, use **delete** instead of **create** in the commands listed below.

a) Specify the physical port.

firepower-4215 /packet-capture/session* # **create** {**phy-port | phy-aggr-port**} *port_id*

**Example:**

**Example:**

```
firepower-4215 /packet-capture/session* # create phy-port Ethernet1/1
firepower-4215 /packet-capture/session/phy-port* #
```

b) Capture packets on a subinterface.

firepower-4215 /packet-capture/session/phy-port* # **set subinterface** *id*

You can only capture packets for one subinterface per capture session, even if you have multiple subinterfaces on one or more parents. Subinterfaces for EtherChannels are not supported. If the parent interface is also allocated to the instance, you can either choose the parent interface or a subinterface; you cannot choose both.

**Example:**

```
firepower-4215 /packet-capture/session/phy-port* # set subinterface 100
firepower-4215 /packet-capture/session/phy-port* #
```

c) For container instances, specify the container instance name.

firepower-4215 /packet-capture/session/phy-port* # **set app-identifier** *instance_name*

**Example:**

```
firepower-4215 /packet-capture/session/phy-port* # set app-identifier asa-instance1
firepower-4215 /packet-capture/session/phy-port* #
```

d) (Optional) For capturing the mac-filter dropped packets from switch, specify the mac-filter drop.

firepower-4215 /packet-capture/session/phy-port* # **set drop** {**mac-filter | disable**}

- **disable**—To disable capture of packets dropped from switch.
- **mac-filter**—To capture switch mac-filter drop

**Note**
The mac-filter option is supported only for the ingress packet capture direction and the default option is always **disable**.

e) (Optional) Apply the desired filter.

firepower-4215 /packet-capture/session/phy-port* # **set** {**source-filter**} *filtername*

**Note**
To remove a filter from a port, use **set source-filter ""**.

f) Repeat the steps above as needed to add all desired ports.

**Step 6** Specify the application source ports that should be included in this packet capture session.

You can capture from multiple ports and can capture from both physical ports and application ports during the same packet capture session. A separate packet capture file is created for each port included in the session.

**Note**
To remove a port from the packet capture session, use **delete** instead of **create** in the commands listed below.

a) Specify the application port.

firepower-4215 /packet-capture/session* # **create app_port** *module_slot link_name interface_name app_name*

**Syntax Description**

| | |
|---|---|
| **module_slot** | Security module in which the application is installed. |
| **link_name** | Any user descriptive name referring to the interface, for example, link1, inside_port1, etc. |
| **interface_name** | Interface attached to the application where packets need to be captured from, for example, Ethernet1/1, Ethernet2/2 |
| **app_name** | Application installed on the module - asa |

b) (Optional) Apply the desired filter.

firepower-4215 /packet-capture/session/phy-port* # **set** {**source-filter**} *filtername*

**Syntax Description**

| | |
|---|---|
| **filtername** | The filter name from the 'create filter' command under packet-capture scope |

**Note**
To remove a filter from a port, use **set source-filter ""**.

c) Repeat the steps above as needed to add all desired application ports.

**Step 7** If you want to start the packet capture session now:

firepower-4215 /packet-capture/session* # **enable**

Newly created packet-capture sessions are disabled by default. Explicit enabling of a session activates the packet capture session when the changes are committed. If another session is already active, enabling a session will generate an error. You must disable the already active packet-capture session before you can enable this session.

**Step 8** Commit the transaction to the system configuration:

firepower-4215 /packet-capture/session* # **commit-buffer**

If you enabled the packet capture session, the system will begin capturing packets. You will need to stop capturing before you can download the PCAP files from your session.

**Example**

```
firepower-4215 # scope packet-capture
firepower-4215 /packet-capture # create session asa1inside
firepower-4215 /packet-capture* # create filter interface1vlan100
firepower-4215 /packet-capture/filter* # set ivlan 100
firepower-4215 /packet-capture/filter* # set srcIP 6.6.6.6
firepower-4215 /packet-capture/filter* # set destIP 10.10.10.10
firepower-4215 /packet-capture/filter* # exit
firepower-4215 /packet-capture/session* # create phy-port Ethernet1/1
firepower-4215 /packet-capture/session/phy-port* # set drop mac-filter
firepower-4215 /packet-capture/session/phy-port* # set src-filter interface1vlan100
firepower-4215 /packet-capture/session/phy-port* # exit
firepower-4215 /packet-capture/session* # enable
firepower-4215 /packet-capture/session* # commit-buffer
firepower-4215 /packet-capture/session #
```

# Deleting Packet Capture Sessions

You can delete an individual packet capture session if it is not currently running or you can delete all inactive packet capture sessions.

**Procedure**

**Step 1** Enter packet capture mode:

firepower-4215 # **scope packet-capture**

**Step 2** To delete a specific packet capture session:

firepower-4215 /packet-capture # **delete session** *session_name*

**Step 3** To delete all inactive packet capture sessions:

firepower-4215/packet-capture # **delete-all-sessions**

**Step 4** Commit the transaction to the system configuration:

firepower-4215 /packet-capture* # **commit-buffer**

### Example

```
firepower-4215 # scope packet-capture
firepower-4215 packet-capture # delete session asa1inside
firepower-4215 packet-capture* # commit-buffer
firepower-4215 packet-capture #
```