

Reference

- Traffic Flow and Inspection, on page 1
- Time and Disk Space, on page 4
- Upgrade Feature History, on page 5

Traffic Flow and Inspection

Schedule maintenance windows when upgrade will have the least impact, considering any effect on traffic flow and inspection.

Traffic Flow and Inspection for Firewall Threat Defense Upgrades

Software Upgrades for Standalone Devices

Devices operate in maintenance mode while they upgrade. Entering maintenance mode at the beginning of the upgrade causes a 2-3 second interruption in traffic inspection. Interface configurations determine how a standalone device handles traffic both then and during the upgrade.

Table 1: Traffic Flow and Inspection: Software Upgrades for Standalone Devices

Interface Configuration		Traffic Behavior
Firewall interfaces	Routed or switched including EtherChannel, redundant, subinterfaces. Switched interfaces are also known as bridge group or transparent interfaces.	Dropped. For bridge group interfaces on the ISA 3000 only, you can use a FlexConfig policy to configure hardware bypass for power failure. This causes traffic to drop during software upgrades but pass without inspection while the device completes its post-upgrade reboot.

Interface Configuration		Traffic Behavior
IPS-only interfaces	Inline set, hardware bypass force-enabled: **Bypass: Force**	Passed without inspection until you either disable hardware bypass, or set it back to standby mode.
	Inline set, hardware bypass standby mode: **Bypass: Standby**	Dropped during the upgrade, while the device is in maintenance mode. Then, passed without inspection while the device completes its post-upgrade reboot.
	Inline set, hardware bypass disabled: **Bypass: Disabled**	Dropped.
	Inline set, no hardware bypass module.	Dropped.
	Inline set, tap mode.	Egress packet immediately, copy not inspected.
	Passive, ERSPAN passive.	Uninterrupted, not inspected.

Software Upgrades for High Availability and Clustered Devices

You should not experience interruptions in traffic flow or inspection while upgrading high availability or clustered devices. For high availability pairs, the standby device upgrades first. The devices switch roles, then the new standby upgrades.

For clusters, the data security module or modules upgrade first, then the control module. During the control security module upgrade, although traffic inspection and handling continues normally, the system stops logging events. Events for traffic processed during the logging downtime appear with out-of-sync timestamps after the upgrade is completed. However, if the logging downtime is significant, the system may prune the oldest events before they can be logged.

Note that hitless upgrades are not supported for single-unit clusters. Interruptions to traffic flow and inspection depend on interface configurations of the active unit, just as with standalone devices.

Software Revert (Major/Maintenance Releases)

You should expect interruptions to traffic flow and inspection during revert, even in a high availability/scalability deployment. This is because revert is more successful when all units are reverted simultaneously. Simultaneous revert means that interruptions to traffic flow and inspection depend on interface configurations only, as if every device were standalone.

Software Uninstall (Patches)

For standalone devices, interruptions to traffic flow and inspection during patch uninstall are the same as for upgrade. In high availability/scalability deployments, you must explicitly plan an uninstall order that minimizes disruption. This is because you uninstall patches from devices individually, even those that you upgraded as a unit.

Traffic Flow and Inspection for Chassis Upgrades

Upgrading FXOS reboots the chassis. For FXOS upgrades to Version 2.14.1+ that include firmware upgrades, the chassis reboots twice—once for FXOS and once for the firmware.

Even in high availability or clustered deployments, you upgrade FXOS on each chassis independently. To minimize disruption, upgrade one chassis at a time; see Upgrade Order.

Table 2: Traffic Flow and Inspection: FXOS Upgrades

Firewall Threat Defense Deployment	Traffic Behavior	Method
Standalone	Dropped.	—
High availability	Unaffected.	**Best Practice:** Update FXOS on the standby, switch active peers, upgrade the new standby.
	Dropped until one peer is online.	Upgrade FXOS on the active peer before the standby is finished upgrading.
Inter-chassis cluster	Unaffected.	**Best Practice:** Upgrade one chassis at a time so at least one module is always online.
	Dropped until at least one module is online.	Upgrade chassis at the same time, so all modules are down at some point.
Intra-chassis cluster (Firepower 9300 only)	Passed without inspection.	Hardware bypass enabled: **Bypass: Standby** or **Bypass-Force**.
	Dropped until at least one module is online.	Hardware bypass disabled: **Bypass: Disabled**.
	Dropped until at least one module is online.	No hardware bypass module.

Traffic Flow and Inspection when Deploying Configurations

Snort typically restarts during the first deployment immediately after upgrade. This means that for Firewall Management Center upgrades, Snort could restart on all managed devices. Snort does not restart after subsequent deployments unless, before deploying, you modify specific policy or device configurations.

Restarting the Snort process briefly interrupts traffic flow and inspection on all devices, including those configured for high availability/scalability. Interface configurations determine whether traffic drops or passes without inspection during the interruption. When you deploy without restarting Snort, resource demands may result in a small number of packets dropping without inspection.

Table 3: Traffic Flow and Inspection: Deploying Configuration Changes

Interface Configuration		Traffic Behavior
Firewall interfaces	Routed or switched including EtherChannel, redundant, subinterfaces. Switched interfaces are also known as bridge group or transparent interfaces.	Dropped.
IPS-only interfaces	Inline set, **Failsafe** enabled or disabled.	Passed without inspection. A few packets might drop if **Failsafe** is disabled and Snort is busy but not down.
	Inline set, **Snort Fail Open: Down**: disabled.	Dropped.
	Inline set, **Snort Fail Open: Down**: enabled.	Passed without inspection.
	Inline set, tap mode.	Egress packet immediately, copy not inspected.
	Passive, ERSPAN passive.	Uninterrupted, not inspected.

Time and Disk Space

Time to Upgrade

We recommend you track and record your own upgrade times so you can use them as future benchmarks. The following table lists some things that can affect upgrade time.

Caution Do not make or deploy configuration changes during upgrade. Even if the system appears inactive, do not manually reboot or shut down. In most cases, do not restart an upgrade in progress. You could place the system in an unusable state and require a reimage. If you encounter issues with the upgrade, including a failed upgrade or unresponsive appliance, see Unresponsive and Failed Firewall Threat Defense Upgrades.

Table 4: Upgrade Time Considerations

Consideration	Details
Versions	Upgrade time usually increases if your upgrade skips versions.
Models	Upgrade time usually increases with lower-end models.
Virtual appliances	Upgrade time in virtual deployments is highly hardware dependent.

Consideration	Details
High availability and clustering	In a high availability or clustered configuration, devices upgrade one at a time to preserve continuity of operations, with each device operating in maintenance mode while it upgrades. Upgrading a device pair or entire cluster, therefore, takes longer than upgrading a standalone device.
Configurations	Upgrade time can increase with the complexity of your configurations, size of event databases, and whether/how they are affected by the upgrade. For example, if you use a lot of access control rules and the upgrade needs to make a backend change to how those rules are stored, the upgrade can take longer.
Components	You may need additional time to perform operating system or virtual hosting upgrades, upgrade package transfers, readiness checks, VDB and intrusion rule (SRU/LSP) updates, configuration deployment, and other related tasks.

Disk Space to Upgrade

To upgrade, the upgrade package must be on the appliance. For device upgrades, you must also have enough space on the Firewall Management Center (in either /Volume or /var) for the device upgrade package. Or, you can use an internal server to store them. Readiness checks should indicate whether you have enough disk space to perform the upgrade. Without enough free disk space, the upgrade fails. For more information, see Configuration and Deployment Checks.

Upgrade Feature History

Table 5: Device Upgrade Feature History

Feature	Minimum Management Center	Minimum Threat Defense	Details
Push packages and check readiness for older ASA FirePOWER and NGPISv devices before upgrade.	7.2.11 7.4.3	—	With the new upgrade capabilities introduced in 7.2.6 and 7.4.1, we deprecated the ability to perform a pre-upgrade package push and readiness check for ASA FirePOWER and NGPISv. These options have returned to the Classic device upgrade workflow. Version restrictions: These devices were last supported in Version 7.0, and the Version 7.4 Firewall Management Center is the last that can manage them.

Feature	Minimum Management Center	Minimum Threat Defense	Details
Firewall Threat Defense and chassis upgrade wizards optimized for lower resolution screens.	7.2.10 7.6.0	Any	We optimized the Firewall Threat Defense and chassis upgrade wizards for lower resolution screens (and smaller browser windows). Text appears smaller and certain screen elements are hidden. If you change your resolution or window size mid-session, you may need to refresh the page for the web interface to adjust. Note that the minimum screen resolution to use the Firewall Management Center is 1280 x 720. New/modified screens: • **Devices** > **Threat Defense Upgrade** • **Devices** > **Chassis Upgrade**
Enable revert from the Firewall Threat Defense upgrade wizard.	7.2.6 7.4.1	Any, if upgrading to 7.1+	You can now enable revert from the Firewall Threat Defense upgrade wizard. Version restrictions: You must be upgrading Firewall Threat Defense to Version 7.1+. Not supported with Firewall Management Center Version 7.3.x or 7.4.0.
View detailed upgrade status from the Firewall Threat Defense upgrade wizard.	7.2.6 7.4.1	Any	The final page of the Firewall Threat Defense upgrade wizard now allows you to monitor upgrade progress. This is in addition to the existing monitoring capability on the Upgrade tab on the Device Management page, and on the Message Center. Note that as long as you have not started a new upgrade flow, **Devices** > **Threat Defense Upgrade** brings you back to this final wizard page, where you can view the detailed status for the current (or most recently complete) device upgrade.

Feature	Minimum Management Center	Minimum Threat Defense	Details
Improved upgrade starting page and package management.	7.2.6 7.4.1	Any	A new upgrade page makes it easier to choose, download, manage, and apply upgrades to your entire deployment. This includes the Firewall Management Center, Firewall Threat Defense, and any older NGIPSv/ASA FirePOWER devices. The page lists all upgrade packages that apply to your current deployment, with suggested releases specially marked. You can easily choose and direct-download packages from Cisco, as well as manually upload and delete packages. Internet access is required to retrieve the list/direct download upgrade packages. Otherwise, you are limited to manual management. Patches are not listed unless you have at least one appliance at the appropriate maintenance release (or you manually uploaded the patch). You must manually upload hotfixes. New/modified screens: • **System**(⚙) > **Product Upgrades** is now where you upgrade the Firewall Management Center and all managed devices, as well as manage upgrade packages. • **System**(⚙) > **Content Updates** is now where you update intrusion rules, the VDB, and the GeoDB. • **Devices** > **Threat Defense Upgrade** takes you directly to the Firewall Threat Defense upgrade wizard. • **System**(⚙) > **Users** > **User Role** > **Create User Role** > **Menu-Based Permissions** allows you to grant access to **Content Updates** (VDB, GeoDB, intrusion rules) without allowing access to **Product Upgrades** (system software). Deprecated screens/options: • **System**(⚙) > **Updates** is deprecated. All Firewall Threat Defense upgrades now use the wizard. • The **Add Upgrade Package** button on the Firewall Threat Defense upgrade wizard has been replaced by a **Manage Upgrade Packages** link to the new upgrade page.
Suggested release notifications.	7.2.6 7.4.1	Any	The Firewall Management Center now notifies you when a new suggested release is available. If you don't want to upgrade right now, you can have the system remind you later, or defer reminders until the next suggested release. The new upgrade page also indicates suggested releases. See: *Cisco Secure Firewall Management Center New Features by Release*

Feature	Minimum Management Center	Minimum Threat Defense	Details
Select devices to upgrade from the Firewall Threat Defense upgrade wizard.	7.2.6 7.3.0 December 13, 2022	Any	Use the wizard to select devices to upgrade. You can now use the Firewall Threat Defense upgrade wizard to select or refine the devices to upgrade. On the wizard, you can toggle the view between selected devices, remaining upgrade candidates, ineligible devices (with reasons why), devices that need the upgrade package, and so on. Previously, you could only use the Device Management page and the process was much less flexible.
Unattended Firewall Threat Defense upgrades.	7.2.6 7.3.0 December 13, 2022	Any	The Firewall Threat Defense upgrade wizard now supports unattended upgrades, using a new **Unattended Mode** menu. You just need to select the target version and the devices you want to upgrade, specify a few upgrade options, and step away. You can even log out or close the browser.
Simultaneous Firewall Threat Defense upgrade workflows by different users.	7.2.6 7.3.0 December 13, 2022	Any	We now allow simultaneous upgrade workflows by different users, as long as you are upgrading different devices. The system prevents you from upgrading devices already in someone else's workflow. Previously, only one upgrade workflow was allowed at a time across all users.
Skip pre-upgrade troubleshoot generation for Firewall Threat Defense.	7.2.6 7.3.0 December 13, 2022	Any	You can now skip the automatic generating of troubleshooting files before major and maintenance upgrades by disabling the new **Generate troubleshooting files before upgrade begins** option. This saves time and disk space. To manually generate troubleshooting files for a Firewall Threat Defense device, choose **System**(⚙) > **Health** > **Monitor**, click the device in the left panel, then **View System & Troubleshoot Details**, then **Generate Troubleshooting Files**.

Feature	Minimum Management Center	Minimum Threat Defense	Details
Copy upgrade packages ("peer-to-peer sync") from device to device.	7.2.0	7.2.0	Instead of copying upgrade packages to each device from the Firewall Management Center or internal web server, you can use the Firewall Threat Defense CLI to copy upgrade packages between devices ("peer to peer sync"). This secure and reliable resource-sharing goes over the management network but does not rely on the Firewall Management Center. Each device can accommodate 5 package concurrent transfers. This feature is supported for Version 7.2.x–7.4.x standalone devices managed by the same Version 7.2.x–7.4.x standalone Firewall Management Center. It is not supported for: • Container instances. • Device high availability pairs and clusters. These devices get the package from each other as part of their normal sync process. Copying the upgrade package to one group member automatically syncs it to all group members. • Devices managed by high availability Firewall Management Centers. • Devices in different domains, or devices separated by a NAT gateway. • Devices upgrading from Version 7.1 or earlier, regardless of Firewall Management Center version. • Devices running Version 7.6+. New/modified CLI commands: **configure p2psync enable**, **configure p2psync disable**, **show peers**, **show peer details**, **sync-from-peer**, **show p2p-sync-status**
Auto-upgrade to Snort 3 after successful Firewall Threat Defense upgrade.	7.2.0	7.0.0	When you use a Version 7.2+ Firewall Management Center to upgrade Firewall Threat Defense to Version 7.2+, you can now choose whether to **Upgrade Snort 2 to Snort 3**. After the software upgrade, eligible devices upgrade from Snort 2 to Snort 3 when you deploy configurations. For devices that are ineligible because they use custom intrusion or network analysis policies, we strongly recommend you manually upgrade to Snort 3 for improved detection and performance. For help, see the *Custom Snort 3 Intrusion Policies for Access Control* for your version. Version restrictions: Not supported for Firewall Threat Defense upgrades to Version 7.0.x or 7.1.x.

Feature	Minimum Management Center	Minimum Threat Defense	Details
Upgrade for single-node clusters.	7.2.0	Any	You can now use the device upgrade page (**Devices** > **Device Upgrade**) to upgrade clusters with only one active node. Any deactivated nodes are also upgraded. Previously, this type of upgrade would fail. This feature is not supported from the system updates page (**System** > **Updates**). Hitless upgrades are also not supported in this case. Interruptions to traffic flow and inspection depend on the interface configurations of the lone active unit, just as with standalone devices. Supported platforms: Firepower 4100/9300, Secure Firewall 3100
Revert a successful device upgrade.	7.1.0	7.1.0	You can now revert major and maintenance upgrades to FTD. Reverting returns the software to its state just before the last upgrade, also called a *snapshot*. If you revert an upgrade after installing a patch, you revert the patch as well as the major and/or maintenance upgrade. **Important** If you think you might need to revert, you must use **System** > **Updates** to upgrade FTD. The System Updates page is the only place you can enable the **Enable revert after successful upgrade** option, which configures the system to save a revert snapshot when you initiate the upgrade. This is in contrast to our usual recommendation to use the wizard on the **Devices** > **Device Upgrade** page. This feature is not supported for container instances. Minimum FTD: 7.1
Improvements to the upgrade workflow for clustered and high availability devices.	7.1.0	Any	We made the following improvements to the upgrade workflow for clustered and high availability devices: • The upgrade wizard now correctly displays clustered and high availability units as groups, rather than as individual devices. The system can identify, report, and preemptively require fixes for group-related issues you might have. For example, you cannot upgrade a cluster on the Firepower 4100/9300 if you have made unsynced changes on Firepower Chassis Manager. • We improved the speed and efficiency of copying upgrade packages to clusters and high availability pairs. Previously, the FMC copied the package to each group member sequentially. Now, group members can get the package from each other as part of their normal sync process. • You can now specify the upgrade order of data units in a cluster. The control unit always upgrades last.
Improved FTD upgrade performance and status reporting.	7.0.0	7.0.0	FTD upgrades are now easier faster, more reliable, and take up less disk space. A new **Upgrades** tab in the Message Center provides further enhancements to upgrade status and error reporting.

Feature	Minimum Management Center	Minimum Threat Defense	Details
Easy-to-follow upgrade workflow for FTD devices.	7.0.0	Any	A new device upgrade page (**Devices** > **Device Upgrade**) on the FMC provides an easy-to-follow wizard for upgrading Version 6.4+ FTD devices. It walks you through important pre-upgrade stages, including selecting devices to upgrade, copying the upgrade package to the devices, and compatibility and readiness checks. To begin, use the new **Upgrade Firepower Software** action on the Device Management page **Devices** > **Device Management** > **Selection**. As you proceed, the system displays basic information about your selected devices, as well as the current upgrade-related status. This includes any reasons why you cannot upgrade. If a device does not "pass" a stage in the wizard, it does not appear in the next stage. If you navigate away from wizard, your progress is preserved, although other users with Administrator access can reset, modify, or continue the wizard. **Note** You must still use **System** > **Updates** to upload or specify the location of FTD upgrade packages. You must also use the System Updates page to upgrade the FMC itself, as well as all non-FTD managed devices. **Note** In Version 7.0, the wizard does not correctly display devices in clusters or high availability pairs. Even though you must select and upgrade these devices as a unit, the wizard displays them as standalone devices. Device status and upgrade readiness are evaluated and reported on an individual basis. This means it is possible for one unit to appear to "pass" to the next stage while the other unit or units do not. However, these devices are still grouped. Running a readiness check on one, runs it on all. Starting the upgrade on one, starts it on all. To avoid possible time-consuming upgrade failures, *manually* ensure all group members are ready to move on to the next step of the wizard before you click **Next**.
Upgrade more FTD devices at once.	7.0.0	Any (source) 6.7.0 (target)	The number of devices you can upgrade at once is now limited by your management network bandwidth—not the system's ability to manage simultaneous upgrades. Previously, we recommended against upgrading more than five devices at a time. **Important** Only upgrades to FTD Version 6.7+ using the FTD upgrade wizard see this improvement. If you are upgrading devices to an older FTD release—even if you are using the new upgrade wizard—we still recommend you limit to five devices at a time.

Feature	Minimum Management Center	Minimum Threat Defense	Details
Upgrade different device models together.	7.0.0	Any	You can now use the FTD upgrade wizard to queue and invoke upgrades for all FTD models at the same time, as long as the system has access to the appropriate upgrade packages. Previously, you would choose an upgrade package, then choose the devices to upgrade using that package. That meant that you could upgrade multiple devices at the same time *only* if they shared an upgrade package. For example, you could upgrade two Firepower 2100 series devices at the same time, but not a Firepower 2100 series and a Firepower 1000 series.
Upgrades remove PCAP files to save disk space.	6.7.0	6.7.0	Upgrades now remove locally stored PCAP files. To upgrade, you must have enough free disk space or the upgrade fails.
Improved FTD upgrade status reporting and cancel/retry options.	6.7.0	6.7.0	You can now view the status of FTD device upgrades and readiness checks in progress on the Device Management page, as well as a 7-day history of upgrade success/failures. The Message Center also provides enhanced status and error messages. A new Upgrade Status pop-up, accessible from both Device Management and the Message Center with a single click, shows detailed upgrade information, including percentage/time remaining, specific upgrade stage, success/failure data, upgrade logs, and so on. Also on this pop-up, you can manually cancel failed or in-progress upgrades (**Cancel Upgrade**), or retry failed upgrades (**Retry Upgrade**). Canceling an upgrade reverts the device to its pre-upgrade state. **Note** To be able to manually cancel or retry a failed upgrade, you must disable the new auto-cancel option, which appears when you use the FMC to upgrade an FTD device: **Automatically cancel on upgrade failure and roll back to the previous version**. With the option enabled, the device automatically reverts to its pre-upgrade state upon upgrade failure. Auto-cancel is not supported for patches. In an HA or clustered deployment, auto-cancel applies to each device individually. That is, if the upgrade fails on one device, only that device is reverted. New/modified screens: • **System** > **Updates** > **Product Updates** > **Available Updates** > **Install** icon for the FTD upgrade package • **Devices** > **Device Management** > **Upgrade** • **Message Center** > **Tasks** New/modified CLI commands: **show upgrade status detail**, **show upgrade status continuous**, **show upgrade status**, **upgrade cancel**, **upgrade retry**

Feature	Minimum Management Center	Minimum Threat Defense	Details
Get FTD upgrade packages from an internal web server.	6.6.0	6.6.0	FTD devices can now get upgrade packages from your own internal web server, rather than from the FMC. This is especially useful if you have limited bandwidth between the FMC and its devices. It also saves space on the FMC. **Note** This feature is supported only for FTD devices running Version 6.6+. It is not supported for upgrades *to* Version 6.6, nor is it supported for the FMC or Classic devices. New/modified screens: We added a **Specify software update source** option to the page where you upload upgrade packages.
Copy upgrade packages to managed devices before the upgrade.	6.2.3	Any	You can now copy (or push) an upgrade package from the FMC to a managed device before you run the actual upgrade. This is useful because you can push during times of low bandwidth use, outside of the upgrade maintenance window. When you push to high availability, clustered, or stacked devices, the system sends the upgrade package to the active/control/primary first. Then, it sends the package to the standby/data/secondary. New/modified screens: **System** > **Updates**

Table 6: Firewall Management Center Upgrade Feature History

Feature	Minimum Management Center	Minimum Threat Defense	Details
Hotfix high availability Firewall Management Centers without pausing synchronization.	7.2.6 7.4.1	Any	Unless otherwise indicated by the hotfix release notes or Cisco TAC, you do not have to pause synchronization to install a hotfix on high availability Firewall Management Centers.
New upgrade wizard for the Firewall Management Center.	7.2.6 7.4.1	Any	A new upgrade starting page and wizard make it easier to perform Firewall Management Center upgrades. After you use **System**(⚙) > **Product Upgrades** to get the appropriate upgrade package onto the Firewall Management Center, click **Upgrade** to begin. Version restrictions: Only supported for Firewall Management Center upgrades from Version 7.2.6+/7.4.1+. Not supported for upgrades from Version 7.3.x or 7.4.0. See: Secure Firewall Threat Defense upgrade guides for Firewall Management Center
Updated internet access requirements for direct-downloading software upgrades.	7.2.6 7.4.1	Any	**Upgrade impact. The system connects to new resources.** The Firewall Management Center has changed its direct-download location for software upgrade packages from sourcefire.com to amazonaws.com.

Feature	Minimum Management Center	Minimum Threat Defense	Details
Improved upgrade starting page and package management.	7.2.6 7.4.1	Any	See Improved upgrade starting page and package management.
Suggested release notifications.	7.2.6 7.4.1	Any	See Suggested release notifications.
Firewall Management Center upgrade does not automatically generate troubleshooting files.	7.2.0	Any	To save time and disk space, the Firewall Management Center upgrade process no longer automatically generates troubleshooting files before the upgrade begins. Note that device upgrades are unaffected and continue to generate troubleshooting files. To manually generate troubleshooting files for the Firewall Management Center, choose **System**(⚙) > **Health** > **Monitor**, click **Firewall Management Center** in the left panel, then **View System & Troubleshoot Details**, then **Generate Troubleshooting Files**.
Upgrades postpone scheduled tasks.	6.4.0	Any	The Firewall Management Center upgrade process now postpones scheduled tasks. Any task scheduled to begin during the upgrade will begin five minutes after the post-upgrade reboot. **Note** Before you begin any upgrade, you must still make sure running tasks are complete. Tasks running when the upgrade begins are stopped, become failed tasks, and cannot be resumed. Note that this feature is supported for all upgrades *from* a supported version. This includes Version 6.4.0.10 and later patches, Version 6.6.3 and later maintenance releases, and Version 6.7.0+. This feature is not supported for upgrades *to* a supported version from an unsupported version.