Release Notes for Cisco Catalyst 9500 Series Switches, Cisco IOS XE Bengaluru 17.6.x

First Published: 2021-08-02

Last Modified: 2024-04-06

Release Notes for Cisco Catalyst 9500 Series Switches, Cisco IOS XE Bengaluru 17.6.x

Introduction

Cisco Catalyst 9500 Series Switches and Cisco Catalyst 9500 Series Switches - High Performance are leading, fixed, core and aggregation enterprise switching platforms and have been purpose-built to address emerging trends in security, IoT, mobility, and cloud.

These switches deliver complete convergence in terms of ASIC architecture with Unified Access Data Plane (UADP) 2.0 on Cisco Catalyst 9500 Series Switches and UADP 3.0 on Cisco Catalyst 9500 Series Switches - High Performance. The platform runs an open Cisco IOS XE that supports model-driven programmability. This series forms the foundational building block for Software-Defined Access (SD-Access), which is Cisco's lead enterprise architecture.

Note With the introduction of the High Performance models in the series, there may be differences in the supported and unsupported features, limitations, and caveats that apply to the Cisco Catalyst 9500 Series Switches and Cisco Catalyst 9500 Series Switches - High Performance models. Throughout this release notes document, any such differences are expressly called out. If they are not, the information applies to all the models in the series.

Whats New In Cisco IOS XE Bengaluru 17.6.8

Hardware Features in Cisco IOS XE Bengaluru 17.6.8

There are no new hardware features in this release.

Software Features in Cisco IOS XE Bengaluru 17.6.8

There are no new software features in this release.

Whats New in Cisco IOS XE Bengaluru 17.6.7

Hardware Features in Cisco IOS XE Bengaluru 17.6.7

There are no new hardware features in this release.

Software Features in Cisco IOS XE Bengaluru 17.6.7

There are no new software features in this release.

Whats New in Cisco IOS XE Bengaluru 17.6.6a

There are no new features in this release. This release provides a fix for CSCwh87343: Cisco IOS XE Software Web UI Privilege Escalation Vulnerability. For more information, see Security Advisory: cisco-sa-iosxe-webui-privesc-j22SaA4z.

Whats New in Cisco IOS XE Bengaluru 17.6.6

Hardware Features in Cisco IOS XE Bengaluru 17.6.6

There are no new hardware features in this release.

Software Features in Cisco IOS XE Bengaluru 17.6.6

There are no new software features in this release.

Whats New in Cisco IOS XE Bengaluru 17.6.5

Hardware Features in Cisco IOS XE Bengaluru 17.6.5

There are no new hardware features in this release.

Software Features in Cisco IOS XE Bengaluru 17.6.5

There are no new software features in this release.

Whats New in Cisco IOS XE Bengaluru 17.6.4

Hardware Features in Cisco IOS XE Bengaluru 17.6.4

Table 1: Hardware Features Introduced on Cisco Catalyst 9500 Series and High Performance Switches

Feature Name	Description and Documentation Link
650-W AC Power Supply Module (C9K-PWR-650WACL-R)	Compatible switch models: C9500-32QC, C9500-24Y4C, C9500-48Y4C For information about the hardware including installation and technical specifications, see the Cisco Catalyst 9500 Series Switches Hardware Installation Guide.

Software Features in Cisco IOS XE Bengaluru 17.6.4

There are no new software features in this release.

Whats New in Cisco IOS XE Bengaluru 17.6.3

Hardware Features in Cisco IOS XE Bengaluru 17.6.3

There are no new hardware features in this release.

Software Features in Cisco IOS XE Bengaluru 17.6.3

There are no new software features in this release.

Whats New in Cisco IOS XE Bengaluru 17.6.2

Hardware Features in Cisco IOS XE Bengaluru 17.6.2

There are no new hardware features in this release.

Software Features in Cisco IOS XE Bengaluru 17.6.2

- Software Features Introduced on All Models
- Software Features Introduced on Cisco Catalyst 9500 Series Switches
- Software Features Introduced on Cisco Catalyst 9500 Series Switches-High Performance

Software Features Introduced on All Models

Feature Name	Description and License Level Information
Data MDT Support for L3 TRM	Introduces support for data multicast distribution tree (MDT) for Layer 3 Tenant Routed Multicast (TRM). Data MDTs are purpose built underlay MDTs to provide optimized forwarding in the MVPN and EVPN core. See BGP EVPN VXLAN → Configuring Tenant Routed Multicast. (Network Advantage)

New on the WebUI
There are no new features on the Web UI in this release.

Serviceability
There are no new serviceability features in this release.

Software Features Introduced on Cisco Catalyst 9500 Series Switches

See Software Features Introduced on All Models for features in this release on Cisco Catalyst 9500 Series Switches.

Software Features Introduced on Cisco Catalyst 9500 Series Switches-High Performance

See Software Features Introduced on All Models for features in this release on Cisco Catalyst 9500 Series Switches.

Whats New in Cisco IOS XE Bengaluru 17.6.1

Hardware Features in Cisco IOS XE Bengaluru 17.6.1

Table 2: Hardware Features Introduced on Cisco Catalyst 9500 Series and High Performance Switches

Feature Name	Description and Documentation Link
10GBASE-CU SFP+ Cable	• Supported cable product numbers: SFP-H10GB-CU4M • Compatible switch models: C9500-24Y4C, C9500-48Y4C For information about these cables, see Cisco 10GBASE SFP+ Modules Data Sheet. For information about device compatibility, see the Transceiver Module Group (TMG) Compatibility Matrix.

Software Features in Cisco IOS XE Bengaluru 17.6.1

• Software Features Introduced on All Models, on page 5

• Software Features Introduced on Cisco Catalyst 9500 Series Switches, on page 7
• Software Features Introduced on Cisco Catalyst 9500 Series Switches-High Performance, on page 7

Software Features Introduced on All Models

Feature Name	Description and License Level Information
IEEE 1588v2 PTP interoperability with MACsec and EtherChannel	Introduces support for PTP with MACsec and EtherChannel interface. (DNA Advantage)
IPv6 Explicit Null Label	Allows you to use IPv6 Explicit Null Label as a VPN label to exchange IPv6 reachability information over the MPLS core. The label has a value of 2. (Network Advantage)
LACP and PAGP over EoMPLS	Allows forwarding of Link Aggregation Control Protocol (LACP) and Port Aggregation Protocol (PAgP) packets over Ethernet-over-MPLS (EoMPLS) pseudowire in the port mode. (Network Advantage)
MLD Snooping over VPLS	Introduces support for Multicast Listener Discovery (MLD) Snooping over Virtual Private LAN Services (VPLS). This feature allows traffic to be forwarded over pseudowires that receive Internet Group Management Protocol (IGMP) or MLD reports from remote provider edge (PE) devices. (Network Advantage)
MPLS Traffic Engineering • IP Explicit Address Exclusion • LSP Attributes • Bundled Interface • Configurable Path Calculation Metric for Tunnels	Multiprotocol Label Switching (MPLS) Traffic Engineering (TE) provides an integrated approach to traffic engineering by incorporating capabilities of Layer 2 into Layer 3. • IP Explicit Address Exclusion: Provides a means to exclude a link or node from the path for MPLS TE label switched path (LSP). • LSP Attributes: Provides an LSP Attribute List feature and a Path Option for Bandwidth Override feature. • Bundled Interface: Enables MPLS Traffic Engineering tunnels over the bundled interfaces, EtherChannel and Gigabit EtherChannel. • Configurable Path Calculation Metric for Tunnels: Enables the user to control the metric used in path calculation for traffic engineering tunnels on a per-tunnel basis. (Network Advantage)

Feature Name	Description and License Level Information
Programmability • NETCONF Access from Guest Shell • YANG Data Models	The following programmability features are introduced in this release: • NETCONF Access from Guest Shell: Introduces support for accessing NETCONF from within the Guest Shell, to run Python scripts and invoke Cisco-custom package CLIs using the NETCONF protocol. (DNA Essentials and DNA Advantage) • YANG Data Models: For the list of Cisco IOS XE YANG models available with this release, navigate to: https://github.com/YangModels/yang/tree/master/vendor/cisco/xe/1761. Revision statements embedded in the YANG files indicate if there has been a model revision. The README.md file in the same GitHub location highlights changes that have been made in the release.

New on the WebUI	
BFD Echo Mode for OSPFv3	Provides a mechanism to detect failures in the network between two adjacent switches, including the interfaces, data links, and forwarding planes. This feature can be configured globally, or per interface.
SDM Templates	Introduces device specific custom SDM templates that help to optimise the use of physical resources on the device.
WCCP - VRF support	Introduces support for virtual routing and forwarding (VRF) with Web Cache Communication Protocol (WCCP).

Serviceability	
match device-type regex *regular-expression*	The command was modified. **regex** keyword was introduced. It allows you to define a regular expression for the device type.
protocol **tlv-type** *number* **value** {*string* | *integer* | {**regex** *regular-expression*}}	The command was modified. **regex** keyword was introduced. It allows you to define a regular expression for the Type-Length-Value (TLV).
show consistency-checker	The command was modified. The following keywords were introduced: • **mcast**: Runs the consistency-checker on the multicast forwarding tables • **objects**: Runs the consistency-checker on objects • **run-id**: Runs the consistency-checker by run ID
show platform software fed switch punt packet-capture cpu-top-talker	The command was modified. **cpu-top-talker** keyword was introduced. It displays the occurrences of an attribute of a packet capture.

Software Features Introduced on Cisco Catalyst 9500 Series Switches

See Software Features Introduced on All Models, on page 5 for features in this release on Cisco Catalyst 9500 Series Switches.

Software Features Introduced on Cisco Catalyst 9500 Series Switches-High Performance

Serviceability	
show platform nat translations	The command was introduced. It records and displays all NAT sessions for monitoring and troubleshooting.
show platform nat translations statistics	The command was introduced. It displays current NAT statistics, including the NAT active sessions.

Important Notes

- Cisco StackWise Virtual: Supported and Unsupported Features, on page 7
- Unsupported Features: All Models, on page 7
- Unsupported Features: Cisco Catalyst 9500 Series Switches, on page 8
- Unsupported Features: Cisco Catalyst 9500 Series Switches - High Performance, on page 8
- Complete List of Supported Features, on page 8
- Accessing Hidden Commands, on page 8
- Default Behaviour—All Models, on page 9
- Default Interface Behaviour on Cisco Catalyst 9500 Series Switches - High Performance Only, on page 9

Cisco StackWise Virtual: Supported and Unsupported Features

The following is a list of features that are supported or unsupported when you enable Cisco StackWise Virtual on a device:

- Layer 2, Layer 3, Security, Quality of Service, Multicast, Application, Monitoring and Management, Multiprotocol Label Switching, High Availability, BGP EVPN VXLAN, Remote Switched Port Analyzer, and Sofware Defined Access are supported.

  Contact the Cisco Technical Support Centre for the specific list of features that are supported under each one of these technologies.

Unsupported Features: All Models

- IPsec VPN
- Performance Monitoring (PerfMon)
- Virtual Routing and Forwarding-Aware (VRF-Aware) web authentication

Unsupported Features: Cisco Catalyst 9500 Series Switches

- Border Gateway Protocol (BGP) Additional Paths
- Cisco TrustSec Network Device Admission Control (NDAC) on Uplinks
- Flexible NetFlow: NetFlow v5 Export Protocol, 4-byte (32-bit) AS Number Support, TrustSec NetFlow IPv4 Security Group Access Control List (SGACL) Deny and Drop Export
- Lawful Intercept
- PIM Bidirectional Forwarding Detection (PIM BFD), PIM Snooping.
- QinQ VLAN Mapping
- Quality of Service: Classification (Layer 3 Packet Length, Time-to-Live (TTL)), per queue policer support, sharped profile enablement for egress per port queue, L2 Miss, Ingress Packet FIFO (IPF)
- Unicast over Point-to-Multipoint (P2MP) Generic Routing Encapsulation (GRE), Multicast over P2MP GRE.

Unsupported Features: Cisco Catalyst 9500 Series Switches - High Performance

- Cisco Application Visibility and Control (AVC)
- Flexlink+
- VLAN Load Balancing for FlexLink+
- Preemption for VLAN Load Balancing
- FlexLink+ Dummy Multicast Packets
- MPLS Label Distribution Protocol (MPLS LDP) VRF-Aware Static Labels
- Network-Based Application Recognition (NBAR) and Next-Generation NBAR (NBAR2)
- QoS Options on GRE Tunnel Interfaces
- Resilient Ethernet Protocol (REP)

Complete List of Supported Features

For the complete list of features supported on a platform, see the Cisco Feature Navigator at: https://cfnng.cisco.com.

Choose the following in the context of the Cisco Catalyst 9500 Series Switches:

- CAT9500: to see all the features supported on the C9500-12Q, C9500-16X, C9500-24Q, C9500-40X models
- CAT9500 HIGH PERFORMANCE (32C; 32QC; 48Y4C; 24Y4C): to see all the features supported on the C9500-24Y4C, C9500-32C, C9500-32QC, and C9500-48Y4C models

Accessing Hidden Commands

From Cisco IOS XE Fuji 16.8.1a, as an improved security measure, the way in which hidden commands can be accessed has changed.

Hidden commands have always been present in Cisco IOS XE, but were not equipped with CLI help. That is, entering a question mark (?) at the system prompt did not display the list of available commands. Hidden commands are only meant to assist Cisco TAC in advanced troubleshooting, and are not documented either.

From Cisco IOS XE Fuji 16.8.1a, hidden commands are available under:

- Category 1: Hidden commands in Privileged or User EXEC mode. Enter the **service internal** command to access these commands.
- Category 2: Hidden commands in one of the configuration modes (global, interface, and so on).

Further, the following points apply to hidden commands under Category 1 and 2:

- The commands have CLI help. Enter a question mark (?) at the system prompt to display the list of available commands.

  Note: For Category 1, enter the **service internal** command before you enter the question mark; you do not have to do this for Category 2.

- The system generates a `%PARSER-5-HIDDEN` syslog message when a hidden command is used. The following is an example:

```
*Feb 14 10:44:37.917: %PARSER-5-HIDDEN: Warning!!! 'show processes memory old-header '
 is a hidden command.
Use of this command is not recommended/supported and will be removed in future.
```

Apart from categories 1 and 2, there are other internal commands displayed on the CLI, for which the system does *not* generate the `%PARSER-5-HIDDEN` syslog message.

Note We recommend that you use any hidden command only under TAC supervision.

If you find that you need to use a hidden command, open a TAC case for help with finding another way of collecting the same information as the hidden command (for a hidden EXEC mode command), or to configure the same functionality (for a hidden configuration mode command) using nonhidden commands.

Default Behaviour—All Models

Beginning from Cisco IOS XE Gibraltar 16.12.5 and later, do not fragment bit (DF bit) in the IP packet is always set to 0 for all outgoing RADIUS packets (packets that originate from the device towards the RADIUS server).

Default Interface Behaviour on Cisco Catalyst 9500 Series Switches - High Performance Only

From Cisco IOS XE Gibraltar 16.11.1, the default interface for all High Performance models in the series changes from Layer 3 to Layer 2. Use the **no switchport** command to change the Layer 2 interface into Layer 3 mode.

The startup configuration has explicit configuration of the **switchport** command for Layer 2 interfaces and the **no switchport** command for Layer 3 interfaces to address this change in behaviour and to support seamless migration.

Supported Hardware

Cisco Catalyst 9500 Series Switches—Model Numbers

The following table lists the supported hardware models and the default license levels they are delivered with. For more information about the available license levels, see section *License Levels*.

Base PIDs are the model numbers of the switch.

Bundled PIDs indicate the orderable part numbers for base PIDs that are bundled with a particular network module. Entering the **show version**, **show module**, or **show inventory** commands on such a switch (bundled PID), displays its base PID.

Table 3: Cisco Catalyst 9500 Series Switches

Switch Model	Default License Level	Description
Base PIDs		
C9500-12Q-E	Network Essentials	12 40-Gigabit Ethernet QSFP+ ports and two power supply slots
C9500-12Q-A	Network Advantage	
C9500-16X-E	Network Essentials	16 1/10-Gigabit Ethernet SFP/SFP+ ports and two power supply slots
C9500-16X-A	Network Advantage	
C9500-24Q-E	Network Essentials	24-Port 40-Gigabit Ethernet QSFP+ ports and two power supply slots
C9500-24Q-A	Network Advantage	
C9500-40X-E	Network Essentials	40 1/10-Gigabit Ethernet SFP/SFP+ ports and two power supply slots
C9500-40X-A	Network Advantage	
Bundled PIDs		
C9500-16X-2Q-E	Network Essentials	16 10-Gigabit Ethernet SFP+ port switch and a 2-Port 40-Gigabit Ethernet (QSFP) network module on uplink ports
C9500-16X-2Q-A	Network Advantage	
C9500-24X-E	Network Essentials	16 10-Gigabit Ethernet SFP+ port switch and an 8-Port 10-Gigabit Ethernet (SFP) network module on uplink ports
C9500-24X-A	Network Advantage	
C9500-40X-2Q-E	Network Essentials	40 10-Gigabit Ethernet SFP+ port switch and a 2-Port 40-Gigabit Ethernet (QSFP) network module on uplink ports
C9500-40X-2Q-A	Network Advantage	
C9500-48X-E	Network Essentials	40 10-Gigabit Ethernet SFP+ port switch and an 8-Port 10-Gigabit Ethernet (SFP) network module on uplink ports
C9500-48X-A	Network Advantage	

Table 4: Cisco Catalyst 9500 Series Switches-High Performance

Switch Model	Default License Level	Description
C9500-24Y4C-E	Network Essentials	24 SFP28 ports that support 1/10/25-GigabitEthernet connectivity, four QSFP uplink ports that support 100/40-GigabitEthernet connectivity; two power supply slots.
C9500-24Y4C-A	Network Advantage	
C9500-32C-E	Network Essentials	32 QSFP28 ports that support 40/100 GigabitEthernet connectivity; two power supply slots.
C9500-32C-A	Network Advantage	
C9500-32QC-E	Network Essentials	32 QSFP28 ports, where you can have 24 ports that support 40-GigabitEthernet connectivity and 4 ports that support 100-GigabitEthernet connectivity, OR 32 ports that support 40-GigabitEthernet connectivity, OR 16 ports that support 100-GigabitEthernet connectivity; two power supply slots.
C9500-32QC-A	Network Advantage	
C9500-48Y4C-E	Network Essentials	48 SFP28 ports that support 1/10/25-GigabitEthernet connectivity; four QSFP uplink ports that supports up to 100/40-GigabitEthernet connectivity; two power supply slots.
C9500-48Y4C-A	Network Advantage	

Network Modules

The following table lists optional network modules for uplink ports available with some configurations .

Network Module	Description
C9500-NM-8X	Cisco Catalyst 9500 Series Network Module 8-port 1/10 Gigabit Ethernet with SFP/SFP+ Note the supported switch models (Base PIDs): • C9500-40X • C9500-16X
C9500-NM-2Q	Cisco Catalyst 9500 Series Network Module 2-port 40 Gigabit Ethernet with QSFP+ Note the supported switch models (Base PIDs): • C9500-40X • C9500-16X

Optics Modules

Cisco Catalyst Series Switches support a wide range of optics and the list of supported optics is updated on a regular basis. Use the Transceiver Module Group (TMG) Compatibility Matrix tool, or consult the tables

at this URL for the latest transceiver module compatibility information: https://www.cisco.com/en/US/products/hw/modules/ps5455/products_device_support_tables_list.html

Compatibility Matrix

To view the software compatibility information between Cisco Catalyst 9500 Series Switches, Cisco Identity Services Engine, and Cisco Prime Infrastructure, go to Cisco Catalyst 9000 Series Switches Software Version Compatibility Matrix.

Web UI System Requirements

The following subsections list the hardware and software required to access the Web UI:

Minimum Hardware Requirements

Processor Speed	DRAM	Number of Colors	Resolution	Font Size
233 MHz minimum[1]	512 MB[2]	256	1280 x 800 or higher	Small

1 We recommend 1 GHz
2 We recommend 1 GB DRAM

Software Requirements

Operating Systems

- Windows 10 or later
- Mac OS X 10.9.5 or later

Browsers

- Google Chrome—Version 59 or later (On Windows and Mac)
- Microsoft Edge
- Mozilla Firefox—Version 54 or later (On Windows and Mac)
- Safari—Version 10 or later (On Mac)

ROMMON Versions

ROMMON, also known as the boot loader, is firmware that runs when the device is powered up or reset. It initializes the processor hardware and boots the operating system software (Cisco IOS XE software image). The ROMMON is stored on the following Serial Peripheral Interface (SPI) flash devices on your switch:

- Primary: The ROMMON stored here is the one the system boots every time the device is powered-on or reset.

- Golden: The ROMMON stored here is a backup copy. If the one in the primary is corrupted, the system automatically boots the ROMMON in the golden SPI flash device.

ROMMON upgrades may be required to resolve firmware defects, or to support new features, but there may not be new versions with every release.

The following table provides ROMMON version information for the Cisco Catalyst 9500 Series Switches. For ROMMON version information of Cisco IOS XE 16.x.x releases, refer to the corresponding Cisco IOS XE 16.x.x release notes of the respective platform.

Release	ROMMON Version (C9500-12Q, C9500-24Q, C9500-16X, C9500-40X)	ROMMON Version (C9500-32C, C9500-32QC, C9500-24Y4C, C9500-48Y4C)	ROMMON Version (C9500X)
Bengaluru 17.6.8	17.6.1r[FC1]	17.6.1r	-
Bengaluru 17.6.7	17.6.1r[FC1]	17.6.1r	-
Bengaluru 17.6.6a	17.6.1r[FC1]	17.6.1r	-
Bengaluru 17.6.6	17.6.1r[FC1]	17.6.1r	-
Bengaluru 17.6.5	17.6.1r[FC1]	17.6.1r	-
Bengaluru 17.6.4	17.6.1r[FC1]	17.6.1r	-
Bengaluru 17.6.3	17.6.1r[FC1]	17.6.1r	-
Bengaluru 17.6.2	17.6.1r[FC1]	17.6.1r	-
Bengaluru 17.6.1	17.6.1r[FC1]	17.6.1r	-
Bengaluru 17.5.1	17.5.1r	17.3.1r[FC2]	-
Bengaluru 17.4.1	17.4.1r	17.3.1r[FC2]	-
Amsterdam 17.3.8a	17.3.1r[FC2]	17.3.1r[FC2]	-
Amsterdam 17.3.8	17.3.1r[FC2]	17.3.1r[FC2]	-
Amsterdam 17.3.7	17.3.1r[FC2]	17.3.1r[FC2]	-
Amsterdam 17.3.6	17.3.1r[FC2]	17.3.1r[FC2]	-
Amsterdam 17.3.5	17.3.1r[FC2]	17.3.1r[FC2]	-
Amsterdam 17.3.4	17.3.1r[FC2]	17.3.1r[FC2]	-
Amsterdam 17.3.3	17.3.1r[FC2]	17.3.1r[FC2]	-
Amsterdam 17.3.2a	17.3.1r[FC2]	17.3.1r[FC2]	-
Amsterdam 17.3.1	17.3.1r[FC2]	17.3.1r[FC2]	-
Amsterdam 17.2.1	17.2.1r[FC1]	17.1.1[FC2]	-

Release	ROMMON Version (C9500-12Q, C9500-24Q, C9500-16X, C9500-40X)	ROMMON Version (C9500-32C, C9500-32QC, C9500-24Y4C, C9500-48Y4C)	ROMMON Version (C9500X)
Amsterdam 17.1.1	17.1.1r [FC1]	17.1.1[FC1]	-

Upgrading the Switch Software

This section covers the various aspects of upgrading or downgrading the device software.

Note You cannot use the Web UI to install, upgrade, or downgrade device software.

Finding the Software Version

The package files for the Cisco IOS XE software are stored on the system board flash device (flash:).

You can use the **show version** privileged EXEC command to see the software version that is running on your switch.

Note Although the **show version** output always shows the software image running on the switch, the model name shown at the end of this display is the factory configuration and does not change if you upgrade the software license.

You can also use the **dir** *filesystem:* privileged EXEC command to see the directory names of other software images that you might have stored in flash memory.

Software Images

Release	Image Type	File Name
Cisco IOS XE Bengaluru 17.6.8	CAT9K_IOSXE	cat9k_lite_iosxe.17.06.08.SPA
	No Payload Encryption (NPE)	cat9k_iosxe_npe.17.06.08.SPA
Cisco IOS XE Bengaluru 17.6.7	CAT9K_IOSXE	cat9k_iosxe.17.06.07.SPA.bin
	No Payload Encryption (NPE)	cat9k_iosxe_npe.17.06.07.SPA
Cisco IOS XE Bengaluru 17.6.6a	CAT9K_IOSXE	cat9k_iosxe.17.06.06a.SPA.bin
	No Payload Encryption (NPE)	cat9k_iosxe_npe.17.06.06a.SP
Cisco IOS XE Bengaluru 17.6.6	CAT9K_IOSXE	cat9k_iosxe.17.06.06.SPA.bin
	No Payload Encryption (NPE)	cat9k_iosxe_npe.17.06.06.SPA

Release	Image Type	File Name
Cisco IOS XE Bengaluru 17.6.5	CAT9K_IOSXE	cat9k_iosxe.17.06.05.SPA.
	No Payload Encryption (NPE)	cat9k_iosxe_npe.17.06.05.
Cisco IOS XE Bengaluru 17.6.4	CAT9K_IOSXE	cat9k_iosxe.17.06.04.SPA.
	No Payload Encryption (NPE)	cat9k_iosxe_npe.17.06.04.
Cisco IOS XE Bengaluru 17.6.3	CAT9K_IOSXE	cat9k_iosxe.17.06.03.SPA.
	No Payload Encryption (NPE)	cat9k_iosxe_npe.17.06.03.
Cisco IOS XE Bengaluru 17.6.2	CAT9K_IOSXE	cat9k_iosxe.17.06.02.SPA.
	No Payload Encryption (NPE)	cat9k_iosxe_npe.17.06.02.
Cisco IOS XE Bengaluru 17.6.1	CAT9K_IOSXE	cat9k_iosxe.17.06.01.SPA.
	No Payload Encryption (NPE)	cat9k_iosxe_npe.17.06.01.

Upgrading the ROMMON

To know the ROMMON or bootloader version that applies to every major and maintenance release, see ROMMON Versions, on page 12.

You can upgrade the ROMMON before, or, after upgrading the software version. If a new ROMMON version is available for the software version you are upgrading to, proceed as follows:

- Upgrading the ROMMON in the primary SPI flash device

  On the C9500-12Q, C9500-16X, C9500-24Q, C9500-40X models of the series, *you must manually upgrade* the ROMMON in the primary SPI flash device, if a new version is applicable, and the release you are upgrading *from* is Cisco IOS XE Gibraltar 16.12.1 or a later release. (So if you upgrade from Cisco IOS XE Gibraltar 16.11.1 for example, a manual upgrade does not apply; the ROMMON is automatically updated, if applicable). Enter the **upgrade rom-monitor capsule primary switch** command in privileged EXEC mode.

  On the C9500-24Y4C, C9500-32C, C9500-32QC, and C9500-48Y4C models of the series, this ROMMON is upgraded automatically. When you upgrade from an existing release on your switch to a later or newer release for the first time, and there is a new ROMMON version in the new release, the system automatically upgrades the ROMMON in the primary SPI flash device, based on the hardware version of the switch.

- Upgrading the ROMMON in the golden SPI flash device

  You must manually upgrade this ROMMON. The manual upgrade applies to all models in the series. Enter the **upgrade rom-monitor capsule golden switch** command in privileged EXEC mode.

Note

- In case of a Cisco StackWise Virtual setup, upgrade the active and standby switch.

After the ROMMON is upgraded, it will take effect on the next reload. If you go back to an older release after this, the ROMMON is not downgraded. The updated ROMMON supports all previous releases.

Software Installation Commands

Summary of Software Installation Commands **Supported starting from Cisco IOS XE Everest 16.6.2 and later releases**	
To install and activate the specified file, and to commit changes to be persistent across reloads: **`install add file`** *`filename`* [**`activate commit`**] To separately install, activate, commit, cancel, or remove the installation file: **`install ?`**	
add file tftp: *filename*	Copies the install file package from a remote location to the device and performs a compatibility check for the platform and image versions.
activate [**auto-abort-timer**]	Activates the file, and reloads the device. The **auto-abort-timer** keyword automatically rolls back image activation.
commit	Makes changes persistent over reloads.
rollback to committed	Rolls back the update to the last committed version.
abort	Cancels file activation, and rolls back to the version that was running before the current installation procedure started.
remove	Deletes all unused and inactive software installation files.

Note The **request platform software** commands are deprecated starting from Cisco IOS XE Gibraltar 16.10.1. The commands are visible on the CLI in this release and you can configure them, but we recommend that you use the **install** commands to upgrade or downgrade.

Summary of request platform software Commands **Note** **This table of commands is not supported on Cisco Catalyst 9500 Series Switches - High Performance.**	
`Device# request platform software package ?`	
clean	Cleans unnecessary package files from media
copy	Copies package to media
describe	Describes package content
expand	Expands all-in-one package to media
install	Installs the package
uninstall	Uninstalls the package

Summary of request platform software Commands Note This table of commands is not supported on Cisco Catalyst 9500 Series Switches - High Performance.	
verify	Verifies In Service Software Upgrade (ISSU) software package compatibility

Upgrading in Install Mode

Follow these instructions to upgrade from one release to another, using **install** commands, in install mode. To perform a software image upgrade, you must be booted into IOS through **boot flash:packages.conf**.

Before you begin

When upgrading from ...	Use these commands...	To upgrade to...
Cisco IOS XE Everest 16.5.1a or Cisco IOS XE Everest 16.6.1	Only **request platform software** commands	Cisco IOS XE Bengaluru 17.6.1
Cisco IOS XE Everest 16.6.2 and all later releases	On Cisco Catalyst 9500 Series Switches, either **install** commands or **request platform software** commands[3]. On Cisco Catalyst 9500 Series Switches - High Performance, only install commands[4].	

[3] The **request platform software** commands are deprecated. So although they are still visible on the CLI, we recommend that you use **install** commands.
[4] Introduced in Cisco IOS XE Fuji 16.8.1a.

The sample output in this section displays upgrade from Cisco IOS XE Bengaluru 17.5.1 to Cisco IOS XE Bengaluru 17.6.1 using **install** commands only.

Procedure

Step 1 Clean-up

install remove inactive

Use this command to clean-up old installation files in case of insufficient space and to ensure that you have at least 1GB of space in flash, to expand a new image.

The following sample output displays the cleaning up of unused files, by using the **install remove inactive** command:

```
Switch# install remove inactive
install_remove: START Wed Jul 21 19:51:48 UTC 2021
Cleaning up unnecessary package files
Scanning boot directory for packages ... done.
Preparing packages list to delete ...
    cat9k-cc_srdriver.17.05.01.SPA.pkg
```

```
      File is in use, will not delete.
    cat9k-espbase.17.05.01.SPA.pkg
      File is in use, will not delete.
    cat9k-guestshell.17.05.01.SPA.pkg
      File is in use, will not delete.
    cat9k-rpbase.17.05.01.SPA.pkg
      File is in use, will not delete.
    cat9k-rpboot.17.05.01.SPA.pkg
      File is in use, will not delete.
    cat9k-sipbase.17.05.01.SPA.pkg
      File is in use, will not delete.
    cat9k-sipspa.17.05.01.SPA.pkg
      File is in use, will not delete.
    cat9k-srdriver.17.05.01.SPA.pkg
      File is in use, will not delete.
    cat9k-webui.17.05.01.SPA.pkg
      File is in use, will not delete.
    cat9k-wlc.17.05.01.SPA.pkg
      File is in use, will not delete.
    packages.conf
      File is in use, will not delete.
  done.
The following files will be deleted:
[R0]:
/flash/cat9k-cc_srdriver.17.05.01.SPA.pkg
/flash/cat9k-espbase.17.05.01.SPA.pkg
/flash/cat9k-guestshell.17.05.01.SPA.pkg
/flash/cat9k-rpbase.17.05.01.SPA.pkg
/flash/cat9k-rpboot.17.05.01.SPA.pkg
/flash/cat9k-sipbase.17.05.01.SPA.pkg
/flash/cat9k-sipspa.17.05.01.SPA.pkg
/flash/cat9k-srdriver.17.05.01.SPA.pkg
/flash/cat9k-webui.17.05.01.SPA.pkg
/flash/cat9k-wlc.17.05.01.SPA.pkg
/flash/packages.conf

Do you want to remove the above files? [y/n]y
[R0]:
Deleting file flash:cat9k-cc_srdriver.17.05.01.SPA.pkg ... done.
Deleting file flash:cat9k-espbase.17.05.01.SPA.pkg ... done.
Deleting file flash:cat9k-guestshell.17.05.01.SPA.pkg ... done.
Deleting file flash:cat9k-rpbase.17.05.01.SPA.pkg ... done.
Deleting file flash:cat9k-rpboot.17.05.01.SPA.pkg ... done.
Deleting file flash:cat9k-sipbase.17.05.01.SPA.pkg ... done.
Deleting file flash:cat9k-sipspa.17.05.01.SPA.pkg ... done.
Deleting file flash:cat9k-srdriver.17.05.01.SPA.pkg ... done.
Deleting file flash:cat9k-webui.17.05.01.SPA.pkg ... done.
Deleting file flash:cat9k-wlc.17.05.01.SPA.pkg ... done.
Deleting file flash:packages.conf ... done.
SUCCESS: Files deleted.
--- Starting Post_Remove_Cleanup ---
Performing Post_Remove_Cleanup on all members
[1] Post_Remove_Cleanup package(s) on switch 1
[1] Finished Post_Remove_Cleanup on switch 1
Checking status of Post_Remove_Cleanup on [1]
Post_Remove_Cleanup: Passed on [1]
Finished Post_Remove_Cleanup

SUCCESS: install_remove Wed Jul 21 19:52:25 UTC 2021
Switch#
```

Step 2 Copy new image to flash

a) **copy tftp:***[[//location]/directory]/filename***flash:**

Use this command to copy the new image from a TFTP server to flash memory. The location is either an IP address or a host name. The filename is specified relative to the directory used for file transfers. Skip this step if you want to use the new image from a TFTP server.

```
Switch# copy tftp://10.8.0.6/image/cat9k_iosxe.17.06.01.SPA.bin flash:
destination filename [cat9k_iosxe.17.06.01.SPA.bin]?
Accessing tftp://10.8.0.6/image/cat9k_iosxe.17.06.01.SPA.bin...
Loading /cat9k_iosxe.17.06.01.SPA.bin from 10.8.0.6 (via GigabitEthernet0/0):
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
[OK - 601216545 bytes]

601216545 bytes copied in 50.649 secs (11870255 bytes/sec)
```

b) **dir flash:**

Use this command to confirm that the image has been successfully copied to flash.

```
Switch# dir flash:*.bin
Directory of flash:/*.bin

Directory of flash:/

434184 -rw- 601216545    Jul 23 2021 10:18:11 -07:00 cat9k_iosxe.17.06.01.SPA.bin
11353194496 bytes total (8976625664 bytes free)
```

Step 3 Set boot variable

a) **boot system flash:packages.conf**

Use this command to set the boot variable to **flash:packages.conf**.

```
Switch(config)# boot system flash:packages.conf
```

b) **no boot manual**

Use this command to configure the switch to auto-boot. Settings are synchronized with the standby switch, if applicable.

```
Switch(config)# no boot manual
Switch(config)# exit
```

c) **write memory**

Use this command to save boot settings.

```
Switch# write memory
```

d) **show bootvar** or **show boot**

Use this command to verify the boot variable (packages.conf) and manual boot setting (no):

```
Switch# show bootvar               <<on the C9500-24Y4C,C9500-32C, C9500-32QC, and
C9500-48Y4C models
BOOT variable = bootflash:packages.conf
MANUAL_BOOT variable = no
BAUD variable = 9600
ENABLE_BREAK variable = yes
BOOTMODE variable does not exist
IPXE_TIMEOUT variable does not exist
CONFIG_FILE variable =

Standby BOOT variable = bootflash:packages.conf
Standby MANUAL_BOOT variable = no
```

```
Standby BAUD variable = 9600
Standby ENABLE_BREAK variable = yes
Standby BOOTMODE variable does not exist
Standby IPXE_TIMEOUT variable does not exist
Standby CONFIG_FILE variable =

Switch# show boot                          <<on the C9500-12Q,C9500-16X C9500-24Q, and
C9500-40X models
Current Boot Variables:
BOOT variable = flash:packages.conf;

Boot Variables on next reload:
BOOT variable = flash:packages.conf;
Manual Boot = no
Enable Break = yes
Boot Mode = DEVICE
iPXE Timeout = 0
```

Step 4 Install image to flash

install add file activate commit

Use this command to install the image.

We recommend that you point to the source image on your TFTP server or the flash drive of the *active* switch, if you have copied the image to flash memory. If you point to an image on the flash or USB drive of a member switch (instead of the active), you must specify the exact flash or USB drive - otherwise installation fails. For example, if the image is on the flash drive of member switch 3 (flash-3): `Switch# install add file flash-3:cat9k_iosxe.17.06.01.SPA.bin activate commit`.

The following sample output displays installation of the Cisco IOS XE Bengaluru 17.6.1 software image in the flash memory:

```
Switch# install add file flash:cat9k_iosxe.17.06.01.SPA.bin activate commit
install_add_activate_commit: Adding PACKAGE
install_add_activate_commit: Checking whether new add is allowed ....
--- Starting Add ---
Performing Add on Active/Standby
 [1] Add package(s) on R0
 [1] Finished Add on R0

Checking status of Add on [R0]
Add: Passed on [R0]
Finished Add

Image added. Version: 17.6.01

install_add_activate_commit: Activating PACKAGE
Following packages shall be activated:
/flash/cat9k-wlc.17.06.01.SPA.pkg
/flash/cat9k-webui.17.06.01.SPA.pkg
/flash/cat9k-srdriver.17.06.01.SPA.pkg
/flash/cat9k-sipspa.17.06.01.SPA.pkg
/flash/cat9k-sipbase.17.06.01.SPA.pkg
/flash/cat9k-rpboot.17.06.01.SPA.pkg
/flash/cat9k-rpbase.17.06.01.SPA.pkg
/flash/cat9k-guestshell.17.06.01.SPA.pkg
/flash/cat9k-espbase.17.06.01.SPA.pkg
/flash/cat9k-cc_srdriver.17.06.01.SPA.pkg

This operation may require a reload of the system. Do you want to proceed? [y/n] y

--- Starting Activate ---
```

```
Performing Activate on Active/Standby
[1] Activate package(s) on R0
    --- Starting list of software package changes ---
    Old files list:
      Removed cat9k-cc_srdriver.17.05.01.SPA.pkg
      Removed cat9k-espbase.17.05.01.SPA.pkg
      Removed cat9k-guestshell.17.05.01.SPA.pkg
      Removed cat9k-rpbase.17.05.01.SPA.pkg
      Removed cat9k-rpboot.17.05.01.SPA.pkg
      Removed cat9k-sipbase.17.05.01.SPA.pkg
      Removed cat9k-sipspa.17.05.01.SPA.pkg
      Removed cat9k-srdriver.17.05.01.SPA.pkg
      Removed cat9k-webui.17.05.01.SPA.pkg
      Removed cat9k-wlc.17.05.01.SPA.pkg
    New files list:
      Added cat9k-cc_srdriver.17.06.01.SSA.pkg
      Added cat9k-espbase.17.06.01.SSA.pkg
      Added cat9k-guestshell.17.06.01.SSA.pkg
      Added cat9k-lni.17.06.01.SSA.pkg
      Added cat9k-rpbase.17.06.01.SSA.pkg
      Added cat9k-rpboot.17.06.01.SSA.pkg
      Added cat9k-sipbase.17.06.01.SSA.pkg
      Added cat9k-sipspa.17.06.01.SSA.pkg
      Added cat9k-srdriver.17.06.01.SSA.pkg
      Added cat9k-webui.17.06.01.SSA.pkg
      Added cat9k-wlc.17.06.01.SSA.pkg
    Finished list of software package changes
  [1] Finished Activate on R0
Checking status of Activate on [R0]
Activate: Passed on [R0]
Finished Activate

--- Starting Commit ---
Performing Commit on Active/Standby
  [1] Commit package(s) on R0
  [1] Finished Commit on R0
Checking status of Commit on [R0]
Commit: Passed on [R0]
Finished Commit
Send model notification for install_add_activate_commit before reload
Install will reload the system now!
SUCCESS: install_add_activate_commit  Wed Jul 21 12:13:05 IST 2021

Switch#Jul 21 12:13:11.023: %PMANTACTION: F0/0vp: Process manager is exiting: n requested
Jul 21 12:13:11.028: %PMAN-5-EXITACTION: C1/0: pvp: Process manager is exiting: reload fru
 action requested
Jul 21 12:13:11.825: %PMAN-5-EXITACTION: R0/0: pvp: Process manager is exiting: reload
action requested

Initializing Hardware...
System Bootstrap, Version 17.4.1r[FC2], RELEASE SOFTWARE (P)

Compiled 30-04-2021 12:00:00.00 by rel
Current ROMMON image : Primary Rommon Image
Last reset cause:LocalSoft
C9500-32QC platform with 16777216 Kbytes of main memory
Preparing to autoboot. [Press Ctrl-C to interrupt]  5     5     /-\|/-\|/-4     \|/-\|/-\|3
     /-\|/-\|/-2     \|/-\|/-\|1     /-\|/-\|/-0

boot: attempting to boot from [bootflash:packages.conf]

boot: reading file packages.conf
<output truncated>
```

Note
The system reloads automatically after executing the **install add file activate commit** command. You do not have to manually reload the system.

Step 5 Verify installation

After the software has been successfully installed, use the **dir flash:** command to verify that the flash partition has ten new `.pkg` files and two `.conf` files.

a) **dir flash:*.pkg**

The following is sample output of the **dir flash:*.pkg** command:

```
Switch# dir flash:*.pkg

Directory of flash:/
475140 -rw- 2012104   Mar 18 2021 09:52:41 -07:00 cat9k-cc_srdriver.17.05.01.SPA.pkg
475141 -rw- 70333380  Mar 18 2021 09:52:44 -07:00 cat9k-espbase.17.05.01.SPA.pkg
475142 -rw- 13256     Mar 18 2021 09:52:44 -07:00 cat9k-guestshell.17.05.01.SPA.pkg
475143 -rw- 349635524 Mar 18 2021 09:52:54 -07:00 cat9k-rpbase.17.05.01.SPA.pkg
475149 -rw- 24248187  Mar 18 2021 09:53:02 -07:00 cat9k-rpboot.17.05.01.SPA.pkg
475144 -rw- 25285572  Mar 18 2021 09:52:55 -07:00 cat9k-sipbase.17.05.01.SPA.pkg
475145 -rw- 20947908  Mar 18 2021 09:52:55 -07:00 cat9k-sipspa.17.05.01.SPA.pkg
475146 -rw- 2962372   Mar 18 2021 09:52:56 -07:00 cat9k-srdriver.17.05.01.SPA.pkg
475147 -rw- 13284288  Mar 18 2021 09:52:56 -07:00 cat9k-webui.17.05.01.SPA.pkg
475148 -rw- 13248     Mar 18 2021 09:52:56 -07:00 cat9k-wlc.17.05.01.SPA.pkg

491524 -rw- 25711568  Jul 23 2021 11:49:33 -07:00 cat9k-cc_srdriver.17.06.01.SPA.pkg
491525 -rw- 78484428  Jul 23 2021 11:49:35 -07:00 cat9k-espbase.17.06.01.SPA.pkg
491526 -rw- 1598412   Jul 23 2021 11:49:35 -07:00 cat9k-guestshell.17.06.01.SPA.pkg
491527 -rw- 404153288 Jul 23 2021 11:49:47 -07:00 cat9k-rpbase.17.06.01.SPA.pkg
491533 -rw- 31657374  Jul 23 2021 11:50:09 -07:00 cat9k-rpboot.17.06.01.SPA.pkg
491528 -rw- 27681740  Jul 23 2021 11:49:48 -07:00 cat9k-sipbase.17.06.01.SPA.pkg
491529 -rw- 52224968  Jul 23 2021 11:49:49 -07:00 cat9k-sipspa.17.06.01.SPA.pkg
491530 -rw- 31130572  Jul 23 2021 11:49:50 -07:00 cat9k-srdriver.17.06.01.SPA.pkg
491531 -rw- 14783432  Jul 23 2021 11:49:51 -07:00 cat9k-webui.17.06.01.SPA.pkg
491532 -rw- 9160      Jul 23 2021 11:49:51 -07:00 cat9k-wlc.17.06.01.SPA.pkg
11353194496 bytes total (9544245248 bytes free)
Switch#
```

b) **dir flash:*.conf**

The following is sample output of the **dir flash:*.conf** command. It displays the .conf files in the flash partition; note the two .conf files:

- `packages.conf`—the file that has been re-written with the newly installed .pkg files
- `cat9k_iosxe.17.06.01.SPA.conf`— a backup copy of the newly installed packages.conf file

```
Switch# dir flash:*.conf

Directory of flash:/*.conf
Directory of flash:/

434197 -rw- 7406 Jul 23 2021 10:59:16 -07:00 packages.conf
516098 -rw- 7406 Jul 23 2021 10:58:08 -07:00 cat9k_iosxe.17.06.01.SPA.conf
11353194496 bytes total (8963174400 bytes free)
```

Step 6 **show version**

After the image boots up, use this command to verify the version of the new image.

The following sample output of the **show version** command displays the Cisco IOS XE Bengaluru 17.6.1 image on the device:

```
Switch# show version
Cisco IOS XE Software, Version 17.06.01
Cisco IOS Software [Bengaluru], Catalyst L3 Switch Software (CAT9K_IOSXE), Version 17.6.1,
 RELEASE SOFTWARE (fc2)
Technical Support: http://www.cisco.com/techsupport
Copyright (c) 1986-2021 by Cisco Systems, Inc.
<output truncated>
```

Downgrading in Install Mode

Follow these instructions to downgrade from one release to another, in install mode.

Before you begin

Note that you can use this procedure for the following downgrade scenarios:

When downgrading from ...	Use these commands...	To downgrade to...
Cisco IOS XE Bengaluru 17.6.x	• On Cisco Catalyst 9500 Series Switches, either **install** commands or **request platform software** commands[5]. • On Cisco Catalyst 9500 Series Switches - High Performance, only **install** commands	Cisco IOS XE Bengaluru 17.5.x or earlier releases.

[5] The **request platform software** commands are deprecated. So although they are still visible on the CLI, we recommend that you use **install** commands.

Note New switch models that are introduced in a release cannot be downgraded. The release in which a switch model is introduced is the minimum software version for that model.

The sample output in this section shows downgrade from Cisco IOS XE Bengaluru 17.6.1 to Cisco IOS XE Bengaluru 17.5.1, using **install** commands.

Procedure

Step 1 Clean-up

install remove inactive

Use this command to clean-up old installation files in case of insufficient space and to ensure that you have at least 1GB of space in flash, to expand a new image.

The following sample output displays the cleaning up of unused files, by using the **install remove inactive** command:

```
Switch# install remove inactive
 install_remove: START Wed Jul 21 11:42:27 IST 2021

Cleaning up unnecessary package files

No path specified, will use booted path bootflash:packages.conf

Cleaning bootflash:
  Scanning boot directory for packages ... done.
  Preparing packages list to delete ...
    cat9k-cc_srdriver.17.06.01.SSA.pkg
      File is in use, will not delete.
    cat9k-espbase.17.06.01.SSA.pkg
      File is in use, will not delete.
    cat9k-guestshell.17.06.01.SSA.pkg
      File is in use, will not delete.
    cat9k-rpbase.17.06.01.SSA.pkg
      File is in use, will not delete.
    cat9k-rpboot.17.06.01.SSA.pkg
      File is in use, will not delete.
    cat9k-sipbase.17.06.01.SSA.pkg
      File is in use, will not delete.
    cat9k-sipspa.17.06.01.SSA.pkg
      File is in use, will not delete.
    cat9k-srdriver.17.06.01.SSA.pkg
      File is in use, will not delete.
    cat9k-webui.17.06.01.SSA.pkg
      File is in use, will not delete.
    cat9k-wlc.17.06.01.SSA.pkg
      File is in use, will not delete.
    packages.conf
      File is in use, will not delete.
  done.
SUCCESS: No extra package or provisioning files found on media. Nothing to clean.

SUCCESS: install_remove  Wed Jul 21 11:42:39 IST 2021
```

Step 2 Copy new image to flash

a) **copy tftp:***[[//location]/directory]/filename***flash:**

Use this command to copy the new image from a TFTP server to flash memory. The location is either an IP address or a host name. The filename is specified relative to the directory used for file transfers. Skip this step if you want to use the new image from a TFTP server.

```
Switch# copy tftp://10.8.0.6/image/cat9k_iosxe.17.05.01.SPA.bin flash:
Destination filename [cat9k_iosxe.17.05.01.SPA.bin]?
Accessing tftp://10.8.0.6//cat9k_iosxe.17.05.01.SPA.bin...
Loading /cat9k_iosxe.17.05.01.SPA.bin from 10.8.0.6 (via GigabitEthernet0/0):
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
[OK - 508584771 bytes]
508584771 bytes copied in 101.005 secs (5035244 bytes/sec)
```

b) **dir flash:**

Use this command to confirm that the image has been successfully copied to flash.

```
Switch# dir flash:*.bin
Directory of flash:/*.bin

Directory of flash:/
```

```
434184 -rw- 508584771 Jul 21 2021 13:35:16 -07:00 cat9k_iosxe.17.05.01.SPA.bin
11353194496 bytes total (9055866880 bytes free)
```

Step 3 Set boot variable

a) **boot system flash:packages.conf**

Use this command to set the boot variable to **flash:packages.conf**.

```
Switch(config)# boot system flash:packages.conf
```

b) **no boot manual**

Use this command to configure the switch to auto-boot. Settings are synchronized with the standby switch, if applicable.

```
Switch(config)# no boot manual
Switch(config)# exit
```

c) **write memory**

Use this command to save boot settings.

```
Switch# write memory
```

d) **show bootvar** or **show boot**

Use this command to verify the boot variable (packages.conf) and manual boot setting (no):

```
Switch# show bootvar                <<on the C9500-24Y4C,C9500-32C, C9500-32QC, and
C9500-48Y4C models
BOOT variable = bootflash:packages.conf
MANUAL_BOOT variable = no
BAUD variable = 9600
ENABLE_BREAK variable = yes
BOOTMODE variable does not exist
IPXE_TIMEOUT variable does not exist
CONFIG_FILE variable =

Standby BOOT variable = bootflash:packages.conf
Standby MANUAL_BOOT variable = no
Standby BAUD variable = 9600
Standby ENABLE_BREAK variable = yes
Standby BOOTMODE variable does not exist
Standby IPXE_TIMEOUT variable does not exist
Standby CONFIG_FILE variable =
```

```
Switch# show boot                         <<on the C9500-12Q,C9500-16X C9500-24Q, and
C9500-40X models
Current Boot Variables:
BOOT variable = flash:packages.conf;

Boot Variables on next reload:
BOOT variable = flash:packages.conf;
Manual Boot = no
Enable Break = yes
Boot Mode = DEVICE
iPXE Timeout = 0
```

Step 4 Downgrade software image

install add file activate commit

Use this command to install the image.

We recommend that you point to the source image on your TFTP server or the flash drive of the *active* switch, if you have copied the image to flash memory. If you point to an image on the flash or USB drive of a member switch (instead of the active), you must specify the exact flash or USB drive - otherwise installation fails. For example, if the image is on the flash drive of member switch 3 (flash-3): `Switch# install add file flash-3:cat9k_iosxe.17.05.01.SPA.bin activate commit`.

The following example displays the installation of the Cisco IOS XE Bengaluru 17.5.1 software image to flash, by using the **install add file activate commit** command.

```
Switch# install add file flash:cat9k_iosxe.17.05.01.SPA.bin activate commit
install_add_activate_commit: Adding PACKAGE
install_add_activate_commit: Checking whether new add is allowed ....
--- Starting Add ---
Performing Add on Active/Standby
[1] Add package(s) on R0
[1] Finished Add on R0
Checking status of Add on [R0]
Add: Passed on [R0]
Finished Add
Image added. Version: 17.05.01.0.269
install_add_activate_commit: Activating PACKAGE

Following packages shall be activated:
/flash/cat9k-wlc.17.05.01.SPA.pkg
/flash/cat9k-webui.17.05.01.SPA.pkg
/flash/cat9k-srdriver.17.05.01.SPA.pkg
/flash/cat9k-sipspa.17.05.01.SPA.pkg
/flash/cat9k-sipbase.17.05.01.SPA.pkg
/flash/cat9k-rpboot.17.05.01.SPA.pkg
/flash/cat9k-rpbase.17.05.01.SPA.pkg
/flash/cat9k-guestshell.17.05.01.SPA.pkg
/flash/cat9k-espbase.17.05.01.SPA.pkg
/flash/cat9k-cc_srdriver.17.05.01.SPA.pkg

This operation may require a reload of the system. Do you want to proceed? [y/n] y


Performing Activate on Active/Standby
1] Activate package(s) on R0
    --- Starting list of software package changes ---
    Old files list:
      Removed cat9k-cc_srdriver.17.06.01.SSA.pkg
      Removed cat9k-espbase.17.06.01.SSA.pkg
      Removed cat9k-guestshell.17.06.01.SSA.pkg
      Removed cat9k-lni.17.06.01.SSA.pkg
      Removed cat9k-rpbase.17.06.01.SSA.pkg
      Removed cat9k-rpboot.17.06.01.SSA.pkg
      Removed cat9k-sipbase.17.06.01.SSA.pkg
      Removed cat9k-sipspa.17.06.01.SSA.pkg
      Removed cat9k-srdriver.17.06.01.SSA.pkg
      Removed cat9k-webui.17.06.01.SSA.pkg
      Removed cat9k-wlc.17.06.01.SSA.pkg
    New files list:
      Added cat9k-cc_srdriver.17.05.01.SPA.pkg
      Added cat9k-espbase.17.05.01.SPA.pkg
      Added cat9k-guestshell.17.05.01.SPA.pkg
      Added cat9k-rpbase.17.05.01.SPA.pkg
      Added cat9k-rpboot.17.05.01.SPA.pkg
      Added cat9k-sipbase.17.05.01.SPA.pkg
      Added cat9k-sipspa.17.05.01.SPA.pkg
      Added cat9k-srdriver.17.05.01.SPA.pkg
      Added cat9k-webui.17.05.01.SPA.pkg
      Added cat9k-wlc.17.05.01.SPA.pkg
```

```
    Finished list of software package changes
  [1] Finished Activate on R0
Checking status of Activate on [R0]
Activate: Passed on [R0]
Finished Activate

--- Starting Commit ---
Performing Commit on Active/Standby
 [1] Commit package(s) on R0
 [1] Finished Commit on R0
Checking status of Commit on [R0]
Commit: Passed on [R0]
Finished Commit

Send model notification for install_add_activate_commit before reload
Install will reload the system now!
SUCCESS: install_add_activate_commit  Wed Jul 21 11:51:01 IST 2021

Jul 21 11:51:07.505: %PMANTvp: Process manager is exiting: ren requested
Jul 21 11:51:07.505: %PMAN-5-EXITACTION: F0/0: pvp: Process manager is exiting: reload fru
 action requested
Jul 21 11:51:07.834: %PMAN-5-EXITACTION: R0/0: pvp: Process manager is exiting: reload
action requested

Initializing Hardware...

System Bootstrap, Version 17.3.1r[FC2], RELEASE SOFTWARE (P)
Compiled 30-04-2021 12:00:00.00 by rel
Current ROMMON image : Primary Rommon Image

Last reset cause:LocalSoft
C9500-32QC platform with 16777216 Kbytes of main memory
Preparing to autoboot. [Press Ctrl-C to interrupt]  5     5     /-\|/-\|/-4     \|/-\|/-\|3
     /-\|/-\|/-2     \|/-\|/-\|1     /-\|/-\|/-0
boot: attempting to boot from [bootflash:packages.conf]
boot: reading file packages.conf

<output truncated>
```

Note
The system reloads automatically after executing the **install add file activate commit** command. You do not have to manually reload the system.

Step 5 Verify version

show version

After the image boots up, use this command to verify the version of the new image.

Note
When you downgrade the software image, the ROMMON version does not downgrade. It remains updated.

The following sample output of the **show version** command displays the Cisco IOS XE Bengaluru 17.5.1 image on the device:

```
Switch# show version
Cisco IOS XE Software, Version 17.05.01
Cisco IOS Software [Bengaluru], Catalyst L3 Switch Software (CAT9K_IOSXE), Version 17.5.1,
 RELEASE SOFTWARE (fc1)
Technical Support: http://www.cisco.com/techsupport
Copyright (c) 1986-2021 by Cisco Systems, Inc.
<output truncated>
```

In Service Software Upgrade (ISSU) with Cisco StackWise Virtual

Follow the instructions described here to perform an In Service Software Upgrade (ISSU) upgrade. Use the procedure described here, only for the releases indicated in the table below. For more general information about ISSU release support and recommended releases, see this technical reference document: In-Service Software Upgrade (ISSU).

Before you begin

Note that you can use this ISSU procedure only for the following scenarios:

When upgrading from...	Use these commands...	To...
Cisco IOS XE Amsterdam 17.3.x	**install add file activate issu commit**	Cisco IOS XE Bengaluru 17.6.x
Not applicable	ISSU does not support downgrade. To downgrade, see Downgrading in Install Mode, on page 23.	Not applicable

Procedure

Step 1 **enable**

Enables privileged EXEC mode. Enter your password if prompted.

```
Switch# enable
```

Step 2 **show version | in INSTALL** or **show version | in System image**

On the Catalyst 9500 Series Switches, use **show version | in INSTALL** command to check the boot mode. ISSU is supported only in install mode. You cannot perform ISSU if the switch is booted in bundle mode.

```
Switch# show version | in INSTALL
Switch Ports Model              SW Version        SW Image              Mode
------ ----- -----              ----------        ----------            ----
*    1 12    C9500-12Q          17.6.1            CAT9K_IOSXE           INSTALL
     2 12    C9500-12Q          17.6.1            CAT9K_IOSXE           INSTALL
```

On Catalyst 9500 Series Switches - High Performance, use **show version | in System image** to check if the switch booted into IOS via " boot flash:packages.conf ". The output should display the following:

```
Switch# show version | in System image
System image file is "flash:packages.conf"
```

You cannot perform ISSU if the switch is booted in bundle mode. If you perform ISSU in bundle mode, you will see the following error.

```
*Jul 10 14:55:57.338: %INSTALL-5-INSTALL_START_INFO: Chassis 1 R1/0: install_engine: Started
 install one-shot ISSU flash:cat9k_iosxe.17.3.02.SPA.bininstall_add_activate_commit: Adding
 ISSU
ERROR: install_add_activate_commit: One-Shot ISSU operation is not supported in bundle boot
 mode
FAILED: install_add_activate_commit  exit(1) Tue Jul 10 14:56:03 UTC 2021
```

Step 3 **dir flash: | in free**

Use this command to check if there is sufficient available memory on flash. Ensure that you have at least 1GB of space in flash to expand a new image.

```
Switch# dir flash: | in free
11353194496 bytes total (8565174272 bytes free)
```

Step 4 **show redundancy**

Use this command to check if the switch is in SSO mode.

```
Switch# show redundancy
Redundant System Information :
------------------------------
       Available system uptime = 4 minutes
Switchovers system experienced = 0
              Standby failures = 0
        Last switchover reason = none

                 Hardware Mode = Duplex
    Configured Redundancy Mode = sso
     Operating Redundancy Mode = sso
              Maintenance Mode = Disabled
                Communications = Up
<output truncated>
```

Step 5 **show boot system**

Use this command to verify that the manual boot variable is set to **no**.

```
Switch# show boot system
Current Boot Variables:
BOOT variable = flash:packages.conf;
MANUAL_BOOT variable = no

Boot Variables on next reload:
BOOT variable = flash:packages.conf;
MANUAL_BOOT variable = no
Enable Break = no
Boot Mode = DEVICE
iPXE Timeout = 0
```

If the manual boot variable is set to **yes**, use the **no boot manual** command in global configuration mode to set the switch for autoboot.

Step 6 **show issu state** [*detail*]

Use this command to verify that no other ISSU process is in progress.

```
Switch# show issu state detail
--- Starting local lock acquisition on chassis 2 ---
Finished local lock acquisition on chassis 2

No ISSU operation is in progress

Switch#
```

Step 7 **show install summary**

Use this command to verify that the state of the image is *Activated & Committed*. Clear the install state if the state is not *Activated & Committed*.

```
Switch# show install summary
[ Switch 1 2 ] Installed Package(s) Information:
```

```
State (St): I - Inactive, U - Activated & Uncommitted,
            C - Activated & Committed, D - Deactivated & Uncommitted
--------------------------------------------------------------------------------
Type  St   Filename/Version
--------------------------------------------------------------------------------
IMG   C    17.6.1.0.2433
```

Step 8 **install add file activate issu commit**

Use this command to automate the sequence of all the upgrade procedures, including downloading the images to both the switches, expanding the images into packages, and upgrading each switch as per the procedures.

```
Switch# install add file tftp:cat9k_iosxe.17.06.01.SPA.bin activate issu commit
```

The following sample output displays installation of Cisco IOS XE Amsterdam 17.3.2a software image with ISSU procedure.

```
Switch# install add file tftp:cat9k_iosxe.17.06.01.SPA.bin activate issu commit
install_add_activate_commit: START Thu Jul 19 06:16:32 UTC 2021
Downloading file tftp://172.27.18.5//cat9k_iosxe.17.06.01.SPA.bin

*Jul 19 06:16:34.064: %INSTALL-5-INSTALL_START_INFO: Switch 1 R0/0: install_engine: Started
 install one-shot ISSU tftp://172.27.18.5//cat9k_iosxe.17.06.01.SPA.bin
Finished downloading file tftp://172.27.18.5//cat9k_iosxe.17.06.01.SPA.bin to
flash:cat9k_iosxe.17.06.01.SPA.bin
install_add_activate_commit: Adding ISSU

--- Starting initial file syncing ---
[1]: Copying flash:cat9k_iosxe.17.06.01.SPA.bin from switch 1 to switch 2
[2]: Finished copying to switch 2
Info: Finished copying flash:cat9k_iosxe.17.06.01.SPA.bin to the selected switch(es)
Finished initial file syncing

--- Starting Add ---
Performing Add on all members
  [1] Add package(s) on switch 1
  [1] Finished Add on switch 1
  [2] Add package(s) on switch 2
  [2] Finished Add on switch 2
Checking status of Add on [1 2]
Add: Passed on [1 2]
Finished Add

install_add_activate_commit: Activating ISSU

NOTE: Going to start Oneshot ISSU install process

STAGE 0: Initial System Level Sanity Check before starting ISSU
=================================================
--- Verifying install_issu supported ---
--- Verifying standby is in Standby Hot state ---
--- Verifying booted from the valid media ---
--- Verifying AutoBoot mode is enabled ---
Finished Initial System Level Sanity Check


STAGE 1: Installing software on Standby
=================================================
--- Starting install_remote ---
Performing install_remote on Chassis remote
[2] install_remote package(s) on switch 2
[2] Finished install_remote on switch 2
install_remote: Passed on [2]
Finished install_remote
```

```
STAGE 2: Restarting Standby
================================================
--- Starting standby reload ---
Finished standby reload

--- Starting wait for Standby to reach terminal redundancy state ---

*Jul 19 06:24:16.426: %SMART_LIC-5-EVAL_START: Entering evaluation period
*Jul 19 06:24:16.426: %SMART_LIC-5-EVAL_START: Entering evaluation period
*Jul 19 06:24:16.466: %HMANRP-5-CHASSIS_DOWN_EVENT: Chassis 2 gone DOWN!
*Jul 19 06:24:16.497: %REDUNDANCY-3-STANDBY_LOST: Standby processor fault (PEER_NOT_PRESENT)
*Jul 19 06:24:16.498: %REDUNDANCY-3-STANDBY_LOST: Standby processor fault (PEER_DOWN)
*Jul 19 06:24:16.498: %REDUNDANCY-3-STANDBY_LOST: Standby processor fault
(PEER_REDUNDANCY_STATE_CHANGE)
*Jul 19 06:24:16.674: %RF-5-RF_RELOAD: Peer reload. Reason: EHSA standby down
*Jul 19 06:24:16.679: %IOSXE_REDUNDANCY-6-PEER_LOST: Active detected switch 2 is no longer
 standby
*Jul 19 06:24:16.416: %NIF_MGR-6-PORT_LINK_DOWN: Switch 1 R0/0: nif_mgr: Port 1 on front
side stack link 0 is DOWN.
*Jul 19 06:24:16.416: %NIF_MGR-6-PORT_CONN_DISCONNECTED: Switch 1 R0/0: nif_mgr: Port 1 on
 front side stack link 0 connection has DISCONNECTED: CONN_ERR_PORT_LINK_DOWN_EVENT
*Jul 19 06:24:16.416: %NIF_MGR-6-STACK_LINK_DOWN: Switch 1 R0/0: nif_mgr: Front side stack
 link 0 is DOWN.
*Jul 19 06:24:16.416: %STACKMGR-6-STACK_LINK_CHANGE: Switch 1 R0/0: stack_mgr: Stack port
1 on Switch 1 is down

<output truncated>

*Jul 19 06:29:36.393: %IOSXE_REDUNDANCY-6-PEER: Active detected switch 2 as standby.
*Jul 19 06:29:36.392: %STACKMGR-6-STANDBY_ELECTED: Switch 1 R0/0: stack_mgr: Switch 2 has
been elected STANDBY.
*Jul 19 06:29:41.397: %REDUNDANCY-5-PEER_MONITOR_EVENT: Active detected a standby insertion
 (raw-event=PEER_FOUND(4))
*Jul 19 06:29:41.397: %REDUNDANCY-5-PEER_MONITOR_EVENT: Active detected a standby insertion
 (raw-event=PEER_REDUNDANCY_STATE_CHANGE(5))
*Jul 19 06:29:42.257: %REDUNDANCY-3-IPC: IOS versions do not match.
*Jul 19 06:30:24.323: %HA_CONFIG_SYNC-6-BULK_CFGSYNC_SUCCEED: Bulk Sync succeededFinished
wait for Standby to reach terminal redundancy state


*Jul 19 06:30:25.325: %RF-5-RF_TERMINAL_STATE: Terminal state reached for (SSO)
STAGE 3: Installing software on Active
================================================
--- Starting install_active ---
Performing install_active on Chassis 1

<output truncated>

[1] install_active package(s) on switch 1
[1] Finished install_active on switch 1
install_active: Passed on [1]
Finished install_active


STAGE 4: Restarting Active (switchover to standby)
================================================
--- Starting active reload ---
New software will load after reboot process is completed
SUCCESS: install_add_activate_commit  Thu Jul 19 23:06:45 UTC 2021
Jul 19 23:06:45.731: %INSTALL-5-INSTALL_COMPLETED_INFO: R0/0: install_engine: Completed
install one-shot ISSU flash:cat9k_iosxe.17.06.01.SPA.bin
Jul 19 23:06:47.509: %PMAN-5-EXITACTION: F0/0: pvp: Process manager is exiting: reload fp
action requested
```

```
Jul 19 23:06:48.776: %PM

Initializing Hardware...

System Bootstrap, Version 17.3.1r[FC2], RELEASE SOFTWARE (P)
Compiled Fri 08/17/2018 10:48:42.68 by rel

Current ROMMON image : Primary
Last reset cause     : PowerOn
C9500-40X platform with 16777216 Kbytes of main memory

boot: attempting to boot from [flash:packages.conf]
boot: reading file packages.conf
#
################################################################################################################################################


Jul 19 23:08:30.238: %PMAN-5-EXITACTION: C0/0: pvp: Process manager is exiting:

Waiting for 120 seconds for other switches to boot
######################
Switch number is 1
All switches in the stack have been discovered. Accelerating discovery



Switch console is now available


Press RETURN to get started.




Jul 19 23:14:17.080: %INSTALL-5-INSTALL_START_INFO: R0/0: install_engine: Started install
commit
Jul 19 23:15:48.445: %INSTALL-5-INSTALL_COMPLETED_INFO: R0/0: install_engine: Completed
install commit ISSU
```

Step 9 **show version**

Use this command to verify the version of the new image.

The following sample output of the **show version** command displays the Cisco IOS XE Amsterdam 17.3.2a image on the device:

```
Switch# show version
Cisco IOS XE Software, Version 17.06.01
Cisco IOS Software [Amsterdam], Catalyst L3 Switch Software (CAT9K_IOSXE), Version 17.6.1,
 RELEASE SOFTWARE (fc2)
Technical Support: http://www.cisco.com/techsupport
Copyright (c) 1986-2021 by Cisco Systems, Inc.
<output truncated>
```

Step 10 **show issu state** [*detail*]

Use this command to verify that no ISSU process is in pending state.

```
Switch# show issu state detail
--- Starting local lock acquisition on chassis 2 ---
Finished local lock acquisition on chassis 2
```

```
No ISSU operation is in progress

Switch#
```

Step 11 **exit**

Exits privileged EXEC mode and returns to user EXEC mode.

Field-Programmable Gate Array Version Upgrade

A field-programmable gate array (FPGA) is a type of programmable memory device that exists on Cisco switches. They are re-configurable logic circuits that enable the creation of specific and dedicated functions.

To check the current FPGA version, enter the **version -v** command in ROMMON mode.

Note

- Not every software release has a change in the FPGA version.
- The version change occurs as part of the regular software upgrade and you do not have to perform any other additional steps.

Licensing

For information about licenses required for the features available on Cisco Catalyst 9000 Series Switches, see Configuring Licenses on Cisco Catalyst 9000 Series Switches.

All licensing information relating to Cisco Catalyst 9000 Series Switches are available on this collection page: Cisco Catalyst 9000 Switching Family Licensing.

Available Licensing Models and Configuration Information

- Cisco IOS XE Fuji 16.8.x and earlier: RTU Licensing is the default and the only supported method to manage licenses.
- Cisco IOS XE Fuji 16.9.1 to Cisco IOS XE Amsterdam 17.3.1: Smart Licensing is the default and the only supported method to manage licenses.

Note On the Cisco Catalyst 9500 Series Switches-High Performance, it is from Cisco IOS XE Fuji 16.8.1a to Cisco IOS XE Amsterdam 17.3.1.

- Cisco IOS XE Amsterdam 17.3.2a and later: Smart Licensing Using Policy, which is an enhanced version of Smart Licensing, is the default and the only supported method to manage licenses.

Scaling Guidelines

For information about feature scaling guidelines, see the Cisco Catalyst 9500 Series Switches datasheet at:

https://www.cisco.com/c/en/us/products/collateral/switches/catalyst-9500-series-switches/datasheet-c78-738978.html

Limitations and Restrictions

With Cisco Catalyst 9500 Series Switches and Cisco Catalyst 9500 Series Switches - High Performance—If a feature is not supported on a switch model, you do not have to factor in any limitations or restrictions that may be listed here. If limitations or restrictions are listed for a feature that is supported, check if model numbers are specified, to know if they apply. If model numbers are not specified, the limitations or restrictions apply to all models in the series.

- Auto negotiation

  Auto negotiation (the **speed auto** command) and half duplex (the **duplex half** command) are not supported on GLC-T or GLC-TE transceivers for 10 Mbps and 100 Mbps speeds. This applies only to the C9500-48Y4C and C9500-24Y4C models of the series.

  We recommend not changing Forward Error Correction (FEC) when auto negotiation is ON. This is applicable to 100G/40G/25G CU cables on the C9500-32C, C9500-32QC, C9500-24Y4C and C9500-48Y4C models of the series.

- Control Plane Policing (CoPP)—The **show run** command does not display information about classes configured under `system-cpp policy`, when they are left at default values. Use the **show policy-map system-cpp-policy** or the **show policy-map control-plane** commands in privileged EXEC mode instead.

- Cisco StackWise Virtual

  - On Cisco Catalyst 9500 Series Switches, when Cisco StackWise Virtual is configured, breakout ports using 4X10G breakout cables, or the Cisco QSFP to SFP or SFP+ Adapter (QSA) module can only be used as data ports; they cannot be used to configure StackWise Virtual links (SVLs) or dual-active detective (DAD) links.

  - On Cisco Catalyst 9500 Series Switches - High Performance,

    - When Cisco StackWise Virtual is configured, breakout ports using 4X25G or 4X10G breakout cables can only be used as data ports; they cannot be used to configure SVLs or DAD links.

    - When Cisco StackWise Virtual is configured, Cisco QSA module with 10G SFP modules can be used as data ports and to configure SVLs or DAD links.

    - When Cisco StackWise Virtual is configured, Cisco QSA module with 1G SFP modules can be used as data ports and to configure DAD links; they cannot be used to configure SVLs since SVLs are not supported on 1G interfaces.

- Cisco TrustSec restrictions—Cisco TrustSec can be configured only on physical interfaces, not on logical interfaces.

- Flexible NetFlow limitations

  - You cannot configure NetFlow export using the Ethernet Management port (GigabitEthernet0/0).

  - You can not configure a flow monitor on logical interfaces, such as layer 2 port-channels, loopback, tunnels.

  - You can not configure multiple flow monitors of same type (ipv4, ipv6 or datalink) on the same interface for same direction.

- Hardware Limitations — Optics:
  - 1G with Cisco QSA Module (CVR-QSFP-SFP10G) is not supported on the uplink ports of the C9500-24Y4C and C9500-48Y4C models.
  - Installation restriction for SFP-10G-T-X module on C9500-24Y4C and C9500-48Y4C— Only eight SFP-10G-T-X modules are supported at a time. If you insert a ninth SFP-10G-T-X module in a lower numbered port than the existing active eight SFP-10G-T-X module, a reload will bring up the ninth transceiver and moves the last existing port with SFP-10G-T-X module to error disabled state. This happens due to the order of sequence ports link bring up where the lower numbered port brings up the link first. This limitation applies in standalone and in Cisco StackWise Virtual setup with two C9500-24Y4C or C9500-48Y4C switches. Each switch can have eight SFP-10G-T-X modules.

    The following error displays on the console if you insert a ninth module with eight active modules:

    ```
    "%IOMD_ETHER_GEIM-4-MAX_LIMIT_XCVR: R0/0: iomd: Number of
    SFP-10G-T-X that can be supported has reached the max limit of 8,
     transceiver is err-disabled. Unplug the transceiver in interface
     TwentyFiveGigE1/0/29
    ```

  - SFP-10G-T-X supports 100Mbps/1G/10G speeds based on auto negotiation with the peer device. You cannot force speed settings from the transceiver.

- Hardware limitations:
  - Use the MODE button to switch-off the beacon LED.
  - All port LED behavior is undefined until interfaces are fully initialized.
  - The following limitations apply to Cisco QSA Module (CVR-QSFP-SFP10G) when Cisco 1000Base-T Copper SFP (GLC-T) or Cisco 1G Fiber SFP Module for Multimode Fiber are plugged into the QSA module:
    - 1G Fiber modules over QSA do not support autonegotiation. Auto-negotiation should be disabled on the far-end devices.
    - Although visible in the CLI, the command [**no**] **speed nonegotiate** is not supported with 1G Fiber modules over QSA.
    - Only GLC-T over QSA supports auto-negotiation.
    - GLC-T supports only port speed of 1000 Mb/s over QSA. Port speeds of 10/100-Mb/s are not supported due to hardware limitation.
  - When you use Cisco QSFP-4SFP10G-CUxM Direct-Attach Copper Cables, autonegotiation is enabled by default. If the other end of the line does not support autonegotation, the link does not come up.
  - Autonegotiation is not supported on HundredGigabitEthernet1/0/49 to HundredGigabitEthernet1/0/52 uplink ports of the C9500-48Y4C models, and HundredGigabitEthernet1/0/25 to HundredGigabitEthernet1/0/28 uplink ports of the C9500-24Y4C models. Disable autonegotiation on the peer device if you are using QSFP-H40G-CUxx and QSFP-H40G-ACUxx cables.
  - For QSFP-H100G-CUxx cables, the C9500-48Y4C and C9500-24Y4C models support the cables only if both sides of the connection are either C9500-48Y4C or C9500-24Y4C.

- For C9500-32C model, the power supply with serial number starting with POG has two fans and the power supply with serial number starting with QCS has a single fan. When you use **show environment status** command, the fan status of one fan is always displayed as `N/A` when the power supply with single fan is installed into the power supply slot. See Configuring Internal Power Supplies.

- Interoperability limitations—When you use Cisco QSFP-4SFP10G-CUxM Direct-Attach Copper Cables, if one end of the 40G link is a Catalyst 9400 Series Switch and the other end is a Catalyst 9500 Series Switch, the link does not come up, or comes up on one side and stays down on the other. To avoid this interoperability issue between devices, apply the the **speed nonegotiate** command on the Catalyst 9500 Series Switch interface. This command disables autonegotiation and brings the link up. To restore autonegotiation, use the **no speed nonegotiation** command.

- In-Service Software Upgrade (ISSU)
  - In-Service Software Upgrade (ISSU)—On Cisco Catalyst 9500 Series Switches (C9500-12Q, C9500-16X, C9500-24Q, C9500-40X), ISSU from Cisco IOS XE Fuji 16.9.x to Cisco IOS XE Gibraltar 16.10.x or to Cisco IOS XE Gibraltar 16.11.x is not supported.
  - On Cisco Catalyst 9500 Series Switches - High Performance (C9500-24Y4C, C9500-32C, C9500-32QC, and C9500-48Y4C), ISSU with Cisco StackWise Virtual is supported only starting from Cisco IOS XE Gibraltar 16.12.1. Therefore, ISSU upgrades can be performed only starting from this release to a later release.
  - While ISSU allows you to perform upgrades with zero downtime, we recommend you to do so during a maintenance window only.
  - If a new feature introduced in a software release requires a change in configuration, the feature should not be enabled during ISSU.
  - If a feature is not available in the downgraded version of a software image, the feature should be disabled before initiating ISSU.

- QoS restrictions
  - When configuring QoS queuing policy, the sum of the queuing buffer should not exceed 100%.
  - For QoS policies, only switched virtual interfaces (SVI) are supported for logical interfaces.
  - QoS policies are not supported for port-channel interfaces, tunnel interfaces, and other logical interfaces.

- Secure Shell (SSH)
  - Use SSH Version 2. SSH Version 1 is not supported.
  - When the device is running SCP and SSH cryptographic operations, expect high CPU until the SCP read process is completed. SCP supports file transfers between hosts on a network and uses SSH for the transfer.

    Since SCP and SSH operations are currently not supported on the hardware crypto engine, running encryption and decryption process in software causes high CPU. The SCP and SSH processes can show as much as 40 or 50 percent CPU usage, but they do not cause the device to shutdown.

- Smart Licensing Using Policy: Starting with Cisco IOS XE Amsterdam 17.3.2a, with the introduction of Smart Licensing Using Policy, even if you configure a hostname for a product instance or device, only

the Unique Device Identifier (UDI) is displayed. This change in the display can be observed in all licensing utilities and user interfaces where the hostname was displayed in earlier releases. It does not affect any licensing functionality. There is no workaround for this limitation.

The licensing utilities and user interfaces that are affected by this limitation include only the following: Cisco Smart Software Manager (CSSM), Cisco Smart License Utility (CSLU), and Smart Software Manager On-Prem (SSM On-Prem).

- TACACS legacy command: Do not configure the legacy **tacacs-server host** command; this command is deprecated. If the software version running on your device is Cisco IOS XE Gibraltar 16.12.2 or a later release, using the legacy command can cause authentication failures. Use the **tacacs server** command in global configuration mode.
- USB Authentication—When you connect a Cisco USB drive to the switch, the switch tries to authenticate the drive against an existing encrypted preshared key. Since the USB drive does not send a key for authentication, the following message is displayed on the console when you enter **password encryption aes** command:

```
Device(config)# password encryption aes
Master key change notification called without new or old key
```

- MACsec is not supported on Software-Defined Access deployments.
- VLAN Restriction—It is advisable to have well-defined segregation while defining data and voice domain during switch configuration and to maintain a data VLAN different from voice VLAN across the switch stack. If the same VLAN is configured for data and voice domains on an interface, the resulting high CPU utilization might affect the device.
- Wired Application Visibility and Control limitations:
  - NBAR2 (QoS and Protocol-discovery) configuration is allowed only on wired physical ports. It is not supported on virtual interfaces, for example, VLAN, port channel nor other logical interfaces.
  - NBAR2 based match criteria ‘match protocol’ is allowed only with marking or policing actions. NBAR2 match criteria will not be allowed in a policy that has queuing features configured.
  - ‘Match Protocol’: up to 256 concurrent different protocols in all policies.
  - NBAR2 and Legacy NetFlow cannot be configured together at the same time on the same interface. However, NBAR2 and wired AVC Flexible NetFlow can be configured together on the same interface.
  - Only IPv4 unicast (TCP/UDP) is supported.
  - AVC is not supported on management port (Gig 0/0)
  - NBAR2 attachment should be done only on physical access ports. Uplink can be attached as long as it is a single uplink and is not part of a port channel.
  - Performance—Each switch member is able to handle 500 connections per second (CPS) at less than 50% CPU utilization. Above this rate, AVC service is not guaranteed.
  - Scale—Able to handle up to 5000 bi-directional flows per 24 access ports and 10000 bi-directional flows per 48 access ports.
- YANG data modeling limitation—A maximum of 20 simultaneous NETCONF sessions are supported.
- Embedded Event Manager—Identity event detector is not supported on Embedded Event Manager.

- The File System Check (fsck) utility is not supported in install mode.
- Switch Web UI allows configuration of data VLANs only and not voice VLANs. If you remove a voice VLAN configured to an interface using the Web UI, then all data VLANs associated with the interface are also removed by default.

Caveats

Caveats describe unexpected behavior in Cisco IOS-XE releases. Caveats listed as open in a prior release are carried forward to the next release as either open or resolved.

Cisco Bug Search Tool

The Cisco Bug Search Tool (BST) allows partners and customers to search for software bugs based on product, release, and keyword, and aggregates key data such as bug details, product, and version. The BST is designed to improve the effectiveness in network risk management and device troubleshooting. The tool has a provision to filter bugs based on credentials to provide external and internal bug views for the search input.

To view the details of a caveat, click on the identifier.

Open Caveats in Cisco IOS XE Bengaluru 17.6.x

There are no open caveats in this release.

Resolved Caveats in Cisco IOS XE Bengaluru 17.6.8

Identifier	Description
CSCwi79020	Unexpected reload on C9K switch while running dot1X and device tracking
CSCwk55493	Port in 4*10 Breakout cable goes down after upgrading C9500 to 17.12.2 peer 9300/9400

Resolved Caveats in Cisco IOS XE Bengaluru 17.6.7

Identifier	Description
CSCwi37669	macro is getting pushed on closed and open auth ports when macro is global enabled
CSCwf10970	fed process crashing after AVB policy-map manipulation

Resolved Caveats in Cisco IOS XE Bengaluru 17.6.6a

Identifier	Description
CSCwh87343	Cisco IOS XE Software Web UI Privilege Escalation Vulnerability For more information, see Security Advisory: cisco-sa-iosxe-webui-privesc-j22SaA4z

Resolved Caveats in Cisco IOS XE Bengaluru 17.6.6

Identifier	Description
CSCwb76541	IOSd Crashes in "Call Home cert update" Process During Trustpool Download
CSCwd28734	Cat9k memory leak in pubd causes switch reload
CSCwe09745	Memory leak in Pubd when continuously trying to connect to remote peer
CSCwe95691	PnP | Cat9k sends DHCP Discover with IP Source address 192.168.1.1 instead of 0.0.0.0
CSCwe36743	Segmentation Fault - Crash - SSH - When Changing AAA Group Configs

Resolved Caveats in Cisco IOS XE Bengaluru 17.6.5

Identifier	Applicable Models	Description
CSCwc01376	Catalyst 9500	Etherchannel member interface going to suspended state
CSCwd51319	Catalyst 9500	C9500: EntSensor shows wrong values after switchover

Resolved Caveats in Cisco IOS XE Bengaluru 17.6.4

Identifier	Applicable Models	Description
CSCwa85199	All models	High CPU Utilization and memory utilization by Smart Licensing Agent

Resolved Caveats in Cisco IOS XE Bengaluru 17.6.3

Identifier	Applicable Models	Description
CSCvy74900	All models	Unexpected reload in HTTP CORE process
CSCvz51752	All models	Randomly CTS enforcement not happening if multiple Tabs are used from the ISE to push COA
CSCvz60442	Catalyst 9500 High Performance	Unable to delete ip helper-address from the VLAN interface
CSCvz85562	Catalyst 9500	Link may not come up between C9300 and C9500 at 25G with SFP-10/25G-CSR-S
CSCwa07035	Catalyst 9500	Linecard stops forwarding traffic

Identifier	Applicable Models	Description
CSCwa17838	Catalyst 9500	Stackwise virtual drop ARP request in secondary private VLAN after reload
CSCwa17969	All models	Cat9k | standby unexpected reload when no ip helper-address global is executed
CSCwa21130	Catalyst 9500 High Performance	9500H QSFP-H40G-CUxM are not recognized or listed as Unknown pluggable optics and link not up
CSCwa67012	All models	Error seen when deleting ip igmp snooping querier

Resolved Caveats in Cisco IOS XE Bengaluru 17.6.2

Identifier	Applicable Models	Description
CSCvy98214	Catalyst 9500	Flexlink+ preempt not work normally and cause traffic down
CSCvz74027	Catalyst 9500 High Performance	C9500 24Y4C does not return exact Chassis status in response to OID 1.3.6.1.4.1.9.9.117.1.2.1.1.2

Resolved Caveats in Cisco IOS XE Bengaluru 17.6.1

There are no resolved caveats in this release.

Troubleshooting

For the most up-to-date, detailed troubleshooting information, see the Cisco TAC website at this URL:

https://www.cisco.com/en/US/support/index.html

Go to **Product Support** and select your product from the list or enter the name of your product. Look under Troubleshoot and Alerts, to find information for the problem that you are experiencing.

Related Documentation

Information about Cisco IOS XE at this URL: https://www.cisco.com/c/en/us/products/ios-nx-os-software/ios-xe/index.html

All support documentation for Cisco Catalyst 9500 Series Switches is at this URL: https://www.cisco.com/c/en/us/support/switches/catalyst-9500-series-switches/tsd-products-support-series-home.html

Cisco Validated Designs documents at this URL: https://www.cisco.com/go/designzone

To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL: https://cfnng.cisco.com/mibs

Communications, Services, and Additional Information

- To receive timely, relevant information from Cisco, sign up at Cisco Profile Manager.
- To get the business results you're looking for with the technologies that matter, visit Cisco Services.
- To submit a service request, visit Cisco Support.
- To discover and browse secure, validated enterprise-class apps, products, solutions and services, visit Cisco DevNet.
- To obtain general networking, training, and certification titles, visit Cisco Press.
- To find warranty information for a specific product or product family, access Cisco Warranty Finder.

Cisco Bug Search Tool

Cisco Bug Search Tool (BST) is a web-based tool that acts as a gateway to the Cisco bug tracking system that maintains a comprehensive list of defects and vulnerabilities in Cisco products and software. BST provides you with detailed defect information about your products and software.

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED “AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

All printed copies and duplicate soft copies of this document are considered uncontrolled. See the current online version for the latest version.

Cisco has more than 200 offices worldwide. Addresses and phone numbers are listed on the Cisco website at www.cisco.com/go/offices.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: https://www.cisco.com/c/en/us/about/legal/trademarks.html. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1721R)

© 2024 Cisco Systems, Inc. All rights reserved.