

Cisco UCS Manager 6.0 Privileges

- Cisco UCS Manager 6.0 Privileges, on page 1

Cisco UCS Manager 6.0 Privileges

This privilege allows a user to perform provisioning operations related to Authentication, Authorization and Accounting. This includes managing users and roles, and configuring services that are exposed to the management interfaces.

Aaa (aaa)

Allows a user to perform provisioning operations related to Authentication, Authorization, and Accounting.

- Configure Key Ring and manage certificates
- Configure communication policy resolution
- Configure DNS providers and domains
- Configure SNMP policies, users, and traps
- Manage users, roles, locales, sessions, and login banners
- Configure management connectivity (HTTP/S, SSH, Telnet, etc.)

Admin (admin)

Provides a user with full access to all operations in Cisco UCS Manager.

Ext Lan Config (ext-lan-config)

Allows configuration of LAN settings on a fabric interconnect, including border ports, VLANs, and PIN groups.

- Configure Ethernet PIN Groups and MAC aging
- Enable/Disable VLAN compression and Ethernet ports
- Configure Fabric Interconnect system name and LACP policy
- Configure NetFlow policies and Ethernet monitoring sessions

Cisco UCS Manager 6.0 Privileges

Service Profile Compute (ls-compute)

Configures most aspects of service profiles, excluding vNIC/vHBA creation.

- Configure Service Profile BIOS policies and storage profiles
- Create/modify/delete Service Profiles and templates
- Configure VMQ policies and maintenance tasks
- Assign usNIC policies and configure scriptable vMedia

Server Maintenance (pn-maintenance)

Performs physical server maintenance operations.

- Acknowledge, decommission, and recover blade/rack servers
- Reset CIMC, KVM, CMOS, and BIOS passwords
- Configure locator and health LEDs
- Reset IO Modules and FEX