

show hd raid verbose

- show hd raid verbose, on page 1

show hd raid verbose

Table 1: show hd raid verbose Command Output Descriptions

Field	Description
HD RAID	
State	The following conditions apply to the RAID function: Available (clean): At least one disk is readyAvailable (active): Disk resynchronizingNot Available
Degraded	The following conditions apply: No: Both disks are readyYes: One disk is ready
UUID	Universal Identification number
Size	Drive size in bytes
Action	The following conditions apply: Idle: Neither resynchronizing nor rebuilding RAIDRecovering (dd% done) RebuildingResynching (dd% done)Checking (dd% done)Repairing (dd% done)
Disk	Disk name

show hd raid verbose

Field	Description
	The following conditions apply to the disk: State: In-sync componentSpare component: Rebuilding RAIDValid image of UUID: Different imageNot used: Set by AdminFaulty componentInvalid partition or imageUnknown partition or image Created Date image created Updated Date image updated Events Interval event count Model Disk model number Serial Number Disk serial number Location Disk location Size Disk size in bytes Partitions Total number of partitions Partition Partition size in bytes and sectors for each partition