

Network Service Virtual Connection Configuration Mode Commands

Command Modes

The Network Service Virtual Connection (NSVC) configuration mode is a sub-mode of the Network Service Entity (NSE) - Peer NSEI (for Frame Relay) configuration mode. The NSVC sub-mode creates a configuration instance for a specific NSVC, within the Gb interface, between a BSS and an SGSN in a 2.5G GPRSFrame Relay network connection.

Exec > Global Configuration > Network Service Entity - Frame Relay Peer NSEI Configuration > NSVC Configuration

configure > network-service-entity peer-nsei *peer_nsei* **framerelay > ns-vc** *nsvc_id*

Entering the above command sequence results in the following prompt:

`[local]`*`host_name`*`(nse-fr-peer-nsei-nse_id-nsvci-`*`nsvc_instance`*`)#`

Important The commands or keywords/variables that are available are dependent on platform type, product version, and installed license(s).

Important For information on common commands available in this configuration mode, refer to the Common Commands chapter.