

show chassis-throughput

This chapter includes the **show chassis-throughput** command output table.

- show chassis-throughput, on page 1

show chassis-throughput

Table 1: show chassis-throughput Command Output Descriptions

Field	Description
Chassis Throughput	Indicates the configured throughput of the chassis.
Card/Cpu	Indicates individual distribution of throughput on per card, per CPU ba
Throughput	Indicates the throughput for the individual card/CPU.

show chassis-throughput