

Session Recovery

With robust hardware failover and redundancy protection, any hardware or software failures on the system can quickly be corrected. However, software failures can occur for numerous reasons, often without prior indication.

This chapter describes the Session Recovery feature that provides seamless failover and reconstruction of subscriber session information in the event of a hardware or software fault.

Important Session Recovery is a licensed Cisco feature. A separate feature license may be required. Contact your Cisco account representative for detailed information on specific licensing requirements. For information on installing and verifying licenses, refer to the *Managing License Keys* section of *Software Management Operations*.

This chapter includes the following sections:

- How Session Recovery Works, on page 1
- Configuring the System to Support Session Recovery, on page 4
- Recovery Control Task Statistics, on page 8
- SRP Monitor-Based Switchovers for ICSR Nodes, on page 11

How Session Recovery Works

This section provides an overview of how this feature is implemented and the recovery process.

The Session Recovery feature provides seamless failover and reconstruction of subscriber session information in the event of a hardware or software fault within the system preventing a fully connected user session from being disconnected.

Session recovery is performed by mirroring key software processes (for example, session manager and AAA manager) within the system. These mirrored processes remain in an idle state (standby-mode) wherein they perform no processing, until they may be needed in the event of a software failure (for example, a session manager task aborts).

There are some situations wherein session recovery may not operate properly. These include:

- Additional software or hardware failures occur during the session recovery operation. For example, an AAA manager fails while the state information it contained was being used to populate the newly activated session manager task.

- A lack of hardware resources (packet processing card memory and control processors) to support session recovery.

Important After a session recovery operation, some statistics, such as those collected and maintained on a per manager basis (AAA Manager, Session Manager, etc.) are in general not recovered, only accounting and billing related information is checkpointed and recovered.

Session Recovery is available for the following functions:

- Any session needing L2TP LAC support (excluding regenerated PPP on top of an HA or GGSN session)
- ASR 5500 only – Closed RP PDSN services supporting simple IP, Mobile IP, and Proxy Mobile IP
- ASR 5500 only – eHRPD service (evolved High Rate Packet Data)
- ASR 5500 only – ePDG service (evolved Packet Data Gateway)
- ASR 5000 only – eWAG service (enhanced Wireless Access Gateway)
- GGSN services for IPv4 and PPP PDP contexts
- HA services supporting Mobile IP and/or Proxy Mobile IP session types with or without per-user Layer 3 tunnels
- ASR 5500 only – HNB-GW: HNB Session over IuH
- ASR 5500 only – HNB-GW: HNB-CN Session over IuPS and IuCS
- ASR 5500 only – HNB-GW: SeGW Session IPSec Tunnel
- ASR 5500 only – HSGW services for IPv4
- IPCF (Intelligent Policy Control Function)
- ASR 5500 only – IPSG-only systems (IP Services Gateway)
- LNS session types (L2TP Network Server)
- MME (Mobility Management Entity)
- ASR 5500 only – NEMO (Network Mobility)
- P-GW services for IPv4
- ASR 5000 only – PDG/TTG (Packet Data Gateway/Tunnel Termination Gateway)
- ASR 5500 only – PDIF (Packet Data Interworking Function)
- PDSN services supporting simple IP, Mobile IP, and Proxy Mobile IP
- S-GW (Serving Gateway)
- SGSN (Serving GPRS Support Node) services
- ASR 5000 and VPC-DI – IPv6 and IPv4IPv6 (dual) PDP session recovery is supported for 3G and 2G services
- SaMOG (S2a Mobility over GTP) Gateway (CGW and MRME)

- ASR 5500 only – SAE-GW (System Architecture Evolution Gateway)
- SCM (Service Control Manager)
- ASR 5500 only – SGSN services (3G and 2.5G services) for IPv4 and PPP PDP contexts

Session recovery is **not supported** for the following functions:

- Destination-based accounting recovery
- GGSN network initiated connections
- GGSN session using more than 1 service instance
- MIP/L2TP with IPSec integration
- MIP session with multiple concurrent bindings
- Mobile IP sessions with L2TP
- Multiple MIP sessions
- :RAB recovery



Important Always refer to the Administration Guides for individual products for other possible session recovery and Interchassis Session Recovery (ICSR) support limitations.

When session recovery occurs, the system reconstructs the following subscriber information:

- Data and control state information required to maintain correct call behavior.
- A minimal set of subscriber data statistics; required to ensure that accounting information is maintained.
- A best-effort attempt to recover various timer values such as call duration, absolute time, and others.
- The idle time timer is reset to zero and the re-registration timer is reset to its maximum value for HA sessions to provide a more conservative approach to session recovery.

Session Recovery is also useful for Software Patch Upgrade activities. When enabled during the software patch process, Session Recovery preserves existing sessions on the active packet processing cards.For more details refer to *Performing Dynamic Software Patch Updates* in the *Software Management Operations* chapter.



Important Any partially connected calls (for example, a session where HA authentication was pending but has not yet been acknowledged by the AAA server) are not recovered when a failure occurs.



Note Failure of critical tasks will result in restarting StarOS. Kernel failures, hypervisor failures or hardware failures will result in the VM restarting or going offline. The use of ICSR between two VPC-DIs or two VPC-SIs is the recommended solution for these types of failure.

Configuring the System to Support Session Recovery

The following procedures allow you to configure the session recovery feature for either an operational system that is currently in-service (able to accept incoming calls) or a system that is out-of-service (not part of your production network and, therefore, not processing any live subscriber/customer data).



Important The session recovery feature, even when the feature use key is present, is disabled by default on the system.

Enabling Session Recovery

As noted earlier, session recovery can be enabled on a system that is out-of-service (OOS) and does not yet have any contexts configured, or on an in-service system that is currently capable of processing calls. However, if the system is in-service, it must be restarted before the session recovery feature takes effect.

Enabling Session Recovery on an Out-of-Service System

The following procedure is for a system that does not have any contexts configured.

To enable the session recovery feature on an out-of-service system, follow the procedure below. This procedure assumes that you begin at the Exec mode prompt.

Procedure

Step 1 At the Exec mode prompt, verify that the session recovery feature is enabled via the session and feature use licenses on the system by running the **show license info** command.

If the current status of the Session Recovery feature is Disabled, you cannot enable this feature until a license key is installed in the system.

Step 2 Use the following configuration example to enable session recovery.

```
configure
 require session recovery
     end
```

Note
After you configure this command, you must save the configuration and then reload the chassis for the command to take effect. For information on saving the configuration file and reloading the chassis, refer to the System Administration Guide for your deployment.

Step 3 Save your configuration as described in *Verifying and Saving Your Configuration*.

The system, when started, enables session recovery, creates all mirrored "standby-mode" tasks, and performs packet processing card reservations and other operations automatically.

Step 4 After the system has been configured and placed in-service, you should verify the preparedness of the system to support this feature as described in Viewing Session Recovery Status, on page 6

Enabling Session Recovery on an In-Service System

When enabling session recovery on a system that already has a saved configuration, the session recovery commands are automatically placed before any service configuration commands in the configuration file.

To enable the session recovery feature on an in-service system, follow the procedure below. This procedure assumes that you begin at the Exec mode prompt.

Procedure

Step 1 At the Exec mode prompt, verify that the session recovery feature is enabled via the session and feature use licenses on the system by running the **show license info** command:

If the current status of the Session Recovery feature is Disabled, You cannot enable this feature until a license key is installed in the system.

Step 2 Use the following configuration example to enable session recovery.

```
configure
  require session recovery
  end
```

This feature does not take effect until after the system has been restarted.

Step 3 Save your configuration as described in *Verifying and Saving Your Configuration*.

Step 4 Perform a system restart by entering the **reload** command:

The following prompt appears:

```
Are you sure&quest; [Yes|No]:
```

Confirm your desire to perform a system restart by entering **yes**.

The system, when restarted, enables session recovery and creates all mirrored "standby-mode" tasks, performs packet processing card reservations, and other operations automatically.

Step 5 After the system has been restarted, you should verify the preparedness of the system to support this feature as described in Viewing Session Recovery Status, on page 6

More advanced users may opt to simply insert the **require session recovery** command syntax into an existing configuration file using a text editor or other means, and then applying the configuration file manually. Exercise caution when doing this to ensure that this command is placed among the first few lines of any existing configuration file; it must appear before the creation of any non-local context.

Disabling the Session Recovery Feature

To disable the session recovery feature on a system, enter the **no require session recovery** command from the Global Configuration mode prompt.

Important If this command is issued on an in-service system, then the system must be restarted by issuing the **reload** command.

Viewing Session Recovery Status

To determine if the system is capable of performing session recovery, when enabled, enter the **show session recovery status verbose** command from the Exec mode prompt.

The output of this command should be similar to the examples shown below.

```
[local]host_name# show session recovery status
Session Recovery Status:
     Overall Status             :  SESSMGR Not Ready For Recovery
     Last Status Update         :  1 second ago

[local]host_name# show session recovery status
Session Recovery Status:
    Overall Status              :  Ready For Recovery
    Last Status Update          :  8 seconds ago

[local]host_name# show session recovery status verbose
Session Recovery Status:
    Overall Status              :  Ready For Recovery
    Last Status Update          :  2 seconds ago

               ----sessmgr----       ----aaamgr----         demux
 cpu state     active    standby     active    standby      active    status
---- -------   ------    -------     ------    -------      ------    ------------
 1/1 Active    2         1           1         1            0         Good
 1/2 Active    1         1           0         0            0         Good
 1/3 Active    1         1           3         1            0         Good
 2/1 Active    1         1           1         1            0         Good
 2/2 Active    1         1           0         0            0         Good
 2/3 Active    2         1           3         1            0         Good
 3/0 Active    0         0           0         0            1         Good (Demux)
 3/2 Active    0         0           0         0            1         Good (Demux)
 4/1 Standby   0         2           0         1            0         Good
 4/2 Standby   0         1           0         0            0         Good
 4/3 Standby   0         2           0         3            0         Good
[local]host_name#
```

Viewing Recovered Session Information

Per subscriber session information is available to show any changes in session recovery status. A field named "Redundancy Status" in output of the **show subscriber debug-info** command shows whether or not the session has been recovered or is the original information. There are two valid outputs for this field:

- **Original** - indicating that this is the original session information, containing all event states and time information.
- **Recreated Session** - indicating that this session was reconstructed during a session recovery operation.

This command can be executed before or after a session recovery operation has been performed, and would show information relative to the specific session.

To view session state information and any session recovery status, enter the following command:

```
[local]host_name# show subscriber debug-info { callid id | msid id | username
 name }
```

Keyword/Variable	Description
callid *id*	Displays subscriber information for the call specified by *id*. The call ID is an 8-byte hexadecimal number.
msid *id*	Displays information for the mobile user identified by an MSID from 7 to 16 digits specified as an IMSI, MIN, or RMI. Wildcard characters $ and * are allowed. The * wildcard matches multiple characters and the $ wildcard matches a single character. If you do not want the wildcard characters interpreted as a wildcard enclose them in single quotes ('). For example; '$'.
username *name*	Displays information for connections for the subscriber identified by a previously configured username. *name* is a sequence of alphanumeric characters and/or wildcard characters ('$' and '*') from 1 to 127 characters in length. The * wildcard matches multiple characters and the $ wildcard matches a single character. If you do not want the wildcard characters interpreted as wildcard enclose them in single quotes ('). For example; '$'.

The following example shows the output of this command both before and after a session recovery operation has been performed. The "Redundancy Status" fields in this example have been bold-faced for clarity.

```
username: user1              callid: 01ca11b1                  msid: 0000100003
    Card/Cpu: 4/2
    Sessmgr Instance: 7
    Primary callline:
    Redundancy Status: Original Session
      Checkpoints        Attempts        Success        Last-Attempt       Last-Success
          Full:               69             68             29800ms            29800ms
          Micro:             206            206             20100ms            20100ms
      Current state: SMGR_STATE_CONNECTED
      FSM Event trace:
            State                            Event
            SMGR_STATE_OPEN                  SMGR_EVT_NEWCALL
            SMGR_STATE_NEWCALL_ARRIVED       SMGR_EVT_ANSWER_CALL
            SMGR_STATE_NEWCALL_ANSWERED      SMGR_EVT_LINE_CONNECTED
            SMGR_STATE_LINE_CONNECTED        SMGR_EVT_LINK_CONTROL_UP
            SMGR_STATE_LINE_CONNECTED        SMGR_EVT_AUTH_REQ
            SMGR_STATE_LINE_CONNECTED        SMGR_EVT_IPADDR_ALLOC_SUCCESS
            SMGR_STATE_LINE_CONNECTED        SMGR_EVT_AUTH_SUCCESS
            SMGR_STATE_LINE_CONNECTED        SMGR_EVT_UPDATE_SESS_CONFIG
            SMGR_STATE_LINE_CONNECTED        SMGR_EVT_LOWER_LAYER_UP
    Data Reorder statistics
    Total timer expiry:              0        Total flush (tmr expiry):    0
            Total no buffers:        0        Total flush (no buffers):    0
            Total flush (queue full): 0       Total flush (out of range):  0
            Total flush (svc change): 0       Total out-of-seq pkt drop:   0
            Total out-of-seq arrived: 0
    IPv4 Reassembly Statistics:
              Success:               0        In Progress: 0
              Failure (timeout):     0        Failure (no buffers): 0
              Failure (other reasons): 0
    Redirected Session Entries:              Allowed:
2000            Current:                                  0
                Added:                                    0                Deleted:
                                  0
```

```
          Revoked for use by different subscriber: 0
Peer callline:
 Redundancy Status: Recovered Session
Checkpoints        Attempts        Success        Last-Attempt        Last-Success
      Full:              0              0                0ms                0ms
      Micro:             0              0                0ms                0ms
  Current state: SMGR_STATE_CONNECTED
  FSM Event trace:
        State                                                    Event
        SMGR_STATE_LINE_CONNECTED            SMGR_EVT_LOWER_LAYER_UP
        SMGR_STATE_CONNECTED                 SMGR_EVT_AUTH_REQ
        SMGR_STATE_CONNECTED                 SMGR_EVT_AUTH_SUCCESS
        SMGR_STATE_CONNECTED                 SMGR_EVT_REQ_SUB_SESSION
        SMGR_STATE_CONNECTED                 SMGR_EVT_RSP_SUB_SESSION
        SMGR_STATE_CONNECTED                 SMGR_EVT_ADD_SUB_SESSION
        SMGR_STATE_CONNECTED                 SMGR_EVT_AUTH_REQ
        SMGR_STATE_CONNECTED                 SMGR_EVT_AUTH_SUCCESS
        SMGR_STATE_CONNECTED                 SMGR_EVT_AUTH_REQ
        SMGR_STATE_CONNECTED                 SMGR_EVT_AUTH_SUCCESS
        SMGR_STATE_CONNECTED                 SMGR_EVT_AUTH_REQ
        SMGR_STATE_CONNECTED                 SMGR_EVT_AUTH_SUCCESS
        SMGR_STATE_CONNECTED                 SMGR_EVT_AUTH_REQ
        SMGR_STATE_CONNECTED                 SMGR_EVT_AUTH_SUCCESS
        SMGR_STATE_CONNECTED                 SMGR_EVT_AUTH_REQ
        SMGR_STATE_CONNECTED                 SMGR_EVT_AUTH_SUCCESS
Data Reorder statistics
        Total timer expiry:        0          Total flush (tmr expiry):  0
        Total no buffers:          0          Total flush (no buffers):  0
        Total flush (queue full):  0          Total flush (out of range):0
        Total flush (svc change):  0          Total out-of-seq pkt drop: 0
        Total out-of-seq arrived:  0
IPv4 Reassembly Statistics:
          Success:                   0        In Progress:               0
          Failure (timeout):         0        Failure (no buffers):      0
          Failure (other reasons):   0
Redirected Session Entries:
          Allowed:                2000         Current:             0
          Added:                               Deleted:             0
          Revoked for use by different subscriber:  0
```

Recovery Control Task Statistics

Recovery Control Task (RCT) statistics show the following:

- Recovery action taken – Migration, Shutdown, Switchover
- Type of event – Planned or Unplanned
- From card to card – slot numbers
- Start time – YYYY-MMM-DD+hh:mm:sss.sss
- Duration – seconds
- Card failure device (such as CPU*n*)
- Card failure reason
- Card is in usable state or not failed
- Recovery action status – Success or failure reason
- If recovery action failed, failure time stamp
- If recovery action failed, failure task facility name
- If recovery action failed, failure instance number

show rct stats Command

The Exec mode **show rct stats** command employs the following syntax:

```
[local]host_name# show rct stats [verbose]
```

Without the **verbose** keyword, a summary output is displayed as show in the example below:

```
RCT stats details (Last 1 Actions)

 #  Action        Type      From  To  Start Time                Duration    Status
--- ------------- --------- ---- ---- ------------------------  ----------  -------
 1  Migration(st) Planned     2    1  2016-Jul-12+13:12:21.865   0.003 sec  Success


RCT stats summary
-----------------
Migrations  =              0
  Management Card:     0             Average time: 0.000 sec
  Packet Card    :     1             Average time: 0.006 sec
Switchovers =              1, Average time - 25.855 sec
```

With the verbose keyword the detailed statistics show in Sample Output for show rct stats verbose, on page 9 are provided.

Sample Output for show rct stats verbose

```
[local]host_name# show rct stats verbose

RCT stats Details (Last 5 Actions)

Stats 1:
    Action          : Migration
    Type            : Planned
    From            : 5
    To              : 6
    Start Time      : 2017-Apr-04+03:02:00.132
    Failure Reason  : CPU_CRITICAL_TASK_FAILURE
    Failure Device  : CPU_0
    Is Card Usable  : Yes
    Recovery Status : Success
    Facility        : N.A
    Instance        : N.A
    Duration        : 066.050 sec
    Graceful        : Enabled
      Recovered [1] :[f:sessmgr, i:6, cpu:50, pid:13170
      Recovered [2] :[f:sessmgr, i:3, cpu:50, pid:13167]

RCT stats Details (Last 5 Actions)

Stats 2:
    Action          : Shutdown
    From            : 12
    To              : 13
    Start Time      : 2017-Apr-04+03:02:10.100
    Is Card Usable  : Yes
    Failure Reason  : NPU_LC_CONNECT_TOP_FAIL
    Failure Device  : PAC_LC_CONNECT_HARDWARE
    Recovery Status : Success
    Facility        : N.A
    Instance        : N.A
    Duration        : 002.901 sec
```

```
    Graceful        : Enabled
      Recovered [1] :[f:sessmgr, i:6, cpu:50, pid:13170
      Recovered [2] :[f:sessmgr, i:3, cpu:50, pid:13167]

Stats 3:
    Action          : Migration
    From            : 7
    To              : 11
    Start Time      : 2017-Apr-04+03:03:40.120
    Is Card Usable  : Yes
    Failure Reason  : N.A.
    Failure Device  : N.A
    Recovery Status : Success
    Facility        : N.A
    Instance        : N.A
    Duration        : 003.423 sec
    Graceful        : Enabled
      Recovered [1] :[f:sessmgr, i:6, cpu:50, pid:13170
      Recovered [2] :[f:sessmgr, i:3, cpu:50, pid:13167]

Stats 4:
    Action          : Migration
    From            : 7
    To              : 11
    Start Time      : 2017-Apr-04+03:03:41.256
    Is Card Usable  : Yes
    Failure Reason  : N.A.
    Failure Device  : N.A
    Recovery Status : TASK_MIGRATION_FAIL_PREMIGRATE
    Facility        : vpnmgr
    Instance        : 13
    Duration        : 005.222 sec
    Graceful        : Enabled
      Recovered [1] :[f:sessmgr, i:6, cpu:50, pid:13170
      Recovered [2] :[f:sessmgr, i:3, cpu:50, pid:13167]

Stats 5:
    Action          : Migration
    From            : 6
    To              : 7
    Start Time      : 2017-Apr-04+04:18:30.106
    Is Card Usable  : Yes
    Failure Reason  : N.A.
    Failure Device  : N.A
    Recovery Status : TASK_MIGRATION_FAIL_RENAME
    Facility        : sessmgr
    Instance        : 63
    Duration        : 004.134 sec
    Graceful        : Enabled
      Recovered [1] :[f:sessmgr, i:6, cpu:50, pid:13170
      Recovered [2] :[f:sessmgr, i:3, cpu:50, pid:13167]

RCT stats Summary
-----------------
Migrations  =       3, Average time = 4.260 sec
Switchovers =       0
```

SRP Monitor-Based Switchovers for ICSR Nodes

Table 1: Feature History

Feature Name	Release Information	Description
Disabling SRP Monitor-based switchovers for ICSR nodes	2025.03.0	This feature lets operators disable Service Redundancy Protocol (SRP) monitor-based switchovers in the ICSR pair nodes preventing interruptions and ensuring session integrity during such events. Command Introduced: **srp-monitor-based-switchover { enable | disable }** **Default Settings**: Enabled – Always-on

Before this feature, transport-side upgrades or troubleshooting could cause unnecessary switchovers in Inter Chassis Session Recovery (ICSR) node pairs. This occurred due to temporary connectivity loss with Border Gateway Protocol (BGP), Authentication, Authorization, and Accounting (AAA), and Diameter endpoints. The Disable SRP Monitor Based Switchover feature allows operators more control over ICSR switchover behavior.

This feature lets operators disable switchovers triggered by failures detected in BGP, AAAA, and Diameter interfaces monitored by the SRP, preventing unwanted switchovers during maintenance or troubleshooting activities.

This feature does not impact manual switchovers and is applicable only for ICSR and SRP enabled nodes.

Session synchronization remains uninterrupted if connectivity between the active and standby nodes is maintained.

Benefits

The disabled SRP monitor based switchover feature in an ICSR node pairs offers several advantages:

- **Reduced Unnecessary Switchovers**: Prevents switchovers caused by temporary connectivity losses during transport-side maintenance, upgrades, or troubleshooting.
- **Improved Operational Stability**: Maintains session integrity and minimizes service disruptions.
- **Increased Control**: Provides operators with the ability to control switchover behavior based on specific operational needs.
- **Simplified Maintenance**: Enables maintenance and troubleshooting on the transport side without the risk of triggering unnecessary switchovers.

Configure srp monitor-based switchover

The SRP Monitor Based Switchover introduces a new CLI command that allows administrators to disable or enable SRP monitor-based switchovers for BGP, AAA, and Diameter interface failures. It does not affect switchovers triggered by card failures, VPP, BFD, volume-based, or HSRP-based monitoring, or manual switchovers.

Enable srp monitor-based switchover

To enable the srp monitor-based switchover feature on the ICSR nodes, follow the procedure. SNMP traps are generated to notify the NMS (Network Management System) when the switchover behavior is enabled. This procedure assumes that you begin at the Exec mode prompt.

Procedure

1. At the Exec mode prompt, enter the **srp-monitor-based-switchover** command to handle internal switchovers based on service-redundancy-protocol monitor configuration.

   Example

   ```
   configure
     srp-monitor-based-switchover
     exit
   end
   ```

2. Specify the enable option to enable the srp monitor-based switchover.

   Example

   ```
   configure
     srp-monitor-based-switchover { enable }
     exit
   end
   ```

3. Save your configuration as described in *Verifying and Saving Your Configuration* section.
4. After the srp monitor-based switchover on the ICSR nodes is enabled, verify the status of the SRP monitor and switchover requests ignored during switchover disable. For more information, see the *Verify srp monitor-based switchover* section.

Disable srp monitor-based switchover

To disable the srp monitor-based switchover feature on the ICSR nodes, follow the procedure. This procedure assumes that you begin at the Exec mode prompt.

Procedure

1. At the Exec mode prompt, enter the **srp-monitor-based-switchover** command to handle internal switchovers based on service-redundancy-protocol monitor configuration.

   Example

   ```
   configure
     srp-monitor-based-switchover
   ```

```
  exit
end
```

2. Specify the disable option to disable the srp monitor-based switchover. During disable function:
   - the system continues to monitor the status of BGP, AAA, and Diameter entities,
   - When a failure is detected in one of these monitored entities and switchovers are disabled, the system will not initiate a switchover. The damping period timer will be re-run,
   - SNMP traps are generated to notify the NMS (Network Management System) when the switchover behavior is disabled, and
   - When switchovers are re-enabled, the system immediately initiates a switchover if any of the monitored entities are still in a failed state and the damping period has elapsed.

   Example

   ```
   configure
     srp-monitor-based-switchover { disable }
     exit
   end
   ```

3. Save your configuration as described in *Verifying and Saving Your Configuration* section.
4. After the srp monitor-based switchover on the ICSR nodes is disabled, verify the status of the SRP monitor and switchover requests ignored during switchover disable. For more information, see the Verify srp monitor section.

Verify SRP monitor

The **show srp monitor** command displays the current status of the SRP monitor, including whether SRP monitor-based switchover is enabled or disabled. The **show srp statistics** command includes a counter for switchover requests ignored during switchover disable.

Using CLI data

The Show CLI's are used to display SRP monitor based switchover related status, counters and SNMP trap details.

show srp monitor

Displays switchover state whether it will perform switchover or not when SRP monitor failures occur.

```
[local]VNF3-CF1# show srp monitor
Auth. probe monitor state: Success
Auth. probe monitors up:   0
Auth. probe monitors down: 0
Auth. probe monitors init: 0

BFD monitor state:         Success
BFD monitors up:           0
BFD monitors down:         0
BFD monitors init:         0

DIAMETER monitor state:         Success
```

```
DIAMETER monitors up:           0
DIAMETER monitors down:         0
DIAMETER monitors init:         0

EGQC monitor state:         Success
CARD monitor state:         Success
VPP monitor state:          Success
SX monitor state:           Success
SRP monitor based switchover mode: Enabled/Disabled
```

show srp statistics

Displays SRP and switchover related statistics. New counter added to display number of switchover occurrences when switchover state for SRP monitor failure is disabled and monitor failure detects.

```
local]VNF3-CF1# show srp statistics
Service Redundancy Protocol:
----------------------------
 Peer Remote Address:                                  2001:4888:10:13:132:1111:1111:149

 Hello Messages Sent:                                      28035
 Hello Messages Received:                                  28036
 Hello Messages Discarded:                                 0
 Configuration Validation Messages Sent:                   81
 Configuration Validation Messages Received:               81
 Configuration Validation Messages Discarded:              0
 Resource Messages Sent:                                   2315
 Resource Messages Received:                               13
 Resource Messages Discarded:                              0
 Switchover Req Messages Sent:                             23
 Switchover Req Messages Received:                         2
 Switchover Rsp Messages Sent:                             2
 Switchover Rsp Messages Received:                         23
 Switchover Rsp Ack Messages Sent:                         0
 Switchover Rsp Ack Messages Received:                     0
 Switchover Messages Discarded:                            0
 Switchover Events:                                        3
 Switchover Req ignored during swo disable:                0
```

show snmp trap history

Displays history about **SRPMonBasedSwitchoverEnabled** and **SRPMonBasedSwitchoverDisabled** traps.

```
[local]pgw# show snmp trap history
There are 34 historical trap records (5000 maximum)

Timestamp                Trap Information
-----------------------
-------------------------------------------------------------------------------------------------------------------------------------------------------
Thu Feb 27 00:06:39 2025 Internal trap notification 52 (CLISessionStart) user #initial-config#
 privilege level Security Administrator ttyname /dev/pts/1
Thu Feb 27 00:06:40 2025 Internal trap notification 1186 (HiddenAccessEnabled) context local
 user #initial-config# ttyname /dev/pts/1 address type IPV4 remote ip address 0.0.0.0
Thu Feb 27 00:07:05 2025 Internal trap notification xxxx (SRPMonBasedSwitchoverEnabled) SRP
 monitor based switchover is enabled for monitor failures
Thu Feb 27 00:07:05 2025 Internal trap notification xxxx (SRPMonBasedSwitchoverDisabled)
SRP monitor based switchover is disabled for monitor failures
Thu Feb 27 00:07:05 2025 Internal trap notification xxxx (SRPMonBasedSwitchoverEnabled) SRP
 monitor based switchover is enabled for monitor failures
```

show snmp trap staistics

Displays statistics about **SRPMonBasedSwitchoverEnabled** and **SRPMonBasedSwitchoverDisabled** traps.

```
[local]pgw# show snmp trap statistics
SNMP Notification Statistics:
  Total number of notifications   : 34
  Last notification sent          : Thursday February 27 00:07:04 EST 2025
  Notification sending is         : enabled
  Notifications have never been disabled
  Notifications have never been cleared
  Notifications in current period : 0
  Notifications in previous period: 0
  Notification monitor period     : 300 seconds

Trap Name                           #Gen #Disc  Disable Last Generated
---------------------------------- ----- -----  ------- --------------------
PortLinkUp                             4     0       0  2025:02:27:00:07:01
CLISessionStart                        1     0       0  2025:02:27:00:06:39
GGSNServiceStart                       1     0       0  2025:02:27:00:06:56
PortUp                                 4     0       0  2025:02:27:00:07:01
SystemStartup                          1     0       0  2025:02:27:00:06:41
PGWServiceStart                        1     0       0  2025:02:27:00:06:56
SGWServiceStart                        1     0       0  2025:02:27:00:07:04
EGTPServiceStart                       3     0       0  2025:02:27:00:07:04
TestModeEntered                        1     0       0  2025:02:27:00:06:39
HiddenAccessEnabled                    1     0       0  2025:02:27:00:06:39
TechSuppPasswdChanged                  1     0       0  2025:02:27:00:06:39
TetheringTACDatabaseUpgradeFailureStatus     1     0       0  2025:02:27:00:07:04
TetheringOSDatabaseUpgradeFailureStatus     1     0       0  2025:02:27:00:07:04
TetheringUADatabaseUpgradeFailureStatus     1     0       0  2025:02:27:00:07:04
DisabledEventIDs                       9     0       0  2025:02:27:00:06:41
CiscoMwsServiceStart                   9     0       9  2025:02:27:00:07:04
EntStateOperEnabled                    4     0       4  2025:02:27:00:07:01
SRPMonBasedSwitchoverEnabled  2     0       0 2025:02:27:00:07:01
SRPMonBasedSwitchoverDisabled  1    0       0  2025:02:27:00:07:00
```

show alarm outstanding

Displays all outstanding alarms. This will be available when **srp-monitor-based-switchover disable** is configured clears when **srp-monitor-based-switchover enable** is configured

.

```
[local]pgw# show alarm outstanding
Sev Object          Event
--- ----------
```

```
MN  Chassis         SRP monitor based switchover is disabled for AAA, Diameter and BGP
monitor failures
```

show alarm all

Displays all alarms. This will be available when **srp-monitor-based-switchover disable** is configured clears when **srp-monitor-based-switchover enable** is configured.

.

```
[local]pgw# show alarm all
Facility Alarm Information:

Audible Alarm OFF
All Central Office (CO) alarms are off

Alarm Statistics:
```

```
  Current Outstanding Alarms
    Total:    1
    Critical: 0
    Major:    0
    Minor:    1
  Cumulative Totals
    Total:    3
    Critical: 0
    Major:    0
    Minor:    3
  Last Alarm Received: Tuesday June 17 02:44:04 EDT 2025

Outstanding Alarms:

Sev Object          Event
--- ----------
--------------------------------------------------------------------------------------------------------------------------------------------------------------

MN  Chassis         SRP monitor based switchover is disabled for AAA, Diameter and BGP
monitor failures
```