

Set Up Wired Network

- Set Up Wired Network, on page 1

Set Up Wired Network

The Cisco Spaces**: Connector** enables you to connect your wired and wireless networks with Cisco Spaces.

To set up a wired network, you must have Cisco Catalyst 9300 Series switches and also Cisco Spaces**: Connector** installed on a virtual machine.

Cisco Spaces: Connector 3.0 is now available under the **Menu (** **)** > **Setup** > **Wired Network** section. You can create 3.0 connectors under the **Wired Network**.

Connector 3.0 capabilities such as service association, instance tracking, and metrics visualizations, are available in the **Wired Network** section.

The Wired Network page includes connector and switch management actions, such as **Create Connector**, **View Connectors**, **Add Switches**, and **View Switches**. In the Configure Spaces Connector section, you can create connectors.

- In the **Configure Spaces Connector** section.
- Click **Create Connectors**.
- Click **Create New Connector**.
- In the **Spaces Connector Name** field, enter the spaces connector name.
- Click **Save**.
- Click **View Connectors**.
- In the **Actions** column, click the Test Connectivity, Edit, or Delete icon if needed.
- In the **Add Switch** section.
- Click **Add Switches**.
- Select **Add new switch**.

  Select **Connectors** from the drop-down list.

In the **Switch Name** field, enter the Switch name.

In the **Switch IP** field, enter Switch IP.

In the **Netconfig Username** field, enter the Netconfig Username.

Click **Add Location**, then select the location from the loation hierarchy.

- Select **Choose switches from another connector**.

  Click **Add Location**, then select the location from the loation hierarchy.

  Choose connector from the drop-down list.

- Select **Import switches from spreadsheet**.

  Select **Connector** from the drop-down list.

  Follow the on-screen instructions.

  Click **Next**.

- Click **Save**.
- Click **View Switches**.
- In the **Actions** column, click the Test Connectivity, Edit, or Delete icon if required.

For more information about setting up Cisco Spaces**: Connector**, refer to the *Cisco Spaces**: Connector** Configuration Guide* at:

https://www.cisco.com/c/en/us/td/docs/wireless/spaces/connector/config/b_connector_30.html.