

# FIPS Certification


- FIPS certification, on page 1
- Enable or disable FIPS mode, on page 1
- Verify FIPS mode using CLI, on page 2


# FIPS certification

FIPS certification is a compliance mode that ensures SSH and GUI functionalities comply with FIPS140-3 security standards from NIST. When enabled, it also ensures that the AP configuration meets FIPS requirements.

**Note** FIPS certification does not support SNMP.

# Enable or disable FIPS mode

This task configures FIPS mode on an access point.

### Procedure

Use the **configure fips** { **enable** | **disable** } command to enable or disable FIPS mode on AP.

**Example:**

```
Device# configure fips enable
```

# Verify FIPS mode using CLI

### Procedure

Use the **show fips** command to verify FIPS mode on the AP.

**Example:**

```
Device# show fips
FIPS: enabled
```