

Credentials Management

• SAN Credentials Management, on page 1

SAN Credentials Management

Choose **Settings > SAN Credentials Management** to display the SNMP access details to the fabric seed switch. If the user has validated the access to all the fabrics, the SNMP credentials for all the seed switches of the fabrics is displayed.

The switch credentials window for the Cisco Nexus Dashboard Fabric Controller has the following fields:

Field	Description
Seed Switch	IP address of the switch.
Username	Specifies the username of the Cisco Nexus Dashboard Fabric Controller user.
Password	Displays the encrypted form of the switch SNMP user.
SNMPv3/SSH	Specifies if the SNMP protocol is validated or not. The default value is **false**.
Auth/Privacy	Specifies the Authentication protocol. The default value is **NOT_SET**.
Status	Displays the status of the switch.

Before the Cisco Nexus Dashboard Fabric Controller user configures the fabric using SNMP, the user must furnish and validate SNMP credentials on the seed switch of the fabric. If the user does not provide valid credentials for the fabric seed switch, the Switch Credentials table shows the default values for SNMPv3/SSH and AuthPrivacy fields.

The following table describes the action items, in the **Actions** menu drop-down list, that appear on **Settings > SAN Credentials Management**.

Action Item	Description
Edit	Select a row from the table and choose **Edit** to update the switch credentials information.
Clear	Clears the switch credentials.
Validate	Revalidates the switch credentials.