

MPLS OAM Commands

- address-family ipv4, on page 2
- address-family ipv4 reply, on page 3
- address-family ipv6 reply, on page 5
- clear mpls oam counters, on page 7
- echo disable-vendor-extension, on page 8
- echo lsp-properties-timeout, on page 9
- echo revision, on page 10
- mpls oam, on page 11
- ping mpls ipv4, on page 12
- ping mpls traffic-eng, on page 17
- ping mpls traffic-eng tunnel-te (P2P), on page 20
- show mpls oam, on page 23
- show mpls oam database, on page 25
- traceroute mpls ipv4, on page 26
- traceroute mpls multipath, on page 30
- traceroute mpls traffic-eng, on page 34
- traceroute mpls traffic-eng tunnel-te (P2P), on page 37

address-family ipv4

To configure the IPv4 address family parameters for MPLS OAM, use the **address-family ipv4** command in MPLS OAM configuration mode.

address-family ipv4 { **apply-group** *group-name* | **exclude-group** *group-name* | **reply ip-header-source** *source-ip* }

Syntax Description

apply-group *group-name*	Applies configuration from the specified group.
exclude-group *group-name*	Excludes the specified group from applying configuration.
reply ip-header-source *source-ip*	Configures the reply parameters for the specified IPv4 source ip address.

Command Default

None

Command Modes

MPLS OAM configuration mode

Command History

Release	Modification
Release 6.0	This command was introduced.

Usage Guidelines

No specific guidelines impact the use of this command.

Task ID

Task ID	Operations
mpls-te	read, write
mpls-ldp	read, write
mpls-static	read, write

Examples

This example displays the **address-family ipv4** command parameters.

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls oam
RP/0/RP0/CPU0:router(config-oam)# address-family ipv4 ?

  apply-group        Apply configuration from a group
  exclude-group      Exclude apply-group configuration from a group
  reply              Configure reply parameters for MPLS OAM address family
  <cr>
```

address-family ipv4 reply

To configure the reply parameters for MPLS OAM IPv4 address family, use the **address-family ipv4 reply** command in MPLS OAM configuration mode.

address-family ipv4 reply **ip-header-source** *source-ip-address*

Syntax Description

ip-header-source *source-ip-address*	Configures the specified MPLS OAM IPv4 source IP address in the reply node.

Command Default

None

Command Modes

MPLS OAM configuration mode

Command History

Release	Modification
Release 24.3.1	This command was introduced.

Usage Guidelines

Use the **address-family ipv4 reply ip-header-source** *source-ip-address* command if an explicit source ip is required in the MPLS OAM reply packets when route policies block packets with non-routed source addresses. By default, the MPLS OAM packets use the local interface address as the source.

Task ID

Task ID	Operations
mpls-te	read, write
mpls-ldp	read, write
mpls-static	read, write

Examples

This example configures the specified MPLS OAM IPv4 source IP address in the reply node.

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls oam
RP/0/RP0/CPU0:router(config-oam)# address-family ipv4 reply ip-header-source 1.1.1.4
RP/0/RP0/CPU0:router(config-oam)# commit
```

This example verifies the above MPLS OAM source IPv4 address configuration in the reply node.

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls oam
RP/0/RP0/CPU0:router(config-oam)# show running-config mpls oam

Thu Jun 20 13:43:28.855 IST
mpls oam
 address-family ipv4
```

```
 reply ip-header-source 1.1.1.4
!
```

address-family ipv6 reply

To configure the reply parameters for MPLS OAM IPv6 address family, use the **address-family ipv6 reply** command in MPLS OAM configuration mode.

address-family ipv6 reply **ip-header-source** *source-ip-address*

Syntax Description

ip-header-source *source-ip-address*	Configures the specified MPLS OAM IPv6 source IP address in the reply node.

Command Default

None

Command Modes

MPLS OAM configuration mode

Command History

Release	Modification
Release 24.3.1	This command was introduced.

Usage Guidelines

Use the **address-family ipv6 reply ip-header-source** *source-ip-address* command if an explicit source ip is required in the MPLS OAM reply packets when route policies block packets with non-routed source addresses. By default, the MPLS OAM packets use the local interface address as the source.

Task ID

Task ID	Operations
mpls-te	read, write
mpls-ldp	read, write
mpls-static	read, write

Examples

This example configures the specified MPLS OAM IPv6 source IP address in the reply node.

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls oam
RP/0/RP0/CPU0:router(config-oam)# address-family ipv6 reply ip-header-source 192::4
RP/0/RP0/CPU0:router(config-oam)# commit
```

This example verifies the above MPLS OAM source IPv6 address configuration in the reply node.

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls oam
RP/0/RP0/CPU0:router(config-oam)# show running-config mpls oam

Thu Jun 20 13:55:12.142 IST
mpls oam
 address-family ipv6
```

```
 reply ip-header-source 192::4
!
```

clear mpls oam counters

To clear MPLS OAM counters, use the **clear mpls oam counters** command in XR EXEC mode.

clear mpls oam counters {**global** | **interface** [*type* *interface-path-id*] | **packet**}

Syntax Description

global	Clears global counters.
interface	Clears counters on a specified interface.
type	Interface type. For more information, use the question mark (**?**) online help function.
interface-path-id	Physical interface or virtual interface. **Note** Use the **show interfaces** command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (**?**) online help function.
packet	Clears global packet counters.

Command Default

No default behavior or values

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

No specific guidelines impact the use of this command.

Task ID

Task ID	Operations
mpls-te	execute
mpls-ldp	execute
mpls-static	execute

Examples

The following example shows how to clear all global MPLS OAM counters:

```
RP/0/RP0/CPU0:router# clear mpls oam counters global
```

echo disable-vendor-extension

To disable sending the vendor extension type length and value (TLV) in the echo request, use the **echo disable-vendor extension** command in MPLS OAM configuration mode. To return to the default behavior, use the **no** form of this command.

echo disable-vendor-extension
no echo disable-vendor-extension

Syntax Description

This command has no arguments or keywords.

Command Default

The default value is 4.

Command Modes

MPLS OAM configuration mode

Command History

Release	Modification
Release 6.0	This command was introduced.

Usage Guidelines

No specific guidelines impact the use of this command.

Task ID

Task ID	Operations
mpls-ldp	read, write
mpls-static	read, write

Examples

The following example shows how to disable inclusion of the vendor extensions TLV in the echo requests:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls oam
RP/0/RP0/CPU0:router(config-oam)# echo disable-vendor-extension
```

echo lsp-properties-timeout

To configure the timeout for LSP properties request in the echo configuration, use the **echo lsp-properties-timeout** command in MPLS OAM configuration mode. To return to the default behavior, use the **no** form of this command.

echo lsp-properties-timeout *timeout*
no echo lsp-properties-timeout

Syntax Description

lsp-properties-timeout *timeout*	Specifies the timeout interval, in milliseconds. Range is 500 to 10000. Default is 2000 ms.

Command Default

The default timeout value is 2 seconds (2000 ms).

Command Modes

MPLS OAM configuration mode

Command History

Release	Modification
Release 26.2.1	This command was introduced.

Usage Guidelines

No specific guidelines impact the use of this command.

Task ID

Task ID	Operations
mpls-ldp	read, write
mpls-static	read, write

Examples

The following example shows how to configure timeout for LSP properties request in the echo configuration:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls oam
RP/0/RP0/CPU0:router(config-oam)# echo lsp-properties-timeout 2000
```

echo revision

To set the echo packet revision, use the **echo revision** command in MPLS OAM configuration mode. To return to the default behavior, use the **no** form of this command.

echo revision {**1** | **2** | **3** | **4**}
no echo revision

Syntax Description

1 | **2** | **3** | **4**	Draft revision number: • 1: RFC-ietf-mpls-lsp-ping-03 (initial) • 2: RFC-ietf-mpls-lsp-ping-03 (rev 1) • 3: RFC-ietf-mpls-lsp-ping-03 (rev 2) • 4: RFC-ietf-mpls-lsp-ping-09 (initial)

Command Default

The default echo revision is 4 (in RFC 9).

Command Modes

MPLS OAM configuration mode

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

No specific guidelines impact the use of this command.

Task ID

Task ID	Operations
mpls-te	read, write
mpls-ldp	read, write
mpls-static	read, write

Examples

The following example shows how to set the echo packet default revision:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls oam
RP/0/RP0/CPU0:router(config-oam)# echo revision 1
```

mpls oam

To enable MPLS OAM LSP verification, use the **mpls oam** command in XR Config mode. To return to the default behavior, use the **no** form of this command.

mpls oam
no mpls oam

Syntax Description

This command has no arguments or keywords.

Command Default

By default, MPLS OAM functionality is disabled.

Command Modes

XR Config mode

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

The **mpls oam** command and OAM functionality is described in the RFC 4379.

Task ID

Task ID	Operations
mpls-te	read, write
mpls-ldp	read, write
mpls-static	read, write

Examples

The following example shows how to enable MPLS OAM:

```
RP/0/RP0/CPU0:router# configure
RP/0/RP0/CPU0:router(config)# mpls oam
RP/0/RP0/CPU0:router(config-oam)#
```

ping mpls ipv4

To check MPLS host reachability and network connectivity by specifying the destination type as a Label Distribution Protocol (LDP) IPv4 address, use the **ping mpls ipv4** command in XR EXEC mode.

ping mpls ipv4 *address/mask* [**destination** *start-address end-address increment*] [**dsmap**] [**exp** *exp-bits*] [**force-explicit-null**] [**interval** *min-send-delay*] [**output interface** *type interface-path-id* [**nexthop** *nexthop-address*]][**pad** *pattern*][**repeat** *count*] [**reply** {**dscp** *dscp-value* | **reply mode** {**ipv4** | **no-reply** | **router-alert**} | **reply pad-tlv**}] [**revision** *version*] [**size** *packet-size*] [**source** *source-address*] [**sweep** *min value max value increment*] [**timeout** *timeout*] [**ttl** *value*] [**verbose**] [**fec-type** {**bgp** | **generic** | **ldp**}]

Syntax Description

address/mask	Address prefix of the target and number of bits in the target address network mask.
destination *start address end address address increment*	(Optional) Specifies a network 127/8 address to be used as the destination address in the echo request packet. ***start address*** Start of the network address. ***end address*** Start of the ending network address. ***address increment*** Incremental value of the network address, which is expressed as a decimal number value or IP address.
dsmap	(Optional) Indicates that a downstream mapping (DSMAP) type length and value should be included in the LSP echo request.
exp *exp-bits*	(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.
force-explicit-null	(Optional) Forces an unsolicited explicit null label to be added to the MPLS label stack and allows LSP ping to be used to detect LSP breakages at the penultimate hop.
interval *min-send-delay*	(Optional) Specifies a send interval, in milliseconds, between requests. Range is 0 to 3600000. Default is 0.
output interface	(Optional) Specifies the output interface where echo request packets are sent.

type	Interface type. For more information, use the question mark (**?**) online help function.
interface-path-id	Physical interface or virtual interface. **Note** Use the **show interfaces** command to see a list of all interfaces currently configured on the router. For more information, use the question mark (**?**) online help function.
nexthop	(Optional) Specifies the nextop as an IP address.
nexthop-iaddress	(Optional) IP address for the next hop.
pad *pattern*	(Optional) Specifies the pad pattern for an echo request.
repeat *count*	(Optional) Specifies the number of times to resend a packet. Range is 1 to 2147483647. Default is 5.
reply dscp *dscp-value*	Specifies the differentiated service codepoint value for an MPLS echo reply.
reply mode [**ipv4** | **router-alert** | **no-reply**]	Specifies the reply mode for the echo request packet. **no-reply** Do not reply **ipv4** Reply with an IPv4 UDP packet (this is the default) **router-alert** Reply with an IPv4 UDP packet with the IP router alert set
reply pad-tlv	Indicates that a pad TLV should be included.
revision *version*	(Optional) Specifies the Cisco extension TLV versioning field: • 1 RFC-ietf-mpls-lsp-ping-03 (initial) • 2 RFC-ietf-mpls-lsp-ping-03 (rev 1) • 3 RFC-ietf-mpls-lsp-ping-03 (rev 2) • 4 RFC-ietf-mpls-lsp-ping-09 (initial)
size *packet size*	(Optional) Specifies the packet size or number of bytes in each MPLS echo request packet. Range is 100 to 17986. Default is 100.

source *source-address*	(Optional) Specifies the source address used in the echo request packet.
sweep *min value max value interval*	(Optional) Specifies a range of sizes for the echo packets sent. ***min value*** Minimum or start size for an echo packet (range is 100 to 17986) ***max value*** Maximum or end size for an echo packet(range is 100 to 17986) ***interval*** Number used to increment an echo packet size(range is 1 to 8993)
timeout *timeout*	(Optional) Specifies the timeout interval, in seconds. Range is 0 to 3600. Default is 2.
ttl *value*	(Optional) Specifies the TTL value to be used in the MPLS labels (range is 1 to 255).
verbose	(Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.
fec-type	(Optional) Specifies FEC type to be used. **bgp** Use FEC type as BGP **generic** Use FEC type as generic **ldp** Use FEC type as LDP

Command Default

exp *exp bits*: 0

interval *min-send-delay*: 0

repeat *count* : 5

reply-mode: IPv4

timeout *timeout* : 2

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

The **output interface** keyword specifies the output interface on which the MPLS echo request packets are sent. If the specified output interface is not part of the LSP, the packets are not transmitted.

In cases where the sweep keyword is used, values larger than the outgoing interface's MTU are not transmitted.

The **ping** command sends an echo request packet to an address, and then awaits a reply. Ping output can help you evaluate path-to-host reliability, delays over the path, and whether the host can be reached or is functioning.

Note The **ping mpls** command is not supported on optical LSPs. If an optical LSP is encountered along the LSP's path, it is treated as a physical interface.

For detailed configuration information about the MPLS **ping** command, see *Cisco ASR 9000 Series Router Cisco IOS XR System Monitoring Configuration Guide for the CRS-1 Router Cisco XR 12000 Series Router*.

Task ID

Task ID	Operations
mpls-te	read, write
mpls-ldp	read, write

Examples

The following example shows the destination type as a label distribution protocol (LDP) prefix and specifies a range of sizes for the echo packets sent:

```
RP/0/RP0/CPU0:router# ping mpls ipv4 140.140.140/32 verbose sweep 100 200 15 repeat 1

  Sending 1, [100..200]-byte MPLS Echos to 140.140.140.140/32,
        timeout is 2 seconds, send interval is 0 msec:

  Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
    'L' - labeled output interface, 'B' - unlabeled output interface,
    'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
    'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
    'P' - no rx intf label prot, 'p' - premature termination of LSP,
    'R' - transit router, 'I' - unknown upstream index,
    'X' - unknown return code, 'x' - return code 0

  Type escape sequence to abort.
  !    size 100, reply addr 196.100.1.26, return code 3
  !    size 115, reply addr 196.100.1.26, return code 3
  !    size 130, reply addr 196.100.1.26, return code 3
  !    size 145, reply addr 196.100.1.26, return code 3
  !    size 160, reply addr 196.100.1.26, return code 3
  !    size 175, reply addr 196.100.1.26, return code 3
  !    size 190, reply addr 196.100.1.26, return code 3

  Success rate is 100 percent (7/7), round-trip min/avg/max = 5/6/8 ms
```

The following example shows the destination type as a label distribution protocol (LDP) prefix and specifies FEC type as generic and verbose option:

```
RP/0/RP0/CPU0:router# ping mpls ipv4 11.11.11.11/32 fec-type generic output interface
gigabitEthernet 0/0/0/3
nexthop 172.40.103.2 verbose

Sending 5, 100-byte MPLS Echos to 11.11.11.11/32,
      timeout is 2 seconds, send interval is 0 msec:

Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
  'L' - labeled output interface, 'B' - unlabeled output interface,
  'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
  'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
  'P' - no rx intf label prot, 'p' - premature termination of LSP,
  'R' - transit router, 'I' - unknown upstream index,
  'X' - unknown return code, 'x' - return code 0

Type escape sequence to abort.

!      size 100, reply addr 11.101.11.11, return code 3
!      size 100, reply addr 11.101.11.11, return code 3
!      size 100, reply addr 11.101.11.11, return code 3
!      size 100, reply addr 11.101.11.11, return code 3
!      size 100, reply addr 11.101.11.11, return code 3

Success rate is 100 percent (5/5), round-trip min/avg/max = 3/4/6 ms
```

ping mpls traffic-eng

To specify the destination type as an MPLS-TE tunnel and tunnel interface, use the **ping mpls traffic-eng** command in XR EXEC mode.

ping mpls traffic-eng tunnel *tunnel-ID* [**dsmap**] [**exp** *exp-bits*] [**force-explicit-null**] [**interval** *min-send-delay*] [**pad** *pattern*] [**repeat** *count*] [**reply** {**dscp** *dscp-value* | **reply mode** {**ipv4** | **no-reply** | **router-alert**} | **reply pad-tlv**}] [**revision** *version*] [**size** *packet-size*] [**source** *source-address*] [**sweep** *min-value max-value increment*] [**timeout** *timeout*] [**ttl** *value*] [**verbose**]

Syntax Description

tunnel *tunnel-ID*	Specifies the destination type as an MPLS traffic engineering (TE) tunnel and the tunnel interface number. The range for the tunnel interface number is from 0 to 65535.
dsmap	(Optional) Indicates that a downstream mapping (DSMAP) type length and value should be included in the LSP echo request.
exp *exp-bits*	(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.
force-explicit-null	(Optional) Forces an unsolicited explicit null label to be added to the MPLS label stack and allows LSP ping to be used to detect LSP breakages at the penultimate hop.
interval *min-send-delay*	(Optional) Specifies a send interval, in milliseconds, between requests. Range is 0 to 3600000. Default is 0.
pad *pattern*	(Optional) Specifies the pad pattern for an echo request.
repeat *count*	(Optional) Specifies the number of times to resend a packet. Range is 1 to 2147483647. Default is 5.
reply dscp *dscp-value*	(Optional) Specifies the differentiated service codepoint value for an MPLS echo reply.
reply mode [**ipv4** | **router-alert** | **no-reply**]	(Optional) Specifies the reply mode for the echo request packet. **no-reply** Do not reply **ipv4** Reply with an IPv4 UDP packet (this is the default) **router-alert** Reply with an IPv4 UDP packet with the IP router alert set
reply pad-tlv	(Optional) Indicates that a pad TLV should be included.

revision *version*	(Optional) Specifies the Cisco extension TLV versioning field: • 1 draft-ietf-mpls-lsp-ping-03 (initial) • 2 draft-ietf-mpls-lsp-ping-03 (rev 1) • 3 draft-ietf-mpls-lsp-ping-03 (rev 2) • 4 draft-ietf-mpls-lsp-ping-09 (initial)
size *packet-size*	(Optional) Specifies the packet size or number of bytes in each MPLS echo request packet. Range is 100 to 17986. Default is 100.
source *source-address*	(Optional) Specifies the source address used in the echo request packet.
sweep *min-value max-value interval*	(Optional) Specifies a range of sizes for the echo packets sent. ***min-value*** Minimum or start size for an echo packet (range is 100 to 17986) ***max-value*** Maximum or end size for an echo packet(range is 100 to 17986) ***interval*** Number used to increment an echo packet size(range is 1 to 8993)
timeout *timeout*	(Optional) Specifies the timeout interval, in seconds. Range is 0 to 3600. Default is 2.
ttl *value*	(Optional) Specifies the TTL value to be used in the MPLS labels (range is 1 to 255).
verbose	(Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.

Command Default

exp *exp-bits*: 0

interval *min-send-delay*: 0

repeat *count*: 5

reply-mode: IPv4

timeout *timeout* : 2

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

The **output interface** keyword specifies the output interface on which the MPLS echo request packets are sent. If the specified output interface is not part of the LSP, the packets are not transmitted.

In cases where the **sweep** keyword is used, values larger than the outgoing interface's MTU are not transmitted.

The **ping** command sends an echo request packet to an address, and then awaits a reply. Ping output can help you evaluate path-to-host reliability, delays over the path, and whether the host can be reached or is functioning.

Note The **ping mpls traffic-eng** command is not supported on optical LSPs. If an optical LSP is encountered along the LSP's path, it is treated as a physical interface.

Task ID

Task ID	Operations
mpls-te	read, write
mpls-ldp	read, write

Examples

The following example shows how to check connectivity by using the **ping mpls traffic-eng** command when a TE tunnel 10 is present. Return code, reply address, and packet size are displayed due to the **verbose** keyword.

```
RP/0/RP0/CPU0:router# ping mpls traffic-eng tunnel 10 repeat 1 verbose

  Sending 1, 100-byte MPLS Echos to tunnel-te10,
        timeout is 2 seconds, send interval is 0 msec:

  Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
    'L' - labeled output interface, 'B' - unlabeled output interface,
    'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
    'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
    'P' - no rx intf label prot, 'p' - premature termination of LSP,
    'R' - transit router, 'X' - unknown return code, 'x' - return code 0

  Type escape sequence to abort.
  !    size 100, reply addr 196.100.1.18, return code 3

  Success rate is 100 percent (1/1), round-trip min/avg/max = 15/15/15 ms
```

ping mpls traffic-eng tunnel-te (P2P)

To specify the destination type as an MPLS-TE tunnel and tunnel interface, use the **ping mpls traffic-eng tunnel-te** command in XR EXEC mode.

ping mpls traffic-eng tunnel-te *tunnel-ID* {**destination** *start-address end-address increment*}[**dsmap**] [**exp** *exp-bits*] [**force-explicit-null**] [**interval** *min-send-delay*] [**lsp** {**active** | **path-protect**}][**pad** *pattern*] [**repeat** *count*] [**reply** {**dscp** *dscp-value* | **mode** {**ipv4** | **no-reply** | **router-alert**} | **pad-tlv**}] [**revision** *version*] [**size** *packet-size*] [**source** *source-address*] [**sweep** *min-value max-value increment*] [**timeout** *timeout*] [**ttl** *value*] [**verbose**]

Syntax Description

tunnel-te *tunnel-ID*	Specifies the destination type as an MPLS traffic engineering (TE) tunnel and the tunnel interface number. The range for the tunnel interface number is 0 to 65535.
destination *start-address end-address increment*	Specifies a network 127/8 address to be used as the destination address in the echo request packet. ***start address*** Start of the network address. ***end address*** Start of the ending network address. ***address increment*** Incremental value of the network address, which is expressed as a decimal number value or IP address.
dsmap	Specifies a **downstream mapping** type length and value which should be included in the LSP echo request.
exp *exp-bits*	(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.
force-explicit-null	(Optional) Forces an unsolicited explicit null label to be added to the MPLS label stack and allows LSP ping to be used to detect LSP breakages at the penultimate hop.
interval *min-send-delay*	(Optional) Specifies a send interval, in milliseconds, between requests. Range is 0 to 3600000. Default is 0.
lsp { **active**		**path-protect**}	(Optional) Specifies the LSP to use.
pad *pattern*	(Optional) Specifies the pad pattern for an echo request.
repeat *count*	(Optional) Specifies the number of times to resend a packet. Range is 1 to 2147483647. Default is 5.
reply dscp *dscp-value*	(Optional) Specifies the differentiated service codepoint value for an MPLS echo reply.

mode [**ipv4** | **router-alert** | **no-reply**]	(Optional) Specifies the reply mode for the echo request packet. **no-reply** Do not reply **ipv4** Reply with an IPv4 UDP packet (this is the default) **router-alert** Reply with an IPv4 UDP packet with the IP router alert set
reply pad-tlv	(Optional) Indicates that a pad TLV should be included.
revision *version*	(Optional) Specifies the Cisco extension TLV versioning field: • 1 RFC-ietf-mpls-lsp-ping-03 (initial) • 2 RFC-ietf-mpls-lsp-ping-03 (rev 1) • 3 RFC-ietf-mpls-lsp-ping-03 (rev 2) • 4 RFC-ietf-mpls-lsp-ping-09 (initial)
size *packet-size*	(Optional) Specifies the packet size or number of bytes in each MPLS echo request packet. Range is 100 to 17986. Default is 100.
source *source-address*	(Optional) Specifies the source address used in the echo request packet.
sweep *min-value max-value interval*	(Optional) Specifies a range of sizes for the echo packets sent. ***min-value*** Minimum or start size for an echo packet (range is 100 to 17986) ***max-value*** Maximum or end size for an echo packet(range is 100 to 17986) ***interval*** Number used to increment an echo packet size(range is 1 to 8993)
timeout *timeout*	(Optional) Specifies the timeout interval, in seconds. Range is 0 to 3600. Default is 2.
ttl *value*	(Optional) Specifies the TTL value to be used in the MPLS labels (range is 1 to 255).

verbose	(Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.

Command Default

exp *exp-bits*: 0

interval *min-send-delay*: 0

repeat *count*: 5

reply-mode: IPv4

timeout *timeout* : 2

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

The **output interface** keyword specifies the output interface on which the MPLS echo request packets are sent. If the specified output interface is not part of the LSP, the packets are not transmitted.

In cases where the **sweep** keyword is used, values larger than the outgoing interface's MTU are not transmitted.

The **ping** command sends an echo request packet to an address, and then waits for a reply. Ping output helps you evaluate path-to-host reliability, delays over the path. It also helps you determine whether the host is reachable or is functioning.

Task ID

Task ID	Operation
mpls-te	read, write
mpls-ldp	read, write

show mpls oam

To display MPLS OAM information, use the **show mpls oam** command in XR EXEC mode.

show mpls oam {**client** | **counters** {**global** | **packet**} | **interface** *type* *interface-path-id*}

Syntax Description

client	Displays clients registered with LSPV server.
counters global	Displays LSP verification global counters.
counters packet	Displays LSP verification packet counters.
interface	Displays LSP verification information for a specific interface.
type	Interface type. For more information, use the question mark (**?**) online help function.
interface-path-id	Physical interface or virtual interface. **Note** Use the **show interfaces** command to see a list of all interfaces currently configured on the router. For more information about the syntax for the router, use the question mark (**?**) online help function.

Command Default

No default behavior or values

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

No specific guidelines impact the use of this command.

Task ID

Task ID	Operations
mpls-te	read
mpls-ldp	read
mpls-static	read

Examples

The following example shows how to display MPLS OAM client information:

```
RP/0/RP0/CPU0:router# show mpls oam client

  Client Process: l2vpn_mgr Node: 0/0/SP Pid: 418014
  Client Process: te_control Node: 0/0/SP Pid: 639227
```

This table describes the significant fields shown in the display.

Table 1: show mpls oam client Command Field Descriptions

Field	Description
Client Process	Process of client.

show mpls oam database

To display MPLS OAM database information, use the **show mpls oam database** command in XR EXEC mode.

show mpls oam database { **requests** | **tt-requests**} [**detail**] [**handle** *handle-value*]

Syntax Description

requests	Displays request database
tt-requests	Displays tree trace request database
detail	(Optional) Displays displayed information.
handle	(Optional) Displays handle information.
handle-value	Generic handle value. Range is from 0 to 4294967295.

Command Default

No default behavior or values

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

No specific guidelines impact the use of this command.

Task ID

Task ID	Operations
mpls-te	read
mpls-ldp	read
mpls-static	read

Examples

The following example shows how to display detailed MPLS OAM database information:

```
RP/0/RP0/CPU0:router# show mpls oam database request detail
```

traceroute mpls ipv4

To learn the routes that packets follow when traveling to their Label Distribution Protocol (LDP) IPv4 destination, use the **traceroute mpls** command in XR EXEC mode.

traceroute mpls ipv4*address/mask* [**destination** *start-address end-address address-increment*] [**exp** *exp-bits*] [**flags fec**] [**force-explicit-null**] [**output** {**interface** *type interface-path-id* [**nexthop** *nexthop-address*] | [**nexthop** *nexthop-address*]}] [**reply** {**dscp** *dscp-value* | **reply mode** {**ipv4** | **router-alert**}}] [**revision** *version*] [**source** *source-address*] [**timeout** *timeout*] [**ttl** *value*] [**verbose**] [**fec-type** {**bgp** | **generic** | **ldp**}]

Syntax Description

address/mask	Specifies the destination type as a label distribution protocol (LDP) prefix. Address prefix of the target and number of bits in the target address network mask.
destination *start-address end-address address-increment*	Specifies a network 127 address to be used as the destination address in the echo request packet. ***start address*** Start of the network address. ***end address*** End of the network address. ***address increment*** Incremental value of the network address.
exp *exp-bits*	(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.
flags fec	(Optional) Specifies that forwarding equivalent class (FEC) stack checking is to be performed at transit routers.
force-explicit-null	(Optional) Forces an unsolicited explicit null label to be added to the MPLS label stack and allows LSP ping to be used to detect LSP breakages at the penultimate hop.
output interface	(Optional) Specifies the output interface in which echo request packets are sent.
type	Interface type. For more information, use the question mark (**?**) online help function.
interface-path-id	Physical interface or virtual interface. **Note** Use the **show interfaces** command to see a list of all interfaces currently configured on the router. For more information, use the question mark (**?**) online help function.

nexthop	(Optional) Specifies the IP address for the next hop.
nexthop-address	(Optional) IP address for the next hop.
reply dscp *dscp-value*	(Optional) Specifies the differentiated service codepoint value for an MPLS echo reply.
reply mode { **ipv4** | **router-alert**}	(Optional) Specifies the reply mode for the echo request packet. **ipv4** Reply with IPv4 UDP packet (this is the default) **router-alert** Reply with IPv4 UDP packet with router alert
revision *version*	(Optional) Specifies the Cisco extension TLV versioning field: • 1 RFC-ietf-mpls-lsp-ping-03 (initial) • 2 RFC-ietf-mpls-lsp-ping-03 (rev 1) • 3 RFC-ietf-mpls-lsp-ping-03 (rev 2) • 4 RFC-ietf-mpls-lsp-ping-09 (initial)
source *source-address*	(Optional) Specifies the source address used in the echo request packet.
timeout *timeoutt*	(Optional) Specifies the timeout interval, in seconds. Range is from 0 to 3600. Default is 2.
ttl *value*	(Optional) Specifies the maximum number of hops (range is 1 to 255).
verbose	(Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.
fec-type	(Optional) Specifies FEC type to be used. **bgp** Use FEC type as BGP **generic** Use FEC type as generic **ldp** Use FEC type as LDP

Command Default

exp *exp-bits*: 0

reply mode: IPv4

timeout *timeout*: 2

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines



Note The **traceroute mpls** command is not supported on optical LSPs. If an optical LSP is encountered along the LSPs path, it is treated as a physical interface.

For detailed configuration information about MPLS LSP trace operations, see *System Monitoring Configuration Guide*.

Task ID

Task ID	Operations
mpls-te	read, write
mpls-ldp	read, write

Examples

The following example shows how to trace a destination:

```
RP/0/RP0/CPU0:router# traceroute mpls ipv4 140.140.140.140/32
destination 127.0.0.10 127.0.0.15 1


Tracing MPLS Label Switched Path to 140.140.140.140/32, timeout is 2
seconds

Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
  'L' - labeled output interface, 'B' - unlabeled output interface,
  'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
  'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
  'P' - no rx intf label prot, 'p' - premature termination of LSP,
  'R' - transit router, 'I' - unknown upstream index,
  'X' - unknown return code, 'x' - return code 0

Type escape sequence to abort.

Destination address 127.0.0.10

  0 196.100.1.41 MRU 4470 [Labels: 19 Exp: 0]
L 1 196.100.1.42 MRU 4470 [Labels: 86 Exp: 0] 360 ms
  2 196.100.1.50 MRU 4470 [Labels: implicit-null Exp: 0] 8 ms
! 3 196.100.1.18 9 ms
```

The following example shows how to trace a destination with FEC type specified as generic and verbose option:

```
RP/0/RP0/CPU0:router# traceroute mpls ipv4 11.11.11.11/32 fec-type generic output interface
 gigabitEthernet 0/0/0/3
nexthop 172.40.103.2 verbose
```

```
Tracing MPLS Label Switched Path to 11.11.11.11/32, timeout is 2 seconds

Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
  'L' - labeled output interface, 'B' - unlabeled output interface,
  'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
  'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
  'P' - no rx intf label prot, 'p' - premature termination of LSP,
  'R' - transit router, 'I' - unknown upstream index,
  'X' - unknown return code, 'x' - return code 0

Type escape sequence to abort.

  0 172.40.103.1 172.40.103.2 MRU 1500 [Labels: 16038 Exp: 0]
L 1 172.40.103.2 173.101.103.1 MRU 1500 [Labels: 16037 Exp: 0] 6 ms, ret code 8
L 2 173.101.103.1 11.101.11.11 MRU 1500 [Labels: implicit-null Exp: 0] 4 ms, ret code 8
! 3 11.101.11.11 6 ms, ret code 3
```

traceroute mpls multipath

To discover all possible paths of an LSP between the ingress and egress routers, use the **traceroute mpls multipath** command in XR EXEC mode.

traceroute mpls multipath ipv4 *address/mask* [**destination** *start-address*/*end-address address-increment*] [**exp** *exp-bits*] [**flags fec**] [**force-explicit-null**] [**hashkey ipv4 bitmap** *bit-size*] [**interval** *min-send-delay*] [**output** {**interface** *type interface-path-id* [**nexthop** *nexthop-address*] | [**nexthop** *nexthop-address*]}] [**reply** {**dscp** *dscp-value* | **reply mode** {**ipv4** | **router-alert**}}] [**retry-count** *count*] [**revision** *version*] [**source** *source-address*] [**timeout** *timeout*] [**ttl** *value*] [**verbose**] [**fec-type** {**bgp** | **generic** | **ldp**}]

Syntax Description

ipv4	Specifies the destination type as a Label Distribution Protocol (LDP) IPv4 address.
address/mask	Address prefix of the target and number of bits in the target address network mask.
destination *start-address end-address address -increment*	(Optional) Specifies a network 127 address to be used as the destination address in the echo request packet. ***start-address*** Start of the network address. ***end-address*** End of the network address. ***address-increment*** Incremental value of the network address.
exp *exp-bits*	(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.
flags fec	(Optional) Specifies that forwarding equivalent class (FEC) stack checking is to be performed at transit routers.
force-explicit-null	(Optional) Forces an unsolicited explicit null label to be added to the MPLS label stack and allows LSP ping to be used to detect LSP breakages at the penultimate hop.
hashkey ipv4 bitmap *bit-size*	(Optional) Allows user control of the hash key/multipath settings. Range is 0 to 256. The default is 32.
interval *min-send-delay*	(Optional) Specifies a send interval, in milliseconds, between requests. Range is 0 to 3600000. Default is 0.
output interface	(Optional) Specifies the output interface where echo request packets are sent.
type	Interface type. For more information, use the question mark (**?**) online help function.

interface-path-id	Physical interface or virtual interface. **Note** Use the **show interfaces** command to see a list of all interfaces currently configured on the router. For more information, use the question mark (**?**) online help function.
nexthop	(Optional) Specifies the IP address for the next hop.
nexthop-address	(Optional) IP address for the next hop.
reply dscp *dscp-value*	(Optional) Specifies the differentiated service codepoint value for an MPLS echo reply.
reply mode [**ipv4** | **router-alert**]	(Optional) Specifies the reply mode for the echo request packet. **ipv4** Reply with IPv4 UDP packet (this is the default) **router-alert** Reply with IPv4 UDP packet with router alert
retry-count *count*	(Optional) Specifies the number of retry attempts during multipath LSP traceroute. A retry is attempted if an outstanding echo request • times out waiting for the corresponding echo reply. • fails to find a valid destination address set to exercise a specific outgoing path. Range is 0 to 10. Default is 3.
revision *version*	(Optional) Specifies the Cisco extension TLV versioning field: • 1 RFC-ietf-mpls-lsp-ping-03 (initial) • 2 RFC-ietf-mpls-lsp-ping-03 (rev 1) • 3 RFC-ietf-mpls-lsp-ping-03 (rev 2) • 4 RFC-ietf-mpls-lsp-ping-09 (initial)
source *source-address*	(Optional) Specifies the source address used in the echo request packet.
timeout *timeout*	(Optional) Specifies the timeout interval, in seconds. Range is from 0 to 3600. Default is 2.
ttl *value*	(Optional) Specifies the maximum number of hops (range is 1 to 255).
verbose	(Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.

fec-type	(Optional) Specifies FEC type to be used. **bgp** Use FEC type as BGP **generic** Use FEC type as generic **ldp** Use FEC type as LDP

Command Default

exp *exp-bits* : 0

hashkey ipv4 bitmap *bit-size*: 4

interval *min-send-delay*: 0

reply mode: IPv4

retry-count: 3

timeout *timeout* : 2

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

The **hashkey ipv4 bitmap** keyword and *bit-size* value control how many addresses are encoded in the DSMAP multipath field. Larger values allow more coverage of equal cost multiple paths throughout the network, but with more processing at the head, mid, and tail routers.

Task ID

Task ID	Operations
mpls-te	read, write
mpls-ldp	read, write

Examples

The following example shows how to specify the destination type as an LDP IPv4 prefix:

```
RP/0/RP0/CPU0:router# traceroute mpls multi ipv4 140.140.140.140/32 verbose
force-explicit-null

  Starting LSP Path Discovery for 140.140.140.140/32

  Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
  'L' - labeled output interface, 'B' - unlabeled output interface,
  'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
  'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
  'P' - no rx intf label prot, 'p' - premature termination of LSP,
```

```
  'R' - transit router, 'I' - unknown upstream index,
  'X' - unknown return code, 'x' - return code 0

  Type escape sequence to abort.

  LL!
  Path 0 found,
  output interface POS0/2/0/3 source 196.100.1.61 destination 127.0.0.1
  0 196.100.1.61 196.100.1.62 MRU 4470 [Labels: 18/explicit-null Exp: 0/0] multipaths 0
  L 1 196.100.1.62 196.100.1.10 MRU 4470 [Labels: 17/explicit-null Exp: 0/0] ret code 8
multipaths 1
  L 2 196.100.1.10 196.100.1.18 MRU 4470 [Labels: implicit-null/explicit-null Exp: 0/0] ret
 code 8 multipaths 1
  ! 3 196.100.1.1018, ret code 3 multipaths 0
  LL!
  Path 1 found,
  output interface GigabitEthernet0/3/0/0 source 196.100.1.5 destination 127.0.0.1
  0 196.100.1.5 196.100.1.37 6 MRU 1500 [Labels: 18/explicit-null Exp: 0/0] multipaths 0
  L 1 196.100.1.6 196.100.1.10 MRU 4470 [Labels: 17/explicit-null Exp: 0/0] ret code 8
multipaths 1
  L 2 10196.0100.21.5 1010 196.0100.21.10 18 MRU 4470 [Labels: implicit-null/explicit-null
 Exp: 0/0] ret code 8 multipaths 1
  ! 3 10196.0100.21.1018, ret code 3 multipaths 0

  Paths (found/broken/unexplored) (2/0/0)
  Echo Request (sent/fail) (6/0)
  Echo Reply (received/timeout) (6/0)
  Total Time Elapsed 80 ms
```

The following example shows how to specify the FEC type as LDP with verbose option:

```
RP/0/RP0/CPU0:router#  traceroute mpls multipath ipv4 11.11.11.11/32 fec-type ldp output
interface gigabitEthernet 0/0/0/3
nexthop 172.40.103.2 verbose

Starting LSP Path Discovery for 11.11.11.11/32

Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
  'L' - labeled output interface, 'B' - unlabeled output interface,
  'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
  'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
  'P' - no rx intf label prot, 'p' - premature termination of LSP,
  'R' - transit router, 'I' - unknown upstream index,
  'X' - unknown return code, 'x' - return code 0

Type escape sequence to abort.

LL!
Path 0 found,
 output interface GigabitEthernet0/0/0/3 nexthop 172.40.103.2
 source 172.40.103.1 destination 127.0.0.0
  0 172.40.103.1 172.40.103.2 MRU 1500 [Labels: 16038 Exp: 0] multipaths 0
L 1 172.40.103.2 173.101.103.1 MRU 1500 [Labels: 16037 Exp: 0] ret code 8 multipaths 1
L 2 173.101.103.1 11.101.11.11 MRU 1500 [Labels: implicit-null Exp: 0] ret code 8 multipaths
 1
! 3 11.101.11.11, ret code 3 multipaths 0

Paths (found/broken/unexplored) (1/0/0)
 Echo Request (sent/fail) (3/0)
 Echo Reply (received/timeout) (3/0)
 Total Time Elapsed 21 ms
```

traceroute mpls traffic-eng

To specify the destination type as an MPLS traffic engineering (TE) tunnel, use the **traceroute mpls traffic-eng** command in XR EXEC mode.

traceroute mpls traffic-eng tunnel *tunnel-ID* [**destination** *start-address end-address address-increment increment-mask*] [**exp** *exp-bits*] [**flags fec**] [**force-explicit-null**] [**reply** {**dscp** *dscp-value* | **reply mode** {**ipv4** | **router-alert**}}] [**revision** *version*] [**source** *source-address*] [**timeout** *timeout*] [**ttl** *value*] [**verbose**]

Syntax Description

tunnel	Specifies the MPLS-TE tunnel type.
tunnel-ID	Tunnel interface.
destination *start-address end-address address -increment increment-mask*	(Optional) Specifies a network 127 address to be used as the destination address in the echo request packet. ***start-address*** Start of the network address. ***end-address*** End of the network address. ***address-increment*** Incremental value of the network address. ***increment-mask*** Incremental mask of the network address.
exp *exp-bits*	(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.
flags fec	(Optional) Specifies that forwarding equivalent class (FEC) stack checking is to be performed at transit routers.
force-explicit-null	(Optional) Forces an unsolicited explicit null label to be added to the MPLS label stack and allows LSP ping to be used to detect LSP breakages at the penultimate hop.
reply dscp *dscp-value*	(Optional) Specifies the differentiated service codepoint value for an MPLS echo reply.
reply mode [**ipv4** | **router-alert**]	(Optional) Specifies the reply mode for the echo request packet. **ipv4** Reply with IPv4 UDP packet (this is the default) **router-alert** Reply with IPv4 UDP packet with router alert

revision *version*	(Optional) Specifies the Cisco extension TLV versioning field: • 1 RFC-ietf-mpls-lsp-ping-03 (initial) • 2 RFC-ietf-mpls-lsp-ping-03 (rev 1) • 3 RFC-ietf-mpls-lsp-ping-03 (rev 2) • 4 RFC-ietf-mpls-lsp-ping-09 (initial)
source *source-address*	(Optional) Specifies the source address used in the echo request packet.
timeout *timeout*	(Optional) Specifies the timeout interval, in seconds. Range is from 0 to 3600. Default is 2.
ttl *value*	(Optional) Specifies the maximum number of hops (range is 1 to 255).
verbose	(Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.

Command Default

exp *exp-bits* : 0

reply mode: IPv4

timeout *timeout* : 2

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

No specific guidelines impact the use of this command.

Task ID

Task ID	Operation
mpls-te	read
mpls-ldp	read

The following example shows how to specify the destination as a MPLS-TE tunnel:

```
RP/0/RP0/CPU0:router#  traceroute mpls traffic-eng tunnel 13

Tracing MPLS TE Label Switched Path on tunnel-te13, timeout is 2 seconds

Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
  'L' - labeled output interface, 'B' - unlabeled output interface,
  'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
  'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
  'P' - no rx intf label prot, 'p' - premature termination of LSP,
  'R' - transit router, 'I' - unknown upstream index,
  'X' - unknown return code, 'x' - return code 0

Type escape sequence to abort.

 0 0.0.0.0 11.0.0.1 MRU 1500 [Labels: 16003 Exp: 0]
```

```
L 1 192.168.200.2 192.168.170.1 MRU 1500 [Labels: implicit-null Exp: 0] 110 ms
! 2 192.168.170.1 0.0.0.0 MRU 0 [No Label] 169 ms
```

traceroute mpls traffic-eng tunnel-te (P2P)

To specify the destination type as an MPLS traffic engineering (TE) tunnel for a point-to-point connection, use the **traceroute mpls traffic-eng tunnel-te (P2P)** command in XR EXEC mode.

traceroute mpls traffic-eng tunnel-te *tunnel-ID* [**destination** *start-address end-address address-increment increment-mask*] [**exp** *exp-bits*] [**flags fec**] [**force-explicit-null**] [**reply** {**dscp** *dscp-value* | **mode** {**ipv4** | **router-alert**}}] [**revision** *version*] [**source** *source-address*] [**timeout** *timeout*] [**ttl** *value*] [**verbose**]

Syntax Description

tunnel-te	Specifies the MPLS-TE tunnel type.
tunnel-ID	Tunnel interface.
destination *start-address end-address address -increment increment-mask*	(Optional) Specifies a network 127 address to be used as the destination address in the echo request packet. ***start-address*** Start of the network address. ***end-address*** End of the network address. ***address-increment*** Incremental value of the network address. ***increment-mask*** Incremental mask of the network address.
exp *exp-bits*	(Optional) Specifies the MPLS experimental field value in the MPLS header for echo replies. Range is 0 to 7. Default is 0.
flags fec	(Optional) Specifies that forwarding equivalent class (FEC) stack checking is to be performed at transit routers.
force-explicit-null	(Optional) Forces an unsolicited explicit null label to be added to the MPLS label stack and allows LSP ping to be used to detect LSP breakages at the penultimate hop.
reply dscp *dscp-value*	(Optional) Specifies the differentiated service codepoint value for an MPLS echo reply.
reply-mode [**ipv4** | **router-alert**]	(Optional) Specifies the reply mode for the echo request packet. **ipv4** Reply with IPv4 UDP packet (this is the default) **router-alert** Reply with IPv4 UDP packet with router alert

revision *version*	(Optional) Specifies the Cisco extension TLV versioning field: • 1 RFC-ietf-mpls-lsp-ping-03 (initial) • 2 RFC-ietf-mpls-lsp-ping-03 (rev 1) • 3 RFC-ietf-mpls-lsp-ping-03 (rev 2) • 4 RFC-ietf-mpls-lsp-ping-09 (initial)
source *source-address*	(Optional) Specifies the source address used in the echo request packet.
timeout *timeout*	(Optional) Specifies the timeout interval, in seconds. Range is from 0 to 3600. Default is 2.
ttl *value*	(Optional) Specifies the maximum number of hops (range is 1 to 255).
verbose	(Optional) Enables verbose output information, including MPLS echo reply, sender address of the packet, and return codes.

Command Default

exp *exp-bits* : 0

reply-mode: IPv4

timeout *timeout* : 2

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 7.0.12	This command was introduced.

Usage Guidelines

No specific guidelines impact the use of this command.

Task ID

Task ID	Operation
mpls-te	read
mpls-ldp	read

The following example shows how to specify the destination as a MPLS-TE tunnel:

```
RP/0/RP0/CPU0:router#  traceroute mpls traffic-eng tunnel-te 13

Tracing MPLS TE Label Switched Path on tunnel-te13, timeout is 2 seconds

Codes: '!' - success, 'Q' - request not sent, '.' - timeout,
  'L' - labeled output interface, 'B' - unlabeled output interface,
  'D' - DS Map mismatch, 'F' - no FEC mapping, 'f' - FEC mismatch,
  'M' - malformed request, 'm' - unsupported tlvs, 'N' - no rx label,
  'P' - no rx intf label prot, 'p' - premature termination of LSP,
  'R' - transit router, 'I' - unknown upstream index,
  'X' - unknown return code, 'x' - return code 0

Type escape sequence to abort.

 0 0.0.0.0 11.0.0.1 MRU 1500 [Labels: 16003 Exp: 0]
```

```
L 1 192.168.200.2 192.168.170.1 MRU 1500 [Labels: implicit-null Exp: 0] 110 ms
! 2 192.168.170.1 0.0.0.0 MRU 0 [No Label] 169 ms
```