

Tech-Support Commands

This module describes commands used to collect the **show** command outputs using Cisco IOS XR software.

The **show tech-support** commands collect common data from commands such as **show version** . Each **show tech-support** command also generates and gathers relevant data for a specific area. This data includes trace output to collect debugging information available in the specific area of interest.

To use commands of this module, you must be in a user group associated with a task group that includes appropriate task IDs. If the user group assignment is preventing you from using any command, contact your AAA administrator for assistance.

- show tech-support custom, on page 1
- show tech support mgbl, on page 19
- show tech support mgbl grpc, on page 21
- show tech-support mgbl netconf, on page 23
- show tech-support mgbl telemetry, on page 24
- show tech-support ztp brief, on page 26

show tech-support custom

To generate and gather tech-support information related to a specific area such as network traffic, control-plane, and the system, use the **show tech-support custom** command in EXEC mode.

show tech-support custom { **traffic** | **control-plane** | **system** }

Syntax Description

traffic	Generates tech-support information related to network traffic.
control-plane	Generates tech-support information related to the control-plane.
system	Generates tech-support information related to the system.

Command Default

None

Command Modes

EXEC mode

Config mode

Command History

Release	Modification
Release 7.3.5	This command was introduced.

Usage Guidelines

This command generates tech-support information that is useful for Cisco Technical Support representatives when troubleshooting a router. By default, the output of this command is saved on the router's hard disk in a file with *.tgz* extension. You can share this file with Cisco Technical Support. To share, use the **copy** command to copy the *.tgz* file to a server or local machine. For example, **copy harddisk:/showtech/***name.tgz* **tftp://***server_path*.

For Cisco Technical Support contact information, see the 'Obtaining Documentation and Submitting a Service Request' section in the Preface.

Table 1: List of Commands collected by each custom option

Custom Option	Release	List of commands outputs collected
Control-plane	Release 7.3.6	

Custom Option	Release	List of commands outputs collected
		show tech-support ipv6 nd show tech-support arp show tech-support ofa show tech-support routing bgp show tech-support routing isis show tech-support routing bfd show tech-support routing ospf show tech-support routing ospfv3 show tech-support mpls ldp show tech-support bcdl show tech-support bcdlv2 show tech-support rib show tech-support mpls lsd show tech-support cef show tech-support cef platform show tech-support gsp show tech-support l2rib show tech-support l2vpn show tech-support lpts show tech-support spp show tech-support clns show tech-support multicast address-family ipv4 show tech-support multicast address-family ipv6 show tech-support grpc show tech-support service-layer show tech-support appmgr show tech-support netconf show tech-support yserver show tech-support grid show tech-support tunnel-ip show tech-support pbr show tech-support bfdhwoff show tech-support flowspec

Custom Option	Release	List of commands outputs collected
		show tech-support access-lists ipv4 show tech-support access-lists ipv6 show tech-support ds show tech-support os show tech-support placed show tech-support qos pi show tech-support processmgr show tech-support spio show tech-support sysdb show tech-support telemetry model-driven show tech-support bundles show tech-support dhcp ipv4 base show tech-support dhcp ipv4 client show tech-support dhcp ipv4 proxy show tech-support dhcp ipv4 relay show tech-support dhcp ipv4 server show tech-support dhcp ipv4 snoop show tech-support dhcp ipv6 base show tech-support dhcp ipv6 client show tech-support dhcp ipv6 proxy show tech-support dhcp ipv6 relay show tech-support dhcp ipv6 server show tech-support ipinfra show tech-support protection-notif show tech-support raw show tech-support rsi show tech-support statsd show tech-support tcp nsr show tech-support udp show tech-support pfi show tech-support cfgmgr show tech-support tty show tech-support rdsfs

Custom Option	Release	List of commands outputs collected
	Release 24.2.11	

Custom Option	Release	List of commands outputs collected
		show tech-support aib show tech-support ipv6 nd show tech-support arp show tech-support ofa show tech-support routing bgp show tech-support routing isis show tech-support routing bfd show tech-support routing ospf show tech-support routing ospfv3 show tech-support mpls ldp show tech-support bcdl show tech-support bcdlv2 show tech-support rib show tech-support mpls lsd show tech-support cef show tech-support cef platform show tech-support gsp show tech-support l2rib show tech-support l2vpn show tech-support l2vpn platform show tech-support lpts show tech-support spp show tech-support clns show tech-support multicast address-family show tech-support multicast address-family show tech-support mgbl show tech-support service-layer show tech-support appmgr show tech-support grid show tech-support tunnel-ip show tech-support pbr show tech-support bfdhwoff show tech-support flowspec

Custom Option	Release	List of commands outputs collected
		show tech-support access-lists ipv4 show tech-support access-lists ipv6 show tech-support ds show tech-support os show tech-support placed show tech-support qos pi show tech-support processmgr show tech-support spio show tech-support sysdb show tech-support bundles show tech-support dhcp ipv4 show tech-support dhcp ipv4 show tech-support dhcp ipv4 show tech-support dhcp ipv4 show tech-support dhcp ipv4 show tech-support dhcp ipv4 show tech-support dhcp ipv6 show tech-support dhcp ipv6 show tech-support dhcp ipv6 show tech-support dhcp ipv6 show tech-support dhcp ipv6 show tech-support ipinfra show tech-support protection-notif show tech-support raw show tech-support rsi show tech-support statsd show tech-support tcp nsr show tech-support udp show tech-support pfi show tech-support cfgmgr show tech-support tty show tech-support rdsfs

Custom Option	Release	List of commands outputs collected
Traffic	Release 7.3.6	

Custom Option	Release	List of commands outputs collected
		show tech-support platform-fwd show tech-support ofa show tech-support cef show tech-support cef platform show tech-support aib show tech-support grid show tech-support bcdl show tech-support bcdlv2 show tech-support mpls lsd show tech-support rib show tech-support fabric link-include show tech-support mpls traffic-eng show tech-support segment-routing traffic-eng show tech-support optics show tech-support qos platform show tech-support platform-pfc show tech-support qos pi show tech-support arp show tech-support ipv6 nd show tech-support gsp show tech-support access-lists platform show tech-support tunnel-ip show tech-support pbr show tech-support bfdhwoff show tech-support flowspec show tech-support ds show tech-support placed show tech-support service-layer show tech-support processmgr show tech-support os show tech-support grpc show tech-support sysdb show tech-support telemetry model-driven

Custom Option	Release	List of commands outputs collected
		show tech-support bundles show tech-support dhcp ipv4 base show tech-support dhcp ipv4 client show tech-support dhcp ipv4 proxy show tech-support dhcp ipv4 relay show tech-support dhcp ipv4 server show tech-support dhcp ipv4 snoop show tech-support dhcp ipv6 base show tech-support dhcp ipv6 client show tech-support dhcp ipv6 proxy show tech-support dhcp ipv6 relay show tech-support dhcp ipv6 server show tech-support ipinfra show tech-support protection-notif show tech-support raw show tech-support rsi show tech-support spio show tech-support statsd show tech-support tcp nsr show tech-support udp show tech-support pfi show tech-support static show tech-support cfgmgr show tech-support snmp ifmib show tech-support resmon
	Release 24.2.11	

Custom Option	Release	List of commands outputs collected
		show tech-support platform-fwd show tech-support ofa show tech-support cef show tech-support cef platform show tech-support aib show tech-support grid show tech-support bcdl show tech-support bcdlv2 show tech-support mpls lsd show tech-support rib show tech-support fabric link-include show tech-support mpls traffic-eng show tech-support mpls rsvp show tech-support mpls static show tech-support mpls oam show tech-support segment-routing traffic-eng show tech-support optics show tech-support qos platform show tech-support platform-pfc show tech-support qos pi show tech-support arp show tech-support ipv6 nd show tech-support gsp show tech-support l2vpn show tech-support l2vpn platform show tech-support access-lists platform show tech-support tunnel-ip show tech-support pbr show tech-support bfdhwoff show tech-support flowspec show tech-support ds show tech-support placed show tech-support service-layer

Custom Option	Release	List of commands outputs collected
		show tech-support processmgr show tech-support os show tech-support mgbl show tech-support sysdb show tech-support bundles show tech-support dhcp ipv4 base show tech-support dhcp ipv4 client show tech-support dhcp ipv4 proxy show tech-support dhcp ipv4 relay show tech-support dhcp ipv4 server show tech-support dhcp ipv4 snoop show tech-support dhcp ipv6 base show tech-support dhcp ipv6 client show tech-support dhcp ipv6 proxy show tech-support dhcp ipv6 relay show tech-support dhcp ipv6 server show tech-support ipinfra show tech-support protection-notif show tech-support raw show tech-support rsi show tech-support spio show tech-support statsd show tech-support tcp nsr show tech-support udp show tech-support pfi show tech-support static show tech-support cfgmgr show tech-support snmp ifmib show tech-support resmon

Custom Option	Release	List of commands outputs collected
System	Release 7.3.6	

Custom Option	Release	List of commands outputs collected
		show tech-support os show tech-support spi show tech-support fpd show tech-support fabric link-include show tech-support interface show tech-support ofa show tech-support optics show tech-support macsec show tech-support gsp show tech-support platform timing show tech-support ptp show tech-support frequency synchronization show tech-support ethernet controllers show tech-support ethernet interfaces show tech-support pfi show tech-support cfgmgr show tech-support sysdb show tech-support processmgr show tech-support grpc show tech-support linux networking show tech-support telemetry model-driven show tech-support parser show tech-support statsd show tech-support ctrace show tech-support control-ethernet show tech-support pmengine show tech-support ptah show tech-support ds show tech-support pam show tech-support placed show tech-support service-layer show tech-support shmwin show tech-support cpa

Custom Option	Release	List of commands outputs collected
		show tech-support install show tech-support keychain show tech-support alarm-mgr show tech-support ntp show tech-support pool show tech-support protection-notif show tech-support rdsfs show tech-support resmon show tech-support snmp show tech-support ssh show tech-support system-recovery show tech-support tacacs show tech-support tam show tech-support tty show tech-support type6 show tech-support ztp show tech-support bmc show tech-support bundles show tech-support snmp ifmib show tech-support ipinfra show tech-support cef show tech-support cef platform show tech-support rsi
	Release 24.2.11	

Custom Option	Release	List of commands outputs collected
		show tech-support os show tech-support spi show tech-support fpd show tech-support fabric link-include show tech-support interface show tech-support ofa show tech-support optics show tech-support macsec show tech-support gsp show tech-support platform timing show tech-support ptp show tech-support frequency synchronization show tech-support ethernet controllers show tech-support ethernet interfaces show tech-support control-ethernet show tech-support pfi show tech-support cfgmgr show tech-support sysdb show tech-support processmgr show tech-support mgbl show tech-support linux networking show tech-support parser show tech-support statsd show tech-support bundles show tech-support ctrace show tech-support control-ethernet show tech-support pmengine show tech-support ptah show tech-support ds show tech-support pam show tech-support placed show tech-support service-layer show tech-support shmwin

Custom Option	Release	List of commands outputs collected
		show tech-support cpa show tech-support install show tech-support keychain show tech-support alarm-mgr show tech-support ntp show tech-support pool show tech-support protection-notif show tech-support rdsfs show tech-support resmon show tech-support snmp show tech-support ssh show tech-support system-recovery show tech-support tacacs show tech-support tam show tech-support tty show tech-support type6 show tech-support ztp show tech-support bmc show tech-support snmp ifmib show tech-support ipinfra show tech-support cef show tech-support cef platform show tech-support rsi

Note This command is not required during normal use of the router.

Task ID

Task ID	Operations
basic-services or cisco-support	read

The following example shows the output of the **show tech-support custom traffic** command:

```
Router# show tech-support custom traffic
++ Show tech start time: 2023-Jun-16.195852.UTC ++
Fri Jun 16 19:58:52 UTC 2023 Waiting for gathering to complete
.....................................................................................................................
```

```
Fri Jun 16 20:05:45 UTC 2023 Compressing show tech output
Show tech output available at 0/RP0/CPU0 :
/harddisk:/showtech/showtech-custom-traffic-2023-Jun-16.195852.UTC.tgz
++ Show tech end time: 2023-Jun-16.200546.UTC ++
```

The following example shows the output of the **show tech-support custom control-plane** command:

```
Router# show tech-support custom control-plane
++ Show tech start time: 2023-Jun-16.194006.UTC ++
Fri Jun 16 19:40:06 UTC 2023 Waiting for gathering to complete
.....................................................................................
Fri Jun 16 19:44:59 UTC 2023 Compressing show tech output
Show tech output available at 0/RP0/CPU0 :
/harddisk:/showtech/showtech-custom-control-2023-Jun-16.194006.UTC.tgz
++ Show tech end time: 2023-Jun-16.194459.UTC ++
```

The following example shows the output of the **show tech-support custom system** command:

```
Router# show tech-support custom system
++ Show tech start time: 2023-Jun-16.194549.UTC ++
Fri Jun 16 19:45:50 UTC 2023 Waiting for gathering to complete
.....................................................................................................................
Fri Jun 16 19:54:24 UTC 2023 Compressing show tech output
Show tech output available at 0/RP0/CPU0 :
/harddisk:/showtech/showtech-custom-system-2023-Jun-16.194549.UTC.tgz
++ Show tech end time: 2023-Jun-16.195425.UTC ++
```

show tech support mgbl

To collect the logs or traces for gRPC module, Network Configuration Protocol (NETCONF) module, and telemetry, use the **show tech-support mgbl** command in the XR EXEC mode.

show tech-support mgbl {file | grpc | list-CLIs | location | netconf | rack | telemetry | time-out}

Syntax Description

mgbl	Executes the commands for manageability components.

file	Specifies a file name with or without a file path where the output is stored. You can either specify the filename or the path of the file. • To specify only the name of the file, use this command: **show tech-support mgbl file** *filename* • To specify the file path, use this command: **show tech-support mgbl file** *filepath* Valid file path options are: • **apphost:** *filename* • **config:** *filename* • **disk0:** *filename* • **ftp:** *filename* • **harddisk:** *filename* • **rootfs:** *filename* • **tftp:** *filename*
grpc	Collects the logs or traces for gRPC module.
list-CLIs	Lists the CLIs related to the manageability components.
location	Specifies the node location.
netconf	Collects the logs or traces for Network Configuration Protocol (NETCONF) module.
rack	Specifies the rack (0/1/2).
telemetry	Collects the logs or traces for telemetry.
time-out	Specifies the timeout configuration for each show command in seconds. The default value is 900 seconds and its ranges between 120-3600 seconds.

Command Default

- The command output is compressed.
- The command does not support location-based collection.

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 24.1.1	This command was introduced.

Usage Guidelines

This command generates tech-support information that is useful for Cisco Technical Support representatives when troubleshooting a router. By default, the output of this command is saved on the router's hard disk in a file with *.tgz* extension. You can share this file with Cisco Technical Support. To share, use the **copy** command

to copy the *.tgz* file to a server or local machine. For example, **copy harddisk:/showtech/***name.tgz* **tftp://***server_path*.

For Cisco Technical Support contact information, see the 'Obtaining Documentation and Submitting a Service Request' section in the Preface.

Task ID

Task ID	Operations
cisco-support	read

This example shows the output of the **show tech-support mgbl** command.

```
RP/0/RP0/CPU0:R0#show tech-support mgbl ?
  file       Specify a valid file name (e.g. disk0:tmp.log)
  grpc       Collect showtech for grpc(cisco-support)
  list-CLIs  list the commands that would be run (don't execute)(cisco-support)
  location   Specify a location(cisco-support)
  netconf    Collect showtech for netconf(cisco-support)
  rack       Specify a rack(cisco-support)
  telemetry  Collect showtech for telemetry(cisco-support)
  time-out   per show command timeout configuration(cisco-support)
  <cr>
```

Note The **show tech-support mgbl**command does not support location-based collection.

```
RP/0/RP0/CPU0:R0#show tech-support mgbl location 0/RP0/CPU0
Mon Feb 19 02:37:03.652 UTC
++ Show tech start time: 2024-Feb-19.023703.UTC ++
This show tech-support doesn't support location based collection. Exiting.
++ Show tech end time: 2024-Feb-19.023703.UTC ++
```

show tech support mgbl grpc

To collect the logs or traces for gRPC module, use the **show tech-support mgbl grpc** command in the XR EXEC mode.

show tech-support mgbl grpc file *{filename | filepath}*

Syntax Description

mgbl	Executes the commands for manageability components.
grpc	Collects the logs or traces for gRPC module.
file	Specifies a file name with or without a file path where the output is stored.
filename	Specifies the name of the file. **show tech-support mgbl grpc file** *filename*

filepath	Specifies the file path with the file name. **show tech-support mgbl grpc file** *filepath* Valid file path options are: • **apphost:** *filename* • **config:** *filename* • **disk0:** *filename* • **ftp:** *filename* • **harddisk:** *filename* • **rootfs:** *filename* • **tftp:** *filename*

Command Default

- The command output is compressed.
- The command does not support location-based collection.

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 24.1.1	This command was introduced.

Usage Guidelines

This command generates tech-support information that is useful for Cisco Technical Support representatives when troubleshooting a router. By default, the output of this command is saved on the router's hard disk in a file with *.tgz* extension. You can share this file with Cisco Technical Support. To share, use the **copy** command to copy the *.tgz* file to a server or local machine. For example, **copy harddisk:/showtech/***name.tgz* **tftp://***server_path*.

For Cisco Technical Support contact information, see the 'Obtaining Documentation and Submitting a Service Request' section in the Preface.

Task ID

Task ID	Operations
cisco-support	read

This example shows the output of the **show tech-support mgbl grpc file** command.

```
RP/0/RP0/CPU0:R0#show tech-support mgbl grpc file disk0:tmp.log
Fri Feb  2 06:12:15.098 UTC
++ Show tech start time: 2024-Feb-02.061215.UTC ++
Fri Feb  2 06:12:16 UTC 2024 Waiting for gathering to complete
............
Fri Feb  2 06:12:53 UTC 2024 Compressing show tech output
Show tech output available at 0/RP0/CPU0 : /disk0:/tmp.log.tgz
++ Show tech end time: 2024-Feb-02.061254.UTC ++
```

Note The **show tech-support mgbl grpc** command does not support location-based collection.

```
RP/0/RP0/CPU0:R0#show tech-support mgbl grpc location 0/RP0/CPU0
Fri Feb  2 06:13:34.590 UTC
++ Show tech start time: 2024-Feb-02.061334.UTC ++
This show tech-support doesn't support location based collection. Exiting.
++ Show tech end time: 2024-Feb-02.061335.UTC ++
```

show tech-support mgbl netconf

To collect the logs or traces for Network Configuration Protocol (NETCONF) module, use the **show tech-support mgbl netconf** command in the XR EXEC mode.

show tech-support mgbl netconf file *{filename | filepath}*

Syntax Description

mgbl	Executes the commands for manageability components.
netconf	Collects the logs or traces for Network Configuration Protocol (NETCONF) module.
file	Specifies a file name with or without a file path where the output is stored.
filename	Specifies the name of the file. **show tech-support mgbl netconf file** *filename*
filepath	Specifies the file path with the file name. **show tech-support mgbl netconf file** *filepath* Valid file path options are: • **apphost:** *filename* • **config:** *filename* • **disk0:** *filename* • **ftp:** *filename* • **harddisk:** *filename* • **rootfs:** *filename* • **tftp:** *filename*

Command Default

- The command output is compressed.
- The command does not support location-based collection.

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 24.1.1	This command was introduced.

Usage Guidelines

This command generates tech-support information that is useful for Cisco Technical Support representatives when troubleshooting a router. By default, the output of this command is saved on the router's hard disk in a file with *.tgz* extension. You can share this file with Cisco Technical Support. To share, use the **copy** command to copy the *.tgz* file to a server or local machine. For example, **copy harddisk:/showtech/***name.tgz* **tftp://***server_path*.

For Cisco Technical Support contact information, see the 'Obtaining Documentation and Submitting a Service Request' section in the Preface.

Task ID

Task ID	Operations
cisco-support	read

This example shows the output of the **show tech-support mgbl netconf file** command.

```
RP/0/RP0/CPU0:R0#show tech-support mgbl netconf file disk0:tmp.log
Fri Feb  2 06:12:15.098 UTC
++ Show tech start time: 2024-Feb-02.061215.UTC ++
Fri Feb  2 06:12:16 UTC 2024 Waiting for gathering to complete
.............
Fri Feb  2 06:12:53 UTC 2024 Compressing show tech output
Show tech output available at 0/RP0/CPU0 : /disk0:/tmp.log.tgz
++ Show tech end time: 2024-Feb-02.061254.UTC ++
```

Note The **show tech-support mgbl netconf** command does not support location-based collection.

```
RP/0/RP0/CPU0:R0#show tech-support mgbl netconf location 0/RP0/CPU0
Fri Feb  2 06:13:34.590 UTC
++ Show tech start time: 2024-Feb-02.061334.UTC ++
This show tech-support doesn't support location based collection. Exiting.
++ Show tech end time: 2024-Feb-02.061335.UTC ++
```

show tech-support mgbl telemetry

To collect the logs or traces for telemetry, use the **show tech-support mgbl telemetry** command in the XR EXEC mode.

show tech-support mgbl telemetry file *{filename | filepath}*

Syntax Description

mgbl	Executes the commands for manageability components.
telemetry	Collects the logs or traces for telemetry.
file	Specifies a file name with or without a file path where the output is stored.

filename	Specifies the name of the file. **show tech-support mgbl telemetry file** *filename*
filepath	Specifies the file path with the file name. **show tech-support mgbl telemetry file** *filepath* Valid file path options are: • **apphost:** *filename* • **config:** *filename* • **disk0:** *filename* • **ftp:** *filename* • **harddisk:** *filename* • **rootfs:** *filename* • **tftp:** *filename*

Command Default

- The command output is compressed.
- The command does not support location-based collection.

Command Modes

XR EXEC mode

Command History

Release	Modification
Release 24.1.1	This command was introduced.

Usage Guidelines

This command generates tech-support information that is useful for Cisco Technical Support representatives when troubleshooting a router. By default, the output of this command is saved on the router's hard disk in a file with *.tgz* extension. You can share this file with Cisco Technical Support. To share, use the **copy** command to copy the *.tgz* file to a server or local machine. For example, **copy harddisk:/showtech/***name.tgz* **tftp://***server_path*.

For Cisco Technical Support contact information, see the 'Obtaining Documentation and Submitting a Service Request' section in the Preface.

Task ID

Task ID	Operations
cisco-support	read

This example shows the output of the **show tech-support mgbl telemetry file** command.

```
RP/0/RP0/CPU0:R0#show tech-support mgbl telemetry file disk0:tmp.log
Fri Feb  2 06:12:15.098 UTC
++ Show tech start time: 2024-Feb-02.061215.UTC ++
Fri Feb  2 06:12:16 UTC 2024 Waiting for gathering to complete
............
Fri Feb  2 06:12:53 UTC 2024 Compressing show tech output
```

```
Show tech output available at 0/RP0/CPU0 : /disk0:/tmp.log.tgz
++ Show tech end time: 2024-Feb-02.061254.UTC ++
```

Note The **show tech-support mgbl telemetry** command does not support location-based collection.

```
RP/0/RP0/CPU0:R0#show tech-support mgbl telemetry location 0/RP0/CPU0
Fri Feb  2 06:13:34.590 UTC
++ Show tech start time: 2024-Feb-02.061334.UTC ++
This show tech-support doesn't support location based collection. Exiting.
++ Show tech end time: 2024-Feb-02.061335.UTC ++
```

show tech-support ztp brief

show tech-support ztp brief

This command has no keywords or arguments.

Command Default

None

Command Modes

EXEC mode

Command History

Release	Modification
Release 26.2.1	This command was introduced.

Usage Guidelines

During a reimage or reload, any ZTP logs collecte prior to the reimage are removed. Only logs from the new boot time onward are retained. To preserve pre-reimage logs for troubleshooting, we recommend you to create a backup of log files during the reimage process.

The **show tech-support ztp brief** command provides a summarized view of ZTP tech-support data. The command does not collect the pre-reimage logs (`var_log_pre_reimage.tgz`).

The **show tech-support ztp brief**complements the **show tech-support ztp** command, which collects more comprehensive debugging information, including pre-reimage logs (`var_log_pre_reimage.tgz`) for in-depth troubleshooting of ztp issues.

Task ID

Task ID	Operations
cisco-support	read

The following example shows the ztp logs collected using the **show tech-support ztp brief** command:

```
Router# #show tech-support ztp brief
Tue May 26 09:58:24.837 UTC
++ Show tech start time: 2026-May-26.095825.UTC ++
Tue May 26 09:58:32 UTC 2026 Waiting for gathering to complete
...
Tue May 26 09:58:49 UTC 2026 Compressing show tech output
Compressed 22544384 bytes into 22544423 bytes ==> 100.00%
```

```
Show tech output available at 0/RP0/CPU0 : /harddisk:/showtech/showtech-SFDR1-ZT

P-2026-May-26.095825.UTC.tar.lz4
++ Show tech end time: 2026-May-26.095850.UTC ++
```