

CLI Templates for Cisco IOS XE Catalyst SD-WAN Devices

- Feature history: CLI templates, on page 1
- CLI templates for Cisco IOS XE Catalyst SD-WAN devices, on page 2
- Using CLI templates in Cisco SD-WAN Manager, on page 3
- Sample configurations for CLI templates, on page 6

Feature history: CLI templates

Developments of CLI templates, release by release.

Table 1: Feature history

Feature Name	Release Information	Description
Device Configuration CLI Templates	Cisco IOS XE Catalyst SD-WAN Release 17.2.1r Cisco vManage 20.1.1	The CLI Templates feature has been updated to support device configuration-based CLIs. You can use these templates to push the device configuration (yang-cli) to devices directly.
CLI Template for Cisco XE SD-WAN Routers	Cisco IOS XE Release 16.11.1a Cisco SD-WAN release 19.1	The CLI Templates for Cisco IOS XE Catalyst SD-WAN device features allow to you configure intent-based CLI templates for Cisco XE SD-WAN routers using Cisco SD-WAN Manager.
VRF Configuration	Cisco IOS XE Catalyst SD-WAN Release 17.2.1r	Support for VRF configuration increased from a total of 100 to a total of 300 VRFs. Supported on: Cisco ASR 1001-HX and Cisco ASR 1002-HX

CLI templates for Cisco IOS XE Catalyst SD-WAN devices

Describes CLI templates, one method of configuring Cisco IOS XE Catalyst SD-WAN devices.

You can configure CLI templates for Cisco IOS XE Catalyst SD-WAN devices in the following ways:

- Device configuration-based CLI templates for Cisco IOS XE Catalyst SD-WAN devices, on page 3
- Intent-based CLI templates for Cisco IOS XE Catalyst SD-WAN devices, on page 4

Note If you generate a CLI template in a higher version of Cisco SD-WAN Manager and then try to apply it in a lower version, it may not be supported depending on the configuration. In this case, Cisco SD-WAN Manager might also deny access and generate an error message. It is recommended that you use a CLI template generated in an earlier version of Cisco SD-WAN Manager. For example, if you are using Cisco vManage Release 20.7.x, you can use a CLI template generated in Cisco vManage Release 20.6.x and earlier releases.

Benefits of CLI templates

- You can reuse any Cisco vEdge-specific Cisco SD-WAN Manager feature templates for Cisco IOS XE Routers. When you create a device template using Cisco XE SDWAN Feature Templates, Cisco SD-WAN Manager displays the intent-based configuration (vEdge CLI syntax) and the corresponding device-based (Cisco XE SDWAN Routers) configuration. You can examine the intent-based configuration and repurpose that to create a separate CLI template for XE SDWAN routers.
- You can make multiple changes to a CLI template in a single edit.
- You can use a single configuration across multiple devices of the same device models. Variables can be used for rapid bulk configuration rollout with unique per-device settings. Common configurations like system-IP, site-id, hostname, IP addresses, and so on, can be defined as editable variables in the template and the same template can be attached to multiple devices.
- You can define custom length for variables in CLI Templates.
- You can use any existing IOS-XE device intent configuration as input for CLI template.
- Content of a CLI template can be used across multiple IOS-XE device types (common CLIs like VPN, VPN interface, BGP, OSPF and so on).

Restrictions of CLI templates

Auxiliary ports: When using a CLI template for Cisco Integrated Services Routers that have an auxiliary port, do not include commands for auxiliary ports, such as `line aux 0`. Doing so results in an error. These commands may be executed directly on the device.

When you import the CLI template configuration using the command, `show sdwan running-config`, you need to add quotes manually for the CLI template on the Cisco SD-WAN Manager.

From Cisco IOS XE Catalyst SD-WAN Release 17.12.x, policies configured using a Cisco Catalyst SD-WAN Controller template are ignored. To configure policies, navigate to **Configuration** > **Policies** > **Custom Options** > **CLI Policy**, add the policy and activate it for Cisco Catalyst SD-WAN Controller.

Using CLI templates in Cisco SD-WAN Manager

You can configure CLI templates in Cisco SD-WAN Manager using these two methods:

- Device configuration-based CLI templates for Cisco IOS XE Catalyst SD-WAN devices
- Intent-based CLI templates for Cisco IOS XE Catalyst SD-WAN devices

Device configuration-based CLI templates for Cisco IOS XE Catalyst SD-WAN devices

A device configuration-based CLI Template for Cisco IOS XE Catalyst SD-WAN devices is a configuration management tool that:

- enables Cisco SD-WAN Manager (vManage 20.1.1 and later) to specify CLI templates using yang-cli,
- pushes only the difference between device and template configurations to Cisco IOS XE Catalyst SD-WAN devices, and
- provides a preview of configuration changes before deployment.

These templates are used alongside feature templates and policies, including localized and security policies, in Cisco SD-WAN Manager.

Note To configure features not accessible using Cisco SD-WAN Manager, we recommend doing the following:

1. Use the relevant feature template in addition to a CLI add-on feature template.
2. For situations where the previous option is not sufficient, use the device configuration-based CLI templates as described in this section.

Create a CLI template using the device configuration option

Procedure

Step 1 From the Cisco SD-WAN Manager menu, choose **Configuration** > **Templates** > **Device Templates**.

Note
In Cisco SD-WAN Release 20.7.x and earlier releases, **Device Templates** is titled as **Device**.

Step 2 From the **Create Template** drop-down list, select **CLI Template**.

Step 3 From the **Device Model** drop-down list, select the type of device for which you are creating the template.

Step 4 In the **Template Name** and **Template Description**, enter a name upto 128 alphanumeric characters and a description upto 2048 alphanumeric characters.

Step 5 Choose **Device configuration**. Using this option, you can provide Cisco IOS XE configuration commands that appear in the output of the `show sdwan running-config` command.

(Optional) To load the running config of a connected device, select it from the Load Running config from reachable device list and click **Search**.

Step 6 In **CLI Configuration**, enter the configuration either by typing it, cutting and pasting it, or uploading a file.

Step 7 To convert an actual configuration value to a variable, select the value and click **Create Variable**. Enter the variable name, and click **Create Variable**.

You can also type the variable name directly, in the format {{*variable-name*}}; for example, {{*hostname*}}.

These variables can be filled in device variables page per device after attaching the template. Values can be entered manually or can be uploaded via a csv file.

Step 8 Click **Add** to save the feature template.

The new device template is displayed in the Device Template table.

Intent-based CLI templates for Cisco IOS XE Catalyst SD-WAN devices

An intent-based CLI template for Cisco IOS XE Catalyst SD-WAN devices is a configuration management tool that:

- allows Cisco SD-WAN Manager to configure CLI templates using intent-based commands,
- supports vEdge device syntax for command input, and
- pushes vEdge syntax-based commands to Cisco IOS XE Catalyst SD-WAN devices in IOS XE syntax.

Intent-based CLI templates enable configuration of Cisco IOS XE Catalyst SD-WAN devices using vEdge syntax via Cisco SD-WAN Manager.

With the support of device configuration-based CLI templates, the intent-based CLI templates will be deprecated. We recommend using the device configuration-based CLI templates as described in Device Configuration-Based CLI Templates for Cisco IOS XE Catalyst SD-WAN Devices.

Using Cisco SD-WAN Manager CLI templates significantly reduces the effort to configure feature templates.

Create a CLI template using the intent option

Procedure

Step 1 From the Cisco SD-WAN Manager menu, choose **Configuration** > **Templates** > **Device Templates**.

Note
In Cisco SD-WAN Release 20.7.x and earlier releases, **Device Templates** is titled as **Device**.

Step 2 From the **Create Template** drop-down list, select **CLI Template**.

Step 3 From the **Device Model** drop-down list, select the type of device for which you are creating the template.

Step 4 In the **Template Name** and **Template Description**, enter a name upto 128 alphanumeric characters and a description upto 2048 alphanumeric characters.

Step 5 The configuration of the CLI template can either be intent-based or based on the device configuration:

- **Intent**: If you specify **Intent**, you specify commands in the Cisco vEdge format. If the device you've selected is a Cisco IOS XE Catalyst SD-WAN device, Cisco SD-WAN Manager converts the configuration for the device.
- **Device configuration**: This option is available from Cisco IOS XE Catalyst SD-WAN Release 17.2.1r and onwards and only for Cisco IOS XE Catalyst SD-WAN devices. For this option, you must specify the entire device configuration as it appears in `show sd-wan running config`.

Note
You can only use this feature with the qualified CLIs described in the *Cisco IOS XE Catalyst SD-WAN Qualified Command Reference Guide*.

Example:

You can upload a configuration file using **Select a File** or copy and paste the CLI configuration. Following is an example of an intent-based CLI with variables.

```
system

   host-name {{hostname}}
   system-ip {{system_ip}}
   domain-id 1

   site-id {{site_id}}
   port-offset           1
   admin-tech-on-failure
   organization-name "XYZ"
   logging
    disk
     enable
! !
```

These variables can be filled in device variables page per device after attaching the template. Values can be entered manually or can be uploaded via a csv file.

Step 6 To save the feature template, click **Add**.

What to do next

Sample configurations for CLI templates

System level configuration

Table 2: System level parameters

CLI Template Configuration	Configuration on the Device
system host-name pm4 system-ip 172.16.255.14 overlay-id 1 site-id 400 control-session-pps 300 admin-tech-on-failure sp-organization-name "XYZ Inc Regression" organization-name "XYZ Regression" console-baud-rate 115200 vbond 10.0.12.26 port 12346	system host-name pm4 system-ip 172.16.255.14 overlay-id 1 site-id 400 control-session-pps 300 admin-tech-on-failure sp-organization-name “XYZ Inc Regression” organization-name “XYZ Inc Regression” console-baud-rate 11520 vbond 10.0.12.26 port 12346

AAA Configuration - authentication, authorization, and accounting (AAA) with RADIUS and TACACS+

Table 3: AAA configuration

CLI Template Configuration	Configuration on the Device

aaa
 auth- order local radius tacacs
 usergroup basic
  task system read write
 task interface read write
!
usergroup netadmin
!
 usergroup operator
task system read
task interface read
task policy read
task routing read
task security read
!
user admin password
 	
6nbbLkA==$ae/DO78l/wluPUohhBU2L6h/
Q.PLkurGvxjRlS9OWB9iTtFwSGNQcABV6F
MW57vuEHvo3zp3qdYVinLmMIu/p/
secret
$9$3/IL3/UF2F2F3E$J9NKBeKlWrq9ExmHk6F5VAiDMOFQfD.QPAmMxDdxz.c
 	
! !
radius
 server 10.99.144.200
  source-interface GigabitEthernet0/0/1
 exit
 server 10.99.144.201
 	
  source-interface GigabitEthernet0/1/0
 exit
!
tacacs
 server 10.0.1.1
  auth-port 50
  vpn 0
  source-interface GigabitEthernet0/0/1
  key 1
  secret-key
8Kcuva0CM871E8czESwV5g/YX4Q8pY1LSNk/+PIDrpCg=
 	
 exit !
!
	aaa group server tacacs+ server-10.0.1.1
	  server-private 10.0.1.1 timeout 5 key
	8vs5hzVg/Z6EeuUdNHTzOwWPsUv9V/50xmcRfShWp3YI=
	
	 ip tacacs source-interface
	GigabitEthernet0/0/1
	!
	aaa group server radius server-10.99.144.200
	 server-private 10.99.144.200 auth-port 1812
	 timeout 5 retransmit 3
	 ip radius source-interface
	GigabitEthernet0/0/1
	!
	aaa group server radius server-10.99.144.201
	
	 server-private 10.99.144.201 auth-port 1812
	 timeout 5 retransmit 3
	 ip radius source-interface
	GigabitEthernet0/1/0
	!
	aaa authentication login default local group
	 radius group tacacs+
	aaa authorization exec default local group
	radius group tacacs+ a
	aa session-id common --- added by default
	
	username admin privilege 15 secret 9
	$9$3/IL3/UF2F2F3E$J9NKBeKlWrq9ExmHk6F5VAiDMOFQfD.QPAmMxDdxz.c

Logging configuration - configures logging to either the local hard drive or a remote host

Table 4: Logging configuration

CLI Template Configuration	Configuration on the Device
logging disk enable file size 12 file rotate 6 ! server 192.168.13.1 vpn 0 source-interface Loopback1 priority alert exit !	logging disk enable ! ! logging persistent size 75497472 filesize 12582912 logging buffered 512000 --- added by default logging host 192.168.13.1 no logging rate-limit logging source-interface Loopback1 logging persistent

Switch port and VLAN configuration

Table 5: Switch port configuration

CLI Template Configuration	Configuration on the Device
interface GigabitEthernet0/1/4 switchport mode trunk access vlan vlan 10 access vlan name "DHCP Vlan" trunk allowed vlan 10 ! no shutdown vpn 10 name "DHCP VPN" interface Vlan10 description "Vlan 10 Mgmt interface" ip address 10.29.35.1/24 no shutdown ! !	interface GigabitEthernet0/1/4 switchport ios-sw:mode trunk switchport ios-sw:trunk allowed vlan 10 no shutdown no ip address exit interface Vlan10 description Vlan 10 Mgmt interface no shutdown arp timeout 1200 vrf forwarding 10 ip address 10.29.35.1 255.255.255.0 ip mtu 1500 exit

Cellular configuration

Table 6: Cellular configuration - configures cellular controllers and cellular interfaces

CLI Template Configuration	Configuration on the Device

vpn 0
  interface Cellular0/2/0
  description "Cellular interface"
  no shutdown
  !
 	
  controller cellular 0/2/0
  lte sim max-retry 1
  lte failovertimer 7
  profile id 1 apn Broadband
  !
	interface Cellular0/2/0
	  description Cellular interface
	  no shutdown
	  ip address negotiated
	  ip mtu 1428
	  mtu 1500
	  exit
	
	  controller Cellular 0/2/0
	  lte sim max-retry 1
	  lte failovertimer 7
	  profile id 1 apn Broadband authentication
	 none pdn-type ipv4

BGP, OSPF, and EIGRP - configures BGP, OSPF, and EIGRP routing protocols under transport or service VPN

Table 7: BGP, OSPF, and EIGRP configuration

CLI Template Configuration	Configuration on the Device

CLI Template Configuration	Configuration on the Device

vpn1
  bgp 2
  shutdown
  distance external 30
  distance internal 250
  distance local 10
  address-family ipv4-unicast
  network 10.0.100.0/24
  redistribute static route-policy route_map
  redistribute connected route-policy route_map
  !
  neighbor 10.0.100.1
  no shutdown
  remote-as 3
  timers
  keepalive 12
  holdtime 20
  connect-retry 300
  advertisement-interval 123
  !
  update-source GigabitEthernet0/0/1
  ebgp-multihop 1
  password $8$9pou4PH9b60B072hcw3MmSSdLCfJk8bVys12lLVb+08=
 	
  address-family ipv4-unicast
 	
vpn 1
  router
  ospf
  router-id 172.16.255.15
  compatible rfc1583
  timers spf 200 1000 10000
  redistribute connected route-policy route_map
  max-metric router-lsa administrative
  area 23
  stub
  interface GigabitEthernet0/0/1
  cost 23
  authentication type message-digest
  authentication authentication-key key1
 	
  exit
  exit
  !
 	
vpn 1
 router
  eigrp 1
  af-interface GigabitEthernet0/0/2
  no split-horizon
  exit-af-interface
  !
 address-family ipv4 network 10.1.10.1/32
 address-family ipv4 topology base
 redistribute omp
 exit-af-topology	

CLI Template Configuration	Configuration on the Device
	router bgp 2 bgp log-neighbor-changes distance bgp 30 250 10 address-family ipv4 unicast vrf 1 neighbor 10.0.100.1 remote-as 3 neighbor 10.0.100.1 activate neighbor 10.0.100.1 ebgp-multihop 1 neighbor 10.0.100.1 maximum-prefix 2147483647 100 neighbor 10.0.100.1 password 0 password neighbor 10.0.100.1 send-community both neighbor 10.0.100.1 timers 12 20 neighbor 10.0.100.1 update-source GigabitEthernet0/0/1 network 10.0.100.0 mask 255.255.255.0 redistribute connected redistribute static route-map route_map exit-address-family ! timers bgp 60 180 router ospf 1 vrf 1 auto-cost reference-bandwidth 100 max-metric router-lsa timers throttle spf 200 1000 10000 router-id 172.16.255.15 default-information originate distance ospf external 110 distance ospf inter-area 110 distance ospf intra-area 110 redistribute connected subnets route-map route_map ! interface GigabitEthernet0/0/1 no shutdown arp timeout 1200 vrf forwarding 1 ip address 10.1.100.14 255.255.255.0 ip redirects ip mtu 1500 ip ospf 1 area 23 ip ospf network broadcast mtu 1500 negotiation auto exit ! router eigrp eigrp-name address-family ipv4 vrf 1 autonomous-system 1 af-interface GigabitEthernet0/0/2 hello-interval 5 hold-time 15 no split-horizon exit-af-interface ! network 10.1.10.1 0.0.0.0 topology base redistribute omp exit-af-topology ! exit-address-family

CLI Template Configuration	Configuration on the Device
	! !

VPN, Interface, and tunnel configuration for WAN and LAN interfaces

Table 8: VPN, Interface, and Tunnel configuration

CLI Template Configuration	Configuration on the Device

vpn 0
  interface GigabitEthernet0/2/0
  ip address 10.1.14.14/24
  tunnel-interface
  encapsulation ipsec
  color lte
  no allow-service bgp
  allow-service dhcp
  allow-service dns
  allow-service icmp
  no allow-service sshd
  no allow-service netconf
  no allow-service ntp
  no allow-service ospf
  no allow-service stun
  allow-service https
  !
  autonegotiate
  no shutdown
  !
  ip route 0.0.0.0/0 10.1.14.13
 	
vpn 512
interface GigabitEthernet0
  ip dhcp-client
ipv6 dhcp-client autonegotiate
no shutdown
! !
	ip route 0.0.0.0 0.0.0.0 10.1.14.13 1
	
	interface GigabitEthernet0/2/0
	  no shutdown
	  arp timeout 1200 – added by default
	  ip address 10.1.14.14 255.255.255.0
	  ip redirects --> added by default
	  ip mtu 1500
	  mtu 1500
	  negotiation auto --> added by default
	  exit
	
	interface Tunnel20 ---> based on the interface 0/2/0
	  no shutdown
	  ip unnumbered GigabitEthernet0/2/0
	  no ip redirects
	  ipv6 unnumbered GigabitEthernet0/2/0
	  no ipv6 redirects
	  tunnel source GigabitEthernet0/2/0
	  tunnel mode sdwan
	
	sdwan
	  interface GigabitEthernet0/2/0
	  tunnel-interface
	  encapsulation ipsec weight 1
	  color lte
	  no last-resort-circuit
	  vmanage-connection-preference 5
	  no allow-service all
	  no allow-service bgp
	  allow-service dhcp
	  allow-service dns
	  allow-service icmp
	  no allow-service sshd
	  no allow-service netconf
	  no allow-service ntp
	  no allow-service ospf
	  no allow-service stun
	
	interface GigabitEthernet0
	no shutdown
	arp timeout 1200
	vrf forwarding Mgmt-intf
	ip address dhcp client-id GigabitEthernet0 ip redirects
	ip dhcp client default-router distance 1 ip
	mtu 1500
	mtu 1500
	negotiation auto

Network Address Translation (NAT) over Direct Internet Access (DIA)

Table 9: NAT over DIA

CLI Template Configuration	Configuration on the Device
vpn 201 interface GigabitEthernet0/0/2.2901 description gigi21 ip address 10.201.201.1/24 mtu 1496 no shutdown vrrp 100 track-omp ipv4 10.201.201.3 ! ! ! dhcp-server address-pool 10.201.201.0/24 exclude 10.201.201.1-10.201.201.10 10.201.201.20-10.201.201.22 offer-time 600 lease-time 86400 admin-state up options default-gateway 10.201.201.1 dns-servers 10.99.139.201 tftp-servers 10.99.139.201 ! ! ! ip route 0.0.0.0/0 vpn 0 ! vpn 0 interface GigabitEthernet0/0/0 ip address 172.16.10.1/24 nat udp-timeout 3 tcp-timeout 40 respond-to-ping ! !	interface GigabitEthernet0/0/2.2901 no shutdown encapsulation dot1Q 2901 vrf forwarding 201 ip address 10.201.201.1 255.255.255.0 ip mtu 1496 vrrp 100 address-family ipv4 vrrpv2 address 10.201.201.3 priority 100 track omp shutdown exit exit ip dhcp excluded-address vrf 201 10.201.201.1 10.201.201.10 ip dhcp excluded-address vrf 201 10.201.201.20 10.201.201.22 ip dhcp pool vrf-201-GigabitEthernet0/0/2.2901 option 150 ip 10.99.139.201 vrf 201 lease 1 0 0 default-router 10.201.201.1 dns-server 10.99.139.201 network 10.201.201.0 255.255.255.0 exit ip dhcp use hardware-address client-id no ip dhcp use class ip dhcp use vrf remote ip nat inside source list nat-dia-vpn-hop-access-list interface GigabitEthernet0/0/0 overload ip nat translation tcp-timeout 40 ip nat translation udp-timeout 3 ip nat route vrf 201 0.0.0.0 0.0.0.0 global interface GigabitEthernet1/0/2 no shutdown arp timeout 1200 ip address 10.1.15.15 255.255.255.0 ip nat outside ip redirects ip mtu 1500 mtu 1500 negotiation auto

NAT64 configuration

Table 10: NAT64 configuration

CLI Template Configuration	Configuration on the Device

vpn 1
  nat64
  v4 pool pool1 start-address 10.1.1.10
  v4 pool pool1 end-address 10.1.1.100
  !
  interface GigabitEthernet3
  ip address 10.1.19.15/24
  nat64
  !
  autonegotiate
  no shutdown
  !
	interface GigabitEthernet3
	  no shutdown
	  arp timeout 1200
	  vrf forwarding 1
	  ip address 10.1.19.15 255.255.255.0
	  negotiation auto
	  nat64 enable
	  nat64 prefix stateful 2001::F/64 vrf 1
	
	  nat64 v4 pool pool1 10.1.1.10 10.1.1.100
	  nat64 v6v4 list global-list pool pool1 vrf 1
	  nat64 translation timeout tcp 60
	  nat64 translation timeout udp 1

Multilink and T1/E1 - configures T1/E1 controller and serial, multilink interfaces

Table 11: Configuring Multilink

CLI Template Configuration	Configuration on the Device

card type t1 0 2
  controller T1 0/2/0
  framing esf
  clock source internal
  linecode b8zs
  cablelength long 0db
  channel-group 1 timeslots 15
  channel-group 2 timeslots 12
  channel-group 3 timeslots 10
  channel-group 4 timeslots 10
!
interface Multilink1
  no shutdown
  encapsulation ppp
  ip address 10.1.10.30 255.255.255.0
  ppp pap sent-username admin password admin
ppp authentication pap
  ppp multilink
  ppp multilink links minimum 1
  ppp multilink fragment disable
  ppp multilink group 1
exit
interface Serial0/2/0:1
  no shutdown
  encapsulation ppp
  bandwidth 1536
  no ip address
  load-interval 30
  ppp pap sent-username admin password admin
ppp authentication pap
  ppp multilink
  ppp multilink group 1
exit
	interface Multilink1
	ip address 10.1.10.30/24 shutdown
	controller T1 0/2/0
	  linecode b8zs
	  channel-group 1
	  channel-group 3
	!
	ppp pap sent-username admin password admin
	ppp authentication pap
	ppp multilink
	ppp multilink group 1

Local QoS policy

Table 12: Local QoS policy

CLI Template Configuration	Configuration on the Device

CLI Template Configuration	Configuration on the Device

vpn 1
  interface GigabitEthernet0/0/1
  ip address 10.2.54.15/24
  no shutdown
  access-list MyACL in
  !
policy
  class-map
  class best-effort queue 3
  class bulk-data queue 2
  class critical-data queue 1
  class voice queue 0
  !
  access-list MyACL
  sequence 10
  match
  dscp 46
  !
  action accept
  class voice
  !
  !
  sequence 20
  match
  source-ip 10.1.1.0/24
  destination-ip 192.168.10.0/24
  !
  action accept
  class bulk-data
  set
  dscp 32
  !
  !
  !
  sequence 30
  match
  destination-ip 192.168.20.0/24
  !
  action accept
  class critical-data
  set
  dscp 22
  !
  !
  !
  sequence 40
  action accept
  class best-effort
  set
  dscp 0
  !
  !
  !
  default-action accept
  !
  qos-scheduler be-scheduler
  class best-effort
  bandwidth-percent 20
  buffer-percent 20
  drops red-drop
  !
  qos-scheduler bulk-scheduler
	interface GigabitEthernet0/0/1
	  access-list MyACL in
	  exit
	  class-map match-any best-effort
	  match qos-group 3
	  !
	  class-map match-any bulk-data
	  match qos-group 2
	  !
	  class-map match-any critical-data
	  match qos-group 1
	  !
	  class-map match-any voice
	  match qos-group 0
	  !
	  policy-map MyQoSMap
	  class best-effort
	  random-detect
	  bandwidth percent 20
	  !
	  class bulk-data
	  random-detect
	  bandwidth percent 20
	  !
	  class critical-data
	  random-detect
	  bandwidth percent 40
	  !
	  class voice
	  priority percent 20
	  !
	  !
	  policy
	  no app-visibility
	  no flow-visibility
	  no implicit-acl-logging
	  log-frequency 1000
	  class-map
	  class best-effort queue 3
	  class bulk-data queue 2
	  class critical-data queue 1
	  class voice queue 0
	  !
	  access-list MyACL
	  sequence 10
	  match
	  dscp 46
	  !
	  action accept
	  class voice
	  !
	  !
	  sequence 20
	  match
	  source-ip 10.1.1.0/24
	  destination-ip 192.168.10.0/24
	  !
	  action accept
	  class bulk-data
	  set
	  dscp 32
	  !

CLI Template Configuration	Configuration on the Device

<pre>   class   bulk-data
    bandwidth-percent 20
    buffer-percent   20
    drops   red-drop
   !
   qos-scheduler critical-scheduler
    class   critical-data
    bandwidth-percent 40
    buffer-percent   40
    drops   red-drop
   !
   qos-scheduler voice-scheduler
    class   voice
    bandwidth-percent 20
    buffer-percent   20
    scheduling   llq
   !
   qos-map MyQoSMap
    qos-scheduler be-scheduler
    qos-scheduler bulk-scheduler
    qos-scheduler critical-scheduler
    qos-scheduler voice-scheduler
   !
  !
 !
!</pre>
	<pre> !
	    !
	    sequence 30
	     match
	      destination-ip 192.168.20.0/24
	     !
	     action accept
	      class critical-data
	      set
	       dscp 22
	      !
	     !
	    !
	    sequence 40
	     action accept
	      class best-effort
	      set
	       dscp 0
	      !
	     !
	    !
	    default-action accept
	   !
	  !
	 !
	!</pre>

Security policy (ZBFW, IPS/IDS, URL-Filtering) configuration

Table 13: Security policy (ZBFW, IPS/IDS, URL-Filtering)

CLI Template Configuration	Configuration on the Device
policy zone internet vpn 0 ! zone zone1 vpn 1 ! zone zone2 vpn 2 ! zone-pair ZP_zone1_internet_fw_policy source-zone zone1 destination-zone internet zone-policy fw_policy ! zone-pair ZP_zone1_zone2_fw_policy source-zone zone1 destination-zone zone2 zone-policy fw_policy ! zone-based-policy fw_policy sequence 1 match source-data-prefix-list subnet1 ! action inspect ! ! default-action pass ! zone-to-nozone-internet deny lists data-prefix-list subnet1 ip-prefix 10.0.10.0/24 ! ! url-filtering url_filter web-category-action block web-categories games block-threshold moderate-risk block text "<![CDATA[<h3>Access" to the requested page has been denied]]>" target-vpns 1 ! intrusion-prevention intrusion_policy security-level connectivity inspection-mode protection log-level err target-vpns 1 ! failure-mode open ! ! !	

CLI Template Configuration	Configuration on the Device

	ip access-list extended fw_policy-seq-1-acl_
	  11 permit object-group
	fw-policy-seq-1-service-og_ object-group
	subnet1 any
	  !
	  ip access-list extended utd-nat-acl
	  10 permit ip any any
	  !
	  class-map type inspect match-all
	fw_policy-seq-1-cm_
	  match access-group name
	fw_policy-seq-1-acl_
	  !
	  policy-map type inspect fw_policy
	  class fw_policy-seq-1-cm_
	  inspect
	  !
	  class class-default
	  pass
	  !
	  !
	  object-group service
	fw_policy-seq-1-service-og_
	  ip
	  !
	parameter-map type inspect-global
	  alert on
	  log dropped-packets
	  multi-tenancy
	  vpn zone security
	  !
	  parameter-map type umbrella global
	  token
	A5EA676087BF66A42DC4F722C2AFD10D00256274
	  dnscrypt
	  vrf 1
	  dns-resolver umbrella
	  match-local-domain-to-bypass
	  !
	  !
	  zone security internet
	  vpn 0
	  !
	  zone security zone1
	  vpn 1
	  !
	  zone security zone2
	  vpn 2
	  !
	  zone-pair security
	ZP_zone1_internet_fw_policy source zone1
	destination internet
	  service-policy type inspect fw_policy
	  !
	  zone-pair security ZP_zone1_zone2_fw_policy
	source zone1 destination zone2
	  service-policy type inspect fw_policy
	  !
	  app-hosting appid utd
	  app-resource package-profile cloud-low
	  app-vnic gateway0 virtualportgroup 0
	guest-interface 0

CLI Template Configuration	Configuration on the Device
	guest-ipaddress 192.168.1.2 netmask 255.255.255.252 ! app-vnic gateway1 virtualportgroup 1 guest-interface 1 guest-ipaddress 192.0.2.2 netmask 255.255.255.252 ! start ! utd multi-tenancy utd engine standard multi-tenancy web-filter block page profile block-url_filter text <\![CDATA[Access to the requested page has been denied Please contact your Network Administrator]]> ! web-filter url profile url_filter categories block games ! block page-profile block-url_filter log level error reputation block-threshold moderate-risk ! ! threat-inspection profile intrusion_policy threat protection policy connectivity logging level err ! utd global ! policy utd-policy-vrf-1 all-interfaces vrf 1 threat-inspection profile intrusion_policy web-filter url profile url_filter exit !

Configuring NTP

Table 14: Configuring NTP

CLI Template Configuration	Configuration on the Device
ntp server 10.29.43.1 source-interface GigabitEthernet1 version 4 exit ! !	ntp server 198.51.241.229 source GigabitEthernet1 version 4

IPv6 configuration

Table 15: IPv6 configuration

CLI Template Configuration	Configuration on the Device
vpn 1 interface GigabitEthernet3 ipv6 address 2671:123A::1/128 shutdown ! !	interface GigabitEthernet3 shutdown arp timeout 1200 vrf forwarding 1 no ip address ip redirects ip mtu 1500 ipv6 address 2671:123A::1/128 ipv6 redirects mtu 1500 negotiation auto exit vrf definition 1 rd 1:1 address-family ipv4 exit-address-family ! address-family ipv6 exit-address-family ! !

Service configuration

In Cisco IOS XE Catalyst SD-WAN Release 17.7.1a and earlier, only the following configurations under **service** can be configured via CLI templates:

```
service pad
service config
service tcp-keepalives-in
service tcp-keepalives-out
service tcp-small-servers
service udp-small-servers
```

VRF configuration

Configure up to 300 VRFs, with a corresponding subinterface for each VRF. The example configures two VRFs.

Warning Do not configure VLAN 1. It is reserved for the native VLAN.

Table 16: VRF configuration

CLI Template Configuration	Configuration on the Device
! vpn 2 router bgp 1000 address-family ipv4-unicast redistribute omp address-family ipv6-unicast redistribute omp ! neighbor 192.0.2.2 no shutdown remote-as 2 ! ipv6-neighbor 2001:DB8:2::2 remote-as 2 ! ! interface GigabitEthernet0/0/0.2 ip address 192.0.2.1/24 ipv6 address 2001: DB8:2::1/64 mtu 1496 no shutdown ! ! vpn 3 router bgp 1000 address-family ipv4-unicast redistribute omp address-family ipv6-unicast redistribute omp ! neighbor 192.0.3.2 no shutdown remote-as 3 ! ipv6-neighbor 2001: DB8:3::2 remote-as 3 ! ! interface GigabitEthernet0/0/0.3 ip address 192.0.3.1/24 ipv6 address 2001: DB8:3::1/64 mtu 1496 no shutdown !	

CLI Template Configuration	Configuration on the Device

	vrf definition 2
	rd 1:2
	address-family ipv4
	  route-target export 1000:2
	  route-target import 1000:2
	  exit-address-family
	!
	address-family ipv6
	  exit-address-family
	!
	!
	router bgp 1000
	bgp log-neighbor-changes
	distance bgp 20 200 20
	!
	address-family ipv4 vrf 2
	  redistribute omp
	  neighbor 192.0.2.2 remote-as 2
	  neighbor 192.0.2.2 activate
	  neighbor 192.0.2.2 send-community both
	exit-address-family
	!
	address-family ipv6 vrf 2
	  redistribute omp
	  neighbor 2001:DB8:2::2 remote-as 2
	  neighbor 2001: DB8:2::2 activate
	  neighbor 2001: DB8:2::2 send-community both
	exit-address-family
	!
	interface GigabitEthernet0/0/0.2
	encapsulation dot1Q 2
	vrf forwarding 2
	ip address 192.0.2.1 255.255.255.0
	ip mtu 1496
	ipv6 address 2001:DB8:2::1/64
	end
	
	vrf definition 3
	rd 1:3
	address-family ipv4
	  route-target export 1000:3
	  route-target import 1000:3
	  exit-address-family
	!
	address-family ipv6
	  exit-address-family
	!
	!
	router bgp 1000
	bgp log-neighbor-changes
	distance bgp 20 200 20
	!
	address-family ipv4 vrf 3
	  redistribute omp
	  neighbor 192.0.3.2 remote-as 3
	  neighbor 192.0.3.2 activate
	  neighbor 192.0.3.2 send-community both
	exit-address-family
	!
	address-family ipv6 vrf 3
	  redistribute omp
	  neighbor 2001:DB8:3::2 remote-as 3

CLI Template Configuration	Configuration on the Device
	neighbor 2001: DB8:3::2 activate neighbor 2001: DB8:3::2 send-community both exit-address-family ! interface GigabitEthernet0/0/0.3 encapsulation dot1Q 3 vrf forwarding 3 ip address 192.0.3.1 255.255.255.0 ip mtu 1496 ipv6 address 2001:DB8:3::1/64 end