

Event Analysis Using External Tools

- Cisco cloud event settings, on page 1
- Event investigation using web-based resources, on page 4
- Configure cross-launch links for Secure Network Analytics, on page 7
- Sending syslog messages for security events, on page 9
- eStreamer server streaming, on page 22
- Event analysis in splunk, on page 26
- IBM QRadar events, on page 26
- History for analyzing event data using external tools, on page 27

Cisco cloud event settings

Cisco cloud event settings are firewall configurations that

- enable devices to send firewall events to the Security Services Exchange (SSE),
- allow external tools to investigate firewall incidents through cloud service integration, and
- unify visibility and enhance threat investigations by forwarding events to various cloud services.

Prerequisites and integration requirements

To allow your devices to send firewall events to Cisco Security Cloud, you must either register the Firewall Management Center with the smart license (**System** (⚙) > **Licenses** > **Smart Licenses**) or enable SecureX integration.

Cisco Security Cloud integration associates the Firewall Management Center with your Security Cloud Control account and brings your secure firewall deployment onboard to the Cisco cloud tenancy, allowing it to connect to Cisco's integrated security cloud services.

For more information about integrating the Firewall Management Center with Cisco Security Cloud, refer to Enable SecureX integration.

Security Services Exchange event consolidation parameters:

- For identifying duplication of intrusion events, the system considers: Initiator IP, Initiator IP, SID, and GID.
- For identifying duplication of connection events and security-related connection events, the system considers: Initiator IP, Initiator IP, and Security Intelligence Category.

- For identifying duplication of file and malware events, all elements except Event Second are considered.

Note The Security Services Exchange does not display the complete list of events from the Firewall Management Center. Instead, it correlates and consolidates events, presenting only unique events. This approach reduces redundancy of events and enhances clarity.

Enable sending events to the Cisco Security Cloud

The cloud region and event types that you configure in the SecureX **Integration** page can be used for multiple integrations when applicable and enabled.

Before you begin

- Ensure that you register the management center with Smart License (**System** (⚙) > **Licenses** > **Smart Licenses**) or enable Cisco Security Cloud integration to allow your devices to send firewall events to Cisco cloud.
- In the Firewall Management Center:
  - Go to the **System** (⚙) > **Configuration** page and give your Firewall Management Center a unique name to clearly identify it in the **Devices** list in the cloud.
  - Add your Firewall Threat Defense devices to the Firewall Management Center, assign licenses to them, and ensure that the system is working correctly. Ensure that you have created the necessary policies and that the generated events are displayed as expected in the Firewall Management Center UI under the **Analysis** menu.
- Ensure that you have your Security Cloud Sign-On credentials and can sign in to the regional cloud in which your account was created.

  For more information on regional cloud URLs and supported device versions, refer to Regional Clouds.
- If you are currently sending events to the cloud using syslog, disable it to avoid duplication.

Follow these steps to enable sending events to the Cisco Security Cloud:

Procedure

Step 1 Determine the regional cloud that you want to use for sending firewall events.

For more information about choosing a regional cloud, refer to Cisco Secure Firewall Threat Defense and Cisco XDR Integration Guide.

Note
If SecureX integration is enabled and the Firewall Management Center is registered to the selected regional cloud, changing the regional cloud disables SecureX integration. You can enable the SecureX integration again after changing the regional cloud.

Step 2 In your Firewall Management Center, choose **Integration** > **SecureX**.

Step 3 Choose a regional cloud from the **Current Region** drop-down list.

Step 4 Check the **Send events to the cloud** check box to enable the cloud event configuration.

Step 5 Select the event types that you want to send to the cloud.

Note
Events that you send to the cloud can be used for multiple integrations, as shown in this table.

Integration	Supported Event Options	Notes
Security Analytics and Logging (SaaS)	All	High-priority connection events include: • Security-related connection events • Connection events related to file and malware events • Connection events related to intrusion events
Cisco Extended Detection and Response (Cisco XDR)	Depending on your version: • Security-related connection events • Intrusion events • File and malware events	Even if you send all the connection events, Cisco XDR supports only security-related connection events. **Note** Cisco XDR is a separately licensed product. It requires an additional subscription beyond the licenses required for Cisco Secure Firewall products. For more information, refer to Cisco XDR Licenses.

Note
- When you enable **Intrusion Events**, the Firewall Threat Defense device sends events along with the impact flag.
- If you enable **File and Malware Events**, in addition to the events sent from the Firewall Threat Defense devices, the Firewall Management Center sends retrospective events.

Step 6 Click **Save**.

Analyze events using Cisco XDR

Cisco Extended Detection and Response (Cisco XDR) is a cloud-based solution that

- unifies visibility by correlating detections across multiple telemetry sources,
- enables security teams to detect, prioritize, and respond to the most sophisticated threats, and
- integrates with Firewall Threat Defense to connect Cisco's integrated security portfolio for a consistent experience that strengthens security across network.

Cisco XDR licensing and migration information

For more information about Cisco XDR, refer to Cisco XDR Help Center.

Important

- Cisco XDR is a separately licensed product. It requires an additional subscription beyond the licenses required for Cisco Secure Firewall products. For more information, refer to Cisco XDR Licenses.
- If you were already sending events to the Cisco Security Cloud using a SecureX subscription before Version 7.6, you can continue to send events to Cisco XDR. However, if you now register your Firewall Management Center to the cloud tenancy using your Security Cloud Control account to send firewall events to Cisco XDR, your Security Cloud Control account must have a Security Analytics and Logging license to forward events to Cisco XDR.

To integrate Firewall Threat Defense with Cisco XDR, refer to Cisco Secure Firewall Threat Defense and Cisco XDR Integration Guide.

Note As of July 31, 2024, Cisco SecureX is phased out and no longer available. Cisco SecureX cannot be provisioned for users, and access to Cisco SecureX is not provided alongside Cisco Secure Firewall product purchases. Additionally, all existing Cisco SecureX environments are disabled, and all capabilities are made unavailable. If you are using Firefox, you should remove Cisco SecureX Ribbon browser extension. For more information, refer to Frequently Asked Questions.

Event investigation using web-based resources

Event investigation using web-based resources is a security analysis method that

- enables quick access to threat intelligence from external sources outside of the Secure Firewall Management Center,
- allows direct navigation from events to relevant information in external resources based on IP addresses, ports, protocol, domain, and SHA-256 hash, and
- provides access to predefined links to commonly used Cisco and third-party threat intelligence services, plus custom links to other web-based services and SIEMs.

Event investigation capabilities

The contextual cross-launch feature supports various investigation scenarios:

- Look up a suspicious source IP address in a Cisco or third-party cloud-hosted service that publishes information about known and suspected threats
- Look for past instances of a particular threat in your organization's historical logs, if your organization stores that data in a Security Information and Event Management (SIEM) application
- Look for information about a particular file, including file trajectory information, if your organization has deployed Cisco Secure Endpoint

When investigating an event, you can click directly from an event in the event viewer or dashboard in the Secure Firewall Management Center to the relevant information in the external resource. This lets you quickly

gather context around a specific event based on its IP addresses, ports, protocol, domain, and/or SHA-256 hash.

Note Some resources may require an account or a product purchase.

Talos IP address investigation

Suppose you are looking at the Top Attackers dashboard widget and you want to find out more information about one of the source IP addresses listed. You want to see what information Talos publishes about this IP address, so you choose the "Talos IP" resource. The Talos website opens to a page with information about this specific IP address.

Manage contextual cross-launch resources

Manage external web-based resources using the **Analysis** > **Advanced** > **Contextual Cross-Launch** page.

Exception: Manage cross-launch links to a Secure Network Analytics appliance following the procedure in Configure cross-launch links for Secure Network Analytics, on page 7.

Pre-defined resources offered by Cisco are marked with the Cisco logo. The remaining links are third-party resources.

You can disable or delete any resources that you do not need, or you can rename them, for example by prefixing a name with a lower-case "z" so the resource sorts to the bottom of the list. Disabling a cross-launch resource disables it for all users. You cannot reinstate deleted resources, but you can re-create them.

To add a resource, refer to Add contextual cross-launch resources, on page 6.

Requirements for custom contextual cross-launch resources

A custom contextual cross-launch resource is an integration feature that

- enables web browser access to predefined or custom resources, and
- restricts configuration and usage based on user role permissions.

Custom contextual cross-launch resource specifications

Custom contextual cross-launch resources must meet these requirements:

- Resources must be accessible via web browser.
- Only HTTP and HTTPS protocols are supported.
- Only GET requests are supported; POST requests are not.
- Encoding of variables in URLs is not supported. While IPv6 addresses may require colon separators to be encoded, most services do not require this encoding.
- Up to 100 resources can be configured, including pre-defined resources.

- You must be an Admin or Security Analyst user to create a cross-launch, but you can also be a read-only Security Analyst to use them.

Add contextual cross-launch resources

In multidomain deployments, you can see and use resources in parent domains, but you can only create and edit resources in the current domain. The total number of resources across all domains is limited to 100.

Before you begin

- If you are adding links to a Secure Network Analytics appliance, check to see if the links you want already exist; most links are automatically created for you when you configure Security Analytics and Logging (On Premises).
- Refer to Requirements for custom contextual cross-launch resources, on page 5.
- If needed for the resource you will link to, create or obtain an account and the credentials needed for access. Optionally, assign and distribute credentials for each user who needs access.
- Determine the syntax of the query link for the resource that you will link to:

  Access the resource via browser and, using the documentation for that resource as needed, formulate the query link needed to search for a specific sample of the type of information you want your query link to find, such as an IP address.

  Run the query, then copy the resulting URL from the browser's location bar.

  For example, you might have the query URL `https://www.talosintelligence.com/reputation_center/lookup?search=10.10.10.10`.

Procedure

Step 1 Choose **Analysis** > **Advanced** > **Contextual Cross-Launch**.

Step 2 Click **New Cross-launch**.

In the form that appears, all fields marked with an asterisk require a value.

Step 3 Enter a unique resource name.

Step 4 Paste the working URL string from your resource into the **URL Template** field.

Step 5 Replace the specific data (such as an IP address) in the query string with an appropriate variable: Position your cursor, then click a variable (for example, **IP**) once to insert the variable.

In the example from the "Before You Begin" section above, the resulting URL might be `https://www.talosintelligence.com/reputation_center/lookup?search={IP}`. When the contextual cross-launch link is used, the {IP} variable in the URL will be replaced by the IP address that the user right-clicks on in the event viewer or dashboard.

For a description of each variable, hover over the variable.

You can create multiple contextual cross-launch links for a single tool or service, using different variables for each.

Step 6 Click **Test with example data** ( ) to test your link with example data.

Step 7 Fix any problems.

Step 8 Click **Save**.

Investigate events using contextual Cross-Launch

Contextual cross-launch allows you to right-click on event data and immediately access external analysis tools and threat intelligence resources. The available options depend on the data type you select, ensuring you only see relevant investigation resources.

Before you begin

If the resource you will access requires credentials, make sure you have those credentials.

Follow these steps to investigate events using contextual cross-launch:

Procedure

Step 1 Navigate to one of the following pages in the Secure Firewall Management Center that shows events:

- A dashboard (**Overview** > **Dashboards heading** > **Dashboard**), or
- An event viewer page (any menu option under the **Analysis** menu that includes a table of events.)

Step 2 Right-click the event of interest and choose the contextual cross-launch resource to use.

If necessary, scroll down in the context menu to see all available options.

The data type you right-click on determines the options you see; for example, if you right-click an IP address, you will only see contextual cross-launch options that are relevant to IP addresses.

For example, to get threat intelligence from Cisco Talos about a source IP address in the intrusion event, choose **Talos SrcIP** or **Talos IP**.

If a resource includes multiple variables, the option to choose that resource is available only for events that have a single possible value for each included variable.

The contextual cross-launch resource opens in a separate browser window.

It may take some time for the query to be processed, depending on the amount of data to be queried, speed of and demand on the resource, and so on.

Step 3 Sign in to the resource if necessary.

Configure cross-launch links for Secure Network Analytics

You can cross-launch from event data in Firewall Threat Defense to related data in your Secure Network Analytics appliance. For more information about the Secure Network Analytics product, visit the Cisco Security Analytics and Logging product page.

For general information about contextual cross-launching, refer to Investigate events using contextual Cross-Launch, on page 7.

Before you begin

- Ensure that a Secure Network Analytics appliance is available for use
- If your device sends events directly to Secure Network Analytics, disable syslog for those devices or assign them an access control policy without syslog configurations. This avoids duplicate events on the remote volume.
- Ensure you have these items:
  - Hostname or IP address of your manager.
  - Credentials for an account on your Secure Network Analytics appliance that has administrator privileges.

If you want to send Firewall Threat Defense data to your Secure Network Analytics appliance using Security Analytics and Logging (On Premises), refer to Remote data storage on a Secure Network Analytics appliance.

Follow these steps to configure a set of cross-launch links to your Secure Network Analytics appliance:

Procedure

Step 1 Choose **Integration** > **Security Analytics & Logging**.

Step 2 You have two options for Secure Network Analytics deployment:

- Manager Only—Deploy a standalone Manager to receive and store events, and from which you can review and query events.
- Data Store—Deploy a Cisco Secure Network Analytics Flow Collector to receive events, a Secure Network Analytics Data Store to store events, and a Manager from which you can review and query events.

Choose the deployment option and click **Start**.

Step 3 Complete the wizard. For more information, refer to the Firewall Management Center Configuration section of Cisco Security Analytics and Logging Firewall Event Integration Guide.

Step 4 Choose **Analysis** > **Advanced** > **Contextual Cross-Launch** to verify your new cross-launch links.

If you want to make changes, return to this procedure; you cannot make changes directly on the contextual cross-launch listing page.

Note

- If you want to change these links later, return to this procedure; you cannot make changes directly on the contextual cross-launch listing page.
- You can manually create additional links to cross-launch into your Secure Network Analytics appliance using the procedure in Add contextual cross-launch resources, on page 6, but those links remain independent of the auto-created resources and you must manage them manually.

What to do next

Use your Secure Network Analytics credentials to cross-launch from an event into the Secure Network Analytics event viewer.

To cross launch from an event in the Firewall Management Center event viewer or dashboard, right-click a relevant event's table cell and choose the appropriate option.

Processing queries may take some time, depending on the amount of data, data transfer speed on the Secure Network Analytics Manager, and other factors.

Sending syslog messages for security events

Sending syslog messages for security events is a data transmission capability that

- sends data related to connection, security intelligence, intrusion, and file and malware events via syslog to a Security Information and Event Management (SIEM) tool or another external event storage and management solution,
- supports events displayed in the Firewall Management Center web interface in the menu options under the Analysis menu, which are sometimes collectively referred to as "the event viewer", and
- handles events that are also sometimes referred to as Snort® events.

Syslog forwarding behavior changes



Note In version 7.2.1, syslog traffic was allowed to be forwarded using route lookup. This enabled the traffic to be forwarded regardless of the interface specified in the logging host configuration. However, in versions 7.2.5.1 and higher, the changes introduced in 7.2.1 were removed.

Thus, from 7.2.5.1 and higher versions, the configuration specified in logging host configuration precedes over the route lookup and the syslog traffic is forwarded from the specified interface.

Security event syslog platform settings

This topic lists the platform settings relevant to syslog messages for security events and notes on applying policy changes.

To find more about the platform settings that apply to syslog messages for security events, refer to *Threat Defense Platform Settings that Apply to Security Event Syslog Messages* in the *Cisco Secure Firewall Management Center Device Configuration Guide* .

If you make changes to syslog settings in any policy, you must redeploy for the changes to take effect.

Best practices for configuring security event syslog messaging

Best practices for configuring security event syslog messaging are recommended configuration approaches that

- ensure consistent syslog configuration across device types,

- optimize security event logging for external analysis tools, and
- avoid configuration conflicts between policy levels.

Configuration approaches by device type

Configuration requirements vary by device type and version.

Table 1: Security event syslog configuration by device

Device and Version	Configuration Location
All	If you will use syslog or store events externally, avoid special characters in object names such as policy and rule names. Object names should not contain special characters, such as commas, that the receiving application may use as separators.
Secure Firewall Threat Defense	**1.** Do the following to configure syslog in Firewall Threat Defense platform settings: **a.** Click **Devices** > **Platform Settings**. **b.** Edit the threat defense settings policy. **c.** In the left navigation pane, click **Syslog**. For more information, refer to *Threat Defense Platform Settings That Apply to Security Event Syslog Messages* in the *Cisco Secure Firewall Management Center Device Configuration Guide*. **2.** In your access control policy **Logging** tab, opt to use the Firewall Threat Defense platform settings. **3.** (For intrusion events) Configure intrusion policies to use the settings in your access control policy **Logging** tab. (This is the default.) Overriding any of these settings is not recommended. For essential details, refer to Send security event syslog messages from your Firewall Threat Defense devices , on page 10.
All other devices	**1.** Create an alert response. **2.** Configure access control policy Logging to use the alert response. **3.** (For intrusion events) Configure syslog settings in intrusion policies. For complete details, refer to Configure security event syslog messages for Classic devices, on page 13.

Send security event syslog messages from your Firewall Threat Defense devices

This task outlines the recommended procedure for sending syslog messages for connection, Security Intelligence, intrusion, file, and malware events from devices managed by Secure Firewall Management Center.

Note Many Firewall Threat Defense syslog settings are not applicable to security events. Configure only the options described in this procedure.

Before you begin

- In Secure Firewall Management Center, configure policies to generate security events and verify that the events you expect to see appear in the applicable tables under the Analysis menu.
- Gather the syslog server IP address, port, and protocol (UDP or TCP):
- Ensure that your devices can reach the syslog server(s).
- Confirm that the syslog server(s) can accept remote messages.
- For additional information about connection logging, refer to Connection Logging.

Follow these steps to configure security event syslog messaging:

Procedure

Step 1 Configure syslog settings for your Firewall Threat Defense device:

a) Click **Devices** > **Platform Settings**.
b) Click **Edit** to edit the platform settings policy associated with your Firewall Threat Defense device.
c) Click **Syslog** from the navigation pane.
d) Click **Syslog Servers** and click **Add** (+) to enter server, protocol, interface, and related information.

If you have questions about options on this page, refer to *Cisco Secure Firewall Management Center Device Configuration Guide*.

e) Click **Syslog Settings** and configure the following settings:

- **Enable timestamp on syslog messages**
- **Timestamp Format**
- **Enable syslog device ID**

f) Click **Logging Setup**.
g) On the **Basic Logging Settings**, select whether or not to **Send syslogs in EMBLEM format**.
h) Click **Save** to save your settings.

Step 2 Configure general logging settings for the access control policy (including file and malware logging):

a) Click **Policies** > **Access Control heading** > **Access Control**.
b) Edit the applicable access control policy.
c) From the **More** drop-down, click **Logging**.
d) Firewall Threat Defense 6.3 and later: Select **Use the syslog settings configured in the Threat Defense Platform Settings policy deployed on the device**.
e) (Optional) Select a **Syslog Severity**.
f) If you want to send file and malware events, select **Send Syslog messages for File and Malware events**.
g) Click **Save**.

Step 3 Enable logging for Security Intelligence events for the access control policy:

a) In the same access control policy, click the **Security Intelligence** tab.

b) In each of the following locations, click **Logging** ( ) and enable beginning and end of connections and **Syslog Server**:

- Beside **DNS Policy**.
- In the **Block List** box, for **Networks** and for **URLs**.

c) Click **Save**.

Step 4 Enable syslog logging for each rule in the access control policy:

a) In the same access control policy, click **Access Control**, and then choose **Add Rule**.

b) Select a rule to edit, and select the **Logging** tab in the rule.

c) Choose whether to log the beginning or end of connections, or both.

(Connection logging generates a lot of data; logging both beginning and end generates roughly double that much data. Not every connection can be logged both at beginning and end.)

d) If you want to log file events, select **Log Files**.

e) Enable **Syslog Server**.

f) Verify that the rule is " **Using default syslog configuration in Access Control Logging**."

g) Click **Confirm**.

h) Repeat for each rule in the policy.

Step 5 If you send intrusion events:

a) Navigate to the intrusion policy associated with your access control policy.

b) In your intrusion policy, from **Advanced Settings** drop-down menu, click **Syslog Alerting**, and then click **Enabled**.

c) If necessary, click **Edit**

d) Enter options:

Option	Value
Logging Host	Unless you will send intrusion event syslog messages to a different syslog server than you will send other syslog messages, leave this blank to use the settings you have configured above.
Facility	This setting is applicable only if you specify a Logging Host on this page. For descriptions, refer to SYSLOG alert facilities. .
Severity	This setting is applicable only if you specify a Logging Host on this page. For descriptions, refer to Syslog severity levels. .

e) Click **Back**.

f) Click **Policy Information** in the left navigation pane.

g) Click **Commit Changes**.

What to do next

- (Optional) Configure different logging settings for individual policies and rules.

  Refer to the applicable table rows in Configuration Locations for Syslogs for Connection and Security Intelligence Events (All Devices), on page 14 .

  These settings will require syslog alert responses, which are configured as described in Create a syslog alert response. They do not use the platform settings you configured in this procedure.

- To configure security event syslog logging for Classic devices, refer to Configure security event syslog messages for Classic devices, on page 13.

- If you are done making changes, deploy your changes to managed devices.

Configure security event syslog messages for Classic devices

Syslog messages generated by Classic devices contain critical security events that help track incidents and maintain compliance. To ensure proper logging, configure both the alert response and relevant policies.

Before you begin

- Configure policies to generate security events.
- Ensure that your devices can reach the syslog server(s).
- Confirm that the syslog server(s) can accept remote messages.
- For important information about connection logging, refer to Connection Logging.

Follow these steps to configure security event syslog messages for Classic devices:

Procedure

Step 1 Configure an alert response for your Classic devices.

For more information, refer to Create a syslog alert response.

Step 2 Configure syslog settings in the access control policy:

a) Click **Policies** > **Access Control heading** > **Access Control**.
b) Edit the applicable access control policy.
c) Click **Logging**.
d) Select **Send using specific syslog alert**.
e) Select the **Syslog Alert** you created above.
f) Click **Save**.

Step 3 If sending file and malware events:

a) Select **Send Syslog messages for File and Malware events**.
b) Click **Save**.

Step 4 If sending intrusion events:

a) Navigate to the intrusion policy associated with your access control policy.
b) In your intrusion policy, from **Advanced Settings** drop-down menu, click **Syslog Alerting**, and then click **Enabled**.

c) If necessary, click **Edit**
d) Enter options:

Option	Value
Logging Host	Unless you will send intrusion event syslog messages to a different syslog server than you will send other syslog messages, leave this blank to use the settings you have configured above.
Facility	This setting is applicable only if you specify a Logging Host on this page. For more information, refer to SYSLOG alert facilities.
Severity	This setting is applicable only if you specify a Logging Host on this page. For more information, refer to Syslog severity levels.

e) Click **Back**.
f) Click **Policy Information** in the navigation pane.
g) Click **Commit Changes**.

What to do next

- (Optional) Configure different logging settings for individual access control rules. For more information, refer to the applicable table rows in Configuration Locations for Syslogs for Connection and Security Intelligence Events (All Devices), on page 14. These settings will require syslog alert responses, which are configured as described in Create a syslog alert response. They do not use the settings you configured above.
- To configure security event syslog logging for Firewall Threat Defense devices, refer to Send security event syslog messages from your Firewall Threat Defense devices , on page 10.

Configuration locations for security event syslogs

These topics describe how to configure location for security event syslogs.

Configuration Locations for Syslogs for Connection and Security Intelligence Events (All Devices)

There are many places to configure logging settings. Use the table below to ensure that you set the options you need.

Important

- Pay careful attention when configuring syslog settings, especially when using inherited defaults from other configurations. Some options may not be available to all managed device models and software versions, as noted in the table below.
- For important information when configuring connection logging, see the chapter on Connection Logging.

Configuration Location	Description and More Information
Devices > **Platform Settings**, Threat Defense Settings policy, **Syslog**	This option applies only to Firewall Threat Defense devices. Settings you configure here can be specified in the Logging settings for an Access Control policy and then used or overridden in the remaining policies and rules in this table. See *Cisco Secure Firewall Management Center Device Configuration Guide*.
Policies > **Access Control heading** > **Access Control**, <each policy>, **Logging**	Settings you configure here are the default settings for syslogs for all connection and security intelligence events, unless you override the defaults in descendant policies and rules at the locations specified in the remaining rows of this table. Recommended setting for Firewall Threat Defense devices: Use Threat Defense Platform Settings. For information, see *Cisco Secure Firewall Management Center Device Configuration Guide*. Required setting for all other devices: Use a syslog alert. If you specify a syslog alert, see Create a syslog alert response. For more information about the settings on the Logging tab, see *Cisco Secure Firewall Management Center Device Configuration Guide*.
Policies > **Access Control heading** > **Access Control**, <each policy>, **Rules**, **Default Action** row, **Logging** ( )	Logging settings for the default action associated with an access control policy. See information about logging in *Cisco Secure Firewall Management Center Device Configuration Guide* and Logging connections with a policy default action.
Policies > **Access Control heading** > **Access Control**, <each policy>, **Rules**, <each rule>, **Logging**	Logging settings for a particular rule in an access control policy. See information about logging in *Cisco Secure Firewall Management Center Device Configuration Guide*.
Policies > **Access Control heading** > **Access Control**, <each policy>, **Security Intelligence**, **Logging** ( )	Logging settings for Security Intelligence Block lists. Click these buttons to configure: • DNS Block List Logging Options • URL Block List Logging Options • Network Block List Logging Options (for IP addresses on the blocked list) See *Cisco Secure Firewall Management Center Device Configuration Guide*
Policies > **Access Control heading** > **Decryption**, <each policy>, **Default Action** row, **Logging** ( )	Logging settings for the default action associated with an SSL policy. See Logging connections with a policy default action.

Configuration Location	Description and More Information
Policies > **Access Control heading** > **Decryption**, <each policy>, <each rule>, **Logging**	Logging settings for SSL rules. See *Cisco Secure Firewall Management Center Device Configuration Guide*.
Policies > **Access Control heading** > **Prefilter**, <each policy>, **Default Action** row, **Logging** ( )	Logging settings for the default action associated with a prefilter policy. See Logging connections with a policy default action.
Policies > **Access Control heading** > **Prefilter**, <each policy>, <each prefilter rule>, **Logging**	Logging settings for each prefilter rule in a prefilter policy. See *Cisco Secure Firewall Management Center Device Configuration Guide*
Policies > **Access Control heading** > **Prefilter**, <each policy>, <each tunnel rule> , **Logging**	Logging settings for each tunnel rule in a prefilter policy. See *Cisco Secure Firewall Management Center Device Configuration Guide*
Additional syslog settings for Firewall Threat Defense cluster configurations:	The *Cisco Secure Firewall Management Center Device Configuration Guide* has multiple references to syslog; search the chapter for "syslog."

Syslog configuration locations for intrusion events (Firewall Threat Defense devices)

Syslog settings for intrusion policies can be specified in various locations. You may also inherit settings from the access control policy or Threat Defense Platform Settings.

The table summarizes each configuration location and its purpose.

Configuration Location	Description and More Information
Devices > **Platform Settings**, Threat Defense Settings policy, **Syslog**	Syslog destinations that you configure here can be specified in the Logging tab of an access control policy which can be the default for an intrusion policy. For more information, refer to *Cisco Secure Firewall Management Center Device Configuration Guide*.
Policies > **Access Control heading** > **Access Control**, <each policy>, **Logging**	Default setting for syslog destination for intrusion events, if the intrusion policy does not specify other logging hosts. See *Cisco Secure Firewall Management Center Device Configuration Guide*.

Configuration Location	Description and More Information
Policies > **Access Control heading** > **Intrusion**, <each policy>, **Advanced Settings**, enable **Syslog Alerting**, click **Edit**	To specify syslog collectors other than the destinations specified in the access control policy Logging tab, and to specify facility and severity, refer to Configure syslog alerting for intrusion events. If you want to use the **Severity** or **Facility** or both as configured in the intrusion policy, you must also configure the logging hosts in the policy. If you use the logging hosts specified in the access control policy, the severity and facility specified in the intrusion policy will not be used.
Policies > **Access Control heading** > **Intrusion** > **Logging** > **IPS settings**	If you want to send syslog messages for IPS events. Default syslog settings configured are used for syslog destinations for IPS events.

Configuration Locations for Syslogs for Intrusion Events (Devices Other than Firewall Threat Defense)

- (Default) Access control policy *Cisco Secure Firewall Management Center Device Configuration Guide*, IF you specify a syslog alert (See Create a syslog alert response.)
- Or see Configure syslog alerting for intrusion events.

By default, the intrusion policy uses the settings in the Logging tab of the access control policy. If settings applicable to devices other than Firewall Threat Defense are not configured there, syslogs will not be sent for devices other than Firewall Threat Defense and no warning appears.

Configuration locations for syslogs for file and malware events

This reference provides information about where to configure syslogs for file and malware events in the system.

Configuration Location	Description and More Information
In an access control policy: **Policies > Access Control**, <each policy>, **Logging**	This is the main location for configuring the system to send syslogs for file and malware events. If you do not use the syslog settings in Firewall Threat Defense Platform Settings, you must also create an alert response. For more information, refer to Create a syslog alert response.
In Firewall Threat Defense Platform Settings: **Devices > Platform Settings**, Threat Defense Settings policy, **Syslog**	These settings apply only to Firewall Threat Defense devices running supported versions, and only if you configure the Logging tab in the access control policy to use Firewall Threat Defense platform settings. See *Cisco Secure Firewall Management Center Device Configuration Guide*.

Configuration Location	Description and More Information
In an access control rule: **Policies > Access Control**, <each policy>, <each rule>, **Logging**	If you do not use the syslog settings in Firewall Threat Defense Platform Settings, you must also create an alert response. For more information, refer to Create a syslog alert response.

Components of security event syslog messages

Describes the structure and components of security event syslog messages, including examples and detailed field descriptions.

Example security event message from Firewall Threat Defense (Intrusion Event)




Table 2: Components of security event syslog messages

Item Number in Sample Message	Header Element	Description
0	PRI	The priority value that represents both Facility and Severity of the alert. The value appears in the syslog messages only when you enable logging in EMBLEM format using Firewall Management Center platform settings. If you enable logging of intrusion events through access control policy Logging tab, the PRI value is automatically displayed in the syslog messages. For information on how to enable the EMBLEM format, refer to *Cisco Secure Firewall Management Center Device Configuration Guide*. For information on PRI, refer to RFC5424.

Item Number in Sample Message	Header Element	Description
1	Timestamp	Date and time the syslog message was sent from the device. • (Syslogs sent from Firewall Threat Defense devices) For syslogs sent using settings in the access control policy and its descendants, or if specified to use this format in the Threat Defense Platform Settings, the date format is the format defined in the ISO 8601 timestamp format as specified in RFC 5424 (yyyy-MM-ddTHH:mm:ssZ), where the letter Z indicates the UTC time zone. • (Syslogs sent from all other devices) For syslogs sent using settings in the access control policy and its descendants, the date format is the format defined in the ISO 8601 timestamp format as specified in RFC 5424 (yyyy-MM-ddTHH:mm:ssZ), where the letter Z indicates the UTC time zone. • Otherwise, it is the month, day, and time in UTC time zone, though the time zone is not indicated. To configure the timestamp setting in Threat Defense Platform Settings, refer to *Cisco Secure Firewall Management Center Device Configuration Guide*.
2	Device or interface from which the message was sent. This can be: • IP address of the interface • Device hostname • Custom device identifier	(For syslogs sent from Firewall Threat Defense devices) If the syslog message was sent using the Threat Defense Platform Settings, this is the value configured in **Syslog Settings** for the **Enable Syslog Device ID** option, if specified. Otherwise, this element is not present in the header. To configure this setting in Threat Defense Platform Settings, refer to *Cisco Secure Firewall Management Center Device Configuration Guide*.
3	Custom value	If the message was sent using an alert response, this is the **Tag** value configured in the alert response that sent the message, if configured. (Refer to Create a syslog alert response.) Otherwise, this element is not present in the header.
4	%FTD	Type of device that sent the message. %FTD is Secure Firewall Threat Defense.

Item Number in Sample Message	Header Element	Description
5	Severity	The severity specified in the syslog settings for the policy that triggered the message. For severity descriptions, refer to *Severity Levels* in the *Cisco Secure Firewall Management Center Device Configuration Guide* or Syslog severity levels.
6	Event type identifier	• 430001: Intrusion event • 430002: Connection event logged at beginning of connection • 430003: Connection event logged at end of connection • 430004: File event • 430005: File malware event
--	Facility	Refer to Facility values and locations for security event syslog messages, on page 20.
--	Remainder of message	Fields and values separated by colons. Fields with empty or unknown values are omitted from messages. For field descriptions, refer to: • Connection and Security-Related Connection Event Fields • Intrusion event fields • File and malware event fields **Note** Field description lists include both syslog fields and fields visible in the event viewer (menu options under the Analysis menu in the Firewall Management Center web interface.) Fields available via syslog are labeled as such. Some fields visible in the event viewer are not available via syslog. Also, some syslog fields are not included in the event viewer (but may be available via search), and some fields are combined or separated.

Facility values and locations for security event syslog messages

Facility values are not generally relevant to syslog messages generated for security events. However, some scenarios may require facility values to be specified.

The table summarizes how facility information is included or derived for different device types and security event categories.

Device	To Include Facility in Connection Events	To Include Facility in Intrusion Events	Location in Syslog Message
Firewall Threat Defense	Use the EMBLEM option in Threat Defense Platform Settings. Facility is always **ALERT** for connection events when sending syslog messages using Threat Defense Platform Settings.	Use the EMBLEM option in Threat Defense Platform Settings or configure logging using the syslog settings in the intrusion policy. If you use the intrusion policy, you must also specify the logging host in the intrusion policy settings. Enable syslog alerting and configure facility and severity on the intrusion policy. For more information, refer to Configure syslog alerting for intrusion events.	Facility does not appear in the message header, but the syslog collector can derive the value based on RFC 5424, section 6.2.1.
Devices other than Firewall Threat Defense	Use an ALERT response.	Use the syslog setting in the intrusion policy advanced settings or an ALERT response identified in the access control policy Logging tab.	

For more information, refer to Facility and severity values for intrusion syslog alerts and Create a syslog alert response.

Syslog message types supported by Secure Firewall devices

Secure Firewall devices can send multiple types of syslog messages.

The table summarizes each message type and provides references for configuration or further information.

Syslog Data Type	See
Audit logs from Firewall Management Center	Stream audit logs to syslog and the Audit and Syslog chapter
Device health and network-related logs from Firewall Threat Defense devices	*Cisco Secure Firewall Management Center Device Configuration Guide*
Connection, security intelligence, and intrusion event logs from Firewall Threat Defense devices	Security event syslog platform settings, on page 9.
Connection, security intelligence, and intrusion event logs from Classic devices	Security event syslog platform settings, on page 9
Logs for file and malware events	Security event syslog platform settings, on page 9

Syslog Data Type	See
IPS Settings	Send Syslog messages for IPS events. Syslog configuration locations for intrusion events (Firewall Threat Defense devices), on page 16

Limitations of syslog for security events

Syslog limitations for security events are system constraints that

- restrict certain object naming conventions and special character usage,
- introduce delays in event delivery to syslog collectors, and
- limit availability of specific file and malware event data types.

Syslog security event restrictions

The following limitations apply when using syslog for security events:

- If you will use syslog or store events externally, avoid special characters in object names such as policy and rule names. Object names should not contain special characters, such as commas, that the receiving application may use as separators.
- It may take up to 15 minutes for events to appear on your syslog collector.
- Data for the following file and malware events is not available via syslog:
  - Retrospective events
  - Events generated by Secure Endpoint

eStreamer server streaming

An eStreamer server is a streaming service that

- streams several kinds of event data from a Secure Firewall Management Center to custom-developed client applications,
- delivers event data either as binary data or as fully-qualified events in plaintext format, and
- requires configuration to specify which event types can be transmitted to requesting clients.

eStreamer server configuration requirements

Before the appliance you want to use as an eStreamer server can begin streaming eStreamer events to an external client, you must configure the eStreamer server to send events to clients, provide information about the client, and generate a set of authentication credentials to use when establishing communication. You can perform all of these tasks from the appliance's user interface. Once your settings are saved, the events you selected will be forwarded to eStreamer clients when requested.

You can control which types of events the eStreamer server is able to transmit to clients that request them.

Note eStreamer Client has been deprioritized, and the eNcoreCLI is End of Life as of 7/1/2024.

For more information, refer to *Secure Firewall Management Center Event Streamer Integration Guide*.

Table 3: Event types transmittable by the eStreamer server

Event type	Description
Intrusion Events	intrusion events generated by managed devices
Intrusion Event Packet Data	packets associated with intrusion events
Intrusion Event Extra Data	additional data associated with an intrusion event such as the originating IP addresses of a client connecting to a web server through an HTTP proxy or load balancer
Discovery Events	Network discovery events
Correlation and Allow List Events	correlation and compliance allow list events
Impact Flag Alerts	impact alerts generated by the Firewall Management Center
User Events	user events
Malware Events	malware events
File Events	file events
Connection Events	information about the session traffic between your monitored hosts and all other hosts.

Comparison of syslog and eStreamer for security eventing

Generally, organizations that do not currently have significant existing investment in eStreamer should use syslog rather than eStreamer to manage security event data externally.

Syslog	eStreamer
No customization required	Significant customization and ongoing maintenance required to accommodate changes in each release
Standard	Proprietary
Syslog standard does not protect against data loss, especially when using UDP	Protection against data loss
Sends directly from devices	Sends from Firewall Management Center, adding processing overhead

Syslog	eStreamer
Support for file and malware events, connection events (including security intelligence events) and intrusion events.	Support for all event types listed in eStreamer server streaming, on page 22.
Some event data can be sent only from Firewall Management Center. For more information, refer to Data sent only via eStreamer, not via syslog, on page 24.	Includes data that cannot be sent via syslog directly from devices. For more information, refer to Data sent only via eStreamer, not via syslog, on page 24.

Data sent only via eStreamer, not via syslog

This reference provides information about data that is available only from Secure Firewall Management Center and thus cannot be sent via syslog from devices.

- Packet Logs
- Intrusion Event Extra Data events

  For description, refer to eStreamer server streaming, on page 22.
- Statistics and aggregate events
- Network Discovery events
- User activity and login events
- Correlation events
- For malware events:
  - retrospective verdicts
  - ThreatName and Disposition, unless information about the relevant SHAs has already been synchronized to the device
- These fields:
  - Impact and ImpactFlag fields

    For description, refer to eStreamer server streaming, on page 22.
  - the IOC_Count field
- Most raw IDs and UUIDs.

  Exceptions:
  - Syslogs for connection events do include these: FirewallPolicyUUID, FirewallRuleID, TunnelRuleID, MonitorRuleID, SI_CategoryID, SSL_PolicyUUID, and SSL_RuleID
  - Syslogs for intrusion events do include IntrusionPolicyUUID, GeneratorID, and SignatureID
- Extended metadata, including but not limited to:
  - User details provided by LDAP, such as full name, department, phone number, etc.

Syslog only provides usernames in the events.

- Details for state-based information such as SSL Certificate details.

  Syslog provides basic information like the certificate fingerprint, but will not provide other certificate details like the cert CN.

- Detailed application information, such as App Tags and Categories.

  Syslog provides only Application names.

Some metadata messages also include extra information about the objects.

- Geolocation information

Choose eStreamer event types

The **eStreamer Event Configuration** checkboxes control which events the eStreamer server can transmit. Your client must still specifically request the types of events you want it to receive in the request message it sends to the eStreamer server. For more information, refer to *Secure Firewall Management Center Event Streamer Integration Guide*.

In a multidomain deployment, you can configure eStreamer Event Configuration at any domain level. However, if an ancestor domain has enabled a particular event type, you cannot disable that event type in the descendant domains.

You must be an Admin user to perform this task, for Firewall Management Center.

Procedure

Step 1 Choose **Integration** > **Other Integrations**.

Step 2 Click **eStreamer**.

Step 3 Under **eStreamer Event Configuration**, check or clear the check boxes next to the types of events you want eStreamer to forward to requesting clients, described in eStreamer server streaming, on page 22.

Step 4 Click **Save**.

Configure eStreamer client communications

Before eStreamer can send eStreamer events to a client, you must add the client to the eStreamer server's peers database from the eStreamer page. You must also copy the authentication certificate generated by the eStreamer server to the client. After completing these steps you do not need to restart the eStreamer service to enable the client to connect to the eStreamer server.

In a multidomain deployment, you can create an eStreamer client in any domain. The authentication certificate allows the client to request events only from the client certificate's domain and any descendant domains. The eStreamer configuration page shows only clients associated with the current domain, so if you want to download or revoke a certificate, switch to the domain where the client was created.

You must be an Admin or Discovery Admin user to perform this task, for Firewall Management Center.

Procedure

Step 1 Choose **Integration** > **Other Integrations**.

Step 2 Click **eStreamer**.

Step 3 Click **Create Client**.

Step 4 In the **Hostname** field, enter the host name or IP address of the host running the eStreamer client.

If you want to encrypt the certificate file, enter a password in the **Password** field.

Note
If you have not configured DNS resolution, use an IP address.

Step 5 Click **Save**.
The eStreamer server now allows the host to access port 8302 on the eStreamer server and creates an authentication certificate to use during client-server authentication.

Step 6 Click **Download** ( ) next to the client hostname to download the certificate file.

Step 7 Save the certificate file to the appropriate directory used by your client for SSL authentication.

Step 8 To revoke access for a client, click **Delete** ( ) next to the host you want to remove.

Note
You do not need to restart the eStreamer service; access is revoked immediately.

Event analysis in splunk

Event analysis in Splunk is a security investigation capability that

- enables you to use the Cisco Secure Firewall app for Splunk as an external tool to display and work with Secure Firewall event data,
- allows you to hunt and investigate threats on your network, and
- requires eStreamer for advanced functionality.

Implementation options

Use eStreamer with the Splunk App - This is an advanced functionality that requires eStreamer configuration. Refer to eStreamer server streaming, on page 22.

For more information about the Splunk App, refer to User Guide for Cisco Secure Firewall App for Splunk.

IBM QRadar events

IBM QRadar events are security functionalities that

- provide an alternate way to display event data using the Cisco Firepower app for IBM QRadar,
- help you analyze, hunt for, and investigate threats to your network, and
- require eStreamer for advanced functionality.

Additional reference information

eStreamer is required for advanced capabilities. For more information, refer to eStreamer server streaming, on page 22.

For more information, refer to https://www.cisco.com/c/en/us/td/docs/security/firepower/integrations/QRadar/integration-guide-for-the-cisco-firepower-app-for-ibm-qradar.html.

History for analyzing event data using external tools

Documents the history of features for analyzing event data using external tools, including enhancements and deprecations.

Feature	Minimum Firewall Management Center	Minimum Firewall Threat Defense	Details
Deprecated: SecureX Ribbon	Any	Any	SecureX Ribbon is deprecated. If you have installed the **Cisco SecureX Ribbon** browser extension in your Firefox browser and are experiencing compatibility errors while using Firewall Management Center, remove the SecureX Ribbon extension. To remove the extension, open Firefox, go to the browser's add-ons or extensions manager, locate the **Cisco SecureX Ribbon** extension, and remove or disable it. Restart Firefox to apply the changes.
Register your firewall deployment to Cisco Security Cloud tenancy using your Cisco Security Cloud Sign-On account and your Security Cloud Control tenant.	Any	Any	You can now register your Firewall Management Center and its managed devices to the Cisco Security Cloud using your Cisco Security Cloud Sign-On account and your Security Cloud Control tenant. Cisco SecureX is phased out and no longer available. If you have an active Cisco SecureX environments, you will continue to receive support from the Cisco Technical Assistance Center (TAC) through the product end-of-support. For more information, refer to Frequently Asked Questions.
SecureX ribbon	7.0	Any	The SecureX ribbon pivots into SecureX for instant visibility into the threat landscape across your Cisco security products. To display the SecureX ribbon in Firewall Management Center, refer to the *Firepower and SecureX Integration Guide* at https://cisco.com/go/firepower-securex-documentation. New/Modified screens: New page: **System** > **SecureX**.

Feature	Minimum Firewall Management Center	Minimum Firewall Threat Defense	Details
Send all connection events to the Cisco cloud	7.0	Any	You can now send all connection events to the Cisco cloud, rather than just sending high-priority connection events. New/Modified screens: New option on the **System** > **Integration** > **Cloud Services**.
Cross-launch to view data in Secure Network Analytics	6.7	Any	This feature introduces a quick way to create multiple entries for your Secure Network Analytics appliance on the Analysis > Contextual Cross-Launch page. These entries allow you to right-click a relevant event to cross-launch Secure Network Analytics and display information related to the data point from which you cross-launched. New menu item: **System** > **Logging** > **Security Analytics and Logging**. New page to configure sending events to Secure Network Analytics.
Contextual cross-launch from additional field types	6.7	Any	You can now cross-launch into an external application using the following additional types of event data: • Access control policy • Intrusion policy • Application protocol • Client application • Web application • Username (including realm) New menu options: Contextual cross-launch options are now available when right-clicking the above data types for events in Dashboard widgets and event tables on pages under the Analysis menu. Supported platforms: Secure Firewall Management Center
Integration with IBM QRadar	6.0 and later	Any	IBM QRadar users can use a new Firepower-specific app to analyze their event data. Available functionality is affected by your Firepower version. Refer to IBM QRadar events, on page 26.

Feature	Minimum Firewall Management Center	Minimum Firewall Threat Defense	Details
Enhancements to integration with SecureX Threat Response	6.5	Any	• Support for regional clouds: • United States (North America) • Europe • Support for additional event types: • File and malware events • High-priority connection events These are connection events related to the following: • Intrusion events • Security Intelligence events • File and malware events Modified screens: New options on **System** > **Integration** > **Cloud Services**. Supported Platforms: All devices supported in this release, either via direct integration or syslog.
Syslog	6.5	Any	The AccessControlRuleName field is now available in intrusion event syslog messages.
Integration with Cisco Security Packet Analyzer	6.5	Any	Support for this feature was removed.
Integration with SecureX Threat Response	6.3 (via syslog, using a proxy collector) 6.4 (direct)	Any	Integrate Firepower intrusion event data with data from other sources for a unified view of threats on your network using the powerful analysis tools in SecureX Threat Response. Modified screens (version 6.4): New options on **System** > **Integration** > **Cloud Services**. Supported Platforms: Secure Firewall Threat Defense devices running version 6.3 (via syslog) or 6.4.
Syslog support for File and Malware events	6.4	Any	Fully-qualified file and malware event data can now be sent from managed devices via syslog. Modified screens: **Policies** > **Access Control** > **Access Control** > **Logging**. Supported Platforms: All managed devices running version 6.4.

Feature	Minimum Firewall Management Center	Minimum Firewall Threat Defense	Details
Integration with Splunk	Supports all 6.x versions	Any	Splunk users can use a new, separate Splunk app, Cisco Secure Firewall app for Splunk, to analyze events. Available functionality is affected by your Firepower version. Refer to Event analysis in splunk, on page 26.
Integration with Cisco Security Packet Analyzer	6.3	Any	Instantly query Cisco Security Packet Analyzer for packets related to an event, then click to examine the results in Cisco Security Packet Analyzer or download them for analysis in another external tool. New screens: **System** > **Integration** > **Packet Analyzer** **Analysis** > **Advanced** > **Packet Analyzer Queries**. New menu options: **Query** > **Packet Analyzer** menu item when right-clicking on an event on Dashboard pages and event tables on pages under the Analysis menu. Supported platforms: Secure Firewall Management Center
Contextual cross-launch	6.3	Any	Feature introduced: Right-click an event to look up related information in predefined or custom URL-based external resources. New screens: **Analysis** > **Advanced** > **Contextual Cross-Launch.** New menu options: Multiple options when right-clicking on an event on Dashboard pages and event tables on pages under the Analysis menu. Supported platforms: Secure Firewall Management Center
Syslog messages for connection and intrusion events	6.3	Any	Ability to send fully-qualified connection and intrusion events to external storage and tools via syslog, using new unified and simplified configurations. Message headers are now standardized and include event type identifiers, and messages are smaller because fields with unknown and empty values are omitted. Supported Platforms: • All new functionality: Firewall Threat Defense devices running version 6.3. • Some new functionality: Non- Firewall Threat Defense devices running version 6.3. • Less new functionality: All devices running versions older than 6.3. For more information, refer to the topics under Sending syslog messages for security events, on page 9 and subtopics.
eStreamer	6.3	Any	Moved eStreamer content from the Host Identity Sources chapter to this chapter and added a summary comparing eStreamer to syslog.