Release Notes for Cisco Catalyst IE3x00 Rugged, IE3400 Heavy Duty, and ESS3300 Series Switches, Cisco IOS XE Cupertino 17.8.x

First Published: 2022-03-24

Last Modified: 2023-02-09

Introduction

This document provides release information for the following Catalyst IE and Cisco ESS switches:

- Cisco Catalyst Rugged Series Switches (IE32000 and IE3300)
- Cisco Catalyst IE3400 Rugged Series (IE3400)
- Cisco Catalyst IE3400 Heavy-Duty Series (IE3400H)
- Cisco Embedded Services 3300 Series (ESS3300)

Cisco Catalyst IE3x00 Rugged Series Switches feature advanced, full Gigabit Ethernet speed for rich real-time data - and a modular, optimized design. These Cisco rugged switches bring simplicity, flexibility and security to the network edge, and are optimized for size, power, and performance.

From their end-to-end security architecture to delivering centralized automation and scale with Cisco intent-based networking, the Cisco Catalyst IE3x00 family is the perfect solution to your switching needs in almost any use case.

Cisco Embedded Services 3300 Series Switches (ESS3300) revolutionize Cisco's embedded networking portfolio with 1G/10G capabilities. ESS3300 switches are optimized to meet specialized form-factor, ruggedization, port density, and power needs of many applications requiring customization. They complement Cisco's off-the-shelf Industrial Ethernet switching portfolio.

On ESS3300, the small form factor, board configuration options, and optimized power consumption provide Cisco partners and integrators the flexibility to design custom solutions for defense, oil and gas, transportation, mining, and other verticals. The ESS3300 runs the trusted and feature-rich Cisco IOS XE Software, allowing Cisco partners and integrators to offer their customers the familiar Cisco IOS CLI and management experience on their ESS3300 solutions.



Note The documentation set for this product strives to use bias-free language. For purposes of this documentation set, bias-free is defined as language that does not imply discrimination based on age, disability, gender, racial identity, ethnic identity, sexual orientation, socioeconomic status, and intersectionality. Exceptions may be present in the documentation due to language that is hardcoded in the user interfaces of the product software, language used based on RFP documentation, or language that is used by a referenced third-party product.

New Features for Cisco Catalyst IE and ESS Switches in Cisco IOS XE 17.8.x

The following features apply to both the IE3x00 and ESS3300 switches unless mentioned.

Feature Name	License Level	Description	Supported Platforms
REP Zero Touch Provisioning (ZTP)	Network Essentials	The REP ZTP feature allows PNP to function on insertion of a new IE switch into an existing REP ring.	• IE3200/IE3300 • IE3400/IE3400H • ESS3300
SGACL Logging	Network Essentials	The switch can provide logging messages about packets permitted or denied by a security group-based access control list (SGACL). Logging is triggered only when the Access Control Entry (ACE) includes the **log** keyword. Support for SGACL Logging also requires that one of the following FPGA Profiles be activated on the switch: • Default Profile • CTS-IPv6 Profile	• IE3400/IE3400H

Feature Name	License Level	Description	Supported Platforms
FPGA Profile	Network Essentials	The switch supports three FPGA profiles with different combinations of features supported in each profile: • default: Supports 1 instance of PRP/HSR, 1 instance of DLR, and CTS IPv4 Security Group Tag (SGT) with VRF and Security Group Access Control List (SGACL) Logging. • cts-ipv6: Supports CTS IPv4 and IPv6 SGT with VRF and SGACL Logging. • redundancy: Supports 1 instance of PRP and 1 instance of DLR.	• IE3400/IE3400H
DSCP Marking on Radius Server	Network Essentials	Cisco IOS XE Software supports differentiated services code point (DSCP) setting for RADIUS packets to allow faster authentication and accounting of RADIUS packets.	• IE3200/IE3300 • IE3400/IE3400H • ESS3300
Network Edge Authentication Topology (NEAT)	Network Essentials	NEAT utilizes the Client Information Signaling Protocol (CISP) in order to propagate client MAC addresses and VLAN information between supplicant and authenticator switches.	• IE3200/IE3300 • IE3400/IE3400H

Important Notes

IE3400: Hardware Changes may Require Action

Some hardware components on the Cisco Catalyst IE3400 Rugged Series and Cisco Catalyst IE3400 Heavy Duty Series switches have changed. The changes, which are automatically handled by the IOS-XE software, do not affect switch functionality or the ordering process.

However, you may need to upgrade the software, depending on which base switch and expansion module you have, as shown in the following table.



Note For detailed information about affected hardware versions, supported software releases, and instructions for different scenarios, see *FN72400 - New Hardware Versions of Cisco Catalyst IE3400 Rugged/IE3400H Heavy Duty Series Will Be Supported with Minimum Software Release - Software Upgrade Recommended* on Cisco.com.

If you have...	Then...
Older versions of the base switch and expansion module	No action is required.
Newer versions of the base switch and expansion module	Deploy one of the supported releases of IOS-XE. Otherwise, you see an error message telling you that the release that you are using is not supported. The supported releases are 17.8.1 and later. Do not downgrade to earlier releases.
Newer version of the base switch with an older version of the expansion module	
Older version of the base switch with a newer version of the expansion module	Deploy one of the supported releases of IOS-XE. Refer to *Field Notice Title* on Cisco.com for details that are appropriate to your deployment.

FPGA Profile

FPGA Profile is supported in Cisco IOS XE release 17.8 and later. In a Cisco IOS XE upgrade from an earlier release that does not support FPGA Profile, for example, an upgrade from Cisco IOS XE 17.7.1 to 17.8.1, the default FPGA Profile is installed. Any features controlled by FPGA Profile that are configured in the switch running the earlier release and that are not included in the default profile will be rejected.

For example, CTS IPv6 is not supported in the default profile, so CTS IPv6 configurations are rejected during bootup after the upgrade. Similarly, after a Cisco IOS XE upgrade where the cts-ipv6 profile is loaded, existing PRP and DLR configurations are rejected upon bootup.

To keep the existing profile and feature configurations after an upgrade:

1. After booting the switch, selected the required FPGA Profile as described in "Changing the FPGA Profile", in System Management Configuration Guide, Cisco Catalyst IE3x00 Rugged, IE3400 Heavy Duty, and ESS3300 Series Switches, chapter "Configuring FPGA Profile".

   Do not copy running-config to startup-config or write memory.

2. Reload the switch.

   The required feature configurations will not be discarded because they are supported by the selected profile.

Accessing Hidden Commands

Hidden commands have always been present in Cisco IOS XE, but were not equipped with CLI help. This means that entering enter a question mark (?) at the system prompt did not display the list of available commands. Such hidden commands are only meant to assist Cisco TAC in advanced troubleshooting and are therefore not documented. For more information about CLI help, see the *Using the Command-Line Interface → Understanding the Help System* chapter of the Command Reference document.

This section provides information about hidden commands in Cisco IOS XE and the security measures in place, when they are accessed. Hidden commands are meant to assist Cisco TAC in advanced troubleshooting and are therefore not documented. For more information about CLI help, see the *Using the Command-Line Interface → Understanding the Help System* chapter of the Command Reference document.

Hidden commands are available under:

- Category 1—Hidden commands in privileged or User EXEC mode. Begin by entering the **service internal** command to access these commands.
- Category 2—Hidden commands in one of the configuration modes (global, interface and so on). These commands do not require the **service internal** command.

Further, the following applies to hidden commands under Category 1 and 2:

- The commands have CLI help. Entering enter a question mark (?) at the system prompt displays the list of available commands.

Note For Category 1, enter the **service internal** command before you enter the question mark; you do not have to do this for Category 2.

- The system generates a %PARSER-5-HIDDEN syslog message when the command is used. For example:

```
*Feb 14 10:44:37.917: %PARSER-5-HIDDEN: Warning!!! 'show processes memory old-header '
 is a hidden command.
Use of this command is not recommended/supported and will be removed in future.
```

Apart from category 1 and 2, there remain internal commands displayed on the CLI, for which the system does NOT generate the %PARSER-5-HIDDEN syslog message.

Important We recommend that you use any hidden command only under TAC supervision. If you find that you are using a hidden command, open a TAC case for help with finding another way of collecting the same information as the hidden command (for a hidden EXEC mode command), or to configure the same functionality (for a hidden configuration mode command) using non-hidden commands.

PoE Limitation on IE3x00

Even when using power supplies that can provide up to a supported maximum (for example, 170W, 240W, or 480W) for the PoE budget, the PoE budget for the IE3x00 defaults to 125W regardless of the power supplies used. You can configure the power budget to use the maximum.



Note Before changing the power budget, the minimum power requirements for the switch need to be considered as well. Please refer to the datasheet for your switch for more details.

To use the power supply's maximum supported wattage for the PoE budget, configure the power supply max wattage in global configuration mode as follows:

1. Verify the maximum amount that the power supplies support for the PoE budget.
2. Enter **power inline max** *max-wattage* to increase the PoE budget based on the power supplies used.

   max-wattage is the maximum available PoE power.

IE3200 and IE 3300 with 10Mbps or 100Mbps speed in Half-Duplex Mode

CRC errors were observed on the IE 3200 and IE3300 platforms when the switch is configured with 10Mbps or 100Mbps speed in half-duplex mode.

As a workaround, configure **no ptp enable** on the half-duplex interface. This improves ingress and egress latencies considerably and ensures that there are no late collisions (and therefore, no CRC errors).

The issue and workaround apply to Cisco IOS XE releases 17.3.5 and later.

Cisco Catalyst IE and ESS Switches: Model Numbers (17.8.x)

The following table lists the supported hardware models and the default license levels they are delivered with. For information about the available license levels, see section *License Levels*.

Model Number	Default License Level	Description
ESS-3300-NCP-E	Network Essentials	Main Board without a cooling plate. 2 ports of 10 GE fiber, 8 ports of GE copper. 4 of the 8 GE copper ports can also be combo ports. Terminal Power: 16W
ESS-3300-NCP-A	Network Advantage	Main Board without a cooling plate. 2 ports of 10 GE fiber, 8 ports of GE copper. 4 of the 8 GE copper ports can also be combo ports. Terminal Power: 16W
ESS-3300-CON-E	Network Essentials	Main Board conduction cooled 2 ports of 10 GE fiber, 8 ports of GE copper. 4 of the 8 GE copper ports can also be combo ports Terminal Power: 16W

Model Number	Default License Level	Description
ESS-3300-CON-A	Network Advantage	Main Board conduction cooled 2 ports of 10 GE fiber, 8 ports of GE copper. 4 of the 8 GE copper ports can also be combo ports Terminal Power: 16W
ESS-3300-24T-NCP-E	Network Essentials	Main Board with a 16p Expansion Board without a cooling plate 2 ports of 10 GE fiber, 24 ports of GE copper 4 of 8 GE ports can be combo ports on mainboard 4 of 16 GE ports can be combo ports on expansion board Terminal Power: 24W
ESS-3300-24T-NCP-A	Network Advantage	Main Board with a 16p Expansion Board without a cooling plate 2 ports of 10 GE fiber, 24 ports of GE copper 4 of 8 GE ports can be combo ports on mainboard 4 of 16 GE ports can be combo ports on expansion board Terminal Power: 24W
ESS-3300-24T-CON-E	Network Essentials	Main Board with a 16p Expansion Board conduction cooled 2 ports of 10 GE fiber, 24 ports of GE copper 4 of 8 GE ports can be combo ports on mainboard 4 of 16 GE ports can be combo ports on expansion board Terminal Power: 24W
ESS-3300-24T-CON-A	Network Advantage	Main Board with a 16p Expansion Board conduction cooled 2 ports of 10 GE fiber, 24 ports of GE copper 4 of 8 GE ports can be combo ports on mainboard 4 of 16 GE ports can be combo ports on expansion board Terminal Power: 24W
IE-3200-8T2S-E	Network Essentials	8 Gigabit Ethernet 10/100/1000 RJ45 ports, 2 fiber 100/1000 SFP-based ports, non-PoE

Model Number	Default License Level	Description
IE-3200-8P2S-E	Network Essentials	8 Gigabit Ethernet 10/100/1000 PoE/PoE+ ports, 2 fiber 100/1000 SFP-based ports; PoE power budget of 240W
IE-3300-8T2S-E	Network Essentials	8 Gigabit Ethernet 10/100/1000 RJ45 ports, 2 fiber 100/1000 SFP-based ports, non-PoE
IE-3300-8P2S-E	Network Essentials	8 Gigabit Ethernet 10/100/1000 PoE/PoE+ ports, 2 fiber 100/1000 SFP-based ports; PoE power budget of 360W (including expansion module)
IE-3300-8T2S-A	Network Advantage	8 Gigabit Ethernet 10/100/1000 RJ45 ports, 2 fiber 100/1000 SFP-based ports, non-PoE
IE-3300-8P2S-A	Network Advantage	8 Gigabit Ethernet 10/100/1000 PoE/PoE+ ports, 2 fiber 100/1000 SFP-based ports; PoE power budget of 360W (including expansion module)
IE-3300-8T2X-A	Network Advantage	8 Gigabit Ethernet 10/100/1000 RJ45 ports, 2 fiber 1/10 Gigabit Ethernet SFP-based ports, non-PoE
IE-3300-8T2X-E	Network Essentials	8 Gigabit Ethernet 10/100/1000 RJ45 ports, 2 fiber 1/10 Gigabit Ethernet SFP-based ports, non-PoE
IE-3300-8U2X-E	Network Essentials	8 Gigabit Ethernet 10/100/1000 4PPoE (802.3bt type 3) ports, 2 fiber 1/10 Gigabit Ethernet SFP-based ports; PoE power budget of 480W
IE-3300-8U2X-A	Network Advantage	8 Gigabit Ethernet 10/100/1000 4PPoE (802.3bt type 3) ports, 2 fiber 1/10 Gigabit Ethernet SFP-based ports; PoE power budget of 480W
IE-3400-8T2S-E	Network Essentials	8 Gigabit Ethernet 10/100/1000 RJ45 ports, 2 fiber 100/1000 SFP-based ports, non-PoE
IE-3400-8T2S-A	Network Advantage	8 Gigabit Ethernet 10/100/1000 RJ45 ports, 2 fiber 100/1000 SFP-based ports, non-PoE
IE-3400-8P2S-E	Network Essentials	8 Gigabit Ethernet 10/100/1000 RJ45 ports, 2 fiber 100/1000 SFP-based ports with PoE
IE-3400-8P2S-A	Network Advantage	8 Gigabit Ethernet 10/100/1000 RJ45 ports, 2 fiber 100/1000 SFP-based ports with PoE
IE-3400H-8T-E	Network Essentials	8x1-Gbps X-Coded ports, 1 Alarm input and 1 Alarm output, 1 Console port, mini-change input for Single power source

Model Number	Default License Level	Description
IE-3400H-8T-A	Network Advantage	8x1-Gbps X-Coded ports, 1 Alarm input and 1 Alarm output, 1 Console port, mini-change input for Single power source
IE-3400H-8FT-E	Network Essentials	8 100-Mbps D-coded ports, 1 Alarm input and 1 Alarm output, 1 Console port, Mini-change input for Single Power Source .
IE-3400H-8FT-A	Network Advantage	8 100-Mbps D-coded ports, 1 Alarm input and 1 Alarm output, 1 Console port, Mini-change input for Single Power Source .
IE-3400H-16T-E	Network Essentials	16x1-Gbps X-Coded ports, 1 Alarm input and 1 Alarm output, 1 Console port, mini-change input for Single power source
IE-3400H-16T-A	Network Advantage	16x1-Gbps X-Coded ports, 1 Alarm input and 1 Alarm output, 1 Console port, mini-change input for Single power source
IE-3400H-16FT-E	Network Essentials	16 100-Mbps D-coded ports, 1 Alarm input and 1 Alarm output, 1 Console port, Mini-change input for Single Power Source .
IE-3400H-16FT-A	Network Advantage	16 100-Mbps D-coded ports, 1 Alarm input and 1 Alarm output, 1 Console port, Mini-change input for Single Power Source .
IE-3400H-24T-E	Network Essentials	24x1-Gbps X-Coded ports, 1 Alarm input and 1 Alarm output, 1 Console port, mini-change input for Single power source
IE-3400H-24T-A	Network Advantage	24x1-Gbps X-Coded ports, 1 Alarm input and 1 Alarm output, 1 Console port, mini-change input for Single power source
IE-3400H-24FT-E	Network Essentials	24 100-Mbps D-coded ports, 1 Alarm input and 1 Alarm output, 1 Console port, Mini-change input for Single Power Source .
IE-3400H-24FT-A	Network Advantage	24 100-Mbps D-coded ports, 1 Alarm input and 1 Alarm output, 1 Console port, Mini-change input for Single Power Source .

Expansion Modules

The following table lists the optional expansion modules for the IE3300 and IE3400 base systems. Modules with IEM-3400-xx are only supported on IE3400 base systems. IEM expansion modules that support PoE are only supported on Base systems that support PoE.

Expansion Module	Description
IEM-3300-4MU	4 copper 2.5Gigabit Ethernet ports. With IEEE 802.3bt type 4 PoE.
IEM-3300-8T	8 copper Gigabit Ethernet ports. Non PoE.
IEM-3300-8P	8 copper Gigabit Ethernet ports. With PoE
IEM-3300-8S	8 SFP Gigabit Ethernet ports. Non PoE.
IEM-3300-16T	16 copper Gigabit Ethernet ports. Non PoE.
IEM-3300-16P	16 copper Gigabit Ethernet ports. With PoE.
IEM-3300-6T2S	6 copper Gigabit Ethernet ports and 2 SFP Gigabit ports. Non PoE.
IEM-3300-14T2S	14 copper Gigabit Ethernet ports, and 2 SFP Gigabit ports. Non PoE.
IEM-3400-8T	8 copper Gigabit Ethernet ports with Advanced features. Non PoE.
IEM-3400-8S	8 SFP Gigabit Ethernet ports with Advanced features. Non PoE.
IEM-3400-8P	8 copper Gigabit Ethernet ports with Advanced features with PoE.

Optics Modules

Cisco Catalyst Series Switches support a wide range of optics and the list of supported optics is updated on a regular basis. Use the Transceiver Module Group (TMG) Compatibility Matrix tool, or consult the tables at this URL for the latest transceiver module compatibility information: https://www.cisco.com/en/US/products/hw/modules/ps5455/products_device_support_tables_list.html

The Cisco Catalyst IE3x00 Rugged, IE3400 Heavy Duty and ESS3300 Series Switches datasheets contain the current list of supported SFP and optics.

WebUI System Requirements

The WebUI is a web browser-based switch management tool that runs on the switch. The following subsections list the hardware and software required to access the WebUI.

Minimum Hardware Requirements

Processor Speed	DRAM	Number of Colors	Resolution
233 MHz minimum[1]	512 MB[2]	256	1280 x 800 or higher

[1] We recommend 1 GHz
[2] We recommend 1 GB DRAM

Software Requirements

Operating Systems

- Windows 10 or later
- Mac OS X 10.9.5 or later

Browsers

- Google Chrome: Version 59 or later (On Windows and Mac)
- Microsoft Edge
- Mozilla Firefox: Version 54 or later (On Windows and Mac)
- Safari: Version 10 or later (On Mac)

Upgrading the Switch Software

This section covers the various aspects of upgrading or downgrading the device software.

Note See the Cisco IOS XE Migration Guide for IIoT Switches for the latest information about upgrading and downgrading switch software.

SSH Algorithms for Common Criteria Certification Limitation

Starting from Cisco IOS XE Release 17.10, the following Key Exchange and MAC algorithms are removed from the default list:

- Key Exchange algorithm:
  - diffie-hellman-group14-sha1
- MAC algorithms:
  - hmac-sha1
  - hmac-sha2-256
  - hmac-sha2-512

Note You can use the **ip ssh server algorithm kex** command to configure the Key Exchange algorithm and the **ip ssh server algorithm mac** command to configure the MAC algorithms.

Finding the Software Version

The package files for Cisco IOS XE software can be found on the system board's internal flash memory device (flash:) or an external USB, depending on the device configuration.

You can use the **show version** privileged EXEC command to see the software version that is running on your switch.

Note Although the **show version** output always shows the software image running on the switch, the model name shown at the end of this display is the factory configuration and does not change if you upgrade the software license.

You can also use the **dir** *filesystem:* privileged EXEC command to see the names and versions of other software images that you might have stored in flash memory.

Software Images 17.8.x

The following table provides the filenames for the IOS XE 17.8.x software image for Cisco Catalyst IE3x00 Rugged, IE3400 Heavy Duty, and ESS3300 Series Switches.

Release	Image Type	Filename
Cisco IOS XE.17.8.1	Universal	ie3x00-universalk9.17.08.01.SPA.bin
		ess3x00-universalk9.17.08.01.SPA.bin
	NPE	ie3x00-universalk9_npe.17.08.01.SPA.bin

Automatic Boot Loader Upgrade

When you upgrade from the existing release on your switch to a later or newer release for the first time, the boot loader may be automatically upgraded, based on the hardware version of the switch. If the boot loader is automatically upgraded, it will take effect on the next reload.

For subsequent Cisco IOS XE releases, if there is a new bootloader in that release, it may be automatically upgraded based on the hardware version of the switch when you boot up your switch with the new image for the first time.

Caution Do not power cycle your switch during the upgrade.

Scenario	Automatic Boot Loader Response

If you boot Cisco IOS XE the first time	Boot loader may be upgraded to version "8.1.2" for IE3x00 and ESS-3300.
	`Checking Bootloader upgrade...`
	`…`
	`Bootloader upgrade successful`

Software Installation Commands

Note For the **install** command to be successful, it is recommended to have a minimum of free space that is twice the size of the image in flash. If there is not enough space available in flash, you are advised to free up space in flash either by issuing the **install remove inactive** command or to manually clean up the flash by removing unwanted core files or any other files that occupy a large amount of space in flash.

Summary of Software Installation Commands for Install Mode	
To install and activate the specified file, and to commit changes to be persistent across reloads—**install add file** *filename* [**activate commit**]	
add file tftp: *filename*	Copies the install file package from a remote location to the device and performs a compatibility check for the platform and image versions.
activate [**auto-abort-timer**]	Activates the file, and reloads the device. The **auto-abort-timer** keyword automatically rolls back image activation.
commit	Makes changes persistent over reloads.
remove	Deletes all unused and inactive software installation files.

Licensing

The information about the licensing packages for features available on Cisco Catalyst IE3x00 Rugged, IE3400 Heavy Duty, and ESS3300 Series Switches and Cisco Catalyst IE3100 Rugged Series Switches are available at: https://www.cisco.com/c/en/us/td/docs/iot/collections/cisco-iiot-licensing.html.

Caveats

Caveats describe unexpected behavior in Cisco IOS XE releases. Caveats listed as open in a prior release are carried forward to the next release as either open or resolved.

Cisco Bug Search Tool

Cisco Bug Search Tool is a web-based tool that acts as a gateway to the Cisco bug tracking system that maintains a comprehensive list of defects and vulnerabilities in Cisco products and software. BST provides you with detailed defect information about your products and software.

Click the link for the caveat in the sections below to view details for the caveat in Bug Search Tool.

Open Caveats in Cisco IOS XE Cupertino 17.8.1

Identifier	Description
CSCwa65562	Vlan assignment fails with %PM-3-INTERNALERROR platform IE-3400

Identifier	Description
CSCwb22624	Incorrect \"show cdp ne\" output when configuring an RSPAN on IE3400/IE3300/IE3200 and ESS3300

Resolved Caveats in Cisco IOS XE Cupertino 17.8.1

Identifier	Description
CSCwa20262	QoS policy-map with just the class-default does not apply its marking action

Troubleshooting

For the most up-to-date, detailed troubleshooting information, see the Cisco TAC website at this URL:

https://www.cisco.com/en/US/support/index.html

Go to **Product Support** and select your product from the list or enter the name of your product. Look under Troubleshoot and Alerts, to find information for the problem that you are experiencing.

Related Documentation

Information about Cisco IOS XE at this URL: https://www.cisco.com/c/en/us/products/ios-nx-os-software/ios-xe/index.html

All support documentation for Cisco Catalyst IE3100 Rugged Series Switches is at this URL: https://www.cisco.com/c/en/us/support/switches/catalyst-ie3100-rugged-series/series.html

Allsupport documentation for Cisco Catalyst IE3100H Heavy Duty Series Switches is at this URL: https://www.cisco.com/c/en/us/support/switches/catalyst-ie3100-heavy-duty-series/series.html

All support documentation for Cisco Catalyst IE3200 Rugged Series Switches is at this URL: https://www.cisco.com/c/en/us/support/switches/catalyst-ie3200-rugged-series/tsd-products-support-series-home.html

All support documentation for Cisco Catalyst IE3300 Rugged Series Switches is at this URL: https://www.cisco.com/c/en/us/support/switches/catalyst-ie3300-rugged-series/tsd-products-support-series-home.html

All support documentation for Cisco Catalyst IE3400 Rugged Series Switches is at this URL: https://www.cisco.com/c/en/us/support/switches/catalyst-ie3400-rugged-series/tsd-products-support-series-home.html

All support documentation for Cisco Catalyst IE3400H Heavy Duty Series Switches is at this URL: https://www.cisco.com/c/en/us/support/switches/catalyst-ie3400-heavy-duty-series/tsd-products-support-series-home.html

All support documentation for Cisco ESS3300 Series Switches is at this URL: https://www.cisco.com/c/en/us/support/switches/embedded-service-3000-series-switches/tsd-products-support-series-home.html

Cisco Validated Designs documents at this URL: https://www.cisco.com/go/designzone

To locate and download MIBs for selected platforms, Cisco IOS releases, and feature sets, use Cisco MIB Locator found at the following URL: http://www.cisco.com/go/mibs

Communications, Services, and Additional Information

- To receive timely, relevant information from Cisco, sign up at Cisco Profile Manager.
- To get the business impact you're looking for with the technologies that matter, visit Cisco Customer Experience.
- To submit a service request, visit Cisco Support.
- To discover and browse secure, validated enterprise-class apps, products, solutions and services, visit Cisco Solution Partner Program.
- To obtain general networking, training, and certification titles, visit Cisco Press.
- To find warranty information for a specific product or product family, access Cisco Warranty Finder.

© 2022 Cisco Systems, Inc. All rights reserved.