

show plugin

- show plugin, on page 1

show plugin

Table 1: show plugin Command Output Descriptions

Field	Description
Patch-directory	Displays the patch directory location.
Base-directory	Displays the base directory location.
Base-version	Displays the base version (default).
Module Priority	Displays the module priority number.
Version	Displays the version number of the plugin.

show plugin