

Gateway Selection Profile Configuration Mode Commands

Command Modes

Exec > Global Configuration > Gateway Selection Profile Configuration

configure > gateway-selection-profile *profile_name*

Entering the above command sequence results in the following prompt:

`[local]`*`host_name`*`(gw-profile-`*`profile_name`*`)#`

Important Available commands or keywords/variables vary based on platform type, product version, and installed license(s).

- description, on page 1
- do show, on page 2
- end, on page 2
- exit, on page 3
- zone, on page 3

description

Product

ePDG

Privilege

Security Administrator, Administrator

Command Modes

Exec > Global Configuration > Gateway Selection Profile Configuration

configure > gateway-selection-profile *profile_name*

Entering the above command sequence results in the following prompt:

`[local]`*`host_name`*`(gw-profile-`*`profile_name`*`)#`

Syntax Description

`description` *`descriptive_string`*

`remove description`

remove

descriptive_string

descriptive_string must be an alphanumeric string from 1 to 100 characters.

Usage Guidelines Use this command to

Example

Use the following command to

do show

Executes all **show** commands while in Configuration mode.

Product All

Privilege Security Administrator, Administrator

Syntax Description `do show`

Usage Guidelines Use this command to run all Exec mode **show** commands while in Configuration mode. It is not necessary to exit the Config mode to run a **show** command.

The pipe character **|** is only available if the command is valid in the Exec mode.



Caution There are some Exec mode **show** commands which are too resource intensive to run from Config mode. These include: **do show support collection**, **do show support details**, **do show support record** and **do show support summary**. If there is a restriction on a specific **show** command, the following error message is displayed:

```
Failure: Cannot execute 'do show support' command from Config mode.
```

end

Exits the current configuration mode and returns to the Exec mode.

Product All

Privilege Security Administrator, Administrator

Syntax Description `end`

Usage Guidelines Use this command to return to the Exec mode.

exit

Exits the current mode and returns to the parent configuration mode.

Product

All

Privilege

Security Administrator, Administrator

Syntax Description

exit

Usage Guidelines

Use this command to return to the parent configuration mode.

zone

Product

ePDG

Privilege

Security Administrator, Administrator

Command Modes

Exec > Global Configuration > Gateway Selection Profile Configuration

configure > gateway-selection-profile *profile_name*

Entering the above command sequence results in the following prompt:

`[local]`*`host_name`*`(gw-profile-`*`profile_name`*`)#`

Syntax Description

zone *zone_fqdn* **action { ignore | mandatory }**

remove zone *zone_fqdn*

remove

zone_fqdn

zone_fqdn must be an alphanumeric string from 1 to 255 characters.

action { ignore | mandatory }

Usage Guidelines

Use this command to

Example

Use the following command to