

show confdmgr

This chapter includes the **show confdmgr** command output tables. ConfD is the engine supporting the NETCONF protocol interface with the Cisco Network Service Orchestrator (NSO) and Elastic Services Controller (ESC).

- show confdmgr, on page 1
- show confdmgr subscriptions, on page 3

show confdmgr

Table 1: show confdmgr Command Output Descriptions

Field	Description
State Information	
State	Indicates current state of the confdmgr proclet: Starting, Started, Stopped.
Subscriptions	Indicates configuration points defined in the Yang model for which confdmgr v be notified when a change occurs.
Last successful id	ID number for the last successful request instance.
Last failed id	ID number for the last failed request instance.
Autosave url	URL specified by the NETCONF Protocol Configuration mode **autosave-conf** command. **Note** This command was made obsolete in 21.2; this field is no longer displayed in 2 higher releases.
Username	Username specified by the NETCONF Protocol Configuration mode **confd-us** command.
Bulkstats	Displays whether event bulkstats collection and reporting on the REST interfa enabled or disabled.

Field	Description
Kpi interval	Displays the time interval in seconds for gathering NSLB Key Performance Indica (KPI) information. If set to 0, this functionality is disabled.
Event notification level	Displays the configured severity level of StarOS events to be sent out as NETCON notifications: critical (1), error (2), warning (3), unusual (4), info (5). This level dic the lowest event severity level that results in a notification.
SNMP notifications	Displays whether SNMP alert and alarm reporting via NETCONF is enabled or disa
REST interface authentication	Displays the certificate verification done on client interfaces: none, peer, or peer-f
REST interface certificate	Displays the name of the certificate.
REST interface host name	If configured, displays the host name the web server will serve. If configured, mand the web server to only service requests whose Host field matches this configured h name. Otherwise displays "Not configured".
Interface / Status / Port The current status (Enabled/Disabled) and configured port number for the NETCONF and REST interfaces.	
Statistics	
Triggers	Number of times confdmgr has requested ConfD to dump the CDB contents back confdmgr which results in a config synchronization by SCT (Shared configuration T
Replays	Number of times a transaction has been replayed. A replay is initiated if, upon sta the last successful transaction ID in confdmgr does not match that of ConfD. This c occur, for example, if confdmgr task restarted when processing the notification fo configuration transaction.
Notifications	Number of times ConfD has sent a configuration update to confdmgr. For example can occur as the result of a "commit" via confd_cli or during a trigger event.
Notification failures	Number of times an update received from ConfD was not processed successfully. number of successes and failures should always equal the total number of notificat
Trigger failures	Number of times a CDB dump to confdmgr failed.
Replay failures	Number of times an attempt to replay a transaction failed.
NETCONF notification failures	Number of times an attempt to issue a NETCONF notification failed.
Unexpected failures	Number of times an unexpected condition was encountered. An error is generated each case.
Successful notifications	Number of times an update received from ConfD was successfully processed. **Note** This field was deprecated in 21.2.

show confdmgr subscriptions

Table 2: show confdmgr subscriptions Command Output Descriptions

Field	Description
Subscriptions	
Path	Pathname for configuration points defined in the Yang model for which confdm to be notified when a change occurs.
Index	Assigned index number
Namespace	staros