

show pilot-packet statistics

This chapter describes the output of the **show pilot-packet statistics** command.

- show pilot-packet statistics, on page 1
- show pilot-packet statistics all, on page 1

show pilot-packet statistics

This chapter describes the output of the **show pilot-packet statistics** command.

show pilot-packet statistics all

Displays statistical information for all Pilot Packet operations on the system.

Table 1: show pilot-packet statistics all Command Output Descriptions

Field	Description
Session manager instance	The sessmgr instance number.
Server name	The name of the server.
NAT Alloc	The total number of Pilot Packets sent for every IP/Port allocation for all NAT enabled calls.
NAT De Alloc	The total number of Pilot Packets sent for every IP/Port deallocation for all NAT enabled calls.
Non NAT Alloc	The total number of Pilot Packets sent for every IP/Port allocation for all non-NAT calls.
Non NAT De Alloc	The total number of Pilot Packets sent for every IP/Port deallocation for all non-NAT calls.
Total Alloc	The total number of Pilot Packets sent for every IP/Port allocation for all call types.

Field	Description
Total De Alloc	The total number of Pilot Packets sent for every IP/Port deallocation for all call types.
RAT-Change-User-Info	The total number of Pilot Packets sent for every subscriber IP allocation on RAT type change.
RAT-Change-NAT-Info	The total number of Pilot Packets sent for every NAT port chunk allocation on RAT type change.