

UPF Troubleshooting Information

This chapter covers the following topics related to monitoring and troubleshooting the UPF features:

- Debug Logging , on page 1
- Monitoring CLI, on page 2
- Monitoring Protocol, on page 3
- RAT Type-based Statistics, on page 3
- Subscriber Level CLI, on page 7
- VPP Statistics, on page 15
- SNMP Support, on page 19
- Troubleshooting UPF Features, on page 20
- Configure Stats Profile for QCI Drop Statistics, on page 22
- NSO configuration considerations, on page 23
- Per-QCI Drop statistics commands, on page 23

Debug Logging

Important The debug logging CLIs must be enabled with the help of System Administrator. Enabling debug logging CLIs can be resource intensive.

Use the following debug CLIs as required:

- **logg filter active facility sx level debug**
- **logg filter active facility user-data level debug**
- **logg filter active facility sessmgr level debug**
- **logg filter active facility uplane level debug**
- **logg filter active facility egtpc level debug**
- **logg filter active facility gtpu level debug**
- **logg filter active facility egtpu level debug**
- **logg filter active facility gtpumgr level debug**

- **logg filter active facility sxdemux level debug**
- **logg filter active facility user-l3tunnel level debug**
- **logg filter active facility aaamgr level debug**
- **logg filter active facility vpp level debug**
- **logg filter active facility dpath level debug**
- **logg active pdu-verbosity 5**
- **logg syslog** *ip_address* **facility** *facilities* **event-verbosity { min | concise | full }**

Monitoring CLI

Subscriber Level Message

Use the **mon sub callid** CLI command for subscriber level message.

Resource Tracking

Use the **show task resources facility** *sessmgr* **all** CLI command to track the CPU/Memory for PROCLET.

Service Status

Use the **show service all** CLI command to check the service status.

Sx Peer Status

Use the **show sx peers** CLI command to check the Sx peer status.

This output of this CLI is enhanced to display the auto config success, config push start time, and config push end time for a Sx peer.

```
[local]laas-si-setup# show sx peers wide
         ID                                                          Restart

|||||||  |                                        Recovery          |   Current   Max
  Peer   Config  Auto-Config  Config Push  Config Push
vvvvvvv  v    Group Name  Node ID      Peer ID     Timestamp         v  Sessions  Session
 State  Failures  Success    Start Time    End Time
------  ----  ----------- ---------   ---------  ------------------ ---- ------- -------
------  -------  --------    ----------   -----------
CAAXDXN  9    CPGROUP11   20.20.20.81  33554433 2025-05-14:05:36:46  0     0        0
 NONE     0         0           NA           NA
CAAXDXN  22   CPGROUP21   20.20.20.101 50331649 2025-05-14:05:36:45  0     0        0
 NONE     0         0           NA           NA

Total Peers:    2
```

GTP-U Peer Status

Use the **show gtpu peers** CLI command to check the GTP-U peer status.

Monitoring Protocol

When using the monitor protocol command, enable option 49 for PFCP, and option 26 for GTP-U.

RAT Type-based Statistics

The RAT Type-based Statistics feature equip users to view data statistics segregated by RAT Type in UPF.

RAT Type-based data statistics in UPF maintains separate buckets. These buckets are created at Session Manager instance level. Bucket is assigned to a subscriber at the time of call-setup, based on RAT Type IE received in “Subscriber-Parameters”. If the IE is not received, “Unknown” RAT Type bucket is assigned to that subscriber. During the session, if UPF receives a new RAT Type for a subscriber, the bucket is changed accordingly.



Important Data statistics are not checkpointed and lost during Session Recovery/ICSR. Only “Current-Subscriber” statistics are recalculated after recovery (during the time of call-audit).

Show Command and Output

The following CLI command displays node-level RAT statistics for UPF: **show user-plane-service statistics rat { 5g-nr | all | eutran | unknown | wlan }**

NOTES:

- **5g-nr**: Displays the data statistics for 5G NR subscribers.
- **all**: Displays the data statistics for all RAT Type subscribers.
- **eutran**: Displays the data statistics for EUTRAN subscribers.
- **unknown**: Displays the data statistics for subscribers of unknown RAT type.
- **wlan**: Displays the data statistics for WLAN subscribers.

Statistics

The following table provides description of each field.

Table 1: show user-plane-service statistics rat all

Field	Description
Current Subscribers	
5G NR	Specifies the total number of current 5G NR subscribers.
EUTRAN	Specifies the total number of current EUTRAN subscribers.
WLAN	Specifies the total number of current WLAN subscribers.

Field	Description
Unknown	Specifies the total number of current subscribers of unknown RAT type.
Data Statistics	
5G NR	Specifies the data statistics for 5G NR subscribers.
Uplink	Specifies data statistics for 5G NR subscribers in uplink direction.
Total Pkts	Specifies the total number of uplink packets for 5G NR subscribers.
Total Bytes	Specifies the total number of uplink bytes for 5G NR subscribers.
Total Dropped Pkts	Specifies the total number of uplink packets dropped for 5G NR subscribers.
Total Dropped Bytes	Specifies the total number of uplink bytes dropped for 5G NR subscribers.
Downlink	Specifies data statistics for 5G NR subscribers in downlink direction.
Total Pkts	Specifies the total number of downlink packets for 5G NR subscribers.
Total Bytes	Specifies the total number of downlink bytes for 5G NR subscribers.
Total Dropped Pkts	Specifies the total number of downlink packets dropped for 5G NR subscribers.
Total Dropped Bytes	Specifies the total number of downlink bytes dropped for 5G NR subscribers.
EUTRAN	Specifies the data statistics for EUTRAN subscribers.
Uplink	Specifies data statistics for EUTRAN subscribers in uplink direction.
Total Pkts	Specifies the total number of uplink packets for EUTRAN subscribers.
Total Bytes	Specifies the total number of uplink bytes for EUTRAN subscribers.
Total Dropped Pkts	Specifies the total number of uplink packets dropped for EUTRAN subscribers.
Total Dropped Bytes	Specifies the total number of uplink bytes dropped for EUTRAN subscribers.
Downlink	Specifies data statistics for EUTRAN subscribers in downlink direction.
Total Pkts	Specifies the total number of downlink packets for EUTRAN subscribers.
Total Bytes	Specifies the total number of downlink bytes for EUTRAN subscribers.
Total Dropped Pkts	Specifies the total number of downlink packets dropped for EUTRAN subscribers.
Total Dropped Bytes	Specifies the total number of downlink bytes dropped for EUTRAN subscribers.
WLAN	Specifies the data statistics for WLAN subscribers.

Field	Description
Uplink	Specifies data statistics for WLAN subscribers in uplink direction.
Total Pkts	Specifies the total number of uplink packets for WLAN subscribers.
Total Bytes	Specifies the total number of uplink bytes for WLAN subscribers.
Total Dropped Pkts	Specifies the total number of uplink packets dropped for WLAN subscribers.
Total Dropped Bytes	Specifies the total number of uplink bytes dropped for WLAN subscribers.
Downlink	Specifies data statistics for WLAN subscribers in downlink direction.
Total Pkts	Specifies the total number of downlink packets for WLAN subscribers.
Total Bytes	Specifies the total number of downlink bytes for WLAN subscribers.
Total Dropped Pkts	Specifies the total number of downlink packets dropped for WLAN subscribers.
Total Dropped Bytes	Specifies the total number of downlink bytes dropped for WLAN subscribers.
Unknown	Specifies the data statistics for subscribers of unknown RAT type.
Uplink	Specifies data statistics for unknown RAT type subscribers in uplink direction.
Total Pkts	Specifies the total number of uplink packets for unknown RAT type subscribers.
Total Bytes	Specifies the total number of uplink bytes for unknown RAT type subscribers.
Total Dropped Pkts	Specifies the total number of uplink packets dropped for unknown RAT type subscribers.
Total Dropped Bytes	Specifies the total number of uplink bytes dropped for unknown RAT type subscribers.
Downlink	Specifies data statistics for unknown RAT type subscribers in downlink direction.
Total Pkts	Specifies the total number of downlink packets for unknown RAT type subscribers.
Total Bytes	Specifies the total number of downlink bytes for unknown RAT type subscribers.
Total Dropped Pkts	Specifies the total number of downlink packets dropped for unknown RAT type subscribers.
Total Dropped Bytes	Specifies the total number of downlink bytes dropped for unknown RAT type subscribers.

Bulk Statistics

The following bulk statistics are included in the User Plane Service schema to track RAT Type-based data statistics events.

Table 2: show bulkstats variables user-plane-service

Variable Name	Data Type	Key	Counter Type
vpnname	String	1	Info
vpnid	Int32	1	Info
servname	String	1	Info
servid	Int32	1	Info
curr-pdn-rat-eutran	Int64	0	Gauge
curr-pdn-rat-5g-nr	Int64	0	Gauge
curr-pdn-rat-wlan	Int64	0	Gauge
curr-pdn-rat-unknown	Int64	0	Gauge
uplink-total-pkts-pdn-rat-eutran	Int64	0	Counter
uplink-total-bytes-pdn-rat-eutran	Int64	0	Counter
uplink-total-pkts-dropped-pdn-rat-eutran	Int64	0	Counter
uplink-total-bytes-dropped-pdn-rat-eutran	Int64	0	Counter
downlink-total-pkts-pdn-rat-eutran	Int64	0	Counter
downlink-total-bytes-pdn-rat-eutran	Int64	0	Counter
downlink-total-pkts-dropped-pdn-rat-eutran	Int64	0	Counter
downlink-total-bytes-dropped-pdn-rat-eutran	Int64	0	Counter
uplink-total-pkts-pdn-rat-5g-nr	Int64	0	Counter
uplink-total-bytes-pdn-rat-5g-nr	Int64	0	Counter
uplink-total-pkts-dropped-pdn-rat-5g-nr	Int64	0	Counter
uplink-total-bytes-dropped-pdn-rat-5g-nr	Int64	0	Counter
downlink-total-pkts-pdn-rat-5g-nr	Int64	0	Counter
downlink-total-bytes-pdn-rat-5g-nr	Int64	0	Counter
downlink-total-pkts-dropped-pdn-rat-5g-nr	Int64	0	Counter
downlink-total-bytes-dropped-pdn-rat-5g-nr	Int64	0	Counter

Variable Name	Data Type	Key	Counter Type
uplink-total-pkts-pdn-rat-wlan	Int64	0	Counter
uplink-total-bytes-pdn-rat-wlan	Int64	0	Counter
uplink-total-pkts-dropped-pdn-rat-wlan	Int64	0	Counter
uplink-total-bytes-dropped-pdn-rat-wlan	Int64	0	Counter
downlink-total-pkts-pdn-rat-wlan	Int64	0	Counter
downlink-total-bytes-pdn-rat-wlan	Int64	0	Counter
downlink-total-pkts-dropped-pdn-rat-wlan	Int64	0	Counter
downlink-total-bytes-dropped-pdn-rat-wlan	Int64	0	Counter
uplink-total-pkts-pdn-rat-unknown	Int64	0	Counter
uplink-total-bytes-pdn-rat-unknown	Int64	0	Counter
uplink-total-pkts-dropped-pdn-rat-unknown	Int64	0	Counter
uplink-total-bytes-dropped-pdn-rat-unknown	Int64	0	Counter
downlink-total-pkts-pdn-rat-unknown	Int64	0	Counter
downlink-total-bytes-pdn-rat-unknown	Int64	0	Counter
downlink-total-pkts-dropped-pdn-rat-unknown	Int64	0	Counter
downlink-total-bytes-dropped-pdn-rat-unknown	Int64	0	Counter

Subscriber Level CLI

Use the following subscriber level CLIs as required:

- **show subscribers user-plane-only full all**
- **show subscribers user-plane-only full msid** *msid_value*
- **show subscribers user-plane-only { seid** *seid_value* **| callid** *callid_value* **} pdr all**
- **show subscribers user-plane-only { seid** *seid_value* **| callid** *callid_value* **} far all**
- **show subscribers user-plane-only { seid** *seid_value* **| callid** *callid_value* **} qer all**
- **show subscribers user-plane-only { seid** *seid_value* **| callid** *callid_value* **} urr all**
- **show subscribers user-plane-only { seid** *seid_value* **| callid** *callid_value* **} bar all**
- **show subscribers user-plane-only { seid** *seid_value* **| callid** *callid_value* **} pdr full all**
- **show subscribers user-plane-only { seid** *seid_value* **| callid** *callid_value* **} urr full all**

- **show subscribers user-plane-only { seid** *seid_value* **| callid** *callid_value* **} far full all**
- **show subscribers user-plane-only { seid** *seid_value* **| callid** *callid_value* **} qer full all**
- **show subscribers user-plane-only { seid** *seid_value* **| callid** *callid_value* **} bar full all**
- **show subscribers user-plane-only { seid** *seid_value* **| callid** *callid_value* **} pdr id** *id_value*
- **show subscribers user-plane-only { seid** *seid_value* **| callid** *callid_value* **} flows full**
- **show subscribers user-plane-only { seid** *seid_value* **| callid** *callid_value* **} bli full all**

show subscribers user-plane-only full msid *msid_value*

The **show subscribers user-plane-only full msid** *msid_value* command displays the specific user information at instance-level and session-level for data collection during troubleshooting.

The following is a sample output of this command:

```
show subscribers user-plane-only full msid 404005123456789

  Local SEID      : [0x0004000000000000] 1125899906842624
  Remote SEID     : [0x0004000000000007] 1125899906842631
State           : Connected
  Connect Time    : Thu Sep 15 20:40:09 2022
  Idle time       : 00h11m25s
  Access Type: uplane-ipv4               Network Type: IP
  user-plane-service-name: UP21
  active-service-scheme-name:
  Callid: 00004e21
  Rulebase: cisco
  Interface Type: Sxb
  eMPS Session: No
  eMPS Session Priority: 0
  Card/Cpu: 1/0                          Sessmgr Instance: 1
  IP address: 11.11.12.0
  Next Hop Ip Address:
  Source context: EPC2-UP                Destination context: ISP1-UP
  PDN-Instance: starent.com
  User-plane-Sx-addr: 20.20.20.106
  Control-plane-Sx-addr: 20.20.20.101
  Number of associated PDRs : 0
  Number of associated ADC PDRs : 0
  Number of associated FARs : 0
  Number of associated QERs : 1
  Number of associated BARs : 0
  Number of associated URRs : 0
  Uplink APN AMBR (bps) : 200000       Downlink APN AMBR (bps) : 200000
  active input acl: IPV4ACL            active output acl: IPV4ACL
  active input ipv6 acl: n/a             active output ipv6 acl: n/a
  Bandwidth Policy: bw_policy1
  FW-and-NAT Policy: n/a
  FW-and-NAT Policy ID: n/a
  Firewall Policy IPv4: n/a
  Firewall Policy IPv6: n/a
  NAT Policy NAT44: n/a
  NAT Policy NAT64: n/a
  Converged Session: No                 Converged Peer Callid:      n/a
  Visited Call: No
  Subscriber Parameters:
  IMSI: 404005123456789
  IMEI: 112233445566778
```

```
  MSISDN: 9890098900
  Charging Characteristics: 0x3412
  Rat Type: 6
  MCC MNC: 123765
  SGSN Address: 20.20.20.61
  ULI: TAI=12546312ab00
  Congestion Level: 0
  GGSN Address: 20.20.20.101
  User-Name: 9890098900@starent.com
  Session-ID: 1414146500000008
  input pkts: 0                                  output pkts: 0
  input bytes: 0                                 output bytes: 0
  input bytes dropped: 0                         output bytes dropped: 0
  input pkts dropped: 0                          output pkts dropped: 0
  CF Buffered Uplink Packets: 0                  CF Buffered Downlink Packets: 0

  CF Buffered Uplink Bytes: 0                    CF Buffered Downlink Bytes: 0
  Uplink Packets in Buffer: 0                    Downlink Packets in Buffer: 0
  Buff Over-limit Uplink Pkts: 0                 Buff Over-limit Downlink Pkts: 0

  DDN buffered pkts : 0                          DDN buffered bytes : 0
  DDN buffer overflow drop pkts : 0              DDN buffer overflow drop bytes : 0

  pk rate from user(bps): 0                      pk rate to user(bps): 0
  ave rate from user(bps): 0                     ave rate to user(bps): 0
  sust rate from user(bps): 0                    sust rate to user(bps): 0
  pk rate from user(pps): 0                      pk rate to user(pps): 0
  ave rate from user(pps): 0                     ave rate to user(pps): 0
  sust rate from user(pps): 0                    sust rate to user(pps): 0
  ipv4 bad hdr: 0                                ipv4 ttl exceeded: 0
ipv4 fragments sent: 0                         ipv4 could not fragment: 0
  ipv4 bad length trim: 0
  input pkts dropped (0 mbr): 0                  output pkts dropped (0 mbr): 0
  ipv4 input acl drop: 0                         ipv4 output acl drop: 0
  ipv6 input acl drop: 0                         ipv6 output acl drop: 0
  ip source violations: 0                        ipv4 output no-flow drop: 0
  ipv6 bad hdr: 0                                ipv6 bad length trim: 0
  ipv4 icmp packets dropped: 0
  APN AMBR Uplink Pkts Drop: 0                    APN AMBR Downlink Pkts Drop: 0
  APN AMBR Uplink Bytes Drop: 0                   APN AMBR Downlink Bytes Drop: 0

  APN AMBR Uplink Pkts IP pref lowered: 0         APN AMBR Downlink Pkts IP pref lowered:
 0
  APN AMBR Uplink Bytes IP pref lowered: 0        APN AMBR Downlink Bytes IP pref lowered:
 0
  ITC Uplink Pkts Drop: 0                         ITC Downlink Pkts Drop: 0
  ITC Uplink Bytes Drop: 0                        ITC Downlink Bytes Drop: 0
  ITC Uplink Pkts IP pref lowered: 0              ITC Downlink Pkts IP pref lowered: 0

  ITC Uplink Bytes IP pref lowered: 0             ITC Downlink Bytes IP pref lowered: 0

  ITC Terminated Flows:: 0                        ITC Redirected Flows: 0
  Flow Action Terminated Flows: 0                 Flow Action Redirected Flows: 0

  ToS marked Uplink Pkts: 0                       ToS marked Downlink Pkts: 0
  CC Dropped Uplink Pkts: 0                       CC Dropped Downlink Pkts: 0
  CC Dropped Uplink bytes: 0                      CC Dropped Downlink Bytes: 0
  Uplink Inflight Pkts: 0                         Downlink Inflight Pkts: 0
  QFI Mismatch Uplink Pkts Drop: 0                QFI Mismatch Downlink Pkts Drop: 0

  Total QoS-Group(s) Active: 0
  DNS-to-EDNS Uplink Pkts: 0                     DNS-to-EDNS Uplink Bytes: 0
  EDNS Response Received: 0
```

```
  Flow information:
    Current Active Flows:
      TCP: 0
      UDP: 0
    Total Flows:
      TCP: 0
      UDP: 0
      FP:  0

Static & Predef Rule Match stats:
Rule Name            Pkts-Down  Bytes-Down Pkts-Up    Bytes-Up   Hits       Match-Bypassed
  FP-Down(Pkts/Bytes)  FP-Up(Pkts/Bytes)
-------------------- ---------- ---------- ---------- ---------- ---------- --------------
  -------------------  -----------------

Dynamic Rule Match stats:
PDR Id   Rule Name            Pkts-Down  Bytes-Down Pkts-Up    Bytes-Up   Hits
Match-Bypassed  FP-Down(Pkts/Bytes)  FP-Up(Pkts/Bytes)
-------- -------------------- ---------- ---------- ---------- ---------- ----------
--------------  -------------------  -----------------

Post-Processing Rule Match stats:
Rule Name            Pkts-Down  Bytes-Down Pkts-Up    Bytes-Up   Hits       Match-Bypassed
  FP-Down(Pkts/Bytes)  FP-Up(Pkts/Bytes)
-------------------- ---------- ---------- ---------- ---------- ---------- --------------
  -------------------  -----------------

Firewall-NAT Access Rule Match stats:
Firewall-Ruledef Name Pkts-Down Bytes-Down    Pkts-Up   Bytes-Up Dr-Pkts-Dn Dr-Byts-Dn
Dr-Pkts-Up Dr-Byts-Up       Hits
-------------------- ---------- ---------- ---------- ---------- ---------- ----------
---------- ---------- ----------

QoS-Group Statistics:
QGR Name             Pkts-Down  Bytes-Down Pkts-Up    Bytes-Up   Hits       Match-Bypassed
  FP-Down(Pkts/Bytes)  FP-Up(Pkts/Bytes)
-------------------- ---------- ---------- ---------- ---------- ---------- --------------
  -------------------  -----------------

  CIoT APN Rate Control:
    Allowed UL Limit:   0                       Allowed DL limit:    0
    Remaining UL Limit: 0                       Remaining DL limit:  0
    Allowed Time unit: unrestricted             Status Validity Time: N/A

  Local SEID      : [0x0004000000000002] 1125899906842626
  Remote SEID     : [0x0004000000000009] 1125899906842633
  State           : Connected
  Connect Time    : Thu Sep 15 20:51:03 2022
Idle time       : 00h00m31s
  Access Type: uplane-ipv4              Network Type: IP
  user-plane-service-name: UP21
  active-service-scheme-name:
  Callid: 00004e23
  Rulebase: cisco
  Interface Type: Sxb
  eMPS Session: No
  eMPS Session Priority: 0
  Card/Cpu: 1/0                         Sessmgr Instance: 1
  IP address: 11.11.12.1
  Next Hop Ip Address:
  Source context: EPC2-UP               Destination context: ISP1-UP
  PDN-Instance: starent.com
  User-plane-Sx-addr: 20.20.20.106
  Control-plane-Sx-addr: 20.20.20.101
```

```
 Number of associated PDRs : 0
 Number of associated ADC PDRs : 0
 Number of associated FARs : 0
 Number of associated QERs : 1
 Number of associated BARs : 0
 Number of associated URRs : 0
 Uplink APN AMBR (bps) : 200000       Downlink APN AMBR (bps) : 200000
 active input acl: IPV4ACL            active output acl: IPV4ACL
 active input ipv6 acl: n/a             active output ipv6 acl: n/a
 Bandwidth Policy: bw_policy1
 FW-and-NAT Policy: n/a
 FW-and-NAT Policy ID: n/a
 Firewall Policy IPv4: n/a
 Firewall Policy IPv6: n/a
 NAT Policy NAT44: n/a
 NAT Policy NAT64: n/a
 Converged Session: No                 Converged Peer Callid:      n/a
 Visited Call: No
 Subscriber Parameters:
 IMSI: 404005123456789
 IMEI: 112233445566778
 MSISDN: 9890098900
 Charging Characteristics: 0x3412
 Rat Type: 6
 MCC MNC: 123765
 SGSN Address: 20.20.20.61
 ULI: TAI=12546312ab00
 Congestion Level: 0
 GGSN Address: 20.20.20.101
 User-Name: 9890098900@starent.com
 Session-ID: 141414650000000A
 input pkts: 0                                 output pkts: 0
 input bytes: 0                                output bytes: 0
 input bytes dropped: 0                        output bytes dropped: 0
 input pkts dropped: 0                         output pkts dropped: 0
 CF Buffered Uplink Packets: 0                 CF Buffered Downlink Packets: 0

 CF Buffered Uplink Bytes: 0                   CF Buffered Downlink Bytes: 0
 Uplink Packets in Buffer: 0                   Downlink Packets in Buffer: 0
 Buff Over-limit Uplink Pkts: 0                Buff Over-limit Downlink Pkts: 0

 DDN buffered pkts : 0                         DDN buffered bytes : 0
 DDN buffer overflow drop pkts : 0             DDN buffer overflow drop bytes : 0

 pk rate from user(bps): 0                     pk rate to user(bps): 0
 ave rate from user(bps): 0                    ave rate to user(bps): 0
 sust rate from user(bps): 0                   sust rate to user(bps): 0
 pk rate from user(pps): 0                     pk rate to user(pps): 0
 ave rate from user(pps): 0                    ave rate to user(pps): 0
 sust rate from user(pps): 0                   sust rate to user(pps): 0
 ipv4 bad hdr: 0                               ipv4 ttl exceeded: 0
 ipv4 fragments sent: 0                        ipv4 could not fragment: 0
 ipv4 bad length trim: 0
 input pkts dropped (0 mbr): 0                 output pkts dropped (0 mbr): 0
 ipv4 input acl drop: 0                        ipv4 output acl drop: 0
 ipv6 input acl drop: 0                        ipv6 output acl drop: 0
 ip source violations: 0                       ipv4 output no-flow drop: 0
 ipv6 bad hdr: 0                               ipv6 bad length trim: 0
 ipv4 icmp packets dropped: 0
 APN AMBR Uplink Pkts Drop: 0                   APN AMBR Downlink Pkts Drop: 0
 APN AMBR Uplink Bytes Drop: 0                  APN AMBR Downlink Bytes Drop: 0

 APN AMBR Uplink Pkts IP pref lowered: 0          APN AMBR Downlink Pkts IP pref lowered:
0
```

```
  APN AMBR Uplink Bytes IP pref lowered: 0         APN AMBR Downlink Bytes IP pref lowered:
0
  ITC Uplink Pkts Drop: 0                           ITC Downlink Pkts Drop: 0
  ITC Uplink Bytes Drop: 0                          ITC Downlink Bytes Drop: 0
  ITC Uplink Pkts IP pref lowered: 0                ITC Downlink Pkts IP pref lowered: 0

  ITC Uplink Bytes IP pref lowered: 0               ITC Downlink Bytes IP pref lowered: 0

  ITC Terminated Flows:: 0                          ITC Redirected Flows: 0
  Flow Action Terminated Flows: 0                   Flow Action Redirected Flows: 0

  ToS marked Uplink Pkts: 0                         ToS marked Downlink Pkts: 0
  CC Dropped Uplink Pkts: 0                         CC Dropped Downlink Pkts: 0
  CC Dropped Uplink bytes: 0                        CC Dropped Downlink Bytes: 0
  Uplink Inflight Pkts: 0                           Downlink Inflight Pkts: 0
  QFI Mismatch Uplink Pkts Drop: 0                  QFI Mismatch Downlink Pkts Drop: 0

  Total QoS-Group(s) Active: 0
  DNS-to-EDNS Uplink Pkts: 0                      DNS-to-EDNS Uplink Bytes: 0
  EDNS Response Received: 0

  Flow information:
    Current Active Flows:
      TCP: 0
      UDP: 0
    Total Flows:
      TCP: 0
      UDP: 0
      FP:  0

Static & Predef Rule Match stats:
Rule Name            Pkts-Down  Bytes-Down Pkts-Up    Bytes-Up   Hits       Match-Bypassed
  FP-Down(Pkts/Bytes)  FP-Up(Pkts/Bytes)
-------------------- ---------- ---------- ---------- ---------- ---------- --------------
  -------------------  ------------------

Dynamic Rule Match stats:
PDR Id   Rule Name            Pkts-Down  Bytes-Down Pkts-Up    Bytes-Up   Hits
Match-Bypassed  FP-Down(Pkts/Bytes)  FP-Up(Pkts/Bytes)
-------- -------------------- ---------- ---------- ---------- ---------- ----------
--------------  -------------------  ------------------

Post-Processing Rule Match stats:
Rule Name            Pkts-Down  Bytes-Down Pkts-Up    Bytes-Up   Hits       Match-Bypassed
  FP-Down(Pkts/Bytes)  FP-Up(Pkts/Bytes)
-------------------- ---------- ---------- ---------- ---------- ---------- --------------
  -------------------  ------------------

Firewall-NAT Access Rule Match stats:
Firewall-Ruledef Name Pkts-Down Bytes-Down    Pkts-Up   Bytes-Up Dr-Pkts-Dn Dr-Byts-Dn
Dr-Pkts-Up Dr-Byts-Up       Hits
-------------------- ---------- ---------- ---------- ---------- ---------- ----------
---------- ---------- ----------

QoS-Group Statistics:
QGR Name             Pkts-Down  Bytes-Down Pkts-Up    Bytes-Up   Hits       Match-Bypassed
  FP-Down(Pkts/Bytes)  FP-Up(Pkts/Bytes)
-------------------- ---------- ---------- ---------- ---------- ---------- --------------
  -------------------  ------------------

  CIoT APN Rate Control:
    Allowed UL Limit:   0                         Allowed DL limit:    0
    Remaining UL Limit: 0                         Remaining DL limit:  0
    Allowed Time unit: unrestricted               Status Validity Time: N/A
```

```
Total subscribers matching specified criteria: 1
```

show subscribers user-plane-only callid *callid-value* rule-match-info { [full] all | rulename *rulename*}

Table 3: Feature History

Feature Name	Release Information	Description
Identify URR Associated With Matching Rule Using a Single Command	2025.01.0	This release introduces a consolidated command for UP to provide a comprehensive overview of per subscriber details, including: • Matched rules and their associated charging actions • The associated URR-ID This enhancement eliminates the need to use multiple commands across the UP or UP and CP to extract and correlate this information per subscriber. **Command Introduced**: **show subscribers user-plane-only callid** *callid* **rule-match-info { [full] all | rulename** *rulename* **}**. **Default Setting**: Enabled by default.

The **show subscribers user-plane-only callid** *callid* **rule-match-info { [full] all | rulename** *rulename* **}** command displays rules that are matched and their associated charging-actions and the associated URR-ID.

Note

- This command displays static, predefined, and dynamic rule matching statistics. It does not display postprocessing, firewall, or any other ruledefs.
- URR-ID corresponding information threshold, and quota needs to be obtained using the **show subscribers user-plane-only callid urr** *urr-ID* command.
- The URR-IDs that are displayed in the command may not be currently present in the output of the **show subscribers user-plane-only callid** *callid* **urr full all**. However, the URR-IDs are populated eventually.
- Executing this command with the **rulename** filter can be CPU intensive.
- Post recovery, when the packet count is lost, the rule-match stats are not recovered but the URR details are recovered.

The following example shows a sample output of the **show subscribers user-plane-only callid 00004e22 rule-match-info full all** command.

```
[local]host_name# show subscribers user-plane-only callid 00004e22 rule-match-info full all

STATIC & PREDEF RULE MATCH INFORMATION:

        RULEDEF NAME: catchall
        Charging-Action name: catchall

        Pkts-Down  Bytes-Down Pkts-Up    Bytes-Up   Hits       Match-Bypassed
FP-Down(Pkts/Bytes)  FP-Up(Pkts/Bytes)
        ---------- ---------- ---------- ---------- ---------- --------------
-------------------  ------------------
                 1         40          2         80          5              0          0/0
              0/0

        RULEDEF NAME: httpAnyMatch
        Charging-Action name: catchall

        Pkts-Down  Bytes-Down Pkts-Up    Bytes-Up   Hits       Match-Bypassed
FP-Down(Pkts/Bytes)  FP-Up(Pkts/Bytes)
        ---------- ---------- ---------- ---------- ---------- --------------
-------------------  ------------------
                 2        716          3        205          5              0          0/0
              0/0


        URR-id: 0x80000131

         URR-id: 0x80000137

DYNAMIC RULE MATCH INFORMATION:

        RULEDEF NAME: dynamic5

        PDR Id   Pkts-Down  Bytes-Down Pkts-Up    Bytes-Up   Hits       Match-Bypassed
FP-Down(Pkts/Bytes)  FP-Up(Pkts/Bytes)
        -------- --------   ---------- ---------- ---------- -------    ----------
--------------       -------------------
        0x0003            0          0          5        285          6              0
      0/0              0/0
        0x0004            3        756          0          0          4              0
```

```
0/0              0/0

  Outer header removal:   GTP-U/UDP/IPv4
  Application ID:         N/A
  Associated FARID:       0x0003
   Destination Interface: Core
   Apply Action:          FORWARD
   Outer Header Creation:
   Remote TEID:           0x0
    Transport Level Marking:         N/A
    Transport Level Marking Options:
      Copy Inner:                    No
      Copy Outer:                    No
    Inner Packet Marking:            N/A

  Outer header removal:
  Application ID:         N/A
  Associated FARID:       0x0004
   Destination Interface: Access
   Apply Action:          FORWARD
   Outer Header Creation: GTP-U/UDP/IPv4
   Remote TEID:           0x60010f20
    Transport Level Marking:         N/A
    Transport Level Marking Options:
      Copy Inner:                    No
      Copy Outer:                    No
    Inner Packet Marking:            N/A

  URR-id: 0x00000007

Total subscribers matching specified criteria: 1
```

VPP Statistics

To determine if the flows are offloaded to VPP, check for Fastpath statistics in the output of the following CLI commands:

- **show user-plane-service statistics all**
- **show user-plane-service statistics analyzer name ip [verbose]**
- **show user-plane-service statistics analyzer name ipv6 [verbose]**
- **show user-plane-service statistics analyzer name tcp [verbose]**
- **show user-plane-service statistics analyzer name udp [verbose]**
- **show user-plane-service statistics analyzer name http [verbose]**
- **show user-plane-service statistics analyzer name rtp [verbose]**
- **show user-plane-service statistics analyzer name ftp [verbose]**

```
show user-plane-service statistics analyzer name ftp verbose

Wednesday July 02 17:47:13 IST 2025
   FTP Session Stats:
      Current Control Sessions:         0         Current Data Sessions:         0
      Total Control Sessions:           0         Total Data Sessions:           1
      Uplink Control Bytes:             0         Downlink Control Bytes:        0
      Uplink Control Pkts:              0         Downlink Control Pkts:         0
```

```
Uplink Data Bytes:                219          Downlink Data Bytes:          3249
Uplink Data Pkts:                   6          Downlink Data Pkts:              9
Uplink Error Bytes:                 0          Downlink Error Bytes:            0
Uplink Error Pkts:                  0          Downlink Error Pkts:             0
Request Succeed:                    0          Request Failed:                  0
Unknown Requests:                   0          Unknown Responses:               0
Uplink Bytes Retrans:               0          Downlink Bytes Retrans:          0
Uplink Pkts Retrans:                0          Downlink Pkts Retrans:           0
RETR commands:                      0          STOR commands:                   0
Unknown packets received:                                                       0
Data packet received without control connection:                               11
Invalid packets:                                                                0
Packets that could not be parsed:
```

- **show subscribers user-plane-only full callid** *call_id*
- **show subscribers user-plane-only callid** *callid_value* **drop-statistics**
- **show user-plane-service statistics drop-counter**
- **show subscribers user-plane-only callid** *callid_value* **flows full**
- **show subscribers user-plane-only callid** *callid_value* **flows flow-id** *flow_id*

show subscribers user-plane-only callid *callid_value* drop-statistics

The **show subscribers user-plane-only callid** *callid_value* **drop-statistics** command displays the packet drop statistics with the respective cause (drop reason) at instance-level and session-level.

The following is a sample output of this command:

```
[local]UPF1# show subscribers user-plane-only callid 00004e21 drop-statistics

         Callid: 00004e21
         Interface Type: <interface-type>

         Packet Drop Data Statistics:
         ----------------------------------------------------
         NAT packets processing failure
            NAT on demand handling:                  0
            ICMP Packet translation:                 0
         FIREWALL packets processing failure
            Policy not found:                        0
         No Matching GX rule found:                  0
         Flow apply action
            Discard:                                 0
            Readdress Failure:                       0
            Packet exceeds the MTU size:                 0
       Failure in processing FAR Buffer packets:     0
       FAR Apply Action Drop:                        0
       Traffic Steering Failure:                     0
       QER Gate Status Closed:                       0
       Content-filtering Discard Action:             0
       IP Header Validation Failed:                  0
       ADF level failure
           DL TFT mismatch:                          0
       URL Blacklisting Discard Action:              0
       QGR Flow Action SGQ Discard:                  0
       QGR Policer Drops:                            0

Total subscribers matching specified criteria: 1
[local]UPF1#
```

show user-plane-service statistics drop-counter

The **show user-plane-service statistics drop-counter** command displays the packet drop statistics with the respective cause (drop reason) at instance-level and session-level.

The following is a sample output of this command:

```
[local]UPF1# show user-plane-service statistics drop-counter

        Packet Drop Data Statistics:
        ----------------------------------------------------
        NAT packets processing failure
           NAT on demand handling:                      0
           IP allocation is in progress:                0
           ICMP Packet translation:                     0
        FIREWALL packets processing failure
           Policy not found:                            0
        No Matching GX rule found:                      0
        Flow apply action
           Discard:                                     0
           Readdress Failure:                           0
           Redirect-URL:                                0
        Packet exceeds the MTU size:                    0
        Failure in processing FAR Buffer packets:       0
        FAR Apply Action Drop:                          0
        Traffic Steering Failure:                       0
        QER Gate Status Closed:                         0
        Content-filtering Discard Action:               0
        IP Header Validation Failed:                    0
        ADF level failure
          UL TEID/QFI key mismatch:                     0
          DL TFT mismatch:                              0
          DL QFI mismatch:                              0
        URL Blacklisting Discard Action:                0
        DDN buffer overflow drop packets:               0
        APN AMBR Packets Drop:                          0
        ITC Packets Drop:                               0
        ACL Drop:                                       0
        CC Dropped Packets:                             0
        FastPath Misc Drops
            Overload Protection:                        0
            Invalid Client:                             0
            Stream ID 0:                                0
            Invalid Stream ID:                          0
```

NOTES:

- For the **show user-plane-service statistics drop-counter** CLI command, the counters for the number of packets dropped due to various reasons are not recovered post sessmgr recovery or ICSR (Inter-Chassis Session Recovery).
- For the **show subscribers user-plane-only callid** *callid_value* **drop-statistics** CLI command, the counters for the number of packets dropped due to various reasons are recovered post sessmgr recovery or ICSR.
- The commands do not duplicate the counters that are captured at the session-level and instance-level.
- The packets dropped due to "Quota Exhaust FAR Apply Action Drop" are accumulated under "CC Dropped Packets" and not under the "FAR Apply Action Drop" counter.
- The packets dropped under "Failure in processing FAR buffered packets" can be due to "no rule match", "teid not found", or other reasons. The respective counter are incremented for such packets.

- The packets dropped due to the "redirect-url" flow action are accumulated under "Redirect-URL" in the **show user-plane-service statistics drop-counter** CLI command.

show subscribers user-plane-only callid *callid_value* flows full

The **show subscribers user-plane-only callid** *callid_value* **flows full** command displays the detailed information at the flow level which are required for debugging purposes.

The following is a sample output of this command:

```
[local]GVK-HUPF# show subscribers user-plane-only callid 017dc662 flows full
Tuesday November 22 18:35:35 UTC 2022

Callid: 017dc662
Interface Type: N4
IP address: n/a

Flow ID: 6:2
Uplink pkts: 0 Downlink pkts: 1
Uplink bytes: 0 Downlink bytes: 1040
Fast Path Info:
Uplink pkts: 0 Downlink pkts: 0
Uplink bytes: 0 Downlink bytes: 0
Total pkts: 0
Uplink Dropped pkts: 0 Downlink Dropped pkts: 4
Uplink Stream ID: 0x0 Downlink Stream ID: 0x1000007
Uplink Stream State: n/a Downlink Stream State: Passive
Client-ID : C6
UE IP address: 12.1.0.3 UE Port: 1001
Server IP address: 100.100.100.10 Server Port: 1001
Protocol: TCP
Service Chain Name: NA
Uplink Sfp Id: NA
Downlink Sfp Id: NA

Flow ID: 6:3
Uplink pkts: 5 Downlink pkts: 2
Uplink bytes: 200 Downlink bytes: 2080
Fast Path Info:
Uplink pkts: 0 Downlink pkts: 3
Uplink bytes: 0 Downlink bytes: 3120
Total pkts: 3
Uplink Dropped pkts: 0 Downlink Dropped pkts: 0
Uplink Stream ID: 0x0 Downlink Stream ID: 0x2000008
Uplink Stream State: n/a Downlink Stream State: Active
Client-ID : C6
UE IP address: 12.1.0.3 UE Port: 1000
Server IP address: 100.100.100.10 Server Port: 1000
Protocol: TCP
Service Chain Name: NA
Uplink Sfp Id: NA
Downlink Sfp Id: NA

Total Number of Active flows : 2
```

show subscribers user-plane-only callid *callid_value* flows flow-id *flow_id*

The **show subscribers user-plane-only callid** *callid_value* **flows flow-id** *flow_id* command displays the detailed information at the flow level which are required for debugging purposes.

The following is a sample output of this command:

```
# show sub user-plane-only callid 00004e22 flows flow-id 1:4

  Callid: 00004e22
  Interface Type: Sxb
  IP address: n/a

  Flow ID: 1:4
  Uplink pkts: 17                                  Downlink pkts: 0
  Uplink bytes: 1026                               Downlink bytes: 0
  Fast Path Info:
   Uplink pkts: 0                                  Downlink pkts: 0
   Uplink bytes: 0                                 Downlink bytes: 0
   Total pkts: 0
   Uplink Dropped pkts: 0                          Downlink Dropped pkts: 0
   Uplink Stream ID: 0x0000008                     Downlink Stream ID: 0x0
   Uplink Stream State: Passive                    Downlink Stream State: n/a
   Client-ID : C2
  UE IP address: 12.2.0.13                         UE Port: 1007
  Server IP address: 100.100.100.10                Server Port: 1005
  Protocol: TCP
  Service Chain Name: NA
  Uplink Sfp Id: NA
  Downlink Sfp Id: NA

Total Number of Active flows : 1
```

SNMP Support

The system uses the Simple Network Management Protocol (SNMP) to send traps or events to the EMS server or an alarm server on the network. You must configure SNMP settings to communicate with those devices.

The *SNMP MIB Reference* describes the MIBs and SNMP traps that are supported by UPF and StarOS.

The following SNMP traps are available in support of their respective feature or functionality:

N4 Session/Node Level Reporting Procedure

The following traps are available to track status and conditions GTP-U path failure:

- EGTPUPathFailure: This trap is generated when no response is received for GTP-U ECHO requests and data path failure is detected toward peer EPC Node.
- EGTPUPathFailureClear: This trap is generated when the data path toward the peer node is available.

UP Session Recovery

The following traps are available after session recovery in the User Plane node:

- ManagerFailure: This trap is generated when there is failure in the Software manager.
- TaskFailed: This trap is generated when a noncritical task has failed and the appropriate recovery steps begin.
- TaskRestart: This trap is generated when a noncritical task has restarted after an earlier failure.
- SessMgrRecoveryComplete: This trap is generated when Session Manager recovery completes. This is typically caused by the failure of Session Manager task and successful completion of recovery.
- ManagerRestart: This trap is generated when the identified manager task has been restarted.

Sx Association

The following traps are available to track the status of an Sx Association:

- SxPeerAssociated: This trap is triggered when an Sx association is detected.
- SxPeerAssociationRelease: This trap is triggered when an Sx association release is detected.

URL Blockedlisting

The following SNMP trap are available in support of URL Blockedlisting feature:

- BLDBError: Specifies the blockedlisting OPTBLDB file error that is displayed with an error code.
- BLDBErrorClear: Specifies the blockedlisting OPTBLDB file error removed.
- BLDBUpgradeError: Specifies the blockedlisting OPTBLDB file error displayed with an error code.
- BLDBUpgradeErrorClear: Specifies the blockedlisting OPTBLDB file error removed.

Enabling SNMP Traps

Use the following configuration to enable an SNMP trap.

```
configure
   snmp trap enable trap_name
   end
```

For supplemental information about SNMP Support, see *Management Settings* chapter in the *ASR 5500 System Administration Guide*.

Troubleshooting UPF Features

N4 or Datapath

The following CLI commands are available for troubleshooting N4 or datapath related issues:

- **show gtpu statistics**
- **show user-plane-service { all | bandwidth-policy | charging-action | edr-format | group-of-ruledefs | gtpp-group | name | pdn-instance | rulebase | ruledef | statistics | xheader-format }**

  NOTES:

  - **all**: Displays all User Plane services.
  - **bandwidth-policy**: Displays information for bandwidth-policy in User Plane service.
  - **charging-action**: Displays information for Charging actions in User Plane service.
  - **edr-format**: Displays information for EDR format in user Plane service.
  - **group-of-ruledefs**: Displays information on Group of Ruledefs configured in User Plane service.
  - **gtpp-group**: Displays information for bandwidth policy in User Plane service.
  - **name**: Displays information for specific User Plane service name.

- **pdn-instance**: Displays information for PDN instance.
- **rulebase**: Displays information for rulebase in User Plane service.
- **ruledef**: Displays information for ruledef in User Plane service.
- **statistics**: Displays node-level statistics for User Plane.

  Additionally, you can also use: **show user-plane-service statistics { all | analyzer | charging-action | fapi | rulebase | tethering-detection }**
- **xheader-format**: Displays information for X-Header format in User Plane service.

- **show user-plane-service content-filtering category policy-id (all | id** *id_value* **}**
  - **content-filtering**: Displays content filtering information.
  - **category**: Displays content filtering category information.
  - **policy-id**: Displays content filtering category Policy-ID and its definition.
  - **all**: Displays definitions of all content filtering category policies.
  - **id** *id_value*: Displays content filtering category definition of a particular Policy-ID. *id_value* is an integer ranging from 1 through 4,294,967,295.

- **show sx-service { all | name | statistics }**

  NOTES:
  - **all**: Displays all Sx Services.
  - **name**: Displays information for specific Sx Service name.
  - **statistics**: Displays the total of collected information for specific protocol since last restart or clear command.

Content Filtering

Use the following CLI command for troubleshooting CF related issues:

In releases prior to 2022.01.0:

```
show user-plane-service inline-services { content-filtering | info |
url-blacklisting }
```

From 2022.01.0 and later releases:

```
show user-plane-service inline-services { content-filtering | info |
url-blockedlisting }
```

NOTES:

- **content-filtering**: Displays content filtering information.
- **info**: Displays information of inline services.
- **url-blockedlisting**: Displays URL Blockedlisting parameters in User Plane service.

URL Blacklisting

Use the following CLI command for troubleshooting URL Blacklisting related issues: **show user-plane-service url-blacklisting database { all | debug-only | facility | url }**

NOTES:

- **all**: Displays all URL Blacklisting database configurations.
- **debug-only**: Displays the URL Blacklisting static database debug information.
- **facility**: Displays URL Blacklisting database configuration per facility.
- **url**: Displays particular database information for URL Blacklisting.

Configure Stats Profile for QCI Drop Statistics

Feature name	Release	Feature description
Per-QCI Packet Drop Counters	2026.03.0	Added support for per-APN, per-QCI packet drop statistics in UPF. The feature introduces configurable stats profiles, enhanced show commands, and reporting of packet drops across 19 consolidated drop categories, enabling improved visibility and troubleshooting of traffic-specific packet loss, including VoLTE and other QoS-sensitive services.

Enable granular tracking and reporting of packet drop counters segmented by QCI value and specific drop reasons.

Note One statistics profile can be associated across muliple APNs.

Follow these steps to configure per-QCI drop statistics:

Procedure

Step 1 Create a statistics profile:

```
Copy Code
configure
  stats-profile <profile_name>
    qci [ all | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | non-std { gbr | non-gbr } ] arp <value>
  end
```

Step 2 Ensure the procedure reflects that you are associating the profile with the APN.

```
bash
Copy Code
configure
  context <ctx_name>
    apn <apn_name>
      stats-profile <profile_name>
    end
```

NSO configuration considerations

When configuring Per-APN Per-QCI Drop Statistics through NSO using the UPF NED, the `arp` parameter in the `stats-profile` configuration is not supported on the UPF. As a result, the UPF returns the following warning:

```
Warning: ARP filtering is not supported on UPF.
ARP values will be ignored and the entry will be tracked per-QCI only.
```

By default, the NSO UPF NED treats this warning as a configuration failure and aborts the commit operation. To commit the configuration successfully, configure the warning as an accepted configuration warning in the StarOS NED. Use the following command:

```
devices global-settings ned-settings cisco-staros behaviour \
config-warning-ignore \
"Warning: ARP filtering is not supported on UPF. ARP values will be ignored and the entry
will be tracked per-QCI only"
```

After configuring the warning as an accepted configuration warning, the Per-APN Per-QCI Drop Statistics configuration can be committed successfully through NSO.

Note The `arp` parameter is ignored on the UPF, and packet drop statistics are maintained on a per-QCI basis only.

Per-QCI Drop statistics commands

Use the following command to display the granular distribution of packet drop counters per QCI.

```
show user-plane-service stats-profile name <name>
```

Example output

The following example displays per-QCI packet drop statistics for the statistics profile:

```
show user-plane-service stats-profile name qci_selfprot_5g_prof
```

```
 ------------------------------------------------------------------------------
 QCI 5   (Non-GBR / IMS Signaling)      [Profile-enabled]
   Packet Drop Reason                                Uplink      Downlink
   ---------------------------------------- ------------- -------------
   Self Protection                                      1             1
   Others                                               1             1
   ---------------------------------------- ------------- -------------
   Total                                                2             2
 ------------------------------------------------------------------------------
```

Display Configured Statistics Profiles

Use the following command to display all configured statistics profiles.

```
show stats-profile all
```

Example output

```
show stats-profile all
Statistics Profiles
--------------------------------
Stats Profile Name : sp1
qci all arp all

Stats Profile Name : sp2
qci 1 arp 1
```

Note The packet drop statistics displayed by the `show user-plane-service stats-profile` command include only drops accounted for by the user-plane service. Packets dropped at the VPP level are not included in these statistics.

Table 4: Drop reason description

Drop Reason	Description
Flow Action Discard	Packets dropped due to flow action configured as discard.
DDN Buffer Overflow	Packets dropped because the DDN buffer exceeded its capacity.
FAR Apply Action Drop	Packets dropped due to FAR action set to drop.
ITC Packets Drop	Packets dropped by ITC processing.
APN AMBR Packets Drop	Packets dropped due to APN AMBR rate enforcement.
CC Dropped Packets	Packets dropped because of charging or credit control restrictions.
QER Gate Status Closed	Packets dropped when the associated QER gate is closed.
NAT Packets Processing Failure	Packets dropped due to NAT processing failures.
FAR Buffer Pkt Processing Failure	Packets dropped because of FAR buffer processing failures.
Packet Exceeds MTU Size	Packets dropped because packet size exceeds the configured MTU.
IP Header Validation Failed	Packets dropped due to invalid or malformed IP headers.
ACL Drop	Packets dropped by Access Control List (ACL) rules.
SGACL Packet Drops	Packets dropped by Security Group ACL (SGACL) policies.
FastPath Misc Drops	Packets dropped for miscellaneous FastPath reasons.
ADF Level Failure	Packets dropped due to ADF processing failures.
QGR Policer Drop	Packets dropped by QGR policing mechanisms.
Overload Protection	Packets dropped to protect the system during overload conditions.
Self Protection	Packets dropped by self-protection mechanisms.

Drop Reason	Description
Others	Packets dropped for reasons not covered by the above categories.